



# SISPM1040-382-LRT

## Industrial 10-port Managed PoE Ethernet Switch



# User Guide

33576 Rev. D

## Trademarks

All trademarks and registered trademarks are the property of their respective owners.

## Copyright Notice/Restrictions

Copyright © 2013-2017 Transition Networks. All rights reserved. No part of this work may be reproduced or used in any form or by any means (graphic, electronic or mechanical) without written permission from Transition Networks. The information contained herein is confidential property of Transition Networks, Inc. The use, copying, transfer or disclosure of such information is prohibited except by express written agreement with Transition Networks, Inc.

## Contact Information

Transition Networks

10900 Red Circle Drive

Minnetonka, MN 55343 USA

tel: +1.952.941.7600 | toll free: 1.800.526.9267 | fax: 952.941.2322

[sales@transition.com](mailto:sales@transition.com) | [techsupport@transition.com](mailto:techsupport@transition.com) | [customerservice@transition.com](mailto:customerservice@transition.com)

### SISPM1040-382-LRT Industrial 10-port Managed PoE Ethernet Switch User Guide 33576

Rev. D

## Revision History

Rev	Date	Description
A	10/22/13	Manual released at Rev. A.
B	10/20/14	Added information on SSL.
C	6/10/15	Added sections 8 and 9 and Appendix A.
D	1/19/17	Update specs and add isolation information for firmware version 1.27. Update for firmware version 1.33 and add power supply info.

## Table of Contents

<b>1. Introduction</b> .....	<b>11</b>
1.1 Description .....	11
1.2 Features .....	11
1.3 Install Cautions and Warnings.....	12
1.4 Electrical Safety Warnings.....	13
<b>2. Hardware Installation</b> .....	<b>14</b>
2.0 Package Contents.....	14
2.1 Installing Switch on DIN-Rail.....	14
2.1.1 Mount the DIN-Rail Clip.....	14
2.2 Wall Mounting Installation .....	15
<b>3. Hardware Overview</b> .....	<b>17</b>
3.1 Front Panel.....	17
3.2 Front Panel LEDs .....	19
3.3 Top Panel .....	20
<b>4. Cables</b> .....	<b>21</b>
4.1 Ethernet Cables.....	21
4.1.1 100BASE-TX/10BASE-T Pin Assignments.....	21
4.2 SFPs.....	23
4.3 Console Cable.....	23
<b>4. Power / Ground / Fault Relay</b> .....	<b>24</b>
4.1 Warnings .....	24
4.2 Proper Earth Ground Isolation .....	25
4.3 Grounding.....	25
4.4 Fault Relay .....	25
4.5 Redundant Power Inputs.....	26
4.6 Power Connection .....	26
<b>6. Web Management</b> .....	<b>27</b>
5.1 Configuration by Web Browser .....	27
5.1.1 About Web-based Management.....	27
5.1.2 System Information .....	28
5.1.3 Front Panel .....	29
5.1.4 Basic Setting .....	30
5.1.4.1 Switch Setting.....	30
5.1.4.2 Admin Password .....	31
5.1.4.3 IP Setting.....	32

5.1.4.4	SNTP and PTP Client Setting .....	33
5.1.4.5	LLDP .....	36
5.1.4.6	Auto Provision .....	37
5.1.4.7	Backup & Restore .....	38
5.1.4.8	Upgrade Firmware .....	39
5.1.4.9	Upgrade HTTPS Certification.....	40
5.1.1	Redundancy.....	43
5.1.1.1	Redundant Ring .....	43
5.1.1.1	Multiple Ring.....	46
5.1.1.2	Multi-Ring .....	47
5.1.1.3	RSTP.....	48
5.1.1.4	MSTP .....	52
5.1.2	Multicast.....	57
5.1.2.1	IGMP Snooping.....	57
5.1.2.2	Static Group .....	58
5.1.3	Port Setting .....	59
5.1.3.1	Port Control .....	59
5.1.3.2	Port Status.....	60
5.1.3.3	Port Alias .....	60
5.1.3.4	Rate Limit .....	61
5.1.3.5	Port Trunk.....	62
5.1.4	VLAN.....	64
5.1.4.1	VLAN Setting - IEEE 802.1Q .....	64
	VLAN Setting – Port Based .....	66
5.1.4.2	VLAN Table .....	67
5.1.5	Traffic Prioritization .....	68
5.1.5.1	QoS Policy.....	68
5.1.5.2	Port-based Priority .....	70
5.1.5.3	COS/802.1p.....	71
5.1.5.4	TOS/DSCP .....	72
5.1.6	DHCP Server .....	73
5.1.6.1	DHCP Server – Setting .....	73
5.1.6.2	DHCP Server – Client List.....	74
5.1.6.3	DHCP Server – Port and IP bindings .....	74
5.1.7	SNMP.....	75
5.1.7.1	SNMP – Agent Setting .....	75
5.1.7.2	SNMP –Trap Setting .....	77

5.1.8	Security .....	78
5.1.8.1	IP Security .....	78
5.1.8.2	Port Security .....	80
5.1.8.3	MAC Blacklist .....	81
5.1.8.4	802.1x Radius Server .....	82
5.1.8.5	TACACS+ .....	86
5.1.9	Warnings .....	87
5.1.10	Monitor and Diag .....	91
5.1.10.1	System Event Log .....	91
5.1.10.2	MAC Address Table .....	92
5.1.10.3	Port Statistic .....	93
5.1.10.4	Port Monitoring .....	94
5.1.10.5	SFP Monitor .....	95
5.1.11	Power over Ethernet (PoE) .....	96
5.1.11.1	Basic Setting .....	96
5.1.11.2	Power over Ethernet - Port Setting .....	99
5.1.11.3	Port Status .....	101
5.1.11.4	PoE Ping Alive Check (Auto Power Reset - APR) .....	102
5.1.11.5	PoE Schedule .....	103
5.1.12	Save Configuration .....	104
5.1.13	Factory Default .....	104
5.1.14	System Reboot .....	105
<b>6.</b>	<b>Command Line Interface (CLI) .....</b>	<b>106</b>
6.1	About CLI Management .....	106
6.2	System Command Set .....	108
6.3	Port CommandSet .....	110
6.4	Trunk Command Set .....	113
6.5	VLAN Command Set .....	114
6.6	Spanning Tree Command Set .....	115
6.7	QoS Command Set .....	118
6.8	IGMP Command Set .....	118
6.9	MAC/Filter Table Command Set .....	119
6.10	SNMP Command Set .....	120
6.11	Port Mirror CommandSet .....	121
6.12	802.1x Command Set .....	121
6.13	TFTP Command Set .....	124
6.14	SYSLOG, SMTP, EVENT Command Set .....	124

6.15	SNTP Command Set .....	126
6.16	Ring Command Set.....	127
6.17	CLI Command Summary .....	128
<b>7.</b>	<b>Technical Specifications .....</b>	<b>134</b>
	Power Supply Features and Specifications .....	136
<b>8.</b>	<b>Troubleshooting.....</b>	<b>139</b>
	Record System and Device Information.....	139
<b>8.</b>	<b>Service, Warranty &amp; Compliance Information .....</b>	<b>141</b>
	Limited Lifetime Warranty.....	141
	Contact Us.....	142
<b>9.</b>	<b>Regulatory Agency Information .....</b>	<b>143</b>
	Declaration of Conformity.....	143
<b>Appendix A</b>	<b>- RADIUS Server and Switch Settings .....</b>	<b>144</b>
	Radius Server and Switch Setting.....	144
	User PC Settings.....	146
<b>Appendix B</b>	<b>- RADIUS - Windows 7 Wired AutoConfig .....</b>	<b>148</b>

# 1. Introduction

The SISPM1040-382-LRT is a managed PoE switch suitable for connecting and powering devices in challenging environments. The two gigabit speed combo ports provide the ultimate flexibility by allowing copper or fiber SFP uplink ports. The two uplink ports can also be used in a redundant ring for maximum network reliability. The switch has a PoE power budget of 240 Watts, provides up to 30 Watts per port on all ports simultaneously, has redundant input power connections, and a fault alarm relay to ensure safe reliable operation in temperatures between -40°C and +75°C (without SFPs). Transition Networks' industrial switches are certified to operate reliably in harsh environments such as those found on factory floors, outdoor enclosures or other challenging environments.

## 1.1 Description

The SISPM1040-382-LRT is a powerful managed industrial switch with many features. The switch can operate in wide temperatures, dusty environments and humid conditions. SISPM1040-382-LRT supports Power over Ethernet, a system to transmit electrical power with data to remote devices over standard twisted-pair cable. The SISPM1040-382-LRT has eight 10/100Base-T(X) PoE+ ports. The SISPM1040-382-LRT can be managed via the Web, Telnet, Console or other third-party SNMP software.

## 1.2 Features

- Store-and-Forward Architecture with 5.6 Gbps Switching Bandwidth
- Dual, Redundant 50 to 57 VDC Power Inputs with Current Overload Protection
- 6 PIN Terminal Block input power connections
- Fault Output Relay rated 1A@24VDC
- Eight PSE ports, providing up to 30 Watts per port
- PoE Ping Alive Check (Auto power Reset - APR)
- DIN Rail and Wall Mount Brackets included
- Extended operating temperature (-40°C to 75°C)
- Redundant Ring with recovery time less than 10ms over 250 units
- STP/RSTP/MSTP (IEEE 802.1D/w/s)
- TOS/DSCP
- QoS Quality of Service (802.1p)
- VLAN with VLAN Tagging and GVRP (802-1Q)
- MVR (Multicast VLAN Registration) support
- IGMP v2/v3 (IGMP Snooping)
- IP-based bandwidth management

- Port configuration, status, statistics, monitoring, and security
- SNTP for synchronizing of clocks over the network
- PTP (Precision Time Protocol) Client clock synchronization
- System Alarms via SYSLOG / SNMP / Trap / Fault Output Relay
- LLDP protocol
- DHCP Client/Server
- Port based network access control (802.1x)
- SSH Security
- RADIUS centralized password management
- SNMPv3 encrypted authentication and access security
- Web / SNMP v1, v2c, v3 / Telnet / CLI SSL/HTTPS device management

## 1.3 Install Cautions and Warnings



**Warning:** Risk of Electrical Shock. Disconnect power before installing the SISPM1040-382-LRT. Failure to observe this warning could result in an electrical shock.



**CAUTION** Only qualified persons should install the SISPM1040-382-LRT. Failure to observe this caution could result in poor performance or damage to the equipment.



**CAUTION** Install the SISPM1040-382-LRT in an operating environment where the temperature range is from  $-40^{\circ}\text{C}$  to  $+75^{\circ}\text{C}$  ( $-104^{\circ}\text{F}$  to  $+167^{\circ}\text{F}$ ), with relative humidity of 5% to 90% non-condensing. Failure to observe this caution could result in poor equipment performance.



**CAUTION** DO NOT install the SISPM1040-382-LRT in areas where strong electromagnetic fields (EMF) exist. Failure to observe this caution could result in poor equipment performance and data corruption.



**WARNING** Disconnect power before installing and wiring the SISPM1040-382-LRT for power. Failure to observe this warning could result in an electrical shock.



**Attention:** this product, like all electronic products, uses semiconductors that can be damaged by ESD (electrostatic discharge). Always observe appropriate precautions when handling.



## 1.4 Electrical Safety Warnings

### Electrical Safety

**IMPORTANT:** This equipment must be installed in accordance with safety precautions.

### Elektrische Sicherheit

**WICHTIG:** Für die Installation dieses Gerätes ist die Einhaltung von Sicherheitsvorkehrungen erforderlich.

### Elektrisk sikkerhed

**VIGTIGT:** Dette udstyr skal 13nstillers I overensstemmelse med sikkerhedsadvarslerne.

### Elektrische veiligheid

**BELANGRIJK:** Dit apparaat moet in overeenstemming met de veiligheidsvoorschriften worden geïnstalleerd.

### Sécurité électrique

**IMPORTANT :** Cet équipement doit être utilisé conformément aux instructions de sécurité.

### Sähköturvallisuus

**TÄRKEÄÄ :** Tämä laite on asennettava turvaohjeiden mukaisesti.

### Sicurezza elettrica

**IMPORTANTE:** questa apparecchiatura deve essere installata rispettando le norme di sicurezza.

### Elektrisk sikkerhet

**VIKTIG:** Dette utstyret skal 13nstillers I samsvar med sikkerhetsregler.

### Segurança eléctrica

**IMPORTANTE:** Este equipamento tem que ser instalado segundo as medidas de precaução de segurança.

### Seguridad eléctrica

**IMPORTANTE:** La instalación de este equipo deberá llevarse a cabo cumpliendo con las precauciones de seguridad.

### Elsäkerhet

**OBS!** Alla nödvändiga försiktighetsåtgärder måste vidtas när denna utrustning används.

## 2. Hardware Installation

### 2.0 Package Contents

Contact your sales representative if you have not received these items:


- One SISPM1040-382-LRT Switch
- One printed Quick Start Guide
- One DIN Rail Mount Kit
- One Console cable
- Five M3 Flat Screws
- One Wall Mount Kit.
- One 6-pin Terminal Block

Please save the packaging for possible future use.

### 2.1 Installing Switch on DIN-Rail

Each switch has a DIN-Rail kit that can be mounted on the rear panel. The DIN-Rail kit provides for easy installation on the DIN-Rail.


#### 2.1.1 Mount the DIN-Rail Clip



DIN-Rail Size

## 2.2 Wall Mounting Installation

A wall mount bracket can be used to mount the switch on a panel or wall. The bracket is mounted to the switch using the enclosed screws.



Wall-Mounting size

### Product Alert Notification

We have been advised by the manufacturer of the Power Over Ethernet Controller chip used in the SISPM1040-382-LRT that direct copper network connections between legacy detect PoE enabled ports is not recommended.

If your network configuration requires a copper connection between two SISPM1040-382-LRT switches, it is necessary to disable PoE on both of the connected ports. It is also recommended that if your network configuration requires a copper port on the SISPM1040-382-LRT to be connected to any other PSE (Power Sourcing Equipment) device, that PoE is disabled on the SISPM1040-382-LRT port.

Based on the notice from our supplier, connections of this type may result in damage to the connected equipment and, in some cases, other PoE equipment connected to different PoE ports on the same SISPM1040-382-LRT.

### **Related Information**

See the SISPM1040-382-LRT Quick Start Guide (33721) for summary installation information.

For Transition Networks Drivers, Firmware, Manual, etc. go to the [Product Support](#) webpage (logon required). For Transition Networks Application Notes, Brochures, Data Sheets, Specifications, etc. go to the [Support Library](#) (no registration required).

Note that this manual provides links to third party web sites for which Transition Networks is not responsible.

## 3. Hardware Overview


The SISPM1040-382-LRT front panel, LEDs, and top panel are described below.

### 3.1 Front Panel

The following table describes the SISPM1040-382-LRT front panel.

Port	Description
<b>10/100 RJ-45 fast Ethernet ports</b>	8 10/100Base-T(X) RJ-45 fast Ethernet ports support auto-negotiation. The default settings are: Speed: auto Duplex: auto Flow control: disable
<b>Gigabit RJ-45 ports</b>	2 10/100/1000Base-T(X) Gigabit ports (combo ports)
<b>SFP ports</b>	2 100/1000Base-X on SFP port (combo)
<b>PoE Ports</b>	Ports 1-8 support the PoE+ function. Compliant with IEEE802.3at PoE+ specifications. Compliant with 802.3at in Environment A when using an isolated power supply. For 802.3at Environment B applications: 1) use an isolated AC/DC power source, e.g. TN 25104, and/or 2) use mid-span injector (s), e.g. MIL-L100i, L1000i-at, between this switch's PSE port and link partner PD port. PoE must not be enabled if two 382-LRT copper ports are connected.
<b>Console</b>	Use RS-232 to RJ-45 connector to manage the switch.
<b>Reset</b>	Push the Reset button for 2 to 3 seconds to reset the switch. Push the Reset button for 5 seconds to reset the switch to its Factory Default settings. The front panel LEDs light momentarily. You may have to refresh your browser to display the System Information page.

The SISPM1040-382-LRT front panel components are shown and described below.



1. LED for PWR. When the PWR links, the green LED will light.
2. LED for PWR1. When the PWR1 links, the green LED will light.
3. LED for PWR2. When the PWR2 links, the green LED will light.
4. LED for R.M (Ring master). This LED lights if the switch is the Ring Master.
5. LED for Ring. This LED lights when the Ring is activated.
6. LED for Fault Relay. When a fault occurs, the amber LED will light.
7. Console port (RJ-45).
8. Reset button. Push the button for 2-3 seconds for reset; push for 5 seconds for factory defaults.
9. LED for PoE power supplied.
10. 10/100Base-T(X) PSE Ethernet ports.
11. LED for Ethernet port speed.
12. LED for Ethernet port link status.
13. 1000 COMBO ports with SFP.
14. LED for SFP ports Link/Act status.

## 3.2 Front Panel LEDs


The SISPM1040-382-LRT front panel LEDs are described below.

LED	Color	Status	Description
<b>PWR</b>	Green	On	DC power ready.
<b>PW1</b>	Green	On	DC power module 1 activated.
<b>PW2</b>	Green	On	DC power module 2 activated.
<b>R.M</b>	Green	On	Ring Master.
<b>Ring</b>	Green	On	Ring enabled.
		Slowly blinking	Ring topology has problem.
		Fast blinking	Ring working normally.
<b>Fault</b>	Amber	On	Fault relay. Power failure or Port down/fail.
10/100Base-T(X) Fast Ethernet ports			
<b>LNK / ACT</b>	Green	On	Port link up.
		Blinking	Data transmitted.
<b>Full Duplex</b>	Amber	On	Port working under full duplex.
Gigabit Ethernet ports			
<b>ACT</b>	Green	On	Port link up.
		Blinking	Data transmitted.
<b>LNK</b>	Amber	On	Port link up.
SFP ports			
<b>LNK / ACT</b>	Green	On	Port link up.
		Blinking	Data transmitted.

### 3.3 Top Panel

The SISPM1040-382-LRT top panel components are shown below:

1. Terminal block opening
2. Terminal block installed
3. Chassis/Frame Ground





## 4. Cables

### 4.1 Ethernet Cables

The SISPM1040-382-LRT switch has standard Ethernet ports. According to the link type, the switches use CAT 3, 4, 5, 5e UTP cables to connect to any other network device (PCs, servers, switches, routers, or hubs). Refer to the following table for cable specifications.

**Cable Types and Specifications**

Cable	Type	Max. Length	Connector
10BASE-T	Cat.3, 4, 5 100-ohm	UTP 100 m (328 ft)	RJ-45
100BASE-TX	Cat.5 100-ohm UTP	UTP 100 m (328 ft)	RJ-45
1000BASE-TX	Cat.5/Cat.5e 100-ohm UTP	UTP 100 m (328ft)	RJ-45

#### 4.1.1 100BASE-TX/10BASE-T Pin Assignments

With 100BASE-TX/10BASE-T cable, pins 1 and 2 are used for transmitting data, and pins 3 and 6 are used for receiving data.

**10/100 P.S.E. Base-TX RJ-45 Pin Assignments**

Pin Number	Assignment
1	P.O.E Power input +
2	P.O.E Power input +
3	P.O.E Power input -
4	Not used
5	Not used
6	P.O.E Power input -
7	Not used
8	Not used

**1000 Base-T RJ-45 Pin Assignments**

Pin Number	Assignment
1	BI_DA+
2	BI_DA-
3	BI_DB+
4	BI_DC+
5	BI_DC-
6	BI_DB-
7	BI_DD+
8	BI_DD-

The SISPM1040-382-LRT switch supports auto MDI/MDI-X operation. You can use a straight-through cable to connect a PC to the switch.

**10/100 Base-TX MDI/MDI-X Pins Assignments**

Pin Number	MDI port	MDI-X port
1	TD+(transmit)	RD+(receive)
2	TD-(transmit)	RD-(receive)
3	RD+(receive)	TD+(transmit)
4	Not used	Not used
5	Not used	Not used
6	RD-(receive)	TD-(transmit)
7	Not used	Not used
8	Not used	Not used


**1000 Base-T MDI/MDI-X Pin Assignments**

Pin Number	MDI port	MDI-X port
1	BI_DA+	BI_DB+
2	BI_DA-	BI_DB-
3	BI_DB+	BI_DA+
4	BI_DC+	BI_DD+
5	BI_DC-	BI_DD-
6	BI_DB-	BI_DA-
7	BI_DD+	BI_DC+
8	BI_DD-	BI_DC-

**Note:** "+" and "-" signs represent the polarity of the wires that make up each wire pair.

## 4.2 SFPs


The switch has fiber optical ports with SFP connectors. The fiber optical ports are in multi-mode (0 to 550M, 850 nm with 50/125 μm, 62.5/125 μm fiber) and single-mode with LC connector. Make sure each SFP is correctly oriented before inserting fully. **Note** that the TX port of Switch A should be connected to the RX port of Switch B. See the Transition Networks [SFP page](#) for more information. See the related SFP manual for important safety cautions and warnings.



## 4.3 Console Cable

The SISPM1040-382-LRT can be managed via the console port. One DB-9 to RJ-45 cable is included in the package. Connect the cable to a serial port on the PC via the RS-232 DB-9 female connector and the other end (RJ-45 connector) connects to the switch console port.

PC pin out (male) assignment	RS-232 with DB9 female connector	DB9 to RJ 45
Pin #2 RD	Pin #2 TD	Pin #2
Pin #3 TD	Pin #3 RD	Pin #3
Pin #5 GD	Pin #5 GD	Pin #5



## 4. Power / Ground / Fault Relay

### 4.1 Warnings



**WARNING:** Do not disconnect modules or wires unless power has been switched off or the area is known to be non-hazardous. The devices may only be connected to the supply voltage shown on the type plate.



#### ATTENTION

1. Be sure to disconnect the power cord before installing and/or wiring your switches.
2. Observe wiring electrical codes. Do not exceed current limits for chosen wiring gauge. Beware of bundling too many high current wires. If the temperature exceeds the maximum ratings, serious damage to your equipment could result.
3. Rules of thumb:
  - Use separate paths to route wiring for power and devices. If power wiring and device wiring paths must cross, make sure the wires are perpendicular at the intersection point.
  - Do not run signal or communications wiring and power wiring through the same wire conduit. To avoid interference, wires with different signal characteristics should be routed separately.
  - Bundle wires of similar electrical characteristics together.
  - Separate input wiring from output wiring.
  - Label the wiring to all devices in the system.



## 4.2 Proper Earth Ground Isolation

For PoE applications, to achieve full isolation between PSE (switch port) and load (PD), the switch must be powered with a 1500 VAC / 2250 VDC isolated power supply.

For applications requiring additional isolation, 1) use an isolated AC/DC power source, e.g. TN 25104, and/or 2) use mid-span injector (s), e.g. MIL-L100i, L1000i-at, between this switch's PSE port and link partner PD port. In addition, earth ground should be connected to the switch chassis.



### WARNING

This case must be earth grounded.  
No DC input may be earth grounded.  
Use Isolated Power Supply.



## 4.3 Grounding

Grounding and wire routing help limit the effects of noise due to electromagnetic interference (EMI). Run the ground connection from the ground screw to the grounding surface prior to connecting devices. Tie earth ground to both AC/DC power supply and switch.

**Chassis Ground:** There is a chassis ground screw, circled in red in the image above, which can be used to ground the device enclosure. Only negative grounding should be used.

The switch does not support positive grounding. Caution: to achieve required input power to RJ45 electrical isolation, the chassis ground must be isolated from the input power. •

Connecting the chassis to earth ground is required. • Connecting the power source's negative rail to earth ground is prohibited. • Connecting the power source's positive rail to earth ground is prohibited.

## 4.4 Fault Relay

The switch provides connection for Fault Output Relay rated 1A@24VDC. The two relay contacts of the 6-pin terminal block connector are used to detect user-configured events. The two wires attached to the fault contacts form an open circuit when a user-configured when an event is triggered. If a user-configured event does not occur, the fault circuit remains closed.



## 4.5 Redundant Power Inputs

The switch has two sets of power inputs, power input 1 and power input 2. The top two contacts and the bottom two contacts of the 6-pin terminal block connector on the switch's top panel are used for the two digital inputs. Positive and negative terminals are labeled **V+** and **V-** for each input. Note polarity on the chassis of the switch. Suitable wire sizes to use for the power connection are 12~22AWG. 16AWG or 18AWG is preferred. Make cable connections before connecting Power.

## 4.6 Power Connection


Connect wires between the **+** terminals on the power supply and the **+** terminals on the switch terminal block. Do the same with the **-** terminals. Maintain correct polarity (not reverse polarity protected). Ensure the screws are tight and the wires secure. Follow the steps below to wire redundant power inputs.

**Caution:** before applying power, insert screw terminal connectors into the switch and verify all connections. Plugging in power connection after energizing power supply(s) may damage the switch.

**Step 1:** Remove the terminal block from its packaging and insert it into the power terminal.

**Step 2:** Insert the negative/positive wires into the V- and V+ terminals, respectively.

**Step 3:** To keep the DC wires from pulling loose, use a small flat-blade screwdriver to tighten the wire-clamp screws on the front of the terminal block connector.



## 6. Web Management

### 5.1 Configuration by Web Browser



**Warning!** Remove physical loop connection before making any connection and upgrading firmware. Do **not** power off equipment while firmware is upgrading.

#### 5.1.1 About Web-based Management

An embedded HTML web server resides in flash memory on the CPU board. It contains advanced management features and allows you to manage the switch from anywhere on the network through a standard web browser.

#### Web Management Defaults

The default values are IP Address: **192.168.1.77**, Subnet Mask: **255.255.255.0**, Default Gateway: **192.168.1.254**, User Name: **root**, Password: **root**.

#### System Login

1. Launch a web browser such as Internet Explorer.
2. At the prompt `http://` type the IP address of the switch. Press “**Enter**”.




3. At the login screen, enter the User name and Password. The default username and password are both “**root**”.



Login screen

4. Press “**Enter**” or select the “**OK**” button; the main interface of the Web-based management displays.

## Main Interface



Main interface - System information page

### 5.1.2 System Information

The system Information page displays the current system, hardware, Time, and software information.


System Name	SISPM1040-382-LRT
System Description	Industrial 10-port managed PoE Ethernet switch with 8x10/100Base-T(X) P.S.E. and 2xGigabit combo ports, SFP socket
System Location	
System Contact	
System OID	1.3.6.1.4.1.868.2.120.0.5.107
Firmware Version	v1.33
Kernel Version	v3.50
MAC Address	00-C0-F2-56-0A-31

System Information interface

The system information will display the configuration of Basic Setting / Switch Setting page.

#### Enable Location Alert

This function can be used to physically locate the switch being configured. When you click the **Enable Location Alert** button, the **PWR1**, **PWR2** and **PWR3** LEDs will start to flash together to visibly identify the switch. To stop the location alert, click the **Disable Location Alert** button; the LEDs will stop flashing.







### 5.1.3 Front Panel


The Main interface page displays the SISPM1040-382-LRT front panel by default. Click “Close” to close the front panel display on the web pages. Click Front Panel to display it again.

You can click on a port to display its current status.



### 5.1.4 Basic Setting

#### 5.1.4.1 Switch Setting



Switch Setting interface

Label	Description
<b>System Name</b>	Assign the name of switch. The maximum length is 64 bytes.
<b>System Description</b>	Assign the description of switch. The maximum length is 256 bytes.
<b>System Location</b>	Assign the switch physical location. The maximum length is 64 bytes.
<b>System Contact</b>	Enter the name of contact person or organization. The maximum length is 256 bytes.
<b>System OID</b>	Displays the SNMP Object ID of enterprise private MIB in the format 1.3.6.1.4.1.868.2.120.0.5.107.
<b>Firmware Version</b>	Displays firmware release version (e.g., v1.33).
<b>Kernel Version</b>	Displays the current system kernel version (e.g., v3.50).
<b>Device MAC</b>	Displays the unique Ethernet hardware address in the format 00-C0-F2-56-0A-31.

### 5.1.4.2 Admin Password

Use this function to change web management login username and password for web, console, and Telnet management security




Admin Password interface

Label	Description
<b>User Name</b>	Enter the new username (the default is <b>“root”</b> ).
<b>New Password</b>	Enter the new password (the default is <b>“root”</b> ).
<b>Confirm Password</b>	Re-enter the new password.
<b>Apply</b>	Click <b>“Apply”</b> to activate the configurations.

### 5.1.4.3 IP Setting

You can configure the IP Settings and DHCP client using the IP Setting screen.



IP Setting interface

Label	Description
<b>DHCP Client</b>	To enable or disable the DHCP client function. When DHCP client function is enabled, the switch will be assigned the IP address from the network DHCP server. The default IP address will be replaced by the IP address which the DHCP server has assigned. After clicking the “ <b>Apply</b> ” button, a popup dialog is displayed to indicate the DHCP client is enabled. The IP address will be updated with the DHCP assigned address.
<b>IP Address</b>	Assign a static IP address that the switch will use. If the DHCP client function is enabled, you do not need to assign the IP address. If a static address needs to be assigned, enter the address in the IP Address box and select the <b>OK</b> button. The default IP address is 192.168.1.77.
<b>Subnet Mask</b>	Assign the subnet mask of the IP address. If DHCP client function is enabled, you do not need to assign the subnet mask.
<b>Gateway</b>	Assign the network gateway address for the switch. The default gateway address is 192.168.1.254.
<b>DNS1</b>	Assign the primary DNS IP address. Keep "0.0.0.0" if never used.
<b>DNS2</b>	Assign the secondary DNS IP address.
<b>Apply</b>	Click “ <b>Apply</b> ” to activate the configurations.

### 5.1.4.4 SNTP and PTP Client Setting

This page includes configuration for SNTP Client, system time, and PTP client.

#### SNTP(Time)

The SNTP (Simple Network Time Protocol) settings let you synchronize the system clock to an SNTP server.





SNTP Configuration interface

Label	Description
<b>SNTP Client</b>	Enable/Disable SNTP client.
<b>UTC Timezone</b>	Choose the UTC timezone of your city. Local time zone settings are provided below.
<b>SNTP Server IP Address</b>	Enter the SNTP server IP address (or domain name address).
<b>Daylight Saving Time</b>	Enable or disable the daylight saving time function. When daylight saving time is enabled, you must configure the daylight saving time period.
<b>Daylight Saving Period</b>	Set the Daylight Saving beginning time and ending time. Both will be different each year.
<b>Daylight Saving Offset</b>	Set up the offset time in hours (turn system clock forward).
<b>Switch Timer</b>	Display the switch current time.
<b>Apply</b>	Click <b>“Apply”</b> to activate the configurations.

**UTC Timezones:**

(GMT-12:00)Eniwetok, Kwajalein (GMT-11:00)Midway Island, Samoa (GMT-10:00)Hawaii  
 (GMT-09:00)Alaska (GMT-08:00)Pacific Time (US & Canada), Tijuana (GMT-07:00)Arizona  
 (GMT-07:00)Mountain Time (US & Canada) (GMT-06:00)Central Time (US & Canada)  
 (GMT-06:00)Mexico City, Tegucigalpa (GMT-06:00)Saskatchewan (GMT-05:00)Bogota, Lima, Quito  
 (GMT-05:00)Eastern Time (US & Canada) (GMT-05:00)Indiana (East) (GMT-04:00)Atlantic Time (Canada)  
 (GMT-04:00)Caracas, La Paz (GMT-04:00)Santiago (GMT-03:30)Newfoundland (GMT-03:00)Brasilia  
 (GMT-03:00)Buenos Aires, Georgetown (GMT-02:00)Mid-Atlantic (GMT-01:00)Azores, Cape Verde Is.  
 (GMT)Casablanca, Monrovia (GMT)Greenwich Mean Time: Dublin, Edinburgh, Lisbon, London  
 (GMT+01:00)Amsterdam, Berlin, Bern, Rome, Stockholm, Vienna (GMT+01:00)Belgrade, Bratislava,  
 Budapest, Ljubljana, Prague (GMT+01:00)Brussels, Copenhagen, Madrid, Paris, Vilnius  
 (GMT+01:00)Sarajevo, Skopje, Sofija, Warsaw, Zagreb (GMT+02:00)Athens, Istanbul, Minsk  
 (GMT+02:00)Bucharest (GMT+02:00)Cairo (GMT+02:00)Harare, Pretoria (GMT+02:00)Helsinki, Riga,  
 Tallinn (GMT+02:00)Jerusalem (GMT+03:00)Baghdad, Kuwait, Riyadh  
 (GMT+03:00)Moscow, St. Petersburg, Volgograd (GMT+03:00)Mairubi  
 (GMT+03:30)Tehran (GMT+04:00)Abu Dhabi, Muscat (GMT+04:00)Baku, Tbilisi  
 (GMT+04:30)Kabul (GMT+05:00)Ekaterinburg (GMT+05:00)Islamabad, Karachi, Tashkent  
 (GMT+05:30)Bombay, Calcutta, Madras, New Delhi (GMT+06:00)Astana, Almaty, Dhaka  
 (GMT+06:00)Colombo (GMT+07:00)Bangkok, Hanoi, Jakarta (GMT+08:00)Beijing, Chongqing, Hong  
 Kong, Urumqi (GMT+08:00)Perth (GMT+08:00)Singapore (GMT+08:00)Taipei (GMT+09:00)Osaka,  
 Sapporo, Tokyo (GMT+09:00)Seoul (GMT+09:00)Yakutsk (GMT+09:30)Adelaide (GMT+09:30)Darwin  
 (GMT+10:00)Brisbane (GMT+10:00)Canberra, Melbourne, Sydney (GMT+10:00)Guam, Port Moresby  
 (GMT+10:00)Hobart (GMT+10:00)Vladivostok (GMT+11:00)Magadan, Solomon Is., New Caledonia  
 (GMT+12:00)Auckland, Wllington (GMT+12:00)Fiji, Kamchatka, Marshall Is.



## PTP Client

The Precision Time Protocol (PTP) is a time-transfer protocol defined in the IEEE 1588-2002 standard that allows precise synchronization of networks (e.g., Ethernet). Accuracy within the nanosecond range can be achieved with this protocol when using hardware generated timestamps.



Label	Description
<b>PTP Client</b>	Enable or Disable the PTP Client. The default is disabled.
<b>Apply</b>	Click " <b>Apply</b> " to activate the configuration.

### 5.1.4.5 LLDP

LLDP (Link Layer Discovery Protocol) allows the switch to broadcast its information to other nodes on the network and store the information it discovers.




LLDP configuration interface

Label	Description
<b>LLDP Protocol</b>	“Enable” or “Disable” LLDP function.
<b>LLDP Interval</b>	The interval of resend LLDP (by default at 30 seconds)
<b>Apply</b>	Click “ <b>Apply</b> ” to set the configurations.
<b>Help</b>	Show help file.
<b>Neighbor Info table</b>	Can show neighbor device information.



### 5.1.4.6 Auto Provision

Auto Provision lets you update the switch firmware automatically. You can put firmware or configuration files on a TFTP server. When you reboot the switch, it will upgrade automatically. Before updating, make sure you have your TFTP server ready and the firmware image and configuration file on the TFTP server. Auto Provision can make sure the configuration data and firmware image file is the newest version automatically from the TFTP server.



Auto Provision interface

Label	Description
<b>Auto Install Configuration file from TFTP server?</b>	Check the box to automatically install the config file from the specified TFTP server.
<b>TFTP Server IP Address</b>	Enter the TFTP server IP address.
<b>Configuration File Name</b>	Enter the Configuration file name for downloading.
<b>Auto Install Firmware Image file from TFTP server?</b>	Check the box to automatically install the firmware image file from the specified TFTP server.
<b>Firmware File Name</b>	Enter the Firmware image file name for downloading.
<b>Apply</b>	Click " <b>Apply</b> " to set the configuration.

### 5.1.4.7 Backup & Restore

TFTP (Trivial File Transfer Protocol) can download user configuration data of the switch from a TFTP server to restore to system.

**Backup** Configuration uploads user configuration data of the switch to a TFTP server for backup.

**Restore** Configuration uses TFTP to download user configuration data of switch from the TFTP server to restore to system. After the configuration data is downloaded successfully, you must restart the switch for the restored configuration to be applied.

Backup & Restore interface

Label	Description
<b>TFTP Server IP Address</b>	Enter the TFTP server IP address.
<b>Backup File Name</b>	Fill the backup file name for downloading.
<b>Restore</b>	Click " <b>Restore</b> " to restore the configurations.
<b>Restore File Name</b>	Enter the file name.
<b>Backup</b>	Click " <b>Backup</b> " to backup the configuration.

**Message:** Apply fail TFTP transmission fail

**Meaning:** The Backup or Restore function failed.

**Recovery:** 1. Click the **Retry** button. 2. Verify the filename and TFTP Server IP address. 3. Retry the Backup or Restore function.

### 5.1.4.8 Upgrade Firmware

TFTP (Trivial File Transfer Protocol) can download a firmware image file from a TFTP server to upgrade the switch. After successfully upgrading firmware, restart the system for the new firmware to be applied.

Upgrade Firmware allows you to update the switch firmware. Before updating, make sure your TFTP server is ready and the firmware image is on the TFTP server.



Upgrade Firmware interface

Label	Description
<b>TFTP Server IP</b>	Enter the TFTP server IP address.
<b>Firmware File Name</b>	Enter the firmware image file name for downloading.
<b>Upgrade</b>	Click “ <b>Upgrade</b> ” to restore the configuration. After a successful firmware upgrade, restart the system for the new firmware to be applied.

#### Backup / Upgrade / Restore Procedure


**Note:** To backup your config file before upgrading the firmware and then restore it after the firmware upgrade, use the following procedure:

1. Make any config changes desired.
2. Save the config.
3. Backup the current config.
4. Upgrade the firmware.
5. Reset to Factory Defaults.
6. Restore the backed-up config (from step 3 above).
7. Reboot the SISPM1040-382-LRT switch.

An ‘Apply Fail - Flash is already updated with this file’ message will display after the firmware upgrade if you attempt to restore the config (Step 6) before defaulting it (Step 5).

### 5.1.4.9 Upgrade HTTPS Certification

At Basic Setting > Upgrade HTTPS Certification you can upgrade the HTTPS certificate.




Label	Description
<b>TFTP Server IP</b>	Enter the TFTP server IP address.
<b>Private Key File Name</b>	Enter the filename of the HTTPS private key.
<b>Pass Phrase for Private Key</b>	Enter the pass phrase for the HTTPS private key.
<b>Certification File Name</b>	Enter the filename of the HTTPS certificate.
<b>Upgrade</b>	Click the <b>Upgrade</b> button when done.


#### HTTPS Certificat Upgrade Procedure

HTTPS makes use of the Secure Socket Layer (SSL) functionality and allows the use of a custom SSL certificate created by the User. The switch uses the OpenSSL format for the customized certificate. To upgrade the HTTPS Certificate:

1. Start the TFTP Server software.



2. Browse to the directory where the SSL Certificates and Keys are located.



3. Connect to the SISPM1040-382-LRT with an HTTP Browser and navigate to the Basic Settings.
4. Select the Upgrade HTTPS Certificate.
5. Enter the following information on the Upgrade HTTPS Certification screen:
  - IP Address of the TFTP Server
  - Private key file name
  - Pass phrase for Private key
  - Certification File name



6. Once all the information has been entered select the **Upgrade** button.  
 The SISPM1040-382-LRT will connect to the TFTP server and look for the private key file and Certificate file in the TFTP server's current directory. The files will be uploaded to the SISPM1040-382-LRT.
7. Once the upload of the files has completed and the Submit OK message is displayed, save the SISPM1040-382-LRT configuration and restart switch.



8. The system will restart. In console mode, it will show that the Certification loaded properly by displaying **OK**.

```


ARMboot Rev 1.22 for G0 Board (Jun  2 2011 - 16:01:39)
Password :
Press 0 or 1 to force boot from which firmware image bank.
Load image bank 0...
Uncompressing...OK.
Start firmware...
$$$ Check User Configuration File ...0.K !!!
$$$ Switch Engine Initialize...0.K !!!
$$$ User Configuration Initialize...0.K !!!
HTTPS: Load user certification OK.
$$$ Protocol Initialize...0.K !!!
    
```

### 5.1.1 Redundancy

Ring support includes three Ring topologies: Redundant Ring, Coupling Ring, and Dual Homing.

#### 5.1.1.1 Redundant Ring

The Redundant Ring Protocol is a very fast network redundancy protocol that provides link fail-over protection with very fast self-healing recovery. This can reduce unexpected damage caused by network topology changes. Note that all switches in a ring should have Redundant Ring enabled.



Redundant Ring interface

The following table describes the labels in this screen.

Label	Description
<b>Redundant Ring</b>	Check the checkbox to enable the Redundant Ring function.
<b>Ring Master</b>	There should be one and only one Ring Master in a ring. However if there are two or more switches set to be the Ring Master, the switch with the lowest MAC address will be the actual Ring Master and the others will be Backup Masters.
<b>1<sup>st</sup> Ring Port</b>	The primary port if this switch is Ring Master.
<b>2<sup>nd</sup> Ring Port</b>	The backup port if this switch is Ring Master.
<b>Coupling Ring</b>	Check the checkbox to enable Coupling Ring. Coupling Ring can be used to divide a large ring into two smaller rings to avoid affecting all switches when network topology changes. It is a good application for connecting two Rings.

<b>Coupling Port</b>	<p>Link to Coupling Port of a switch in another ring. Coupling Ring needs four switches to build an active and a backup link.</p> <p>Set a port as the Coupling port. The coupled four ports of four switches will be run in active/backup mode.</p> <p>Note that only two switches can enable Coupling Ring in a ring. More or less than two is invalid.</p>
<b>Dual Homing</b>	<p>Check the checkbox to enable Dual Homing. By selecting Dual Homing mode, the Ring will be connected to normal switches through two RSTP links (e.g., the backbone Switch). The two links work in active/backup mode, and connect each Ring to the normal switches in RSTP mode.</p> <p>Note that only two switches can enable Dual Homing in a ring. More or less than two is invalid.</p>
<b>Homing Port</b>	At the dropdown select the port you want as the Dual Homing Port.
<b>Apply</b>	Click "Apply" to set the configurations.

**Messages:** *Apply fail Wrong data submitted* and *This switch is Master switch.*

*Meaning:* The same port has both Primary port and Backup port assignments.


*Recovery:* Change the 1st Ring Port setting or the 2nd Ring Port setting.

**Note:**


- We suggest you not set one switch as both a Ring Master and a Coupling Ring at the same time due to heavy load.
- Network redundancy protocol should be correctly configured for all switches in the redundant network before actually connecting any backup/redundant path in order to prevent the inadvertent generation of traffic loops.
- Do not enable more than one redundancy protocol (e.g., Redundant Ring and RSTP) at the same time.




**Redundant Ring:**



**Coupling Ring:**




**Dual Homing:**



### 5.1.1.1 Multiple Ring

Navigate to the Redundancy > Multiple Ring menu path to display the Multiple Ring configuration table.



Multiple Ring interface


The following table describes the labels in this screen.

Label	Description
<b>Enable</b>	Check the checkbox to enable Multiple Rings.
<b>Uplink Port</b>	At the dropdowns, select a first and second uplink port (must be different port numbers).
<b>Edge Port</b>	Check <u>one</u> of the checkboxes for the port to become the Ring Edge Port.
<b>State</b>	The state of the ring port (e.g., Linkup, Linkdown).

If the message “*Apply fail The selected ports should be different to each other*” displays, click the **Retry** button, change one of the parameters above, and click the **Apply** button again.

### 5.1.1.2 Multi-Ring

Navigate to the Redundancy > Multi-Ring menu path to display the Multi Ring configuration table.



Multi-Ring interface

The following table describes the labels in this screen.


Label	Description
<b>Enable</b>	Check the checkbox to enable Multi-Ring.
<b>Ring Protocol</b>	At the dropdown, select the redundant ring protocol to be used: <b>Turb* Ring</b> : use the Turb* Ring protocol. <b>X-Ring</b> : use the X- Ring protocol. <b>MRP Ring</b> : use the MRP Ring protocol.
<b>1<sup>st</sup> Ring Port</b>	At the dropdown, select the first ring port (Port.01 - Port.08, G1, or G2).
<b>2<sup>nd</sup> Ring Port</b>	At the dropdown, select the second ring port (Port.01 - Port.08, G1, or G2; must be a different port than the 1st Ring Port selected).

### 5.1.1.3 RSTP

The Rapid Spanning Tree Protocol (RSTP) is an evolution of the Spanning Tree Protocol. It provides faster spanning tree convergence after a topology change. The system also supports STP and the system will auto detect the connected device that is running STP or RSTP protocol. RSTP configures full, simple, and symmetric connectivity throughout a Bridged Local Area Network that comprises individual LANs interconnected by Bridges. It is the most common network redundancy protocol. Refer to IEEE 802.1W for details.

#### RSTP Setting

Here you can enable/disable RSTP function, and set parameters for each port.



RSTP Setting interface

The following table describes the labels in this screen.

Label	Description
<b>RSTP Mode</b>	You must enable the RSTP function before configuring the related parameters. The default is Disable.
<b>Priority (0-61440)</b>	A value used to identify the root bridge. The bridge with the lowest value has the highest priority and is selected as the root. Note that if bridge priority is changed, the RSTP <u>must</u> be restarted. This value must be a multiple of 4096 according to the protocol standard rule.
<b>Max Age Time(6-40)</b>	The number of seconds a bridge waits without receiving Spanning-tree Protocol configuration messages before attempting a reconfiguration. Enter a value between 6 and 40. The default is 20.

<b>Hello Time (1-10)</b>	The time that controls how often the switch sends out the BPDU packet to check RSTP current status. Enter a value between 1 and 10 seconds. The default is 2 seconds.
<b>Forwarding Delay Time (4-30)</b>	The number of seconds a port waits before changing from its Rapid Spanning-Tree Protocol learning and listening states to the forwarding state. Enter a value between 4 and 30. The default is 15 seconds.
<b>Apply</b>	Click " <b>Apply</b> " to set the configurations.

**NOTE:** Follow the rule to configure the Max Age, Hello Time, and Forward Delay Time:  
 $2 \times (\text{Forward Delay Time value} - 1) \geq \text{Max Age value} \geq 2 \times (\text{Hello Time value} + 1)$

**Note:**

- Network redundancy protocol should be correctly configured for all switches in a redundant network before actually connecting any backup/redundant path in order to prevent the inadvertent generation of traffic loops.
- Two redundancy protocols (e.g., Redundant Ring and RSTP) can not be enabled at the same time. The message "*Apply fail Another redundancy protocol is running. Only one could be run at the same time*" displays if this occurs. Disable one or more redundancy protocols and continue.

## RSTP Information

Show RSTP algorithm results at this table:

**TRANSITION NETWORKS** SISPM1040-382-LRT

### RSTP Information

#### Root Bridge Information

Bridge ID	8000-00C0F2560A31
Root Priority	32768
Root Port	N/A
Root Path Cost	0
Max Age Time	20
Hello Time	2
Forward Delay Time	15

#### Port Information

Port	Path Cost	Port Priority	OperP2P	OperEdge	STP Neighbor	State	Role
Port.01	2000000	128	False	True	False	Forwarding	Non Stp
Port.02	2000000	128	True	True	False	Disabled	Disabled
Port.03	2000000	128	True	True	False	Disabled	Disabled
Port.04	2000000	128	True	True	False	Disabled	Disabled
Port.05	2000000	128	True	True	False	Disabled	Disabled
Port.06	2000000	128	True	True	False	Disabled	Disabled
Port.07	2000000	128	True	True	False	Forwarding	Designated
Port.08	2000000	128	True	True	False	Disabled	Disabled
G1	2000000	128	True	True	False	Disabled	Disabled
G2	2000000	128	True	True	False	Disabled	Disabled

Label	Description
<b>Path Cost (1-200000000)</b>	The cost of the path to the other bridge from this transmitting bridge at the specified port. Enter a number 1 - 200000000. The default value is 200000 for mega-ports and 20000 for giga-ports.
<b>Port Priority (0-240)</b>	Decide which ports should be blocked by priority in the LAN. Valid values are 0 ~ 240 in steps of 16. The default value is 128.
<b>Admin P2P</b>	Some of the rapid state transactions that are possible within RSTP are dependent on whether the port configured can only be connected to exactly one other bridge (i.e., it is served by a point-to-point LAN segment), or it can be connected to two or more bridges (i.e., It is served by a shared medium LAN segment). This function allows the P2P status of the link to be manipulated administratively. <b>True</b> means P2P enabled. <b>False</b> means P2P disabled.
<b>Admin Edge</b>	The port directly connected to end stations, and it cannot create bridging loop in the network. To configure the port as an edge port, set the port to <b>“True”</b> . The value of this parameter is used by a Designated Port in order to determine how rapidly it may transition to the Forwarding Port State.


	All ports directly connected to end stations cannot create bridging loops in the network and can thus directly transition to forwarding, skipping the listening and learning stages.
<b>Admin Non Stp</b>	The port can include or exclude STP mathematic calculation. <b>True</b> excludes STP mathematic calculation (this port will not participate in RSTP). <b>False</b> includes the STP mathematic calculation.
<b>Apply</b>	Click " <b>Apply</b> " to set the configuration.

### 5.1.1.4 MSTP

Multiple Spanning Tree Protocol (MSTP) is a standard protocol base on IEEE 802.1s. The MSTP function allows several VLANs to be mapped to a reduced number of spanning tree instances because most networks do not need more than a few logical topologies. MSTP supports a load balancing scheme and is less CPU intensive than PVST (Cisco proprietary technology).



#### MSTP Bridge Setting



MSTP Setting interface


The following table describes the labels in the MSTP > Bridge Setting screen.

Label	Description
<b>MSTP Enable</b>	You must enable or disable MSTP function before configuring the related parameters.
<b>Force Version</b>	The Force Version parameter can be used to force a VLAN Bridge



	that supports RSTP to operate in an STP-compatible manner.
<b>Configuration Name</b>	The same MST Region must have the same MST configuration name.
<b>Revision Level (0-65535)</b>	The same MST Region must have the same revision level.
<b>Priority (0-61440)</b>	A value used to identify the root bridge. The bridge with the lowest value has the highest priority and is selected as the root. If the value changes, you must reboot the switch. The value must be a multiple of 4096 according to the protocol standard rule.
<b>Max Age Time (6-40)</b>	The number of seconds a bridge waits without receiving a Spanning-tree Protocol configuration message before attempting a reconfiguration. Enter a value of 6 - 40 seconds.
<b>Hello Time (1-10)</b>	The setting follows the rule below to configure the Max Age, Hello Time, and Forward Delay Time as the controlled switch sends out the BPDU packet to check RSTP current status. Enter a value 1 - 10. $2 \times (\text{Forward Delay Time value} - 1) \geq \text{Max Age value} \geq 2 \times (\text{Hello Time value} + 1)$
<b>Forward Delay Time (4-30)</b>	The number of seconds a port waits before changing from its Rapid Spanning-Tree Protocol learning and listening states to the forwarding state. Enter a value of 4 - 30 seconds.
<b>Max Hops (1-40)</b>	This parameter is additional to those specified for RSTP. A single value applies to all Spanning Trees within an MST Region (the CIST and all MSTIs) for which the Bridge is the Regional Root.
<b>Apply</b>	Click " <b>Apply</b> " to activate the configuration settings.


**MSTP Bridge Port**



MSTP Port interface

Label	Description
<b>Port No.</b>	Select the port that you want to configure.
<b>Priority (0-240)</b>	Decide which port should be blocked by priority in the LAN. Enter a number 0 - 240. The value of priority must be a multiple of 16.
<b>Path Cost (1-200000000)</b>	The cost of the path to the other bridge from this transmitting bridge at the specified port. Enter a number between 1 and 200000000.
<b>Admin P2P</b>	Some of the rapid state transactions that are possible within RSTP are dependent upon whether the port configured can only be connected to exactly one other bridge (i.e., it is served by a point-to-point LAN segment), or it can be connected to two or more bridges (i.e., it is served by a shared medium LAN segment). This function allows the P2P status of the link to be manipulated administratively. <b>True</b> means P2P enabling. <b>False</b> means P2P disabling.
<b>Admin Edge</b>	Select <b>true</b> or <b>false</b> at the dropdown.
<b>Admin Non Stp</b>	The port can include or exclude STP mathematic calculation. <b>True</b> excludes STP mathematic calculation. <b>False</b> includes the STP mathematic calculation.
<b>Apply</b>	Click " <b>Apply</b> " to activate the configurations.

### MSTP Instance Setting




MSTP Instance interface

Label	Description
<b>Instance</b>	Select the MSTP instance (1 – 15).
<b>State</b>	Enable or disable the instance.
<b>VLANs</b>	Set which VLAN(s) will belong which instance. Two different instances can not include the same VLAN ID.
<b>Priority (0-61440)</b>	A value used to identify the root bridge. The bridge with the lowest value has the highest priority and is selected as the root. If the value changes, you must reboot the switch. The value must be a multiple of 4096 according to the protocol standard rule.
<b>Apply</b>	Click “ <b>Apply</b> ” to activate the configurations.

The message “*Apply fail MSTP instance VLAN can't overlap*” displays if the VLANs in two different instances include the same VLAN IDs.

### MSTP Instance Port




MSTP Instance Port interface

Label	Description
<b>Instance</b>	Set the instance’s information except CIST.
<b>Port</b>	Selecting the port that you want to configure.
<b>Priority (0-240)</b>	Decide which port should be blocked by priority in the LAN. Enter a number from 0 - 240. The value of Priority must be a multiple of 16.
<b>Path Cost (1-200000000)</b>	The cost of the path to the other bridge from this transmitting bridge at the specified port. Enter a number from 1 - 200000000.
<b>Apply</b>	Click “ <b>Apply</b> ” to set the configurations.

## 5.1.2 Multicast

### 5.1.2.1 IGMP Snooping

Internet Group Management Protocol (IGMP) is used by IP hosts to register their dynamic multicast group membership. IGMP has 3 versions, IGMP v1, v2 and v3. Refer to RFC 1112, 2236 and 3376. IGMP Snooping improves the performance of networks that carry multicast traffic. It provides the ability to “prune” multicast traffic so that it travels only to those end destinations that require the traffic and it reduces the amount of traffic on the Ethernet LAN.



IGMP Snooping interface

The following table describes the labels in this screen.

Label	Description
<b>IGMP Snooping</b>	Enable/Disable IGMP snooping. At the dropdown select Enable V2, Enable v3, or Disable for the current IP multicast list.
<b>IGMP Query Mode</b>	Switch will be IGMP querier or not. There should be one and only one IGMP querier in an IGMP application. The "Auto" mode means that the querier is the one with a lower IP address.
<b>IGMP Snooping Table</b>	Shows the current IP multicast list.
<b>Apply</b>	Click <b>“Apply”</b> to set the configurations.

### 5.1.2.2 Static Group

Multicasts are similar to broadcasts; they are sent to all end stations on a LAN or VLAN.

Static Group is the system by which end stations only receive multicast traffic if they register to join specific multicast groups. With Static Group, network devices only forward multicast traffic to the ports that are connected to registered end stations.

#### **Procedure:**

1. **IP Address:** Assign a multicast group IP address in the range of 224.0.0.0 ~ 239.255.255.255.
2. **Member Ports:** Tick the check box beside the port number to include them as the member ports in the specific multicast group IP address.
3. Click "Add".
4. If you want to delete an entry from table, select the entry and click "Delete".


**Message:** Apply fail Table full

**Message:** Apply fail string must contain 1 - 3 dots (.)

## 5.1.3 Port Setting

### 5.1.3.1 Port Control

This function lets you set port state, speed/duplex, flow control, and security.



Port Control interface


The following table describes the labels in this screen.

Label	Description
<b>Port No.</b>	Port number for this setting.
<b>State</b>	Enable or Disable port transmission.
<b>Speed/Duplex</b>	You can set to AutoNegotiation, 100-full, 100-half, 10-full, or 10-half mode.
<b>Flow Control</b>	Select "Disable", "Asymmetric", or "Symmetric" flow control. "Disable" will disable flow control ability. "Symmetric" means that flow control ability will be decided by the result of auto negotiation. Only both of linked up ports enable flow control, the flow control ability is just active. "Asymmetric" means that flow control ability is always active on this port whether the linked partner port enabled or not.
<b>Security</b>	Enabled port security will disable MAC address learning on this port. So only the frames with MAC addresses in the port security list will be forwarded, otherwise packets will be discarded.
<b>Auto Detect 100/1000 SFP</b>	Select Enable to automatically detect the SFP port's SFP Module speed (100M or 1000M).

**Messages:** Apply fail The port type and setting of member ports in a trunk group should be the same

### 5.1.3.2 Port Status


The Port Status table displays the current port status information (Type, Link state, Speed/Duplex setting, and Flow Control setting). See the previous section for parameter descriptions.



Port Status interface

### 5.1.3.3 Port Alias


Here you can define a name for each port.





### 5.1.3.4 Rate Limit

Here you can limit traffic on all ports, including broadcast, multicast and flooded unicast. You can also set “Ingress” or “Egress” to limit traffic received or transmitted bandwidth.



Rate Limit interface

The following table describes the labels in this screen.


Label	Description
<b>Ingress Limit Frame Type</b>	You can select “All”, “Broadcast only”, “Broadcast/Multicast” or “Broadcast/Multicast/Flooded Unicast” mode. Select what kinds of frames are limited against ingress rate limit. If an ingress frame is not included in this setting, it will not be limited. Note that this setting is only against ingress rate limit but not egress.
<b>Ingress</b>	The switch port received traffic rate. The value of ingress rate limit. The unit of rate is kbps, and 1 Mbps is equal to 1024 kbps.
<b>Egress</b>	The switch port transmitted traffic rate. The value of egress rate limit. The unit of rate is kbps, and 1 Mbps is equal to 1024 kbps.
<b>Apply</b>	Click “Apply” to activate the configuration settings.

**Note:** Rate range is from 100 Kbps to 102400 kbps (i.e., 100Mbps) for mega-ports, or 256000 kbps (i.e., 250Mbps) for giga-ports. Zero means no limit.

### 5.1.3.5 Port Trunk

#### Port Trunk – Setting


You can select static trunk or 802.3ad LACP to combine several physical links with a logical link to increase the bandwidth. Port trunking (aka, Link Aggregation) is specified in IEEE 802.3ad. Port trunking allows one or more links to be aggregated together to form a Link Aggregation Group, such that a MAC client can treat the Link Aggregation Group as if it were a single link.



Port Trunk - Setting interface

The following table describes the labels in this screen.

Label	Description
<b>Group ID</b>	Select the ports to join a trunk group.
<b>Type</b>	The switch supports Static trunk and 802.3ad LACP. Join a static trunk group directly or determine by IEEE 802.3ad LACP dynamically. Note that the types should be the same for all member ports in a group. The port type and setting of member ports in a trunk group should be the same.
<b>Work Ports</b>	Select the number of active ports in a dynamic group (LACP). The default value of work ports is the maximum number of ports for the group. If the number is not the maximum number of ports, the other inactive ports in the dynamic group will be suspended (no traffic). Once the active port is broken, the suspended port will be activated automatically. The number of member ports in a trunk group should be 2 - 4.
<b>Apply</b>	Click “ <b>Apply</b> ” to set the configurations.

**Port Trunk – Status**

Port Trunk - Status interface

The following table describes the labels in this screen.

Label	Description
<b>Group ID</b>	Trunk Group number.
<b>Trunk Member</b>	Shows the Group port information.
<b>Type</b>	Shows the current port trunk type (e.g., Static).

## 5.1.4 VLAN

A Virtual LAN (VLAN) is a logical network grouping that limits the broadcast domain, which allows you to isolate network traffic. Only the members of the VLAN will receive traffic from the same members of the VLAN. Basically, creating a VLAN from a switch is logically equivalent to connecting a group of network devices to another Layer 2 switch. However, all the network devices are still plugged into the same switch physically.

The switch supports port-based and 802.1Q (tagged-based) VLAN. The default configuration of VLAN operation mode is at “**802.1Q**”.


IEEE 802.1Q defines the operation of Virtual LAN (VLAN) Bridges that permit the definition, operation and administration of Virtual LAN topologies within a Bridged LAN infrastructure. The GARP (Generic Attribute Registration Protocol) VLAN Registration Protocol (GVRP) defines a GARP application that provides the 802.1Q-compliant VLAN pruning and dynamic VLAN creation on 802.1Q trunk ports. Refer to IEEE 802.1Q for details.

### 5.1.4.1 VLAN Setting - IEEE 802.1Q

Tagged-based VLAN is an IEEE 802.1Q specification standard, and it is possible to create a VLAN using devices from different switch vendors. IEEE 802.1Q VLAN uses a technique to insert a “tag” into the Ethernet frames. Tag contains a VLAN Identifier (VID) that indicates the VLAN numbers.

You can create Tag-based VLAN, and enable or disable GVRP protocol. There are 256 VLAN groups to available. Enable 802.1Q VLAN, then all ports on the switch belong to default VLAN, VID is 1. The default VLAN cannot be deleted.

GVRP allows automatic VLAN configuration between the switch and nodes. If the switch is connected to a device with GVRP enabled, you can send a GVRP request by using the VID of a VLAN defined on the switch; the switch will automatically add that device to the existing VLAN.



VLAN Setting – 802.1Q interface

Label	Description
<b>VLAN Operation Mode</b>	Select the VLAN operating mode: Disabled, Port Based, or <b>802.1Q</b> mode.
<b>GVRP Mode</b>	Enable or Disable the GVRP function.
<b>Management VLAN ID</b>	Management VLAN can provide the network administrator a secure VLAN to manage the switch. Only this VLAN can manage this switch. Zero means this function is disabled.
<b>Port No.</b>	Select the port to configure.
<b>Link Type</b>	At the dropdown, select one of the three link types supported: <b>Access</b> Link: the access link only supports an untagged VID. <b>1QTrunk</b> Link: the 1Q trunk link only supports multiple tagged VIDs. <b>Hybrid</b> Link: the hybrid link supports an untagged VID and multiple tagged VIDs.
<b>Untagged VIDs</b>	Set the port default VLAN ID for untagged devices that connect to the port. The range is 1 to 4094.
<b>Tagged VIDs</b>	Set the tagged VIDs to carry different VLAN frames to other switches. The switch supports 1~4094 and multiple VIDs.
<b>Apply</b>	Click “ <b>Apply</b> ” to set the configurations.


**Note:** Use the comma to separate multiple tagged VIDs (e.g., 2-4,6 means joining Tagged VLAN 2, 3, 4 and 6).

**Note:** ports with the same VID means they are in the same VLAN group.

### VLAN Setting – Port Based

Packets only go to the members of the same VLAN group. Note that all unselected ports are treated as belonging to another single VLAN. If port-based VLAN is enabled, the VLAN-tagging is ignored.

From the default page, click the **Add** button to display the config page:




VLAN Configuration – Port Based interface

The following table describes the labels in this screen.

Label	Description
<b>VLAN Operation Mode</b>	Select the mode at the dropdown ( <b>Disabled</b> , <b>Port Based</b> , or <b>802.1Q</b> mode).
<b>Group Name</b>	Enter the VLAN name.
<b>VLAN ID</b>	Specify the VLAN ID
<b>Add</b>	Click “Add” to enter VLAN add interface.
<b>Edit</b>	Click to edit the existing VLAN.
<b>Delete</b>	Click to delete the existing VLAN.
<b>Help</b>	Show the related help file.
<b>Add</b>	Select port to join the VLAN group.
<b>Remove</b>	Remove port from the VLAN group
<b>Apply</b>	Click “ <b>Apply</b> ” to set the configurations.
<b>Help</b>	Show help file.

### 5.1.4.2 VLAN Table

VLAN > VLAN Table displays the VLAN Table parameters: VLAN ID, Untagged Ports, and Tagged Ports.



The screenshot shows the web interface for Transition Networks. The top left features the logo and the device name "SISPM1040-382-LRT". A navigation menu on the left lists various settings, with "VLAN" expanded to show "VLAN Setting" and "VLAN Table". The "VLAN Table" section is active, displaying a table with the following data:

VLAN ID	Untagged Ports	Tagged Ports
1	P1,P2,P3,P4,P5,P6,P7,P8,G1,G2	

## 5.1.5 Traffic Prioritization

Traffic Prioritization includes three modes: port based, 802.1p/COS, and TOS/DSCP. Using the traffic prioritization function, you can classify the traffic into four classes for differential network applications. The SISPM1040-382-LRT supports a non-blocking, 4 priority, output port queue architecture. The traffic can be prioritized by port, COS field in VLAN tag and TOS field in IP header.

### Priority Type:

**Port-based:** the output priority is determined by ingress port.

**COS only:** the output priority is determined by COS only.

**TOS only:** the output priority is determined by TOS only.

**COS first:** the output priority is determined by COS and TOS, but COS first.


**TOS first:** the output priority is determined by COS and TOS, but TOS first.

**COS/802.1p:** COS (Class Of Service) is well known as 802.1p. It describes that the output priority of a packet is determined by user priority field in 802.1Q VLAN tag. The priority value is supported 0~7.

**COS Port Default:** When an ingress packet has not VLAN tag, a default priority value is considered and determined by ingress port.

**TOS/DSCP:** TOS (Type of Service) is a field in IP header of a packet. This TOS field is also used by Differentiated Services and is called the Diff Serv Code Point (DSCP). The output priority of a packet can be determined by this field and the priority value is supported 0~63.

### 5.1.5.1 QoS Policy



Traffic Prioritization interface




The following table describes the labels in this screen.

Label	Description
<b>QOS Mode</b>	<p><b>Port-based:</b> the output priority is determined by ingress port.</p> <p><b>COS only:</b> the output priority is determined by COS only.</p> <p><b>TOS only:</b> the output priority is determined by TOS only.</p> <p><b>COS first:</b> the output priority is determined by COS and TOS, but COS first.</p> <p><b>TOS first:</b> the output priority is determined by COS and TOS, but TOS first.</p>
<b>QOS Policy</b>	<p><b>Using the 8,4,2,1 weight fair queue scheme:</b> the output queues will follow 8:4:2:1 ratio to transmit packets from the highest to lowest queue.</p> <p>For example: 8 high queue packets, 4 middle queue packets, 2 low queue packets, and the one lowest queue packets are transmitted in one turn.</p> <p><b>Use the strict priority scheme:</b> the packets in a higher queue will always be transmitted first until the higher queue is empty.</p>
<b>Apply</b>	Click " <b>Apply</b> " to set the configuration settings.
<b>Help</b>	Show the related help file.

### 5.1.5.2 Port-based Priority

When Priority Type is set to Port-based, the output priority is determined by the ingress port.




Port-based Priority interface

The following table describes the labels in this screen.

Label	Description
<b>Priority</b>	Assign Port with a priority queue. Four priority queues can be assigned: High, Middle, Low, and Lowest.
<b>Apply</b>	Click “ <b>Apply</b> ” to set the configuration.
<b>Help</b>	Show help file.

### 5.1.5.3 COS/802.1p



COS/802.1p interface

The following table describes the labels in this screen.

Label	Description
<b>COS/802.1p</b>	COS (Class Of Service) is well known as IEEE 802.1p. It describes that the output priority of a packet is determined by the user priority field in the 802.1Q VLAN tag. The priority values range from 0 to 7. The COS value maps to 4 priority queues: High, Middle, Low, and Lowest.
<b>COS Port Default</b>	When an ingress packet does not have a VLAN tag, a default priority value is determined by ingress port. At the dropdown, select 0-7.
<b>Apply</b>	Click <b>Apply</b> to set the configurations.
<b>Help</b>	Show help file.

### 5.1.5.4 TOS/DSCP



TOS/DSCP interface


The following table describes the labels in this screen.

Label	Description
<b>TOS/DSCP</b>	TOS (Type of Service) is a field in IP header of a packet. This TOS field is also used by Differentiated Services and is called the Differentiated Services Code Point (DSCP). The output priority of a packet can be determined by this field and the priority has values from 0 to 63. DSCP value maps to 4 priority queues: High, Middle, Low, and Lowest.
<b>Apply</b>	Click “ <b>Apply</b> ” to set the configurations.
<b>Help</b>	Show help file.

## 5.1.6 DHCP Server

### 5.1.6.1 DHCP Server – Setting

The system can provide a DHCP server function. If enabled, the switch will be a DHCP server.



DHCP Server Configuration interface

Label	Description
<b>DHCP Server</b>	Enable or Disable the DHCP Server function. When set to Enable, the switch will be the DHCP server on your local network
<b>Start IP Address</b>	The beginning of the dynamic IP address range. For example: if the dynamic IP address range is from 192.168.1.100 to 192.168.1.200, then IP address 192.168.1.100 will be the first IP address assigned.
<b>End IP Address</b>	The end of the dynamic IP address range. For example: if the dynamic IP assigned range is from 192.168.1.100 to 192.168.1.200, then IP address 192.168.1.200 will be the last IP address assigned.
<b>Subnet Mask</b>	The subnet mask.
<b>Gateway</b>	The gateway in your network.
<b>DNS</b>	The IP Address of the Domain Name Server in your network.
<b>Lease Time (Hour)</b>	The time period before the system will reset the assigned dynamic IP to ensure the IP address is in used.
<b>Apply</b>	Click " <b>Apply</b> " to set the configuration.

### 5.1.6.2 DHCP Server – Client List


When the DHCP server function is activated, the system will collect the DHCP client information and display it here.



DHCP Server Client Entries interface

### 5.1.6.3 DHCP Server – Port and IP bindings

You can assign the specific IP address which is in the assigned dynamic IP range to the specific port. When the device is connecting to the port and asks for dynamic IP assigning, the system will assign the IP address that has been assigned before to the connected device.



DHCP Server Port and IP Binding interface

### 5.1.7 SNMP

Simple Network Management Protocol (SNMP) is the protocol developed to manage nodes (servers, workstations, routers, switches and hubs etc.) on an IP network. SNMP lets network administrators manage network performance, find and solve network problems, and plan for network growth. Network management systems learn of problems by receiving traps or change notices from network devices implementing SNMP.

#### 5.1.7.1 SNMP – Agent Setting

You can set SNMP agent related information using the Agent Setting Function.



SNMP – Agent Setting interface


Label	Description
<b>SNMP Agent Version</b>	The switch supports SNMP V1/V2c, and SNMP V3. The SNMP V1/ V2c agent use a community string match for authentication, which means SNMP servers access objects with read-only or read/write permissions with the community default string public/private. SNMP V3 requires an authentication level of MD5 or DES to encrypt data to enhance data security.
<b>SNMP V1/V2c Community</b>	SNMP Community should be set for SNMP V1/V2c. Four sets of "Community String/Privilege" are supported. Each Community String is maximum 32 characters. Keep empty to remove this Community string.

<b>SNMPv3 Engine ID</b>	The SNMPv3 Engine ID in the format 800003640300c0f2560a31.
<b>SNMP v3 User</b>	<p>If SNMP V3 agent is selected, the SNMPv3 user profile should be set for authentication. The User Name is required. The Auth Password is encrypted by MD5 and the Privacy Password which is encrypted by DES. There are maximum 8 sets of SNMPv3 User and maximum 16 characters in user name, and password.</p> <p>When SNMP V3 agent is selected, you can:</p> <ol style="list-style-type: none"> <li>1. Enter the SNMPv3 user name only.</li> <li>2. Enter the SNMPv3 user name and Auth Password.</li> <li>3. Enter the SNMPv3 user name, Auth Password and Privacy Password (which can be different than the Auth Password).</li> </ol> <p>To remove a current user profile:</p> <ol style="list-style-type: none"> <li>1. Enter the SNMPv3 user name you want to remove.</li> <li>2. Click the "Remove" button.</li> </ol>
<b>Current SNMPv3 User Profile</b>	Displays a table with the User Name, Auth. Password, and Priv. Password.
<b>Apply</b>	Click to make the settings.
<b>Add</b>	Click to add an instance.
<b>Remove</b>	Click to delete the selected instance.



### 5.1.7.2 SNMP –Trap Setting

A trap manager is a management server that receives traps, the system alerts generated by the switch. If no trap manager is defined, no traps will be issued. Create a trap manager by entering the IP address of the SNMP trap receiving server and a community string. To define management systems, enter the server’s IP address, SNMP community strings and select the SNMP version.




SNMP –Trap Setting interface

Label	Description						
<b>Server IP</b>	The server IP address to receive Traps.						
<b>Community</b>	The Community for authentication.						
<b>Trap Version</b>	Trap Version supports V1 and V2c.						
<b>Trap Server Profile</b>	Displays all SNMP Trap servers configured: <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p><b>Trap Server Profile</b></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 33%;">Server IP</th> <th style="width: 33%;">Community</th> <th style="width: 33%;">Trap Version</th> </tr> </thead> <tbody> <tr> <td>192.168.1.30</td> <td>secwing</td> <td>v2</td> </tr> </tbody> </table> </div>	Server IP	Community	Trap Version	192.168.1.30	secwing	v2
Server IP	Community	Trap Version					
192.168.1.30	secwing	v2					
<b>Add</b>	Add a trap server profile.						
<b>Remove</b>	Remove a selected trap server profile.						
<b>Help</b>	Show help file.						

### 5.1.8 Security


Five useful functions that can enhance the security of the switch:

IP Security, Port Security, MAC Blacklist, 802.1x protocol, and TACACS+.



#### 5.1.8.1 IP Security

Only IP addresses in the Secure IP List can manage the switch through your defined management mode (Web, Telnet, or SNMP). IP security can enable/disable remote management via Web or Telnet or SNMP. Additionally, IP security can restrict remote management to some specific IP addresses. Only these secure IP addresses can manage this switch remotely.




IP Security interface

Label	Description
<b>IP Security Mode</b>	Enable/Disable the IP security function.
<b>Enable WEB(HTTP) Management</b>	Enable/Disable remote management from a Web browser. Check the box to enable WEB Management.
<b>Enable HTTPS Management</b>	Enable/Disable remote management from a secure Web browser. Check the box to enable Secure HTTP Web Management.
<b>Enable Telnet Management</b>	Enable/Disable remote management from Telnet. Check the box to enable Telnet Management.
<b>Enable SSH Management</b>	Enable/Disable remote management via SSH (Secure Shell). Check the box to enable SSH Management.

<b>Enable SNMP Management</b>	Enable/Disable remote management from SNMP. Check the box to enable SNMP Management.
<b>Secure IP List</b>	Assign up to 10 secure IP addresses. Only these IP addresses will be able to manage the switch after clicking "Apply".
<b>Apply</b>	Click " <b>Apply</b> " to set the configurations.
<b>Help</b>	Show help file.

### 5.1.8.2 Port Security

Port security is used to add static MAC addresses to the hardware forwarding database. If port security is enabled at the Port Control page, only frames with MAC addresses in this list will be forwarded, otherwise will be discarded.



Port Security interface

Label	Description
<b>MAC Address</b>	Input MAC Address to a specific port.
<b>Port No.</b>	Select port of switch.
<b>Add</b>	Add an entry of MAC and port information.
<b>Delete</b>	Delete the entry.
<b>Help</b>	Show help file.

**To add a static MAC address:**

1. In the MAC address box, enter a MAC address (e.g. 001122334455).
2. In the Port Number box, select a port number.
3. Click the "Add" button.

**To delete a static MAC address:**

1. In the MAC address box, enter a MAC address.
2. Click the "Delete" button.


Port Security List

MAC Address	Port
001122334455	Port.02
112233445566	Port.03

### 5.1.8.3 MAC Blacklist

MAC Blacklist can eliminate the traffic forwarding to specific MAC addresses in the list.

Any frames forwarding to MAC addresses in this list will be discarded. The target device will never receive any frames.



MAC Blacklist interface

Label	Description
<b>MAC Address</b>	Enter a MAC Address to add to the MAC Blacklist.
<b>Add</b>	Add an entry to Blacklist table.
<b>Delete</b>	Delete the entry.
<b>Help</b>	Show help file.

**To add a MAC address filter:**


1. In the MAC Address box, enter a MAC address (e.g. 001122334455).
2. Click the "Add" button.

**To delete a filter MAC address:**

1. In the MAC address box, enter a MAC address.
2. Click the "Delete" button.

### 5.1.8.4 802.1x Radius Server

IEEE 802.1x makes use of the physical access characteristics of IEEE802 LAN infrastructures in order to provide a means of authenticating and authorizing devices attached to a LAN port that has point-to-point connection characteristics, and of preventing access to that port in cases in which the authentication and authorization process fails. Refer to IEEE 802.1X - Port Based Network Access Control.



802.1x Radius Server interface

**Note:** firmware version v1.32 provided a fix for TLS v1.1 and v1.2 vulnerability for secure communications applications. Note that EAP MD5 must be set as the default authentication method on any Radius server. This applies to Radius servers such as FreeRadius which may accept MD5 and have TLS as the default setting in EAP configuration.


The RADIUS parameters are described in the table below. See “Appendix A - Radius Server and Switch Settings” for more setup details.

Label	Description
<b>802.1x Protocol</b>	Enable or Disable 802.1X Radius Server functionality.
<b>Radius Server IP</b>	The IP address of the authentication server.
<b>Server Port</b>	Set the UDP port number used by the authentication server to authenticate.

<b>Accounting Port</b>	Set the UDP port number used by the authentication server to retrieve accounting information.
<b>Shared Key</b>	A key shared between this switch and authentication server.
<b>NAS, Identifier</b>	A string used to identify this switch.
<b>Advanced Setting</b>	
<b>Quiet Period</b>	Set the time interval between authentication failure and the start of a new authentication attempt. During this period of time it will not attempt to acquire a supplicant. The default time is 60 seconds.
<b>Tx Period</b>	Set the time that the switch can wait for response to an EAP request/identity frame from the client before resending the request. This is the period of time to transmit an EAPOL PDU. The default is 30 seconds.
<b>Supplicant Timeout</b>	Set the period of time the switch waits for a supplicant response to an EAP request. The timeout conditions in the exchanges between the supplicant and authentication server. The default is 30 seconds.
<b>Server Timeout</b>	Set the period of time the switch waits for a Radius server response to an authentication request. The timeout conditions in the exchanges between the authenticator and authentication server. The default is 30 seconds.
<b>Max Requests</b>	Set the maximum number of times to retry sending packets to the supplicant. This is the number of reauthentication attempts that are permitted before the specific port becomes unauthorized. The default is 2 times.
<b>Re-Auth Period</b>	Set the period of time after which clients connected must be re-authenticated. Enter a nonzero number of seconds between periodic reauthentication of the supplications. The default is 3600 seconds.
<b>Apply</b>	Click " <b>Apply</b> " to set the configurations.
<b>Help</b>	Show help file.

### 802.1x-Port Authorized Setting

Set the 802.1x authorized mode of each port.



802.1x Port Authorize interface


The following table describes the labels in this screen.

Label	Description
<b>Port Authorize Mode</b>	<p><b>Reject:</b> force this port to be unauthorized.</p> <p><b>Accept:</b> force this port to be authorized.</p> <p><b>Authorize:</b> the state of this port as determined by the outcome of the 802.1x authentication.</p> <p><b>Disable:</b> this port will not participate in 802.1x.</p>
<b>Apply</b>	Click " <b>Apply</b> " to set the configurations.
<b>Help</b>	Show help file.



**802.1x-Port Authorized State**


Displays the 802.1x port authorized state. See the parameter descriptions above.



802.1x Port Authorize State interface

### 5.1.8.5 TACACS+

This page lets you configure TACACS+ Server and Client authentication parameters.




TACACS+ interface

Label	Description
<b>Server Configuration</b>	
<b>Enabled</b>	Check the box to enable each TACACS+ Server instance. Up to five TACACS+ Servers can be configured.
<b>Server IP Address</b>	Enter the TACACS+ Server IP address.
<b>Port</b>	Enter the TACACS+ Server UDP port number. The default is commonly-used port # 48 or 49.
<b>Secret Key</b>	Enter the auth secret key for the TACACS+ Server.
<b>Client Configuration</b>	
<b>Client</b>	For each client (Console, Telnet , Web) select an authentication method.
<b>Authentication Method</b>	At the dropdown, select either <b>Local</b> or <b>TACACS+</b> as the method for TACACS+ user authentication.
<b>Apply</b>	Click “Apply” to set the configurations.

### 5.1.9 Warning


The Warning function is a very important tool for managing the switch. You can manage the switch by SYSLOG, SMTP (e-mail), and Fault Alarm.



Warnings help you to monitor the switch status from a remote site. When events occur, the warning message is sent to your designated server, E-MAIL, or relay fault switch panel. System alarm supports two warning modes: SYSLOG and E-MAIL. You can monitor the switch through selected system events.

#### Warning > Fault Alarm


When any selected fault event occurs, the front panel Fault LED lights and the electric relay will signal at the same time.



Label	Description
<b>Power Failure</b>	Fault alarm when any selected power failure. This switch support dual power inputs. Check the box for PWR 1 and/or PWR 2.
<b>Port Link Down/Broken</b>	Fault alarm when any selected port link down or broken. Check the box for Port.01 - Port.08, G1, and/or G2.
<b>Apply</b>	Click <b>“Apply”</b> to set the configurations.
<b>Help</b>	Show help file.

**System Warning – SYSLOG Setting**

Syslog is a protocol to transmit event notification messages across networks. Refer to IETF RFC 3164 - The BSD SYSLOG Protocol.



System Warning – SYSLOG Setting interface

Label	Description
<b>Syslog Mode</b>	<p><b>Disable:</b> disable SYSLOG.</p> <p><b>Client Only:</b> log to local system.</p> <p><b>Server Only:</b> log to a remote SYSLOG server.</p> <p><b>Both:</b> log to both of local and remote server.</p>
<b>SYSLOG Server IP Address</b>	The remote SYSLOG Server IP address.
<b>Apply</b>	Click " <b>Apply</b> " to set the configurations.
<b>Help</b>	Show help file.

### System Warning – SMTP Setting

SMTP (Simple Mail Transfer Protocol) is a protocol for e-mail transmission across the Internet.

Refer to RFC 821 - Simple Mail Transfer Protocol.

System Warning – SMTP Setting interface


Label	Description
<b>E-mail Alert</b>	Enable/Disable transmission system warning events by e-mail.
<b>Sender E-mail Address</b>	Enter the mail server address.
<b>Mail Subject</b>	The Subject of the mail (e.g., Automated Email Alert).
<b>Sender</b>	Set up the email account to send the alert.
<b>Authentication</b>	Check the box if the SMTP server needs authentication; enter: <b>Username:</b> the authentication username. <b>Password:</b> the authentication password. <b>Confirm Password:</b> re-enter password.
<b>Recipient E-mail Address 1 - 6</b>	The recipient's E-mail address. Up to six e-mail recipients are supported.
<b>Apply</b>	Click " <b>Apply</b> " to set the configurations.
<b>Help</b>	Show help file.

**System Warning – Event Selection**

Syslog and SMTP are the two warning methods supported by the system.

Check the corresponding box to enable the system event warning method you want.

**Note** that the checkbox can not be checked when SYSLOG or SMTP is disabled.



System Warning – Event Selection interface

Label	Description
<b>System Cold Start</b>	Issue a log event when the device executes a cold start.
<b>Power Status</b>	Issue an alert when a power up or down is detected.
<b>SNMP Authentication Failure</b>	Issue an alert when there is a SNMP authentication failure.
<b>Redundant Ring Topology Change</b>	Issue an alert when a Redundant Ring topology change is detected.
<b>Port Event</b>	At the dropdown, select the action to be taken when an event occurs: Disable, Link Up, Link Down, Link Up & Link Down.
<b>Apply</b>	Click <b>Apply</b> to set the configurations.

## 5.1.10 Monitor and Diag

### 5.1.10.1 System Event Log

If the System Log client is enabled, system event logs are displayed in this table.

Click the "Reload" button to get the newest event logs and refresh this page.

Click the "Clear" button to clear all logs in system.




System Event Log interface

Label	Description
<b>Page</b>	At the dropdown, select which log page to display.
<b>Reload</b>	Click to display the newest event logs and refresh this page.
<b>Clear</b>	Click to clear the log table.
<b>Help</b>	Show help file.

### 5.1.10.2 MAC Address Table

Refer to IEEE 802.1 D Section 7.9. The MAC Address Table is a filtering database that supports queries by the Forwarding Process, to determine whether a frame received by a given port with a given destination MAC address is to be forwarded through a given potential transmission port.

This page shows all MAC addresses mapping to a selected port in table.




MAC Address Table interface

Label	Description
<b>Port No.</b>	Show all MAC addresses mapping to a selected port in table.
<b>Clear MAC Table</b>	Click to clear all MAC addresses in the table.
<b>MAC Address Table Aging Time</b>	Assign an aging time; it <u>must</u> be a multiple of 5 minutes. The valid range is 0-3825 seconds.
<b>Auto Flush MAC Address Table When Ports Link Down</b>	Check the checkbox to enable the function to the Flush MAC table when the port links down.
<b>Apply</b>	Click “Apply” to set the configuration.



### 5.1.10.3 Port Statistic

Port statistics show several statistics counters for all ports.




Port Statistics interface

Label	Description
<b>Type</b>	Show port speed and media type.
<b>Link</b>	Show port link status.
<b>State</b>	Show ports as Forwarding, Listening, or Learning.
<b>TX Good Packet</b>	The number of good packets sent by this port.
<b>TX Bad Packet</b>	The number of bad packets sent by this port.
<b>RX Good Packet</b>	The number of good packets received by this port.
<b>RX Bad Packet</b>	The number of bad packets received by this port.
<b>TX Abort Packet</b>	The number of packets aborted by this port.
<b>Packet Collision</b>	The number of times a collision was detected by this port.
<b>Clear</b>	Click to reset all counters to zero for all ports.
<b>Help</b>	Show help file.

### 5.1.10.4 Port Monitoring

The Port Monitoring function supports TX (egress) only, RX (ingress) only, and both TX/RX monitoring. **TX monitoring** sends any data that egress out checked TX source ports to a selected TX destination port as well. **RX monitoring** sends any data that ingress in checked RX source ports out to a selected RX destination port as well as sending the frame where it normally would have gone. **Note:** keep all source ports unchecked in order to disable port monitoring.




Port monitoring interface

Label	Description
<b>Destination Port</b>	The port will receive a copied frame from source port for monitoring purposes.
<b>Source Port</b>	The port will be monitored. Check the box for TX or RX to be monitored.
<b>TX</b>	The frames coming into the switch port.
<b>RX</b>	The frames received by switch port.
<b>Apply</b>	Click “ <b>Apply</b> ” to activate the configuration settings.
<b>Help</b>	Show help file.

### 5.1.10.5 SFP Monitor

This function can measure the temperature of SFP modules that support the DDM function. You can manage and set up the event alarm module through DDM Web page.



SFP Monitor interface


Label	Description
<b>Temperature ( °C )</b>	The measured (reported) SFP temperature in degrees Celsius.
<b>Vcc (V)</b>	The measured (reported) SFP vottage in Volts.
<b>TX Bias ( μ W )</b>	The measured (reported) SFP transmit bias in microWatts.
<b>TX Power ( μ W )</b>	The measured (reported) SFP transmit power in microWatts.
<b>RX Power ( μ W )</b>	The measured (reported) SFP receive power in microWatts.
<b>Warning Temperature</b>	Set the Warning Temperature in degrees C. The valid range is 0~100 degrees C.
<b>Event Alarm</b>	Select the warning method; either Syslog and/or SMTP (E-mail).
<b>Apply</b>	Click “ <b>Apply</b> ” to activate the configuration settings.
<b>Refresh</b>	Click to update the page data.

### 5.1.11 Power over Ethernet (PoE)

#### 5.1.11.1 Basic Setting

This page is for setting PoE parameters. The switch has eight ports (Port 1 - 8) that act as PSE (Power Sourcing Equipment) ports. **Note** that direct copper network connections between legacy detect PoE enabled ports is not recommended. See the “[Product Alert Notification](#)” on page 16 for details.

PoE (Power over Ethernet) technology is used to transmit electrical power to remote devices over standard Ethernet cables. PoE eliminates the need for an additional power supply for each connected PD (Powered Device), making it a cost-effective and convenient solution for deploying networks in places where placing a power supply is difficult or expensive to deploy. This page lets you set up basic PoE functions and view switch PoE status.



PoE Basic Setting interface

Label	Description
<b>Maximum Power Budget</b>	Setting for maximum power available. This is the maximum amount of power that can be allocated to all switch ports. Allocated power to each port will be subtracted from the total power budget.

<b>Power Limit Mode</b>	<p>This switch offers three power limit modes to provide power catering for different use scenarios.</p> <p><b>Max of AF/AT:</b> the switch supports both the IEEE 802.3af and 802.3at standards. The 802.3af allows for a maximum continuous output power of 15.40 W and the 802.3at allows for 34.20 W.</p> <p><b>Class:</b> by enabling this option, the switch will provide power to PDs in accordance to their classes, restricting the power supply to each PD to their maximum power levels. PD classes rang from 0 to 4.</p> <p><b>Port Setting:</b> by enabling this option, the switch will provide power to PDs in accordance to the value you have specified. For more information on the settings, please refer to Power Limit in Port Setting.</p>
<b>Legacy PD Detection</b>	<p>Check the checkbox to enable legacy PD detection. Legacy PDs refers to powered devices manufactured before the IEEE standard was finalized and do not have the expected PD signature required by the PSE's detection signal. Such PDs usually feature large capacitance as the detection signature that does not completely comply with the 802.3af specs.</p> <p>By enabling this option, the switch will probe for legacy PDs and if a legacy PD is detected, the switch will provide power to the PD.</p>
<b>Total Power Consumption</b>	Displays the total amount of power provided by the switch to PDs in Watts.
<b>Power Voltage</b>	Displays the output voltage of the switch for PoE ports.
<b>POE Chip Temperature</b>	Displays the temperature (in °C) of the chip during operation, allowing you to monitor the temperature, helping prevent port overheating.
<b>POE Chip Status</b>	<p>Displays the status of the chip during operation. The statuses include Normal, Resetting, No response, PoE controller error, and PoE device error, as described below:</p> <p><b>Normal:</b> the chip is functioning normally</p> <p><b>Resetting:</b> the chip is reinitiating.</p> <p><b>No response:</b> the chip is not responding.</p> <p><b>PoE controller error:</b> the PoE controller chip fails to operate functionally.</p> <p><b>PoE device error:</b> the PoE device chip fails to operate functionally.</p>
<b>Apply</b>	Click " <b>Apply</b> " to activate the configuration settings.
<b>Help</b>	Show help file.


**802.3af Classification**

A PD can optionally present a classification signature to the PSE to indicate the maximum power it will draw while operating. The IEEE specification defines this signature as a constant current draw when the PSE port voltage is in the VCLASS range (between 15.5V and 20.5V), with the current level indicating one of five possible PD classes. For example, a typical PD load line, starting with the slope of the 25k $\Omega$  signature resistor below 10V, then transitioning to the classification signature current (e.g., Class 3) in the VCLASS range. The table below shows the possible classification values:

<b>Class</b>	<b>Result</b>
Class 0	No Class Signature Present; Treat Like Class 3
Class 1	3W
Class 2	7W
Class 3	13W
Class 4	25.5W (Type 2)

**5.1.11.2 Power over Ethernet - Port Setting**

This interface is for setting the 8 PoE ports (Port.01 - Port.08) that act as PSE (Power Sourcing Equipment) ports.



PoE Port Setting interface


Label	Description
<b>Port No.</b>	Displays the PoE port number to which the settings on this row will be applied.
<b>Enable</b>	Check the box to enable the PoE function on a per-port basis. The checkbox allows you to enable or disable the PoE function of each port. When checked, the PoE function is enabled.
<b>Force Power</b>	When the function is enabled, the system will force PSE to feed power to the PD even if the power requested by the PD is higher than the value defined by its class.
<b>Priority</b>	This drop-down list provides options for the power supply priority for each port. There are three levels of power priority: Low, High, and Critical (highest). The priority is useful when the switch is fully loaded and cannot supply sufficient power to every port. When enabled, the switch supplies power to ports with higher priority, and powers down some ports with lower priority. <b>Critical</b> is the highest priority level. Ports set to this level are guaranteed power before any ports assigned to the other two priority levels. <b>High</b> is the second highest level. Ports set to this level receive power only if all the ports set to the Critical level are already receiving power. If there is not enough power to support all of the ports set to the High priority level, power is provided to the ports based on port number, in ascending order.

	<b>Low</b> is the lowest priority level. This is the default setting. Ports set to this level only receive power if all the ports assigned to the other two levels are already receiving power. Like other levels, if there is not enough power to support all of the ports set to the Low priority level, power is provided to the ports based on port number, in ascending order.
<b>Power Limit</b>	Enter the maximum power in watts that can be delivered to a port (< 36000 mW).
<b>Apply</b>	Click " <b>Apply</b> " to activate the configuration settings.
<b>Help</b>	Show help file.



### 5.1.11.3 Port Status

This page displays detailed PoE status for each each Port. The information for individual ports varies with their PoE states.




PoE Port Status interface

Label	Description
<b>Port No.</b>	Port number (Port.01 - Port.08).
<b>State</b>	Displays the PoE state of individual ports. The state can be: <b>Detecting:</b> the port is not connected to any PD or is detecting the PD. <b>No Powered:</b> power is not delivered. The connected device maybe not a PD or an error may have occurred when detecting. <b>Powered:</b> power is delivered to a PD. In this case, other columns in the same row will show related values.
<b>Current (mA)</b>	Displays the current used by the PD for this port in milliamps (mA).
<b>Voltage (V)</b>	Displays the voltage used by the PD for this port in Volts.
<b>Power (mW)</b>	Displays the power consumed by the PD for this port. The power is measured in milliwatts (mW).
<b>Class</b>	Displays the class of the PD for this port and the power consumed by the PD. When Bypass classification is enabled, the class value will not be shown.

### 5.1.11.4 PoE Ping Alive Check (Auto Power Reset - APR)

You can control the PoE function by using this feature to turn ON or OFF other PoE devices which connect with the assigned port. With APR enabled, it automatically pings the device on a configured schedule and if the device does not respond to the configured number of pings, the switch toggles PoE power on the port which automatically resets the device.




PoE Ping Alive Check interface

Label	Description
<b>Mode</b>	Enable or disable the PoE Ping Alive Check function globally.
<b>Event Alarm by SMTP</b>	At the dropdown select Enable to send alarm message via SMTP. When Enabled and a “ping” fails, you are notified by e-mail.
<b>Port No.</b>	You can configure the Ping function per PoE port number.
<b>Ping IP Address</b>	Enter the IP Address to Ping.
<b>Interval Time</b>	Enter the interval between Pings sent (10 ~120 seconds).
<b>Retry Time</b>	Set the amount of time before a Ping retry is attempted (1~5 seconds).
<b>Failure Log</b>	Tracks “Ping Check ” failures.
<b>Failure Action</b>	Set the action to take when a failure occurs: Nothing, Restart Forever, Restart Once, Power On, or Power Down.
<b>Reboot Time</b>	Set the amount of time to wait after a ping check failure before rebooting the switch. Only valid if “Failure Action” is set to “Restart Forever” or “Restart Once”. The valid range is 3-120 seconds. The default is 15 seconds.

### 5.1.11.5 PoE Schedule

You can schedule a date and time to enable or disable the Power over Ethernet function.

**Note** that the SNTP function must be Enabled for PoE scheduling to work.



PoE Schedule interface

The following table describes the labels in this screen.

Label	Description
<b>Schedule on</b>	At the dropdown, select the Port to configure PoE scheduling. Schedule on Port.01, Port.02, Port.03, Port.04, Port.05, Port.06, Port.07, Port.08, or Port.01~Port.08.
<b>Schedule mode</b>	At the dropdown, select Enable or disable PoE schedule mode.
<b>Select all</b>	Check the box to select all dates and times. Uncheck the box to de-select all dates and times.
<b>Hour</b>	Check to enable the time(s) for PoE scheduling (00 - 23).
<b>Sunday - Saturday</b>	Check to enable PoE function for one or more days.
<b>Apply</b>	Click “ <b>Apply</b> ” to activate the configuration settings.

### 5.1.12 Save Configuration

If any configuration changes are made, you must click the **“Save Configuration”** button to save the current configuration data to the permanent flash memory. Otherwise, the current configuration is lost when the switch is powered off or when the system is reset.



Save Configuration interface

The following table describes the labels in this screen.

Label	Description
<b>Save</b>	Save all configuration changes.
<b>Help</b>	Show help file.

The message *“Save to Flash OK! Press Here to back to Previous Page.”* displays when successfully completed. Click the link to return to the Save Configuration page. .

### 5.1.13 Factory Default

Here you can reset switch to its factory default configuration. After clicking the "Reset" button, you must restart the system for the default configuration to be applied at next start.



Factory Default interface

To reset the switch to its default configuration, click the **Reset** button to reset all configurations to the default values. You can check the boxes to **“Keep current IP address setting?”** and **“Keep current username & password?”**.

### 5.1.14 System Reboot

Here you can click the [Reboot] button to restart the switch.



System Reboot interface

The following table describes the labels in this screen.

Label	Description
<b>Reboot</b>	Click the button to start an immediate re-boot.

During the re-boot process, the message “*Rebooting ... After several seconds, reconnect the system.*” displays. **Note** that you may need to refresh your web browser to display the System information page again.

## 6. Command Line Interface (CLI)

### 6.1 About CLI Management

In addition to Web-based management, the SISPM1040-382-LRT also supports CLI management. Before configuring by RS-232 serial console, use an RJ45 to DB9-F cable to connect the Switches' RS-232 Console port to your PCs' COM port. You can use HyperTerminal, PuTTY, Tera Term, Telnet, or similar program.

Follow the steps below to access the console via **HyperTerminal**.

1. At Windows desktop, click Start -> Programs -> Accessories -> Communications -> Hyper Terminal.
2. Enter a name for new connection
3. Select COM port number to use.
4. Use the COM port properties settings: 9600 for Bits per second, 8 for Data bits, None for Parity, 1 for Stop bits, and None for Flow control.
5. The Console login screen displays. Use the keyboard to enter the Username and Password (both **root**), then press "**Enter**".

#### CLI Management by Telnet

You can use "**TELNET**" to configure the switch. The default IP Address is **192.168.1.77**.

Follow the steps below to access the console via Telnet.

1. Telnet to the IP address of the switch from the Windows "**Run**" command (or from the MS-DOS prompt).
2. The Login screen displays. Use the keyboard to enter the Username and Password (both **root**), and then press "**Enter**".

**Note:** firmware version v1.27 made CLI enhancements: add port alias in web UI, add port alias info for port event log in syslog, add port alias info for port linkup/down SNMP trap, add SSH and TACACS+, add setting check in POE Setting page, add CLI commands (security https, security ssh, no security https, no security ssh).

**CLI Command Levels**

<b>Modes</b>	<b>Access Method</b>	<b>Prompt</b>	<b>Exit Method</b>	<b>About This Model</b>
User EXEC	Begin a session with your switch.	switch>	Enter <b>logout</b> or <b>quit</b> .	The user commands available at the level of user is the subset of those available at the privileged level. Use this mode to <ul style="list-style-type: none"> <li>• Enter menu mode.</li> <li>• Display system information.</li> </ul>
Privileged EXEC	Enter the <b>enable</b> command while in user EXEC mode.	switch#	Enter <b>disable</b> to exit.	The privileged command is advance mode. Use Privileged mode to <ul style="list-style-type: none"> <li>• Display advance function status</li> <li>• save configures</li> </ul>
Global configuration	Enter the <b>configure</b> command while in privileged EXEC mode.	Switch (config)#	To exit to privileged EXEC mode, enter <b>exit</b> or <b>end</b>	Use this mode to configure parameters that apply to your Switch as a whole.
VLAN database	Enter the <b>vlan database</b> command while in privileged EXEC mode.	Switch (vlan)#	To exit to user EXEC mode, enter <b>exit</b> .	Use this mode to configure VLAN-specific parameters.
Interface configuration	Enter the <b>interface</b> command (with a specific interface)while in global configuration mode	Switch (config-if)#	To exit to global configuration mode, enter <b>exit</b> . To exit privileged EXEC mode enter <b>exit</b> or <b>end</b> .	Use this mode to configure parameters for the switch and Ethernet ports.

## Command Level Symbols

Mode	Symbol of Command Level
User EXEC	E
Privileged EXEC	P
Global configuration	G
VLAN database	V
Interface configuration	I

## 6.2 System Command Set

SISPM1040-382-LRT Commands	Level	Description	Example
<b>show config</b>	E	Show switch configuration	switch>show config
<b>show terminal</b>	P	Show console information	switch#show terminal
<b>write memory</b>	P	Save your configuration into permanent memory (flash rom)	switch#write memory
<b>system name</b> [System Name]	G	Configure system name	switch(config)#system name xxx
<b>system location</b> [System Location]	G	Set switch system location string	switch(config)#system location xxx
<b>system description</b> [System Description]	G	Set switch system description string	switch(config)#system description xxx
<b>system contact</b> [System Contact]	G	Set switch system contact window string	switch(config)#system contact xxx
<b>show system-info</b>	E	Show system information	switch>show system-info
<b>ip address</b> [ip-address] [Subnet-mask] [Gateway]	G	Configure the IP address of switch	switch(config)#ip address 192.168.1.1 255.255.255.0 192.168.1.254
<b>ip dhcp</b>	G	Enable DHCP client function of switch	switch(config)#ip dhcp



<b>show ip</b>	<b>P</b>	Show IP information of switch	switch#show ip
<b>no ip dhcp</b>	<b>G</b>	Disable DHCP client function of switch	switch(config)#no ip dhcp
<b>reload</b>	<b>G</b>	Halt and perform a cold restart	switch(config)#reload
<b>default</b>	<b>G</b>	Restore to default	Switch(config)#default
<b>admin username</b> [Username]	<b>G</b>	Changes a login username. (maximum 10 words)	switch(config)#admin username xxxxxx
<b>admin password</b> [Password]	<b>G</b>	Specifies a password (maximum 10 words)	switch(config)#admin password xxxxxx
<b>show admin</b>	<b>P</b>	Show administrator information	switch#show admin
<b>dhcpserver enable</b>	<b>G</b>	Enable DHCP Server	switch(config)#dhcpserver enable
<b>dhcpserver lowip</b> [Low IP]	<b>G</b>	Configure low IP address for IP pool	switch(config)# dhcpserver lowip 192.168.1.1
<b>dhcpserver highip</b> [High IP]	<b>G</b>	Configure high IP address for IP pool	switch(config)# dhcpserver highip 192.168.1.50
<b>dhcpserver subnetmask</b> [Subnet mask]	<b>G</b>	Configure subnet mask for DHCP clients	switch(config)#dhcpserver subnetmask 255.255.255.0
<b>dhcpserver gateway</b> [Gateway]	<b>G</b>	Configure gateway for DHCP clients	switch(config)#dhcpserver gateway 192.168.1.254
<b>dhcpserver dnsip</b> [DNS IP]	<b>G</b>	Configure DNS IP for DHCP clients	switch(config)# dhcpserver dnsip 192.168.1.1
<b>dhcpserver leasetime</b> [Hours]	<b>G</b>	Configure lease time (in hour)	switch(config)#dhcpserver leasetime 1
<b>dhcpserver ipbinding</b> [IP address]	<b>I</b>	Set static IP for DHCP clients by port	switch(config)#interface fastEthernet 2 switch(config-if)#dhcpserver ipbinding 192.168.1.1
<b>show dhcpserver configuration</b>	<b>P</b>	Show configuration of DHCP server	switch#show dhcpserver configuration
<b>show dhcpserver clients</b>	<b>P</b>	Show client entries of DHCP server	switch#show dhcpserver clinets
<b>show dhcpserver ip-binding</b>	<b>P</b>	Show IP-Binding information of DHCP	switch#show dhcpserver ip-binding

		server	
<b>no dhcpserver</b>	<b>G</b>	Disable DHCP server function	switch(config)#no dhcpserver
<b>security enable</b>	<b>G</b>	Enable IP security function	switch(config)#security enable
<b>security http</b>	<b>G</b>	Enable IP security of HTTP server	switch(config)#security http
<b>security telnet</b>	<b>G</b>	Enable IP security of telnet server	switch(config)#security telnet
<b>security ip</b> [Index(1..10)] [IP Address]	<b>G</b>	Set the IP security list	switch(config)#security ip 1 192.168.1.55
<b>show security</b>	<b>P</b>	Show the information of IP security	switch#show security
<b>no security</b>	<b>G</b>	Disable IP security function	switch(config)#no security
<b>no security http</b>	<b>G</b>	Disable IP security of HTTP server	switch(config)#no security http
<b>no security telnet</b>	<b>G</b>	Disable IP security of telnet server	switch(config)#no security telnet

### 6.3 Port CommandSet

SISPM1040-382-LRT Commands	Level	Description	Example
<b>interface fastEthernet</b> [Portid]	<b>G</b>	Choose the port for modification.	switch(config)#interface fastEthernet 2
<b>duplex</b> [full   half]	<b>I</b>	Use the duplex configuration command to specify the duplex mode of operation for Fast Ethernet.	switch(config)#interface fastEthernet 2 switch(config-if)#duplex full
<b>speed</b> [10 100 1000 auto]	<b>I</b>	Use the speed configuration command to specify the speed mode of	switch(config)#interface fastEthernet 2 switch(config-if)#speed 100

		operation for Fast Ethernet., the speed can't be set to 1000 if the port isn't a giga port.	
<b>flowcontrol mode</b> [Symmetric Asymmetric]	I	Use the flowcontrol configuration command on Ethernet ports to control traffic rates during congestion.	switch(config)#interface fastEthernet 2 switch(config-if)#flowcontrol mode Asymmetric
<b>no flowcontrol</b>	I	Disable flow control of interface	switch(config-if)#no flowcontrol
<b>security enable</b>	I	Enable security of interface	switch(config)#interface fastEthernet 2 switch(config-if)#security enable
<b>no security</b>	I	Disable security of interface	switch(config)#interface fastEthernet 2 switch(config-if)#no security
<b>bandwidth type all</b>	I	Set interface ingress limit frame type to "accept all frame"	switch(config)#interface fastEthernet 2 switch(config-if)#bandwidth type all
<b>bandwidth type broadcast-multicast-flooded-unicast</b>	I	Set interface ingress limit frame type to "accept broadcast, multicast, and flooded unicast frame"	switch(config)#interface fastEthernet 2 switch(config-if)#bandwidth type broadcast-multicast-flooded-unicast
<b>bandwidth type broadcast-multicast</b>	I	Set interface ingress limit frame type to "accept broadcast and multicast frame"	switch(config)#interface fastEthernet 2 switch(config-if)#bandwidth type broadcast-multicast
<b>bandwidth type broadcast-only</b>	I	Set interface ingress limit frame type to "only accept broadcast frame"	switch(config)#interface fastEthernet 2 switch(config-if)#bandwidth type broadcast-only
<b>bandwidth in</b> [Value]	I	Set interface input bandwidth. Rate	switch(config)#interface fastEthernet 2

		Range is from 100 kbps to 102400 kbps or to 256000 kbps for giga ports, and zero means no limit.	switch(config-if)#bandwidth in 100
<b>bandwidth out</b> [Value]	I	Set interface output bandwidth. Rate Range is from 100 kbps to 102400 kbps or to 256000 kbps for giga ports, and zero means no limit.	switch(config)#interface fastEthernet 2 switch(config-if)#bandwidth out 100
<b>show bandwidth</b>	I	Show interfaces bandwidth control	switch(config)#interface fastEthernet 2 switch(config-if)#show bandwidth
<b>state</b> [Enable   Disable]	I	Use the state interface configuration command to specify the state mode of operation for Ethernet ports. Use the disable form of this command to disable the port.	switch(config)#interface fastEthernet 2 switch(config-if)#state Disable
<b>show interface configuration</b>	I	show interface configuration status	switch(config)#interface fastEthernet 2 switch(config-if)#show interface configuration
<b>show interface status</b>	I	show interface actual status	switch(config)#interface fastEthernet 2 switch(config-if)#show interface status
<b>show interface accounting</b>	I	show interface statistic counter	switch(config)#interface fastEthernet 2

			switch(config-if)#show interface accounting
<b>no accounting</b>	<b>I</b>	Clear interface accounting information	switch(config)#interface fastEthernet 2 switch(config-if)#no accounting

## 6.4 Trunk Command Set

SISPM1040-382-LRT Commands	Level	Description	Example
<b>aggregator priority</b> [1to65535]	<b>G</b>	Set port group system priority	switch(config)#aggregator priority 22
<b>aggregator activityport</b> [Port Numbers]	<b>G</b>	Set activity port	switch(config)#aggregator activityport 2
<b>aggregator group</b> [GroupID] [Port-list] <b>lacp</b> <b>workp</b> [Workport]	<b>G</b>	Assign a trunk group with LACP active. [GroupID] :1to3 [Port-list]:Member port list, This parameter could be a port range(ex.1-4) or a port list separate by a comma(ex.2, 3, 6) [Workport]: The amount of work ports, this value could not be less than zero or be large than the amount of member ports.	switch(config)#aggregator group 1 1-4 lacp workp 2 or switch(config)#aggregator group 2 1,4,3 lacp workp 3
<b>aggregator group</b> [GroupID] [Port-list] <b>nolacp</b>	<b>G</b>	Assign a static trunk group. [GroupID] :1to3 [Port-list]:Member port list, This parameter could be a port range(ex.1-4) or a port list separate by a	switch(config)#aggregator group 1 2-4 nolacp or switch(config)#aggregator group 1 3,1,2 nolacp

		comma(ex.2, 3, 6)	
<b>show aggregator</b>	<b>P</b>	Show the information of trunk group	switch#show aggregator
<b>no aggregator lacp</b> [GroupID]	<b>G</b>	Disable the LACP function of trunk group	switch(config)#no aggregator lacp 1
<b>no aggregator group</b> [GroupID]	<b>G</b>	Remove a trunk group	switch(config)#no aggregator group 2

## 6.5 VLAN Command Set

SISPM1040-382-LRT Commands	Level	Description	Example
<b>vlan database</b>	<b>P</b>	Enter VLAN configure mode	switch#vlan database
<b>vlan</b> [8021q   gvrp]	<b>V</b>	To set switch VLAN mode.	switch(vlan)# vlanmode 802.1q or switch(vlan)# vlanmode gvrp
<b>no vlan</b> [VID]	<b>V</b>	Disable vlan group(by VID)	switch(vlan)#no vlan 2
<b>no gvrp</b>	<b>V</b>	Disable GVRP	switch(vlan)#no gvrp
<b>IEEE 802.1Q VLAN</b>			
<b>vlan 8021q port</b> [PortNumber] <b>access-link untag</b> [UntaggedVID]	<b>V</b>	Assign a access link for VLAN by port, if the port belong to a trunk group, this command can't be applied.	switch(vlan)#vlan 802.1q port 3 access-link untag 33
<b>vlan 8021q port</b> [PortNumber] <b>trunk-link tag</b> [TaggedVID List]	<b>V</b>	Assign a trunk link for VLAN by port, if the port belong to a trunk group, this command can't be applied.	switch(vlan)#vlan 8021q port 3 trunk-link tag 2,3,6,99 or switch(vlan)#vlan 8021q port 3 trunk-link tag 3-20
<b>vlan 8021q port</b> [PortNumber] <b>hybrid-link untag</b> [UntaggedVID] <b>tag</b> [TaggedVID List]	<b>V</b>	Assign a hybrid link for VLAN by port, if the port belong to a trunk group, this command can't be applied.	switch(vlan)# vlan 8021q port 3 hybrid-link untag 4 tag 3,6,8 or switch(vlan)# vlan 8021q port 3 hybrid-link untag 5 tag 6-8

<b>vlan 8021q aggregator</b> [TrunkID] <b>access-link untag</b> [UntaggedVID]	<b>V</b>	Assign a access link for VLAN by trunk group	switch(vlan)#vlan 8021q aggregator 3 access-link untag 33
<b>vlan 8021q aggregator</b> [TrunkID] <b>trunk-link tag</b> [TaggedVID List]	<b>V</b>	Assign a trunk link for VLAN by trunk group	switch(vlan)#vlan 8021q aggregator 3 trunk-link tag 2,3,6,99 or switch(vlan)#vlan 8021q aggregator 3 trunk-link tag 3-20
<b>vlan 8021q aggregator</b> [PortNumber] <b>hybrid-link untag tag</b> [UntaggedVID] [TaggedVID List]	<b>V</b>	Assign a hybrid link for VLAN by trunk group	switch(vlan)# vlan 8021q aggregator 3 hybrid-link untag 4 tag 3,6,8 or switch(vlan)# vlan 8021q aggregator 3 hybrid-link untag 5 tag 6-8
<b>show vlan</b> [VID] or <b>show vlan</b>	<b>V</b>	Show VLAN information	switch(vlan)#show vlan 23

## 6.6 Spanning Tree Command Set

SISPM1040-382-LRT Commands	Level	Description	Example
<b>spanning-tree enable</b>	<b>G</b>	Enable spanning tree	switch(config)#spanning-tree enable
<b>spanning-tree priority</b> [0to61440]	<b>G</b>	Configure spanning tree priority parameter	switch(config)#spanning-tree priority 32767
<b>spanning-tree max-age</b> [seconds]	<b>G</b>	Use the spanning-tree max-age global configuration command to change the interval between messages the spanning tree receives from the root switch. If a switch does not	switch(config)# spanning-tree max-age 15

		receive a bridge protocol data unit (BPDU) message from the root switch within this interval, it recomputed the Spanning Tree Protocol (STP) topology.	
<b>spanning-tree hello-time</b> [seconds]	<b>G</b>	Use the spanning-tree hello-time global configuration command to specify the interval between hello bridge protocol data units (BPDUs).	switch(config)#spanning-tree hello-time 3
<b>spanning-tree forward-time</b> [seconds]	<b>G</b>	Use the spanning-tree forward-time global configuration command to set the forwarding-time for the specified spanning-tree instances. The forwarding time determines how long each of the listening and learning states last before the port begins forwarding.	switch(config)# spanning-tree forward-time 20
<b>stp-path-cost</b> [1to200000000]	<b>I</b>	Use the spanning-tree cost interface configuration command to set the path cost for Spanning Tree	switch(config)#interface fastEthernet 2 switch(config-if)#stp-path-cost 20



		Protocol (STP) calculations. In the event of a loop, spanning tree considers the path cost when selecting an interface to place into the forwarding state.	
<b>stp-path-priority</b> <b>[Port Priority]</b>	<b>I</b>	Use the spanning-tree port-priority interface configuration command to configure a port priority that is used when two switches tie for position as the root switch.	switch(config)#interface fastEthernet 2 switch(config-if)# stp-path-priority 127
<b>stp-admin-p2p</b> <b>[Auto True False]</b>	<b>I</b>	Admin P2P of STP priority on this interface.	switch(config)#interface fastEthernet 2 switch(config-if)# stp-admin-p2p Auto
<b>stp-admin-edge</b> <b>[True False]</b>	<b>I</b>	Admin Edge of STP priority on this interface.	switch(config)#interface fastEthernet 2 switch(config-if)# stp-admin-edge True
<b>stp-admin-non-stp</b> <b>[True False]</b>	<b>I</b>	Admin NonSTP of STP priority on this interface.	switch(config)#interface fastEthernet 2 switch(config-if)# stp-admin-non-stp False
<b>Show spanning-tree</b>	<b>E</b>	Display a summary of the spanning-tree states.	switch>show spanning-tree
<b>no spanning-tree</b>	<b>G</b>	Disable spanning-tree.	switch(config)#no spanning-tree

## 6.7 QoS Command Set

SISPM1040-382-LRT Commands	Level	Description	Example
<b>qos policy</b> [weighted-fair strict]	<b>G</b>	Select QoS policy scheduling	switch(config)#qos policy weighted-fair
<b>qos prioritytype</b> [port-based cos-only tos-only cos-first tos-first]	<b>G</b>	Setting of QoS priority type	switch(config)#qos prioritytype
<b>qos priority portbased</b> [Port] [lowest low middle high]	<b>G</b>	Configure Port-based Priority	switch(config)#qos priority portbased 1 low
<b>qos priority cos</b> [Priority][lowest low middle high]	<b>G</b>	Configure COS Priority	switch(config)#qos priority cos 22 middle
<b>qos priority tos</b> [Priority][lowest low middle high]	<b>G</b>	Configure TOS Priority	switch(config)#qos priority tos 3 high
<b>show qos</b>	<b>P</b>	Display the information of QoS configuration	switch>show qos
<b>no qos</b>	<b>G</b>	Disable QoS function	switch(config)#no qos

## 6.8 IGMP Command Set

SISPM1040-382-LRT Commands	Level	Description	Example
<b>igmp enable</b>	<b>G</b>	Enable IGMP snooping function	switch(config)#igmp enable
<b>igmp-query auto</b>	<b>G</b>	Set IGMP query to auto mode	switch(config)#igmp-query auto
<b>igmp-query force</b>	<b>G</b>	Set IGMP query to force mode	switch(config)#igmp-query force
<b>show igmp configuration</b>	<b>P</b>	Displays the details of an IGMP configuration.	switch#show igmp configuration
<b>show igmp multi</b>	<b>P</b>	Displays the details of an IGMP snooping entries.	switch#show igmp multi

<b>no igmp</b>	<b>G</b>	Disable IGMP snooping function	switch(config)#no igmp
<b>no igmp-query</b>	<b>G</b>	Disable IGMP query	switch#no igmp-query

## 6.9 MAC/Filter Table Command Set

SISPM1040-382-LRT Commands	Level	Description	Example
<b>mac-address-table static hwaddr [MAC]</b>	<b>I</b>	Configure MAC address table of interface (static).	switch(config)#interface fastEthernet 2 switch(config-if)#mac-address-table static hwaddr 000012345678
<b>mac-address-table filter hwaddr [MAC]</b>	<b>G</b>	Configure MAC address table(filter)	switch(config)#mac-address-table filter hwaddr 000012348678
<b>show mac-address-table</b>	<b>P</b>	Show all MAC address table	switch#show mac-address-table
<b>show mac-address-table static</b>	<b>P</b>	Show static MAC address table	switch#show mac-address-table static
<b>show mac-address-table filter</b>	<b>P</b>	Show filter MAC address table.	switch#show mac-address-table filter
<b>no mac-address-table static hwaddr [MAC]</b>	<b>I</b>	Remove an entry of MAC address table of interface (static)	switch(config)#interface fastEthernet 2 switch(config-if)#no mac-address-table static hwaddr 000012345678
<b>no mac-address-table filter hwaddr [MAC]</b>	<b>G</b>	Remove an entry of MAC address table (filter)	switch(config)#no mac-address-table filter hwaddr 000012348678
<b>no mac-address-table</b>	<b>G</b>	Remove dynamic entry of MAC address table	switch(config)#no mac-address-table

## 6.10 SNMP Command Set

SISPM1040-382-LRT Commands	Level	Description	Example
<b>snmp agent-mode</b> [v1v2c   v3]	<b>G</b>	Select the agent mode of SNMP	switch(config)#snmp agent-mode v1v2c
<b>snmp-server host</b> [IP address] <b>community</b> [Community-string] <b>trap-version</b> [v1 v2c]	<b>G</b>	Configure SNMP server host information and community string	switch(config)#snmp-server host 192.168.10.50 community public trap-version v1 (remove) Switch(config)# no snmp-server host 192.168.10.50
<b>snmp community-strings</b> [Community-string] <b>right</b> [RO RW]	<b>G</b>	Configure the community string right	switch(config)#snmp community-strings public right RO or switch(config)#snmp community-strings public right RW
<b>snmp snmpv3-user</b> [User Name] <b>password</b> [Authentication Password] [Privacy Password]	<b>G</b>	Configure the userprofile for SNMPV3 agent. Privacy password could be empty.	switch(config)#snmp snmpv3-user test01 password AuthPW PrivPW
<b>show snmp</b>	<b>P</b>	Show SNMP configuration	switch#show snmp
<b>show snmp-server</b>	<b>P</b>	Show specified trap server information	switch#show snmp-server
<b>no snmp community-strings</b> [Community]	<b>G</b>	Remove the specified community.	switch(config)#no snmp community-strings public
<b>no snmp snmpv3-user</b> [User Name] <b>password</b> [Authentication Password] [Privacy Password]	<b>G</b>	Remove specified user of SNMPv3 agent. Privacy password could be empty.	switch(config)# no snmp snmpv3-user test01 password AuthPW PrivPW
<b>no snmp-server host</b>	<b>G</b>	Remove the SNMP	switch(config)#no snmp-server

[Host-address]		server host.	192.168.10.50
----------------	--	--------------	---------------

## 6.11 Port Mirror CommandSet

SISPM1040-382-LRT Commands	Level	Description	Example
<b>monitor rx</b>	<b>G</b>	Set RX destination port of monitor function	switch(config)#monitor rx
<b>monitor tx</b>	<b>G</b>	Set TX destination port of monitor function	switch(config)#monitor tx
<b>show monitor</b>	<b>P</b>	Show port monitor information	switch#show monitor
<b>monitor</b> [RX TX Both]	<b>I</b>	Configure source port of monitor function	switch(config)#interface fastEthernet 2 switch(config-if)#monitor RX
<b>show monitor</b>	<b>I</b>	Show port monitor information	switch(config)#interface fastEthernet 2 switch(config-if)#show monitor
<b>no monitor</b>	<b>I</b>	Disable source port of monitor function	switch(config)#interface fastEthernet 2 switch(config-if)#no monitor

## 6.12 802.1x Command Set

SISPM1040-382-LRT Commands	Level	Description	Example
<b>8021x enable</b>	<b>G</b>	Use the 802.1x global configuration command to enable 802.1x protocols.	switch(config)# 8021x enable
<b>8021x system radiusip</b> [IP address]	<b>G</b>	Use the 802.1x system radius IP global configuration command to change the radius server IP.	switch(config)# 8021x system radiusip 192.168.1.1
<b>8021x system serverport</b> [port ID]	<b>G</b>	Use the 802.1x system server port global configuration command to change the radius server port	switch(config)# 8021x system serverport 1815

<b>8021x system accountport</b> [port ID]	<b>G</b>	Use the 802.1x system account port global configuration command to change the accounting port	switch(config)# 8021x system accountport 1816
<b>8021x system sharekey</b> [ID]	<b>G</b>	Use the 802.1x system share key global configuration command to change the shared key value.	switch(config)# 8021x system sharekey 123456
<b>8021x system nasid</b> [words]	<b>G</b>	Use the 802.1x system nasid global configuration command to change the NAS ID	switch(config)# 8021x system nasid test1
<b>8021x misc quietperiod</b> [sec.]	<b>G</b>	Use the 802.1x misc quiet period global configuration command to specify the quiet period value of the switch.	switch(config)# 8021x misc quietperiod 10
<b>8021x misc txperiod</b> [sec.]	<b>G</b>	Use the 802.1x misc TX period global configuration command to set the TX period.	switch(config)# 8021x misc txperiod 5
<b>8021x misc supportimeout</b> [sec.]	<b>G</b>	Use the 802.1x misc supp timeout global configuration command to set the supplicant timeout.	switch(config)# 8021x misc supportimeout 20
<b>8021x misc servertimeout</b> [sec.]	<b>G</b>	Use the 802.1x misc server timeout global configuration command to set the server timeout.	switch(config)#8021x misc servertimeout 20

<b>8021x misc maxrequest</b> [number]	<b>G</b>	Use the 802.1x misc max request global configuration command to set the MAX requests.	switch(config)# 8021x misc maxrequest 3
<b>8021x misc reauthperiod</b> [sec.]	<b>G</b>	Use the 802.1x misc reauth period global configuration command to set the reauth period.	switch(config)# 8021x misc reauthperiod 3000
<b>8021x portstate</b> [disable   reject   accept   authorize]	<b>I</b>	Use the 802.1x port state interface configuration command to set the state of the selected port.	switch(config)#interface fastethernet 3 switch(config-if)#8021x portstate accept
<b>show 8021x</b>	<b>E</b>	Display a summary of the 802.1x properties and also the port sates.	switch>show 8021x
<b>no 8021x</b>	<b>G</b>	Disable 802.1x function	switch(config)#no 8021x

### 6.13 TFTP Command Set

SISPM1040-382-LRT Commands	Level	Description	Defaults Example
<a href="#">backup flash:backup_cfg</a>	G	Save configuration to TFTP and need to specify the IP of TFTP server and the file name of image.	switch(config)#backup flash:backup_cfg
<a href="#">restore flash:restore_cfg</a>	G	Get configuration from TFTP server and need to specify the IP of TFTP server and the file name of image.	switch(config)#restore flash:restore_cfg
<a href="#">upgrade flash:upgrade_fw</a>	G	Upgrade firmware by TFTP and need to specify the IP of TFTP server and the file name of image.	switch(config)#upgrade lash:upgrade_fw

### 6.14 SYSLOG, SMTP, EVENT Command Set

SISPM1040-382-LRT Commands	Level	Description	Example
<a href="#">systemlog ip</a> [IP address]	G	Set System log server IP address.	switch(config)# systemlog ip 192.168.1.100
<a href="#">systemlog mode</a> [client server both]	G	Specified the log mode	switch(config)# systemlog mode both
<a href="#">show systemlog</a>	E	Display system log.	Switch>show systemlog
<a href="#">show systemlog</a>	P	Show system log client & server information	switch#show systemlog
<a href="#">no systemlog</a>	G	Disable systemlog functon	switch(config)#no systemlog
<a href="#">smtp enable</a>	G	Enable SMTP function	switch(config)#smtp enable
<a href="#">smtp serverip</a> [IP address]	G	Configure SMTP server IP	switch(config)#smtp serverip 192.168.1.5
<a href="#">smtp authentication</a>	G	Enable SMTP authentication	switch(config)#smtp authentication



<b>smtp account</b> [account]	<b>G</b>	Configure authentication account	switch(config)#smtp account User
<b>smtp password</b> [password]	<b>G</b>	Configure authentication password	switch(config)#smtp password
<b>smtp rcptemail</b> [Index] [Email address]	<b>G</b>	Configure Rcpt e-mail Address	switch(config)#smtp rcptemail 1 <a href="mailto:Alert@test.com">Alert@test.com</a>
<b>show smtp</b>	<b>P</b>	Show the information of SMTP	switch#show smtp
<b>no smtp</b>	<b>G</b>	Disable SMTP function	switch(config)#no smtp
<b>event device-cold-start</b> [Systemlog SMTP Both]	<b>G</b>	Set cold start event type	switch(config)#event device-cold-start both
<b>event authentication-failure</b> [Systemlog SMTP Both]	<b>G</b>	Set Authentication failure event type	switch(config)#event authentication-failure both
<b>event Ring-topology-change</b> [Systemlog SMTP Both]	<b>G</b>	Set s ring topology changed event type	switch(config)#event ring-topology-change both
<b>event systemlog</b> [Link-UP Link-Down Both]	<b>I</b>	Set port event for system log	switch(config)#interface fastethernet 3 switch(config-if)#event systemlog both
<b>event smtp</b> [Link-UP Link-Down Both]	<b>I</b>	Set port event for SMTP	switch(config)#interface fastethernet 3 switch(config-if)#event smtp both
<b>show event</b>	<b>P</b>	Show event selection	switch#show event
<b>no event device-cold-start</b>	<b>G</b>	Disable cold start event type	switch(config)#no event device-cold-start
<b>no event authentication-failure</b>	<b>G</b>	Disable Authentication failure event typ	switch(config)#no event authentication-failure
<b>no event Ring-topology-change</b>	<b>G</b>	Disable Ring topology changed event type	switch(config)#no event ring-topology-change
<b>no event systemlog</b>	<b>I</b>	Disable port event for system log	switch(config)#interface fastethernet 3 switch(config-if)#no event systemlog
<b>no event smpt</b>	<b>I</b>	Disable port event for SMTP	switch(config)#interface fastethernet 3

			switch(config-if)#no event smtp
<b>show systemlog</b>	<b>P</b>	Show system log client & server information	switch#show systemlog

## 6.15 SNTP Command Set

SISPM1040-382-LRT Commands	Level	Description	Example
<b>sntp enable</b>	<b>G</b>	Enable SNTP function	switch(config)#sntp enable
<b>sntp daylight</b>	<b>G</b>	Enable daylight saving time, if SNTP function is inactive, this command can't be applied.	switch(config)#sntp daylight
<b>sntp daylight-period</b> [Start time] [End time]	<b>G</b>	Set period of daylight saving time, if SNTP function is inactive, this command can't be applied. Parameter format: [yyyymmdd-hh:mm]	switch(config)# sntp daylight-period 20060101-01:01 20060202-01-01
<b>sntp daylight-offset</b> [Minute]	<b>G</b>	Set offset of daylight saving time, if SNTP function is inactive, this command can't be applied.	switch(config)#sntp daylight-offset 3
<b>sntp ip</b> [IP]	<b>G</b>	Set SNTP server IP, if SNTP function is inactive, this command can't be applied.	switch(config)#sntp ip 192.169.1.1
<b>sntp timezone</b> [Timezone]	<b>G</b>	Set timezone index, use "show sntp timzezone" command to get more information of index number	switch(config)#sntp timezone 22

<b>show sntp</b>	<b>P</b>	Show SNTP information	switch#show sntp
<b>show sntp timezone</b>	<b>P</b>	Show index number of time zone list	switch#show sntp timezone
<b>no sntp</b>	<b>G</b>	Disable SNTP function	switch(config)#no sntp
<b>no sntp daylight</b>	<b>G</b>	Disable daylight saving time	switch(config)#no sntp daylight

## 6.16 Ring Command Set


SISPM1040-382-LRT Commands	Level	Description	Example
<b>Ring enable</b>	<b>G</b>	Enable ing	switch(config)# ring enable
<b>Ring master</b>	<b>G</b>	Enable ring master	switch(config)# ring master
<b>Ring couplering</b>	<b>G</b>	Enable couple ring	switch(config)# ring couplering
<b>Ring dualhoming</b>	<b>G</b>	Enable dual homing	switch(config)# ring dualhoming
<b>Ring ringport</b> [1st Ring Port] [2nd Ring Port]	<b>G</b>	Configure 1st/2nd Ring Port	switch(config)# ring ringport 7 8
<b>Ring couplingport</b> [Coupling Port]	<b>G</b>	Configure Coupling Port	switch(config)# ring couplingport 1
<b>Ring controlport</b> [Control Port]	<b>G</b>	Configure Control Port	switch(config)# ring controlport 2
<b>Ring homingport</b> [Dual Homing Port]	<b>G</b>	Configure Dual Homing Port	switch(config)# ring homingport 3
<b>show Ring</b>	<b>P</b>	Show Ring information	switch#show ring
<b>no Ring</b>	<b>G</b>	Disable Ring	switch(config)#no ring
<b>no Ring master</b>	<b>G</b>	Disable ring master	switch(config)# no ring master
<b>no Ring couplering</b>	<b>G</b>	Disable couple ring	switch(config)# no ring couplering
<b>no Ring dualhoming</b>	<b>G</b>	Disable dual homing	switch(config)# no ring dualhoming

## 6.17 CLI Command Summary

### 6.17.1 Terminal Emulator Examples

Examples from HyperTerminal, PuTTY, Tera Term, and Telnet are provided below.

**PuTTY login successful prompt:**




```

192.168.1.77 - PuTTY
login as: root
root@192.168.1.77's password:

?: List, <TAB>: Complete, <ctrl+z>: Up level, <ctrl+q>: Logout
switch>
  
```


**TeraTerm SSH Auth Login:**



```

192.168.1.77 - Tera Term VT
File Edit Setup Control Window Help
?: List, <TAB>: Complete, <ctrl+z>: Up level, <ctrl+q>: Logout
switch>
  
```

**Telnet login:**




```

Telnet 192.168.1.77
SISPM1040-382-LRT
Command Line Interface

Username :
Password :

Telnet 192.168.1.77
?: List, <TAB>: Complete, <ctrl+z>: Up level, <ctrl+q>: Logout
switch>
  
```

**Telnet *list* command:**



```

Telnet 192.168.1.77
?: List, <TAB>: Complete, <ctrl+z>: Up level, <ctrl+q>: Logout
switch>
enable          Enter Privileged EXEC mode
logout          Logout command line shell
ping            Ping function
quit            Logout command line shell
show            Show function
switch>show    Show function
show            Show switch configure
switch>show    Show system information
config          Show switch configure
switch>con     Show system information
switch>enable  Show switch configure
switch#        Show system information
configure      Enter Global configuration mode
disable        Leave Privileged EXEC mode
poe            Configure PoE function
show            Show function
vlan           Enter the vlan database command
write          Write current device configuration to memory
switch#_
  
```

### 6.17.2 CLI Examples

**Example 1:** show the available top-level commands using the `?`:

```
?: List, <TAB>: Complete, <ctrl+z>: Up level, <ctrl+q>: Logout
switch> ?
enable          Enter Privileged EXEC mode
logout          Logout command line shell
ping           Ping function
quit           Logout command line shell
show           Show function
```

**Example 2:** show the available show commands:

```
switch>show ?
config          Show switch configure
system-info     Show system information
switch>
```

**Example 3:** show the available config commands:

```
switch> enable
switch#con
switch#configure ?
<ENTER>
switch#configure
switch(config)# ?
8021x          Configure IEEE802.1x function
admin          Configure administrator
aggregator     Configure aggregator port setting
auto-sfp       Enable/disable to auto detect 100/1000 SFP
check-concurrence Check redundancy protocol concurrence
default        Restore to factory default configuration
dhcpserver     Configure DHCP server
end            Leave Global configuration mode
event          Configure system event selection
exit           Leave Global configuration mode
fault-relay    Configure Fault Relay Alarm function
igmp           IGMP function setting
interface      Enter the interface command (with a specific interface)
ip             Configure IP address
lldp           LLDP function setting
```

```

mac-address-table      Configure MAC address entry
mstp                   Configure MSTP
multi-ring             Configure Multi-Ring
multicast-filtering    Configure multicast filtering entry
multiple-ring          Configure Multiple Ring
---- More (q/Q to quit) ----
no                     Disable setting
ptp                    PTP function setting
qos                    Configure QOS function
reload                 Reboot switch
ring                   Configure Redundant Ring
rstp                   Configure RSTP
security               Configure IP security
sfp-monitor            Configure SFP temperature alarm
smtp                   Configure SMTP function
snmp                   SNMP function
sntp                   Set SNTP function
syslog                 Configure SYSLOG function
system                 Configure system detail information
tacacs+                TACACS+ configuration
tftp                   Transfer file by TFTP
switch(config)#

```

**Example 4:** show system information:

```

switch>show system <tab>
switch>show system-info
Name:                SISPM1040-382-LRT
Description: Industrial 10-port managed PoE Ethernet switch with 8x10/100Base-T(X) P.S.E.
and 2xGigabit combo ports, SFP socket
Location:
Contact:
Firmware Version: v1.33
Kernel Version: v3.50
MAC Address: 00-C0-F2-56-0A-31
IP Address: 192.168.1.77
System OID: 1.3.6.1.4.1.868.2.120.0.5.107
OK.
switch>

```

**Example 5:** show config information:

```
switch>show config

=====System Information=====

Name:          SISPM1040-382-LRT
Description: Industrial 10-port managed PoE Ethernet switch with 8x10/100Base-T(X) P.S.E.
and 2xGigabit combo ports, SFP socket
Location:
Contact:
Firmware Version: v1.33
Kernel Version: v3.50
MAC Address: 00-C0-F2-56-0A-31
IP Address: 192.168.1.77
System OID: 1.3.6.1.4.1.868.2.120.0.5.107
OK.
---- More (q/Q to quit) ----

=====IP Information=====

DHCP client is inactive
Address ip:192.168.1.77
Address subnet:255.255.255.0
Address gateway:192.168.1.254
Address DNS1:0.0.0.0
Address DNS2:0.0.0.0

OK.
---- More (q/Q to quit) ----

=====Terminal Information=====

Baudrate(bits/sec): 9600
Data Bits: 8
Parity Check: none
Stop Bits: 1
Flow Control: none
```

OK.

---- More (q/Q to quit) ----

=====Interface Configuration=====

Port	State	Link State	Auto Neg.	Speed	Status	Duplex	Status	Flow Control
	Cfg Act			Config Actual	Config Actual	Config Actual	Config Actual	
Port.01	ON  ON	N/A	Auto	100	N/A	Full	N/A	SYM  N/A
Port.02	ON  ON	N/A	Auto	100	N/A	Full	N/A	SYM  N/A
Port.03	ON  ON	N/A	Auto	100	N/A	Full	N/A	SYM  N/A
Port.04	ON  ON	N/A	Auto	100	N/A	Full	N/A	SYM  N/A
Port.05	ON  ON	N/A	Auto	100	N/A	Full	N/A	SYM  N/A
Port.06	ON  ON	N/A	Auto	100	N/A	Full	N/A	SYM  N/A
Port.07	ON  ON	UP	Auto	100	100	Full	Full	SYM  On
Port.08	ON  ON	N/A	Auto	100	N/A	Full	N/A	SYM  N/A
G1	ON  ON	N/A	Auto	1000	N/A	Full	N/A	SYM  N/A
G2	ON  ON	N/A	Auto	1000	N/A	Full	N/A	SYM  N/A

Auto Detect 100/1000 SFP: enabled

OK.

---- More (q/Q to quit) ----

=====Interface Status=====

Port	Type	Link State	Speed	Duplex	Flow	Ctrl	Security
			Duplex		Ctrl		
Port.01	100TX	Down	Enable	N/A	N/A	ON	
Port.02	100TX	Down	Enable	N/A	N/A	ON	
Port.03	100TX	Down	Enable	N/A	N/A	ON	
Port.04	100TX	Down	Enable	N/A	N/A	ON	
Port.05	100TX	Down	Enable	N/A	N/A	ON	
Port.06	100TX	Down	Enable	N/A	N/A	ON	
Port.07	100TX	Up	Enable	100/FULL	ON	ON	
Port.08	100TX	Down	Enable	N/A	N/A	ON	



```
G1      1GTX/SFP Down Enable  N/A      N/A  ON
G2      1GTX/SFP Down Enable  N/A      N/A  ON
```

```
OK.
```

```
---- More (q/Q to quit) ----
```

## 7. Technical Specifications

Physical Ports	
10/100 Base-T(X) Ports in RJ45 Auto MDI/MDIX with PSE	8
Gigabit Combo Ports with 10/100/1000Base-T(X) and 100/1000Base-X SFP port	2
Technology	
Ethernet Standards	IEEE 802.3 for 10Base-T, 802.3u for 100Base-TX and 100Base-FX IEEE 802.3z for 1000Base-X, 802.3ab for 1000Base-T IEEE 802.3x for Flow control, 802.3ad for LACP (Link Aggregation Control Protocol) IEEE 802.1D for STP (Spanning Tree Protocol), 802.1p for COS (Class of Service) IEEE 802.1Q for VLAN Tagging IEEE 802.1w for RSTP (Rapid Spanning Tree Protocol) IEEE 802.1s for MSTP (Multiple Spanning Tree Protocol) IEEE 802.1x for Authentication IEEE 802.1AB for LLDP (Link Layer Discovery Protocol)
MAC Table	8192 MAC addresses
Priority Queues	4
Processing	Store-and-Forward
Switch Properties	Switching latency: 7 us Switching bandwidth: 5.6Gbps Max. Number of Available VLANs: 4096 IGMP multicast groups: 1024 Port rate limiting: User Define
Security Features	Enable/disable ports, MAC based port security Port based network access control (802.1x) VLAN (802.1Q) to segregate and secure network traffic Supports Q-in-Q VLAN for performance & security to expand the VLAN space Radius centralized password management SNMP v1/v2c/v3 encrypted authentication and access security
Software Features	STP/RSTP/MSTP (IEEE 802.1D/w/s) Redundant Ring with recovery time less than 10ms over 250 units TOS/Diffserv supported Quality of Service (802.1p) for real-time traffic VLAN (802.1Q) with VLAN tagging and GVRP supported IGMP Snooping for multicast filtering Port configuration, status, statistics, monitoring, security SNTP for synchronizing of clocks over network PTP Client (Precision Time Protocol) clock synchronization support DHCP Server / Client support Port Trunk support MVR (Multicast VLAN Registration) support
Network Redundancy	Redundant Ring, Multiple Ring, Multi-Ring, STP, RSTP, MSTP, Coupling Ring, Dual Homing. Only one redundancy protocol can be enabled at a time.

Warning / Monitoring	Relay output for fault event alarming Syslog server / client to record and view events Include SMTP for event warning notification via email Event selection support
DDM Function	Voltage / Current / Temperature
RS-232 Serial Console Port	RS-232 in RJ45 connector with console cable. 9600bps, 8, N, 1
<b>LED indicators</b>	
Power/PoE LED	Green : Power LED x 3, Green : PoE LED x 8
Ring LED	Green : Indicates system operating in Ring mode
R.M. LED	Green : Indicates system operating in Ring Master mode
Fault LED	Amber : Indicates unexpected event occurred
10/100Base-T(X) RJ45 Port	Green LED for port Link/Act. Amber for Duplex/Collision.
10/100/1000Base-T(X) RJ45 Port LED	Green for Link/Act. Amber for 100Mbps indicator
100/1000Base-X Fiber Port	Green LED for port Link/Act.
<b>Fault contact</b>	
Relay	Relay output to carry capacity of 1A at 24VDC
<b>Power</b>	
Redundant Input Power	Dual DC inputs. 50 ~ 57VDC on 6-pin terminal block
Power Consumption (Typ.)	7.68 Watts (power consumption of P.S.E. is not included)
Overload Current Protection	Present
Reverse polarity protection	Not Present
<b>Physical Characteristic</b>	
Enclosure	IP-30
Dimension (W x D x H)	74.3 (W) x 109.2 (D) x 153.6 (H) mm (2.93 x 4.3 x 6.05 inch)
Weight (g)	1185 g
<b>Environmental</b>	
Storage Temperature	-40 to 85°C (-40 to 185°F)
Operating Temperature	-40 to 75°C (-40 to 167°F)
Operating Humidity	5% to 95% Non-condensing
<b>Regulatory approvals</b>	
EMI	FCC Part 15, CISPR (EN55022) class A
EMS	EN61000-4-2 (ESD), EN61000-4-3 (RS), EN61000-4-4 (EFT), EN61000-4-5 (Surge), EN61000-4-6 (CS), EN61000-4-8, EN61000-4-11
Shock	IEC60068-2-27
Free Fall	IEC60068-2-32
Vibration	IEC60068-2-6
Safety	EN60950-1
<b>Warranty</b>	Lifetime

**Power Supply Features and Specifications**

Use the +V ADJ access to the small Phillips screw; turn clockwise to increase voltage. It is adjustable 48-55V. Recommend adjusting output to a minimum of 53VDC out for PoE+ applications.

Industrial DIN Rail Mounted Power Supply 25104:

**Power Supply Features**

94% High Efficiency / 150% Peak Load

Convection air cooling

UL 508 approved / RoHS compliant

Protected against Short Circuit, Overload, Over Voltage, and Overheating

MTBF 169.3 Khrs



**Power Supply Specifications**

<p>Power Output</p>	<p>Output Voltage 48VDC                  Current Rating 5A                  Power Rating 240 Watts                  Ripple &amp; Noise Max 120mVp-p                  Voltage Range 48~55VDC                  Voltage Tolerance ±1.0%                  Line Regulation ±0.5%                  Load Regulation ±1.0%                  Setup, Rise Time 300ms, 60ms                  Hold Up Time 20ms</p>
<p>Power Input</p>	<p>Voltage Range Switch Selectable                  88~132VAC                  124~370VDC                  Frequency Range 47~63Hz                  Efficiency 94%                  AC Current (Typical) 2.6A@115VAC                  1.3A@230VAC                  Inrush Current (Cold) 33A@115VAC                  65A@230VAC</p>
<p>Protection</p>	<p>Overload 105~160%                  Overvoltage 56~65V</p>
<p>Dimensions</p>	<p>Width: 2.48" [63 mm] x Depth: 5.26" [113.5 mm] x Height: 4.93" [125.2 mm]</p>

Environment	Operating: -25°C to +60°C Storage: -40°C to +85°C Humidity: 20% to 95% (non-condensing)
Weight	2.27 lbs. [1.03 kg]
Compliance	Safety: UL508, TUV EN60950-1, IEC60068-2-6 (Vibration) EMC Emission: EN55022, CISPR22 Class B, EN61000-3-2, EN61000-3-3; EMC Immunity: EN61000-4-2, EN61000-4-3, EN61000-4-4, EN61000-4-5, EN61000-4-6, EN61000-4-8, EN61000-4-11, EN55024, EN61000-6-2, EN50082-2, EN61204-3, SEMI F47, GL Approved
Warranty	Lifetime

### Power Supply Standards

Safety: UL508

TUV EN60950-1

Vibration: IEC60068-2-6

EMC EmissionEN55022

CISPR22 Class B

EN61000-3-2

EN61000-3-3

EMC ImmunityEN61000-4-2

EN61000-4-3, EN61000-4-4, EN61000-4-5, EN61000-4-6, EN61000-4-8,

EN61000-4-11

EN55024

EN61000-6-2


EN50082-2

EN61204-3

SEMI F47

GL Approved

**Power Supply Dimensions**



## 8. Troubleshooting

1. Verify the [Hardware Installation](#) information on page 14.
2. Check the status of the [Front Panel LEDs](#) on page 19.
3. Check the cabling; see section 4. [Cables](#) on page 21.
4. Verify the proper operation of other network equipment.
5. Verify proper operation of any third party packages (e.g., web browser, terminal emulation software, servers, etc.).
6. Run available system tests and check the various statistics pages.
7. Try switching modes (from CLI to web UI or vice versa).
8. Check the Syslog and/or System Event Log.
9. See if a firmware upgrade is available and upgrade the switch if possible.
10. Save your config and then try a Reset to Factory Defaults and/or a System Reboot.
11. Collect system and device information; see below.
12. Contact Transition Networks Tech Support; see [Contact Us](#) on page 142 below.

### Record System and Device Information

After performing the Troubleshooting steps above, and before contacting Transition Networks Technical Support, please record system and device information to help the Tech Support specialist.

1. Model name: \_\_\_\_\_
2. System Name: \_\_\_\_\_
3. System OID: \_\_\_\_\_
4. Firmware Version: \_\_\_\_\_
5. IP Address of switch: \_\_\_\_\_
6. DNS Server or DHCP Server configured? \_\_\_\_\_
7. Record any error messages displayed: \_\_\_\_\_  
\_\_\_\_\_
8. Your Transition Networks service contract number: \_\_\_\_\_

Describe the failure: \_\_\_\_\_  
\_\_\_\_\_

Describe any action(s) already taken to resolve the problem (e.g., change mode, reboot, etc.):  
\_\_\_\_\_  
\_\_\_\_\_

The serial and revision numbers of all involved TN products in the network: \_\_\_\_\_

---

---

Describe your network environment (layout, cable type, etc.): \_\_\_\_\_

---

---

Network load and frame size at the time of trouble (if known): \_\_\_\_\_

The device history (i.e., have you returned the device before, is this a recurring problem, etc.):

---

---

Any previous Return Material Authorization (RMA) numbers: \_\_\_\_\_

---



## 8. Service, Warranty & Compliance Information

### Limited Lifetime Warranty

Effective for Products Shipped May 1, 1999 and After. Every Transition Networks labeled product purchased after May 1, 1999, and not covered by a fixed-duration warranty will be free from defects in material and workmanship for its lifetime. This warranty covers the original user only and is not transferable.

This warranty does not cover damage from accident, acts of God, neglect, contamination, misuse or abnormal conditions of operation or handling, including over-voltage failures caused by use outside of the product's specified rating, or normal wear and tear of mechanical components.

Transition Networks will, at its option:

- Repair the defective product to functional specification at no charge
- Replace the product with an equivalent functional product
- Refund a portion of purchase price based on a depreciated value

To return a defective product for warranty coverage, contact Transition Networks' Customer Support for a return authorization number.

Send the defective product postage and insurance prepaid to the following address:

Transition Networks, Inc.  
10900 Red Circle Drive  
Minnetonka, MN 55343  
USA

Attn: RETURNS DEPT: CRA/RMA # \_\_\_\_\_

Failure to properly protect the product during shipping may void this warranty. The return authorization number must be written on the outside of the carton to ensure its acceptance. We cannot accept delivery of any equipment that is sent to us without a CRA or RMA number.

CRA's are valid for 60 days from the date of issuance. An invoice will be generated for payment on any unit(s) not returned within 60 days.

Upon completion of a demo/ evaluation test period, units must be returned or purchased within 30 days. An invoice will be generated for payment on any unit(s) not returned within 30 days after the demo/ evaluation period has expired.

The customer must pay for the non-compliant product(s) return transportation costs to Transition Networks for evaluation of said product(s) for repair or replacement. Transition Networks will pay for the shipping of the repaired or replaced in-warranty product(s) back to

the customer (any and all customs charges, tariffs, or/and taxes are the customer's responsibility).

Before making any non-warranty repair, Transition Networks requires a \$200.00 charge plus actual shipping costs to and from the customer. If the repair is greater than \$200.00, an estimate is issued to the customer for authorization of repair. If no authorization is obtained, or the product is deemed not repairable, Transition Networks will retain the \$200.00 service charge and return the product to the customer not repaired. Non-warranted products that are repaired by Transition Networks for a fee will carry a 180-day limited warranty. All warranty claims are subject to the restrictions and conventions set forth by this document.

Transition Networks reserves the right to charge a \$50 fee for all testing and shipping incurred, if after testing, a return is classified as "No Problem Found."

THIS WARRANTY IS YOUR ONLY REMEDY. NO OTHER WARRANTIES, SUCH AS FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSED OR IMPLIED. TRANSITION NETWORKS IS NOT LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, ARISING FROM ANY CAUSE OR THEORY. AUTHORIZED RESELLERS ARE NOT AUTHORIZED TO EXTEND ANY DIFFERENT WARRANTY ON TRANSITION NETWORKS'S BEHALF.

### Contact Us

**Technical Support:** Technical support is available 24-hours a day

US and Canada: 1-800-260-1312

International: 00-1-952-941-7600

### Main Office

tel: +1.952.941.7600 | toll free: 1.800.526.9267 | fax: 952.941.2322

[sales@transition.com](mailto:sales@transition.com) | [techsupport@transition.com](mailto:techsupport@transition.com) | [customerservice@transition.com](mailto:customerservice@transition.com)

### Address

Transition Networks

10900 Red Circle Drive

Minnetonka, MN 55343, U.S.A.

**Web:** <https://www.transition.com>

## 9. Regulatory Agency Information

### Switch Regulatory Approvals

EMI FCC Part 15, CISPR (EN55022) class A

EMS EN61000-4-2 (ESD)

EN61000-4-3 (RS),

EN61000-4-4 (EFT),

EN61000-4-5 (Surge),

EN61000-4-6 (CS),

EN61000-4-8,

EN61000-4-11

Shock IEC60068-2-27

Free Fall IEC60068-2-32

Vibration IEC60068-2-6

Safety EN60950-1

### Declaration of Conformity

<b><i>Declaration of Conformity</i></b>			
<i>Transition Networks, Inc.</i>			
<small>Manufacturer's Name</small>			
<i>10900 Red Circle Drive, Minnetonka, Minnesota 55343 U.S.A.</i>			
<small>Manufacturer's Address</small>			
<b><i>Declares that the product(s)</i></b>			
<i>SISPM1040-382-LRT</i>			
<b><i>Conforms to the following Product Regulations:</i></b>			
FCC Part 15, CISPR (EN55022) Class A EN61000-4-2 (ESD), EN61000-4-3 (RS), EN61000-4-4 (EFT), EN61000-4-5 (Surge), EN61000-4-6 (CS), EN61000-4-8, and EN61000-4-11 (Shock: IEC60068-2-27, Free Fall: IEC60068-2-32, Vibration: IEC60068-2-6, and Safety: EN60950-1)			
I, the undersigned, hereby declare that the equipment specified above conforms to the above Directive(s) and Standard(s).			
<i>Minnetonka, Minnesota</i>	<i>February 18<sup>th</sup>, 2015</i>	<i>Stephen Anderson</i>	
<small>Place</small>	<small>Date</small>	<small>Signature</small>	
		<i>Stephen Anderson</i>	<i>Vice President of Engineering</i>
		<small>Full Name</small>	<small>Position</small>
			<small>TS141E</small>

## Appendix A - RADIUS Server and Switch Settings


This section provides MS WinRadius and Windows / PC settings. See section 5.1.8.6 - "802.1x 802.1x - Radius Server" for the SISPM1040 RADIUS parameter descriptions.

### Radius Server and Switch Setting


1. Enable the WinRadius tool.



2. Set the Radius Server IP、NSA and Port.



3. Create a new User.



4. Enter the Switch Radius Server settings. Note: all settings need the same Radius Server settings.

**802.1x - Radius Server**

**Radius Server Setting**

802.1x Protocol	Enable
Radius Server IP	192.168.10.66
Server Port	1812
Accounting Port	1813
Shared Key	12345678
NAS, Identifier	NAS_L2_SWITCH

**Advanced Setting**

Quiet Period	60
TX Period	30
Supplicant Timeout	30
Server Timeout	30
Max Requests	2
Re-Auth Period	3600

Apply Help

5. Select 802.1x Authorize Port (e.g., select Port 1 and Port 2 = Authorize).



**802.1x - Port Authorize Mode**


Port No.	Port Authorize Mode
Port.01	Authorize
Port.02	Authorize
Port.03	Accept
Port.04	Accept
Port.05	Accept
Port.06	Accept
Port.07	Accept
G1	Accept
G2	Accept
G3	Accept



Apply Help


6. Continue with the User PC Settings section below.

## User PC Settings



1. **Enable Windows 802.1x Services:** To complete this procedure, you must first enable the Wired AutoConfig service, which is turned off by default.
  - a. Click the **Start** button . In the search box, type **services.msc**, and then press Enter.  If you are prompted for an administrator password or confirmation, type the password or provide confirmation.
  - b. In the Services dialog box, click the **Standard** tab at the bottom of main pane, right-click **Wired AutoConfig**, and then click **Start**.



- c. Open Network Connections by clicking the **Start** button , and then clicking **Control Panel**. In the search box, type **adapter**, and then, under Network and Sharing Center, click **View network connections**.
- d. Right-click the connection that you want to enable 802.1X authentication for, and then click **Properties**.  If you are prompted for an administrator password or confirmation, type the password or provide confirmation.




- a. Click the **Authentication** tab, and then select the **Enable IEEE 802.1X authentication** check box.



- b. In the **Choose a network authentication method** list, click the method you want to use. To configure additional settings, click **Settings**.

## Appendix B - RADIUS - Windows 7 Wired AutoConfig

This section provides a procedure for configuring RADIUS in Windows 7 using Wired AutoConfig. Windows [Wired AutoConfig](#) (dot3svc) is a service that configures (IEEE 802.1X port-based security settings on IEEE 802.3 Ethernet adapters.



### 1. Radius Server Setting

Create a new user:

- User name = test1234
- Password = 12345678
- Shared key = 12345678 (need the same switch settings)
- NAS Secret = 12345678 (need the same switch settings)

### 2. Switch Radius Setting

Use the switch with all default settings except Setting Radius Server settings as below:

- 802.1x Protocol = enable
- Radius Server IP = 192.168.10.79
- Shared key = 12345678 (need the same Radius Server settings)
- NAS Secret = 12345678 (need the same Radius Server setting)



**TRANSITION NETWORKS** SISPM1040-382-LRT

### 802.1x - Radius Server

**Radius Server Setting**

802.1x Protocol	Enable
Radius Server IP	192.168.10.79
Server Port	1812
Accounting Port	1813
Shared Key	12345678
NAS, Identifier	12345678

**Advanced Setting**

Quiet Period	60
TX Period	30
Supplicant Timeout	30
Server Timeout	30
Max Requests	2
Re-Auth Period	3600

Apply Help

3. Connect Port 4 to Client PC; on Port 04 set Port Authorize Mode to **Authorize** and click the **Apply** button:

**TRANSITION NETWORKS** SISPM1040-382-LRT

### 802.1x - Port Authorize Mode


Port No.	Port Authorize Mode
Port.01	Accept
Port.02	Accept
Port.03	Accept
Port.04	Authorize
Port.05	Accept
Port.06	Accept
Port.07	Accept
Port.08	Accept
G1	Accept
G2	Accept

Apply Help


#### 4. Client User Setting (Windows 7)

##### **Enable Wired AutoConfig on your Computer**

- Click the Windows Start button and type services.msc into the search box.
- In the services window locate the service named Wired AutoConfig.
- Right click on this service and click on properties.




- Start this Service.



**5. Configure the Local LAN connection for 802.1X authentication**

- Right click on your network adapter and select Properties.
- Click on the Authentication tab and select the option for IEEE 802.1X authentication.
- Choose the network authentication method Microsoft: EAP-**MD5**:





**Transition Networks**

10900 Red Circle Drive

Minnetonka, MN 55343 USA

tel: 952-941-7600 or 1-800-526-9267

fax: 952-941-2322

Copyright © 2013-2017 Transition Networks. All rights reserved. Printed in the U.S.A.

SISPM1040-382-LRT Industrial 10-port Managed PoE Ethernet Switch User Guide