

Secure Remote Access (SRA)

Quick Start Guide

Note: See the related manuals for important Ordering, Features, Specifications, Applications, Back Panels, LEDs, Unpacking, Package Contents, Power Supply, Setup, Network Config, System Requirements, Product Views, Troubleshooting, Labeling, Regulatory Agency, Safety, Cautions and Warnings, and Warranty information.



Introduction

The Lantronix Secure Remote Access (SRA) solution creates a secure tunnel to provide a bidirectional communication channel from a Network Operations Center (NOC) to a Remote Site. The solution generally does not require configuration changes to the Remote Site Firewall. The Remote Access Device (RAD) is located at a Remote Site and initiates a connection with the Management Access Portal (MAP) located at the NOC or Host Site. Once the tunnel is established, the Network Administrator at the NOC can connect via VPN over the tunnel to devices in the same network as the Remote Access Device, or via Port Forwarding to any device the RAD can address. **Note:** When using VPN mode, IP addresses at the Remote Site and NOC or Host Site cannot overlap (i.e., must be on different sub-networks).

Package Contents

Verify you have received one SRA-RAD-01 or one SRA-MAP-01, one Doc postcard, one Power Supply per device, this document, and one Bag with screws, rubber plugs, and rubber feet. One CABLE-SRA-NMC (USB to DB9F Serial Null Modem Cable) may be included as an optional accessory.

Power Supplies

SRA power supplies include 25168 for North America, 25183 for United Kingdom, and 25184 for Europe.

System Requirements

- SRA devices must have one interface with a gateway that allows Internet access.
- You must have OpenVPN (Windows) client installed when using the VPN solution for the remote site; not necessary for Port Forwarding. Note that some Windows versions allow just one active VPN client connection at a time.
- When using VPN mode, the IP subnet for the LAN1 interface on the MAP cannot overlap with the IP subnet being forwarded by any of its RADs.
- External IP (Internet facing IP) address with available port 443.
- IP address(es) for the MAP within your network topology.
- Network setup details of remote sites.
- A null modem cable with a female DB9 connector, such as the CABLE-SRA-NMC available through Lantronix if using CLI to program units.

MAP Configuration Requirements

"MAP users" refers to users at headquarters/Network Operations Center (NOC) using SRA to access devices at remote sites. MAP requirements:

- The MAP requires Internet accessible port 443 available:
 - this will likely be forwarded from the firewall and it doesn't matter which interface is given port 443;
 - the interface receiving 443 should have a gateway providing Internet access.
- MAP users will access the Web UI via the LAN1 interface.
- The MAP must have Internet access to communicate with the RADs; so one interface must have a gateway assigned statically or via DHCP.
- If both interfaces are in use, make sure only one has a gateway assigned.

The simplest configuration would be to disable WAN1, statically assign an IP address with gateway on LAN1 and forward port 443 from an external IP Address on your firewall to this IP address. DHCP can be used on LAN1 but it is expected that the IP Address does not change; configure your DHCP server to hand out a specific IP address to the LAN1 port.

If the MAP is to be on separate (tiered) networks, the WAN1 interface can be configured with DHCP, configuring the DHCP server to hand out a specific IP address to the WAN1 interface, or with a static IP Address and gateway while the LAN1 interface is given an IP address on the separate MAP users network. In this scenario, port 443 would be forwarded from the firewall to WAN1. Make sure that if the MAP is behind a firewall that port 443 from the External IP Address is forwarded to one of the interfaces on the MAP.


RAD Configuration Requirements

The RAD requires 1) Internet access and 2) access to devices/network that MAP users want to manage. Most RAD networks are a single (flat) network with DHCP servers available. For Port Forwarding, the simplest configuration is the default: WAN1 connected to this flat network, LAN1 not used. The RAD will use WAN1 both for internet access and to connect to the devices the MAP users must manage.

For VPN, WAN1 would be connected to the network with Internet access, likely using DHCP (the default setting on WAN1) or configured with an IP Address and gateway. For VPN, LAN1 would be configured for the separate network that is to be accessed by the MAP users.

Note that a RAD ID can include spaces and that disconnected RADs can be removed (RED status). A RAD ID can be modified while connected to the MAP. On the MAP, duplicate RAD IDs can exist; avoid this if possible. If multiple RADs are created with the same RAD ID, disconnect the matching ones and then delete all from the MAP. While disconnected, the RAD IDs should be changed so they are unique.

Overall View



Note: see the Configuration Examples section in the Web User Guide manual.

Setup

Caution: To avoid arcing on the DC jack, plug in the DC jack first, then plug the AC adapter into mains.

Power Supplies: The available power supplies for SRA include 25168 North America Power Supply, 25183 UK Power Supply, and 25184 Europe Power Supply. The 25168 power supply for North America, 25183 for UK, and 25184 for Europe are the same except for the connector and housing. Compliance labeling varies by market.

Use Serial port settings Baud Rate: 115200, Data Bits: 8, Parity: None, Stop Bits: 1, HW Flow Control: None, and SW Flow Control=No as console port settings. You cannot use the serial cable to update the firmware. When connecting to the serial port on SRA units, use a null modem cable with a female DB9 connector, such as the CABLE-SRA-NMC available through Lantronix.


MAP Setup

1. Connect Cat5/6 cable from PC to LAN1 port on MAP.
2. Open a web browser and go to 192.168.1.10.
3. Login using default username/password: admin/admin.
4. Go to MAP Configuration Tab and fill in MAP ID, Internet Facing IP, and Ext Port. Click Apply.
5. Go to Network Configuration tab.
6. Fill in network configuration information. Click Apply.
7. Change PC IP address to work with new MAP IP address.
8. Log back into the MAP.
9. Go to Network Info tab and verify network information is correct.

RAD Setup

1. Connect Cat5/6 cable from PC to LAN1 port on RAD.
2. Open a web browser and go to 192.168.1.10.
3. Login using default username/password: admin/admin.
4. Go to Network Configuration tab.
5. Fill in network configuration information. Click Apply.
6. Change PC IP address to work with new RAD IP address.
7. Log back into the RAD.
8. Go to Network Info tab and verify network information is correct.
9. Go to Configurations tab and assign a Site ID and select Update ID.
10. Go to Configurations tab and select Configure VPN.
11. Fill in Mgmt IP, Client IP, and Client count. (Note: Leave VPN Mode as “Disabled”.)
12. Select Save VPN Config.
13. Go to Configurations tab and select Add MAP.
14. Fill in Internet facing IP, External Port, set Mode to VPN, set Status to Enabled in the order shown below.
15. Select Save MAP Config. You will now lose connection to the RAD unit.
16. Connect WAN1 and LAN1 into 192.168.2.0/24 network at the remote site.

Back Panels



SRA-MAP Back Panel



SRA-RAD Back Panel

CONSOLE: DB-9 connector for Command Line Interface (CLI) operation.

WAN1: RJ-45 connector for IP connectivity.

LAN1: : RJ-45 connector for IP connectivity.

LAN2: : RJ-45 connector; currently not used (SRA-MAP only).

PROG1: RJ-45 connector; currently not used (SRA-MAP only).

USB: USB connector for firmware upgrades.

12VDC: Power connection to DC power supply.

Front Panel

The front panel has three green LEDs (labeled PWR, 1, and 2) and a RESET button (not used).



Front Panel (RAD and MAP)

RAD LED Descriptions

PWR: Power; continuously lit means RAD power is good.

LED 1: currently not used; always off.

LED 2: currently not used; always off.

MAP LED Descriptions

PWR: Power; continuously lit means MAP power is good.

LED 1: currently not used; always off.

LED 2: currently not used; always off.

Basic Troubleshooting: **1.** Verify Ordering Information. **2.** Verify Features supported. **3.** Verify Specifications. **4.** Check Front Panel LEDs. **5.** Verify System Requirements. **6.** Review Setup. **7.** Record Device and System Information. **8.** Contact Technical Support.

CLI Troubleshooting: The most common mistake is not using a null-modem cable: if you have a multimeter, check that the pins 2 and 3 are crossed. Do NOT use gender changers! The recommended terminal emulation program for any platform is PuTTY. See the [PuTTY download site](#). Use Serial port settings Speed: 115200, Parity: None, Data bits: 8, Stop bits: 1, HW Flow Control: No, and SW Flow Control: No as console port settings. Do not use the serial cable to update the firmware. Use a null modem cable with a female DB9 connector, such as the CABLE-SRA-NMC available through Lantronix.

For More Information : For Lantronix Drivers, Firmware, etc. go to the [Product Support](#) webpage (logon required). For Lantronix Manuals, Brochures, Data Sheets, etc. go to the [Support Library](#) (no logon required).

Related Manuals: SRA Install Guide 33838, Web User Guide 33795, CLI Reference 33839 and Release Notes.

Contact Us : Lantronix Corporate Headquarters; 7535 Irvine Center Drive, Suite100, Irvine, CA 92618, USA.
Toll Free: 800-526-8766. Phone: 949-453-3990. Fax: 949-453-3995. [Technical Support](#). [Sales Offices](#).