



EMG™ Edge Management Gateway User Guide

EMG 8500
EMG 7500
EMG 7500W

Intellectual Property

© 2025 Lantronix, Inc. All rights reserved. No part of the contents of this publication may be transmitted or reproduced in any form or by any means without the written permission of Lantronix.

Lantronix is a registered trademarks of Lantronix, Inc. in the United States and other countries. *EMG* and *SLC* are trademarks of Lantronix, Inc.

Patented: <http://www.lantronix.com/legal/patents/>; additional patents pending.

Windows and *Internet Explorer* are registered trademarks of Microsoft Corporation. *Firefox* is a registered trademark of the Mozilla Foundation. *Chrome* is a trademark of Google Inc. All other trademarks and trade names are the property of their respective holders.

Warranty

For details on the Lantronix warranty policy, please go to our web site at <https://www.lantronix.com/legal/warranty-policy/>.

Contacts

Lantronix Corporate Headquarters

48 Discovery, Suite 250
Irvine, CA 92618, USA

Toll Free: 800-526-8766
Phone: 949-453-3990
Fax: 949-453-3995

Technical Support

Online: <https://www.lantronix.com/support>

Sales Offices

For a current list of our domestic and international sales offices, go to the Lantronix web site at <https://www.lantronix.com/about-us/contact>.

Open Source Software

Some applications are Open Source software licensed under the Berkeley Software Distribution (BSD) license, the GNU General Public License (GPL) as published by the Free Software Foundation (FSF), or the Python Software Foundation (PSF) License Agreement for Python 2.7.3 (Python License). Lantronix grants you no right to receive source code to the Open Source software; however, in some cases, rights and access to source code for certain Open Source software may be available directly from Lantronix' licensors. Your use of each Open Source component or software is subject to the terms of the applicable license. The BSD license is available at <http://opensource.org/licenses>. The GNU General Public License is available at <http://www.gnu.org/licenses/>. The Python License is available at <http://cmpt165.csil.sfu.ca/Python-Docs/license.html>. Your use of each Open Source component or software is subject to the terms of the applicable license.

OPEN SOURCE SOFTWARE IS DISTRIBUTED WITHOUT ANY WARRANTY, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. SEE THE APPLICABLE LICENSE AGREEMENT FOR ADDITIONAL INFORMATION.

Disclaimer & Revisions

All information contained herein is provided “AS IS.” Lantronix undertakes no obligation to update the information in this publication. Lantronix does not make, and specifically disclaims, all warranties of any kind (express, implied or otherwise) regarding title, non-infringement, fitness, quality, accuracy, completeness, usefulness, suitability or performance of the information provided herein. Lantronix shall have no liability whatsoever to any user for any damages, losses and causes of action (whether in contract or in tort or otherwise) in connection with the user's access or usage of any of the information or content contained herein. The information and specifications contained in this document are subject to change without notice.

Operation of this equipment in a residential area is likely to cause interference, in which case the user, at his or her own expense, will be required to take whatever measures may be required to correct the interference.

Note: *This equipment has been tested and found to comply with the limits for Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with this user guide, may cause interference to radio communications. Operation of this equipment in a residential area is likely to cause interference, in which case the user will be required to correct the interference at his own expense.*

User Information

Class A Equipment (Broadcasting and communication equipments for office work)

Seller and user shall be noticed that this equipment is suitable for electromagnetic equipments for office work (Class A) and it can be used outside home.

Changes or modifications made to this device that are not explicitly approved by Lantronix will void the user's authority to operate this device.

Revision History

Date	Rev.	Comments
October 2019	A	Initial release for EMG 8500
February 2020	B	◆ Updated the compliance section. ◆ Added information about device-unique local default password for devices manufactured after January 1, 2020 and installed with firmware version 8.2.0.1 or greater.
April 2020	C	This document describes the EMG firmware release 8.3.0.0. It contains the initial release for EMG 7500 and includes the following software changes: ◆ Added Wi-Fi support, both WLAN client mode and access point mode. ◆ Upgraded FIPS support with latest security algorithms and added support for VPN, SNMP, and Web SSH added in FIPS mode. ◆ Expanded Zero Touch Provisioning (ZTP) to support more methods of downloading a configuration to apply to a factory default EMG. ◆ Added internal analog modem support, including alternate network path support, with fail-over and fail-back. Note: EMG 8500 firmware cannot be installed on EMG 7500, and vice versa.
July 2020	D	Updated for firmware release 8.4.0.0R9. It contains the following software changes for EMG 8500 and EMG 7500: ◆ For the cellular modem that acquires the IP address dynamically, if the IP address is configured as the default gateway, fail-over gateway or VPN tunnel local IP address, the IP address will be automatically updated when it changes. ◆ Added an option for reverse path filtering in Network Settings. ◆ Added an option in VPN to start the VPN tunnel in network fail-over mode. ◆ Updated Web Server support of TLS protocol to include TLSv1.3.
September 2020	E	Updated for firmware release 8.5.0.0R6. It contains the following software changes for EMG 8500 and EMG 7500: ◆ Added support for SNMP v3 with X.509 certificates ◆ Added support for importing ECDSA and ED25519 SSH host keys ◆ Added System Info page in Maintenance, which generates ZIP file with System Information ◆ Added support for SMTP authentication, with email login credentials and TLS
January 2021	F	Added the UL conformity declaration certificate for hardware compliance.
April 2021	G	Updated with power details and photo of EMG 7500 with cellular module only. Updated the compliance section with cellular bands for US and EU (Table E-3).
May 2021	H	Updated the EU DoC for EMG 7500 (Figure E-6).
October 2021	J	Updated for firmware release 8.7.0.0R10. ◆ Added support for integrated 4 port Ethernet switch ◆ Added support for DHCP server and DHCP relay on Ethernet switch
September 2022	K	Added EMG 7500W for Wi-Fi model variant. Added EMG 8500 UL statements. Updated for firmware release 8.9.0.0R5. It contains the following software changes: ◆ Added support for ConsoleFlow proxy server ◆ Added option for G520 cellular gateway as failover gateway. ◆ Added modem access lists, USB serial support on front USB port, and forwarding from cellular interface. ◆ Updated CLI syntax

Date	Rev.	Comments
January 2023	L	Updated for firmware release 9.0.0.0R1. It contains the following software changes: ◆ Added support for exporting the current configuration as a text file ◆ Added audit log messages option for ConsoleFlow ◆ Added AES192 and AES256 options to SNMPv3 encryption ◆ Updated CLI syntax
June 2023	M	Updated for firmware release 9.1.0.0. ◆ Added RSA Host Key Algorithm and NIST Algorithm options to SSH server ◆ Upgraded OpenSSH. DSA SSH keys are no longer supported ◆ Upgraded system log format from RFC3164 to RFC5424 ◆ Updated IP filter rule limit in a ruleset to 256 rules ◆ Added capability to disable Discovery Server for Secure Lantronix Network ◆ Added support for saving sysinfo files in a CLI batch script ◆ Added support for SSH two factor authentication ◆ Added support for cellular MTU configuration ◆ Added speed test diagnostics to the CLI ◆ Added security best practices to Security Considerations appendix ◆ Added cellular modem FOTA ◆ Updated CLI syntax
December 2023	N	Updated for firmware release 9.2.0.0. ◆ Added support for configuring the TCP port for TACACS+ server ◆ Added character escape option for configuration text file ◆ Added support for two Ethernet virtual interfaces ◆ Added support for two VLANs on Ethernet switch to group a subset of switch ports into a logical network. ◆ Updated CLI syntax
March 2024	P	Updated for firmware release 9.3.0.0. ◆ Renamed ConsoleFlow to PercepXion ◆ Added support for integrated PDU management ◆ Added FTP server one time password option ◆ Expanded protocol source IP address selection to include IPv4 and IPv6 addresses for both physical interfaces and virtual interfaces ◆ Added support for configuring IPv6 static routes ◆ Added support for SSH out from CLI to IPv6 addresses and hostnames that resolve to IPv6 addresses ◆ FIPS mode is now deprecated ◆ Updated CLI syntax
January 2025	R	Updated for firmware release 9.5.0.0 ◆ Added support for PercepXion web connect ◆ Added option to “show slcnetwork” CLI command to output in CSV format ◆ Added option to disable console port ◆ Added support for IPv6 addresses in IP Filter ◆ Added support for 3 additional NTP servers ◆ Added support for 6 additional DNS servers ◆ Added option for auto-refresh of device port counters and status ◆ Added support for failover while Ethernet bonding is enabled ◆ Added option for auto reboot after kernel panic ◆ Added appendix about Ansible interoperability ◆ Removed wall mount bracket kit ◆ Updated CLI syntax

Date	Rev.	Comments
July 2025	T	Updated for firmware release 9.6.0.0 ◆ Added filtering (GREP) functionality for CLI show commands ◆ Added failover/failback statistics ◆ Added support for failover while Ethernet bonding is enabled ◆ Added support for SSH ECDSA public keys ◆ Added SSH server algorithm selection ◆ Web server TLS cipher suites can be enabled or disabled ◆ Added REST API section ◆ Added support for NTP authentication ◆ Added support for managing APC7900B Switched Rack PDU ◆ Added CLI help subsections for “set network” and “show network” ◆ Updated CLI syntax

Table of Contents

1: About this Guide	23
Purpose and Audience	23
Summary of Chapters	23
Additional Documentation	24
2: Introduction	25
EMG 8500 Overview	25
EMG 7500 Overview	26
Key Features	26
Console Management	26
Performance Monitoring	27
Security	27
Power	27
Integration with Lantronix PercepXion™	27
Applications	27
Protocol Support	28
Configuration Methods	28
Product Information Label	29
EMG 8500 Hardware Components	30
EMG 7500 / EMG 7500W Hardware Components	31
System Features	32
Access Control	32
Device Port Buffer	32
Console Port Interface	32
Device Port Interfaces	33
I/O Modules	34
Ethernet Switch Module	34
Network Connections	35
Connectivity Modules	36
Front Panel LEDs	37
Digital IO Port	39
3: EMG 8500 Installation	40
EMG 8500 Package Contents	40
Ordering Information	41
User Supplied Items	41
Customize an EMG 8500	41
Hardware Specifications	42

Physical Installation	43
Rack Mount Installation	44
Wall Mount Installation	45
Connecting to a Device Port	47
Connecting to Network Ports	48
Connecting Terminals	48
Power Input	49
Modular Expansion for I/O Module Bays	50
I/O Module or Ethernet Switch Module Installation	51
Modular Expansion for Connectivity Module Bays	52
Connectivity Module Installation	53
Modem Installation	55
4: EMG 7500 / EMG 7500W Installation	56
EMG 7500 Package Contents	56
Ordering Information	56
User Supplied Items	56
Hardware Specifications	57
Physical Installation	58
Rack Mount Installation	59
Wall Mount Installation	60
Connecting to a Device Port	61
Connecting to Network Ports	63
Connecting Terminals	63
Power Input	64
Modem Installation	65
5: Quick Setup	66
Recommendations	66
IP Address	66
Lantronix Provisioning Manager	67
Method #1 Quick Setup on the Web Page	67
Network Settings	69
Date & Time Settings	69
Administrator Settings	70
Method #2 Quick Setup on the Command Line Interface	71
Next Step	73
Limiting Sysadmin User Access	73
6: Web and Command Line Interfaces	75
Web Manager	75
Logging in	77

Logging Out	78
Web Page Help	78
Command Line Interface	78
Logging In	78
Logging Out	79
Command Syntax	79
Command Line Help	79
Tips	79
General CLI Commands	80
	81

7: Networking 82

Requirements	82
Network Port Settings	83
Ethernet Interfaces (Eth1 and Eth2)	86
Gateway	88
Fail-Over Settings	89
TCP Keepalive Parameters	90
Fail-Over Cellular Gateway Configuration	91
Advanced Cellular Gateway Configuration	93
Fail-Over Cellular Gateway Firmware	94
Load Cellular Gateway Firmware Options	94
Ethernet Counters	94
Network Commands	95
Hostname & Name Servers	95
FQDN List	97
Virtual Interfaces	97
Virtual Interface Commands	100
Cellular Modem Settings	100
Cellular Interface	102
Cellular Modem Configuration	102
Cellular Modem Firmware	103
Load Cellular Modem Firmware Options	103
Cellular Status	103
Firmware Over the Air (FOTA)	105
Cellular Modem Commands	107
Wireless Settings	107
Wireless Overview	107
Wireless Client Settings	111
Wireless Access Point Settings	119
Ethernet Switch	121
Port Statistics	123
Switch Commands	125

VLANs	125
VLAN Commands	126
DHCP	126
DHCP Server Settings	128
DHCP Relay Settings	129
DHCP Commands	129
IP Filter	130
Viewing IP Filters	130
Mapping Rulesets	130
Enabling IP Filters	131
Configuring IP Filters	132
Rule Parameters	133
Updating an IP Filter	134
Deleting an IP Filter	134
IP Filter Commands	134
Routing	135
Dynamic Routing	135
Static Routing and IPv4 Static Routes	135
IPv6 Static Routing	136
Routing Commands	137
Forwarding	137
VPN Settings	139
Sample ipsec.conf Files	150
VPN Commands	155
Performance Monitoring	156
Performance Monitoring - Add/Edit Probe	159
Performance Monitoring - Results	162
Performance Monitoring Commands	165

8: Services 166

System Logging and Other Services	166
SSH/Telnet/Logging	166
System Logging	167
Audit Log	168
SSH	168
Telnet	169
Web SSH/Web Telnet Settings	169
SMTP	170
Discovery Server	170
SSH Algorithms	170
SSH/Telnet/Logging Commands	171
SNMP	171
v1/v2c Communities	175

Version 3	176
V3 User Read-Only	176
V3 User Read-Write	176
V3 User Trap	176
Version 3 TLS (over TCP)	177
Services Commands	178
NFS and SMB/CIFS	178
SMB/CIFS Share	180
NFS and SMB/CIFS Commands	180
Secure Lantronix Network	180
Browser Issues	183
Troubleshooting Browser Issues	184
Web SSH/Telnet Copy and Paste	186
Secure Lantronix Network Commands	186
Date and Time	187
Date and Time Commands	190
Web Server	191
Web Server - Web Sessions	192
Web Server - SSL Certificate	193
Web Server - Ciphers	196
Admin Web Commands	197
REST API	198
PercepXion	199
PercepXion Commands	205

9: USB/SD Card Port 206

USB/SD Card Storage	206
Manage Files	209
USB Serial Settings	210
Data Settings	212
IP Settings	212
USB Commands	212
SD Card Commands	212

10: Device Ports 213

Connection Methods	213
Permissions	213
I/O Modules	214
Device Status	215
Device Ports	215
Telnet/SSH/TCP in Port Numbers	216
Device Port Global Commands	217
Device Ports - Settings	218

Device Port Settings	220
IP Settings	222
Data Settings	223
Hardware Signal Triggers	224
Modem Settings (Device Ports)	225
Modem Settings: Text Mode	226
Modem Settings: PPP Mode	226
Port Status and Counters	228
Device Ports - Power Management	228
Device Port - Sensorsoft Device	231
Device Port Commands	233
Device Commands	233
Interacting with a Device Port	234
Device Ports - Logging and Events	235
Local Logging	235
NFS File Logging	235
USB and SD Card Logging	235
Token/Data Detection	236
Syslog Logging	236
Token & Data Detection	237
Local Logging	239
Log Viewing Attributes	239
NFS File Logging	239
USB / SD Card Logging	239
Syslog Logging	239
Logging Commands	240
Console Port	240
Console Port Commands	241
Internal Modem	242
Internal Modem Commands	246
DIO Port	246
DIO Commands	247
Xmodem	248
Xmodem Commands	250
Host Lists	251
Host Parameters	251
Host List Commands	254
Sites	255
Site Commands	257
Access Lists	257
Access List Commands	259
Modem Dialing States	259
Dial In	259

Dial-back	260
Dial-on-demand	261
Dial-in & Dial-on-demand	261
Dial-back & Dial-on-demand	262
CBCP Server and CBCP Client	262
CBCP Server	262
CBCP Client	263
Key Sequences	263

11: Power Management 265

Integrated PDU Management	265
Power Commands	268
Remote Power Managers	268
Devices - RPMs	268
RPMs - Add Device	272
RPMs - Manage Device	275
RPMs - Outlets	279
RPM Shutdown Procedure	279
Optimizing and Troubleshooting RPM Behavior	281
RPM Commands	282

12: Scripts 283

Script Commands	288
Batch Script Syntax	289
Interface Script Syntax	290
Primary Commands	291
Secondary Commands	292
Control Flow Commands	294
Custom Script Syntax	296
Example Scripts	298

13: Connections 317

Typical Setup Scenarios for the EMG unit	317
Terminal Server	317
Remote Access Server	318
Reverse Terminal Server	318
Multiport Device Server	319
Console Server	319
Connection Configuration	320
Connection Commands	322

14: User Authentication 323

Authentication Methods	323
Authentication Commands	325
User Rights	326
Local and Remote User Settings	327
Sysadmin Account Default Login Values	328
Adding, Editing or Deleting a User	329
Shortcut	333
Local Users Commands	333
Remote User Rights Commands	333
NIS	334
NIS Commands	336
LDAP	337
LDAP Commands	341
RADIUS	342
RADIUS Commands	345
User Attributes & Permissions from LDAP Schema or RADIUS VSA	345
Kerberos	347
Kerberos Commands	349
TACACS+	350
TACACS+ Groups	350
TACACS+ Commands	354
Groups	355
Group Commands	358
SSH Keys	358
Overview	358
Imported Keys	358
Exported Keys	358
Create an SSH Key	359
SSH Server/Host Keys	362
SSH Key Commands	364
Custom Menus	365
Custom User Menu Commands	367

15: Maintenance 368

Firmware & Configurations	368
Zero Touch Provisioning Configuration Restore	368
Creating a Certificate	369
HTTPS Push Configuration Restore	371
Factory Reset with External Storage Device	372
Internal Temperature	374
Site Information	374
EMG Firmware	374
Boot Banks and Bootloader Settings	375

Load Firmware Via Options	376
Configuration Management	376
Manage Files	378
Administrative Commands	378
System Logs	379
System Log Commands	380
Audit Log	381
Audit Log Commands	381
Email Log	382
Logging Commands	382
Diagnostics	383
Diagnostic Commands	386
Status/Reports	386
View Report	387
Status Commands	388
Emailing Logs and Reports	389
Events	391
Events Commands	393
Banners	393
Administrative Banner Commands	394
System Info	394

16: Application Examples 396

Telnet/SSH to a Remote Device	397
Dial-in (Text Mode) to a Remote Device	399
Local Serial Connection to Network Device via Telnet	401

17: Command Reference 403

Introduction to Commands	403
Command	403
Command Line Help	404
Tips	404
Administrative Commands	405
Audit Log Commands	420
Authentication Commands	420
Kerberos Commands	421
LDAP Commands	422
Local Users Commands	424
NIS Commands	427
RADIUS Commands	428
TACACS+ Commands	429
User Permissions Commands	431
Remote User Commands	433

Access List Commands	435
Cellular Modem Commands	436
PercepXion Commands	437
CLI Commands	441
Connection Commands	443
Console Port Commands	447
Custom User Menu Commands	447
Email Commands	449
Date and Time Commands	450
Device Commands	452
Device Port Commands	453
DHCP Commands	457
DIO Commands	458
Diagnostic Commands	459
Events Commands	465
Groups Commands	466
Host List Commands	467
Internal Modem Commands	468
IP Filter Commands	469
Logging Commands	471
Network Commands	473
NFS and SMB/CIFS Commands	477
Performance Monitoring Commands	479
Power Commands	483
Routing Commands	483
RPM Commands	484
Script Commands	486
SD Card Commands	489
Services Commands	490
Site Commands	492
SLC Network Commands	493
SNMP Commands	493
SSH Key Commands	496
Status Commands	499
Switch Commands	500
System Log Commands	502
USB Access Commands	503
USB Device Commands	503
USB Serial Commands	504
USB Storage Commands	504
USB Modem Commands	507
Virtual Interface Commands	508
VPN Commands	510

WLAN Commands	512
Temperature Commands	514
Xmodem Commands	516
Appendix A: Security Considerations	517
Security Practice	517
Factors Affecting Security	517
Security Best Practices	517
Appendix B: Safety Information	519
Safety Precautions	519
Cover	519
Power Plug	519
Input Supply	520
Grounding	520
Rack Mounting	520
Wall Mounting	520
Port Connections	520
Appendix C: Adapters and Pinouts	522
Appendix D: Protocol Glossary	525
Appendix E: Compliance Information	529
Federal Communication Commission Interference Statement	531
Statement:	531
Safety and Hazards	542
RoHS, REACH, and WEEE Compliance Statement	547
Appendix F: Ansible Interoperability	548
Ansible Installation	548
Ansible Setup	549
Pinging Hosts and Running Playbooks	551

List of Figures

Figure 2-1 EMG 8500 Edge Management Gateway (front view)	25
Figure 2-2 EMG 7500 Edge Management Gateway (front view)	26
Figure 2-3 Product Label (EMG 8500 shown)	29
Figure 2-4 EMG 8500 Unit (front side)	30
Figure 2-5 EMG 8500 Unit (back side)	30
Figure 2-6 EMG 7500 / EMG 7500W Unit (front side)	31
Figure 2-7 EMG 7500W Unit with Wi-Fi Module (back side)	31
Figure 2-8 EMG 7500 Unit with USB I/O Module (back side)	32
Figure 2-9 Console Port Pinout	33
Figure 2-11 EMG 8500 Dual WAN Ethernet Ports	35
Figure 2-12 EMG 8500 Dual SFP Ports	36
Figure 2-13 EMG 8500 LTE Cellular Modem Module	37
Figure 2-15 Digital I/O Port	39
Figure 3-4 EMG 8500 Rack Mount Dimensions	44
Figure 3-5 EMG 8500 Wall Mount Dimensions	45
Figure 3-8 Sample Device Port Connections (Front Side)	48
Figure 3-9 Power Input	50
Figure 3-10 Available I/O Module Configurations for EMG 8500	51
Figure 3-11 Sample Connectivity Module Configuration (Back Side)	53
Figure 4-3 EMG 7500 Rack Mount Configurations	59
Figure 4-4 EMG 7500 Rack Mount Screw Placement	59
Figure 4-5 Wall Mount Configuration	60
Figure 4-8 EMG 7500 (Front Side)	62
Figure 4-9 EMG 7500 / EMG 7500W Power Input	64
Figure 5-2 Quick Setup	68
Figure 5-3 Quick Setup Completed in Web Manager	70
Figure 5-4 Home	70
Figure 5-5 Beginning of Quick Setup Script	71
Figure 5-6 Quick Setup Completed in CLI	72
Figure 6-1 Web Page Layout	75
Figure 6-2 Sample Dashboard	76
Figure 7-1 Network > Network Settings (1 of 2)	84
Figure 7-2 Network > Network Settings (2 of 2)	85
Figure 7-3 Network Settings > SFP NIC Information & Diagnostics	86
Figure 7-4 Hostname & Name Servers	96

Figure 7-5 Network > Cellular Modem Settings Page	101
Figure 7-6 Update WiFi Firmware	110
Figure 7-7 Network > Wireless Settings	112
Figure 7-8 Network > Wireless Settings > WLAN Profiles	114
Figure 7-9 Network > Wireless Settings > Access Point Settings	120
Figure 7-10 Network > Ethernet Switch	122
Figure 7-11 Network > Switch > Configure Port Settings	123
Figure 7-12 Network > DHCP	128
Figure 7-13 Network > IP Filter	130
Figure 7-14 Network > IP Filter Ruleset (Adding/Editing Rulesets)	132
Figure 7-15 Network > Routing	135
Figure 7-16 Network > Forwarding	138
Figure 7-17 Network > VPN (1 of 2)	141
Figure 7-18 Network > VPN (2 of 2)	142
Figure 7-19 Network > Perf Monitoring	157
Figure 7-20 Performance Monitoring - Add/Edit Probe	159
Figure 7-22 Performance Monitoring - Operations	165
Figure 8-1 Services > SSH/Telnet/Logging	167
Figure 8-2 Services > SNMP (1 of 2)	172
Figure 8-3 Services > SNMP (2 of 2)	173
Figure 8-4 Services > NFS & SMB/CIFS	179
Figure 8-5 Services > Secure Lantronix Network	181
Figure 8-6 IP Address Login Page	182
Figure 8-7 SSH or Telnet CLI Session	182
Figure 8-8 Disabled Port Number Popup Window	183
Figure 8-9 Services > Secure Lantronix Network - Search Options	184
Figure 8-10 Services > Date & Time	188
Figure 8-11 Services > Web Server	191
Figure 8-12 Web Server - Web Sessions	193
Figure 8-13 Web Server - SSL Certificate	194
Figure 8-14 Web Server - Ciphers List	197
Figure 8-15 Services > PercepXion	202
Figure 9-1 Devices > USB / SD Card	207
Figure 9-2 Devices > USB > Configure	208
Figure 9-3 Devices > SD Card > Configure	208
Figure 9-4 Firmware and Configurations - Manage Files	210
Figure 9-5 Devices > USB/SD Card - Serial Port	211
Figure 9-6 Devices > USB/SD Card > USB - Serial	211

Figure 10-2 Devices > Device Status	215
Figure 10-3 Devices > Device Ports	216
Figure 10-4 Device Ports > Settings (1 of 2)	219
Figure 10-5 Device Ports > Settings (2 of 2)	220
Figure 10-7 Device Ports - Power Management	230
Figure 10-8 Devices > Device Ports - Sensorsoft	232
Figure 10-9 Sensorsoft Status	233
Figure 10-10 Devices > Device Ports - Logging & Events	237
Figure 10-11 Devices > Console Port	240
Figure 10-12 Devices > Internal Modem	243
Figure 10-13 Devices > Host Lists	251
Figure 10-14 Devices > View Host Lists	253
Figure 10-15 Devices > Sites	255
Figure 11-1 Devices > RPMs	269
Figure 11-2 RPM Shutdown Order	270
Figure 11-3 RPM Notifications	270
Figure 11-4 RPM Raw Data Log	271
Figure 11-5 RPM Logs	272
Figure 11-6 RPM Environmental Log	272
Figure 11-7 Devices > RPMs - Add Device	273
Figure 11-8 RPMs - Manage Device	276
Figure 11-9 RPMs - Outlets	279
Figure 12-1 Devices > Scripts	283
Figure 12-2 Adding or Editing New Scripts	284
Figure 12-3 Scripts > Custom Scripts - Scheduler	286
Figure 13-1 Terminal Server	317
Figure 13-2 Remote Access Server	318
Figure 13-3 Reverse Terminal Server	318
Figure 13-4 Multiport Device Server	319
Figure 13-5 Console Server	320
Figure 13-6 Devices > Connections	321
Figure 13-7 Current Connections	322
Figure 14-1 User Authentication > Auth Methods	324
Figure 14-3 User Authentication > Local/Remote Users	327
Figure 14-4 User Authentication > Local/Remote User Settings	330
Figure 14-5 User Authentication > NIS	334
Figure 14-6 User Authentication > LDAP	338
Figure 14-7 User Authentication > RADIUS	342

Figure 14-8 User Authentication > Kerberos	347
Figure 14-9 User Authentication > TACACS+	351
Figure 14-10 User Authentication > Groups	356
Figure 14-11 User Authentication > SSH Keys	360
Figure 14-12 Current Host Keys	363
Figure 14-13 User Authentication > Custom Menus	365
Figure 15-1 Maintenance > Firmware & Configurations	373
Figure 15-2 Network > Firmware/Config > Manage	378
Figure 15-3 Maintenance > System Logs	379
Figure 15-4 View System Logs	380
Figure 15-5 Maintenance > Audit Log	381
Figure 15-6 Maintenance > Email Log	382
Figure 15-7 Maintenance > Diagnostics	383
Figure 15-8 Diagnostics Output	386
Figure 15-9 Maintenance > Status/Reports	387
Figure 15-10 Generated Status/Reports	388
Figure 15-11 Emailed Log or Report	389
Figure 15-12 About EMG	390
Figure 15-13 Maintenance > Events	391
Figure 15-14 Maintenance > Banners	393
Figure 15-15 System Info	394
Figure 16-1 EMG - Configuration	396
Figure 16-2 Remote User Connected to a SUN Server via the Console Manager	397
Figure 16-3 Dial-in (Text Mode) to a Remote Device	399
Figure 16-4 Local Serial Connection to Network Device via Telnet	401
Figure C-1 RJ45 Receptacle to DB25M DCE Adapter for the EMG Unit (PN 200.2066A)	522
Figure C-2 RJ45 Receptacle to DB25F DCE Adapter for the EMG Unit (PN 200.2067A)	523
Figure C-3 RJ45 Receptacle to DB9M DCE Adapter for the EMG Unit (PN 200.2069A)	523
Figure C-4 RJ45 Receptacle to DB9F DCE Adapter for the EMG Unit (PN 200.2070A)	524
Figure C-5 RJ45 Receptacle to DB25M DTE Adapter (PN 200.2073)	524
Figure E-4 EMG 8500, EU Declaration of Conformity	533
Figure E-5 EMG 8500 EU Declaration of Conformity, continued	534
Figure E-6 EMG 7500 EU Declaration of Conformity	535
Figure E-11 UL Declaration of Conformity	545
Figure E-12 UL Declaration of Conformity, continued	546

List of Tables

Table 2-10 Device DCE (Reversed) & DTE Port Pinout	33
Table 2-14 LED Indicators	37
Table 3-1 EMG 8500 Parts	40
Table 3-2 EMG 8500 User Replaceable Device Modules	40
Table 3-3 EMG 8500 Technical Specifications	42
Table 3-6 Console Port and Device Port - Reverse Pinout Disabled	47
Table 3-7 Device Port - Reverse Pinout Enabled (Default)	47
Table 4-1 EMG 7500 Parts	56
Table 4-2 EMG 7500 Technical Specifications	57
Table 4-6 Console Port and Device Port - Reverse Pinout Disabled	61
Table 4-7 Device Port - Reverse Pinout Enabled (Default)	62
Table 5-1 Methods of Assigning an IP Address	66
Table 6-3 SCS Commands	80
Table 6-4 CLI Keyboard Shortcuts	81
Table 7-21 Error Conditions Detected by Probes	164
Table 10-1 Supported I/O Module Configurations	214
Table 10-6 Port Status and Counters	228
Table 12-4 Interface Script Syntax Definitions	290
Table 12-5 Primary Commands	291
Table 12-6 Secondary Commands	293
Table 12-7 Control Flow Commands	294
Table 14-2 User Types and Rights	326
Table 17-1 Actions and Category Options	403
Table E-1 Regional Certifications	529
Table E-2 Country Transmitter IDs	529
Table E-3 Cellular Bands for US and EU	530
Table E-7 EU Statements	536
Table E-8 Conducted Transmit Power Specifications.	542
Table E-9 EMG 7500W Conducted Transmit Power Specifications.	543
Table E-10 EMG 7500W Wi-Fi Specifications	544

1: About this Guide

Purpose and Audience

This guide provides the information needed to install, configure, and use the Lantronix EMG™ edge management gateway. The EMG gateway is for IT professionals who must remotely and securely configure and administer servers, routers, switches, telephone equipment, or other devices equipped with a serial port for facilities that are typically remote branch offices or “distributed” IT locations.

Note: EMG edge management gateways are referred to as either EMG, EMG 8500, EMG 7500, or EMG 7500W when referring to the specific series. Edge management gateway or console manager may be used to describe the EMG devices.

Summary of Chapters

The remaining chapters in this guide include:

Chapter	Description
Chapter 2: Introduction	Describes the EMG models, their main features, and the protocols they support.
Chapter 3: EMG 8500 Installation	Provides technical specifications; describes connection form factors and power supplies; provides instructions for installing the EMG 8500.
Chapter 4: EMG 7500 / EMG 7500W Installation	Provides technical specifications; describes connection form factors and power supplies; provides instructions for installing the EMG 7500 or EMG 7500W.
Chapter 5: Quick Setup	Provides instructions for getting your EMG unit up and running and for configuring required settings.
Chapter 6: Web and Command Line Interfaces	Describes the web and command line interfaces available for configuring the EMG. The configuration chapters (6-15) provide detailed instructions for using the web interface and include equivalent command line interface commands.
Chapter 7: Networking	Provides instructions for configuring network ports, firewall and routing settings, and VPN.
Chapter 8: Services	Provides instructions for enabling and disabling system logging, SSH and Telnet logins, SNMP, SMTP, and the date and time.
Chapter 9: USB/SD Card Port	Provides instructions for using the USB and SD Card ports.
Chapter 10: Device Ports	Provides instructions for configuring global device port settings, individual device port settings, and console port settings.
Chapter 11: Power Management	Provides instructions for using RPMs.
Chapter 12: Scripts	Provides instructions for creating scripts to automate tasks performed on the EMG command line interface (CLI) or on device ports.
Chapter 13: Connections	Provides instructions for configuring connections and viewing, updating, or disconnecting a connection.

Chapter (continued)	Description
Chapter 14: User Authentication	Provides instructions for enabling or disabling methods that authenticate users who attempt to log in via the web, SSH, Telnet, or the console port. Provides instructions for creating custom menus.
Chapter 15: Maintenance	Provides instructions for upgrading firmware, viewing system logs and diagnostics, generating reports, and defining events. Includes information about web pages and commands used to shut down and reboot the EMG.
Chapter 16: Application Examples	Shows three different configurations to set up and use the EMG unit.
Chapter 17: Command Reference	Lists and describes all of the commands available on the EMG command line interface.
Appendix A: Security Considerations	Provides tips for enhancing EMG security.
Appendix B: Safety Information	Lists safety precautions for using the EMG.
Appendix C: Adapters and Pinouts	Includes adapter and pinout diagrams.
Appendix D: Protocol Glossary	Lists the protocols supported by the EMG unit with brief descriptions.
Appendix E: Compliance Information	Provides information about the EMG unit's compliance with industry standards.

Additional Documentation

Visit the Lantronix [web site](#) for the latest documentation and resources.

Document	Description
EMG 8500 Quick Start Guide or EMG 7500 Quick Start Guide	Provides accessories and part number information, hardware installation instructions, directions to connect the EMG unit, and network IP configuration information.
EMG 8500 Product Brief or EMG 7500 Product Brief	Provides product overview and specifications.

2: Introduction

The EMG edge management gateway enables IT system administrators to manage remote servers and IT infrastructure equipment securely over the Internet.

IT equipment can be configured, administered, and managed in a variety of ways, but most devices have one of two methods in common: via a USB port and/or via an RS-232 serial port, sometimes called a console, auxiliary, or management port. These ports are often accessed directly by connecting a terminal or laptop to them, meaning that the administrator must be in the same physical location as the equipment. The EMG gives the administrator a way to access them remotely from anywhere there is a network or modem connection.

This chapter provides an introduction to the following EMG models:

- ◆ EMG 8500
- ◆ EMG 7500
- ◆ EMG 7500W

Most features are common to EMG 8500 and EMG 7500 / EMG 7500W, however, differences between the models are noted.

EMG 8500 Overview

The EMG 8500 is a modular edge management gateway that offers serial RJ45 and USB console connectivity with user swappable I/O modules and connectivity modules. These user swappable modules are also referred to as FRUs (field replaceable units)

The EMG 8500 unit can accommodate up to two user swappable I/O modules (4 port serial RJ45 and/or 4 port serial USB) or one I/O module and one Ethernet switch (4 LAN ports) on the front side of the EMG 8500 unit.

For connectivity, the EMG 8500 provides dual WAN Ethernet or dual small form-factor pluggable (SFP) network ports and up to two user swappable modules for one LTE cellular modem, one Wi-Fi card, or one dialup analog modem.

Figure 2-1 EMG 8500 Edge Management Gateway (front view)




EMG 7500 Overview

The EMG 7500 is a modular edge management gateway that offers serial RJ45 and USB console connectivity with pre-installed I/O modules and connectivity modules. The EMG 7500 unit can accommodate one I/O module (4 port serial RJ45 or 4 port serial USB) on the front of the unit and one I/O module (4 port serial RJ45 or 4 port serial USB), one Ethernet switch (4 port), or one connectivity module (Wi-Fi card, dialup modem) on the back. In addition, it supports one optional internal LTE cellular modem for a total of two modules on the back of the unit. The modules on the EMG 7500 are not user-swappable.

The EMG 7500 provides dual WAN Ethernet network ports for in-band network connectivity.

Figure 2-2 EMG 7500 Edge Management Gateway (front view)



Key Features

Console Management

- ◆ Enables system administrators to remotely manage devices with serial and/or USB console ports with RS-232C (now EIA-232) or USB compatible serial consoles in a 1U-tall rack space.
- ◆ RJ45 RS-232 or USB Type A serial console connections
 - EMG 8500 provides up to 8 serial RJ45 RS-232 or USB Type A console connections.
 - EMG 7500 provides up to 8 serial RJ45 RS-232 or USB Type A console connections.
 - EMG 7500W provides up to 4 serial RJ45 RS-232 or USB Type A console connections.
- ◆ Managed Ethernet switch (4 port)
- ◆ In-band network device access
 - EMG 8500 offers dual 10/100/1000 BASE-T ports or dual 1 Gb SFP ports
 - EMG 7500 / EMG 7500W offers dual 10/100/1000 BASE-T ports
- ◆ Out-of-band network device access
 - Local terminal, internal cellular modem (LTE cellular), Wi-Fi, or dialup analog modem

- EMG 8500 provides two user-swappable connectivity modules on the back.
- EMG 7500 / EMG 7500W provides one internal cellular modem and one slot on the back which can house a connectivity module.
- ◆ Modular design
 - EMG 8500 offers two user swappable I/O modules (front only) and two user swappable connectivity modules (back only).
 - EMG 7500 / EMG 7500W offers one I/O module (front) and one I/O or connectivity module plus optional internal cellular modem (back). Modules are pre-installed and cannot be replaced by the user.
- ◆ Data logging, device port buffering, network performance monitoring, system event logs and console event notification via email
- ◆ Integrated automatic fail-over/fail-back mechanism for seamless connection to IT equipment
- ◆ Sun Break Safe compatible
- ◆ Remote power manager (RPM) control of UPS and PDU devices
- ◆ Scripting to automate tasks performed on the CLI or on device ports

Performance Monitoring

- ◆ Performance Monitoring probes to analyze network performance

Security

- ◆ Enterprise-grade security and secure user access control with local or remote authentication

Power

- ◆ Input: 100-240 Vac, 1.5 A, 47-63 Hz
- ◆ Output: 12 Vdc, 8.34 A
- ◆ Convection cooled, silent operation, low power consumption

Integration with Lantronix PercepXion™

- ◆ Compatible with Lantronix PercepXion™ management software for an end-to-end Out-of-Band (OOB) management solution.

Applications

The EMG is suitable for remote and secure management of the following types of IT equipment:

- ◆ **Servers:** Unix, Linux, Windows, and others.
- ◆ **Networking equipment:** Routers, switches, storage networking.
- ◆ **Telecom:** PBX, voice switches.
- ◆ **Other systems with serial interfaces:** Heating/cooling systems, security/building access systems, uninterruptible power supply (UPS), medical devices.

Protocol Support

The EMG supports the following protocols:

- ◆ TCP/IP network protocol
- ◆ SSH, TLS, Telnet and TCP for connections in and out of device ports
- ◆ DHCP and BOOTP for dynamic IP address assignment
- ◆ DNS for IP address name resolution
- ◆ SNMP for remote monitoring and management
- ◆ SCP, FTP, and SFTP for file transfers and firmware upgrades
- ◆ TFTP for firmware upgrades
- ◆ SMTP for mail transfer
- ◆ HTTPS for secure browser-based configuration
- ◆ NTP for time synchronization
- ◆ UDP, PPP with PAP/CHAP, NFS and CIFS for data storage
- ◆ LDAP/AD, NIS, RADIUS with VSA support, CHAP, PAP, Kerberos, TACACS+, and SecurID (via RADIUS) for remote authentication
- ◆ Callback Control Protocol (CBCP) for PPP server callback
- ◆ StrongSwan IPsec for VPN access

For brief descriptions of these protocols, see [Appendix D: Protocol Glossary](#).

Configuration Methods

After installation, the EMG requires configuration. For the unit to operate correctly on a network, it must have a unique IP address on the network. This IP address references the specific unit.

For details on how to configure the unit with basic network settings, see [Chapter 5: Quick Setup](#).

The EMG provides the following methods for logging into the unit to configure EMG settings monitor performance:

- ◆ **Web Manager:** View and configure all settings through a secure, encrypted web interface using most web browsers (Firefox, Chrome, or Internet Explorer with the latest browser updates). See [Chapter 6: Web and Command Line Interfaces](#).
- ◆ **Command Line Interface (CLI):** The command mode may be accessed through Telnet, SSH, Web Telnet/SSH or connecting a terminal (or a PC running a terminal emulation program) to the unit's console port. See [Chapter 6: Web and Command Line Interfaces](#).

Product Information Label

The product information label on the unit contains the following information about the specific unit:

- ◆ QR Code
- ◆ Product Part Number
- ◆ Product Revision
- ◆ Manufacturing Date Code
- ◆ Country of Manufacturing Origin
- ◆ Hardware Address (MAC address or serial number)
- ◆ Device ID (used to connect to PercepXion)


Figure 2-3 Product Label (EMG 8500 shown)



The marking information is located at the bottom of the apparatus for EMG 7500W.


EMG 8500 Hardware Components

Figure 2-4 EMG 8500 Unit (front side)



The appearance and function of the EMG unit will depend upon the type(s) of I/O modules installed in the bays.

Figure 2-5 EMG 8500 Unit (back side)




The appearance and function of the EMG unit will depend upon the type(s) of connectivity modules installed in the bays.

The EMG supports the use of single mode and multi-mode fiber optic SFP transceiver modules. SFP modules are purchased separately.




EMG 7500 / EMG 7500W Hardware Components

Figure 2-6 EMG 7500 / EMG 7500W Unit (front side)



The appearance and function of the EMG unit will depend upon the type of I/O module installed.

Figure 2-7 EMG 7500W Unit with Wi-Fi Module (back side)



The appearance and function of the EMG unit will depend upon the model that has been purchased. [Figure 2-7](#) shows an EMG 7500W unit with an internal cellular modem and a Wi-Fi card.

Figure 2-8 EMG 7500 Unit with USB I/O Module (back side)



System Features

This section describes the system features for the EMG edge management gateway. Most features are common to EMG 8500 and EMG 7500 / EMG 7500W, however, differences between the models are noted.

Access Control

The system administrator controls access to attached servers or devices by assigning access rights to up to 128 user profiles. Each user has an assigned ID, password, and access rights. Other user profile access options may include externally configured authentication methods such as RADIUS, TACACS+, NIS, and LDAP. Groups are supported in LDAP, RADIUS (using VSA), and TACACS+ (using priv_lvl).

Device Port Buffer

The EMG unit supports real-time data logging for each device port. The port can save the data log to a file, send an email notification of an issue, or take no action.


You can define the path for logged data on a port-by-port basis, configure file size and number of files per port for each logging event, and configure the device log to send an email alert message automatically to the appropriate parties indicating a particular error.

Console Port Interface

The EMG unit supports local access through a dedicated front panel serial console port. The console port supports the RS-232C (EIA-232) standard. RJ45 cabling (e.g., category 5 or 6 patch cabling) is used.

[Figure 2-9](#) shows the Console port pinout and description.

The console port supports the following baud rate options: 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400, 460800, and 921600 baud.

Figure 2-9 Console Port Pinout

DTE Pin	Description
1	RTS (output)
2	DTR (output)
3	TXD (output)
4	Ground
5	Ground
6	RXD (input)
7	DSR (input)
8	CTS (input)

Device Port Interfaces

RS-232 RJ45 Interface

All devices attached to the RJ45 device ports must support the RS-232C (EIA-232) standard. For serial RJ45 device ports, RJ45 cabling (e.g., category 5 or 6 patch cabling) is used.

Serial RJ45 device ports for the EMG are reversed by default so that straight-through RJ45 patch cables may be used to connect to Cisco and Sun RJ45 serial console ports. See [Table 2-10](#). The serial RJ45 ports have software reversible pinouts to switch between DTE and DCE applications.

The serial RJ45 ports match the RJ45 pinouts of the console ports of many popular devices found in a network environment, and where different can be converted using Lantronix adapters. The RJ45 ports have software reversible pinouts to switch between digital terminal equipment (DTE) and digital communications equipment (DCE) applications. RJ45 to DB9/DB25 adapters are available from Lantronix. For serial pinout information, see [Appendix C: Adapters and Pinouts on page 522](#).

Table 2-10 Device DCE (Reversed) & DTE Port Pinout

DCE Pin	DTE Pin	Description
8	1	RTS (output)
7	2	DTR (output)
6	3	TXD (output)
5	4	Ground
4	5	Ground
3	6	RXD (input)
2	7	DSR (input)
1	8	CTS (input)

Additional device port features:

- ◆ RAW TCP, Telnet or SSH to a serial port by IP address per port or by IP address and TCP port number
- ◆ Simultaneous access on the same port - "listen" and "direct" connect mode
- ◆ Device ports support the following baud rate options: 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400, 460800, and 921600 baud.

USB Interface

USB device ports can be used with a USB type A connector to serial adapter, if needed.

I/O Modules

User-replaceable I/O device port modules apply to EMG 8500 only.

EMG 8500 provides two slots for user replaceable I/O device port modules to be installed on the front side of the unit. When installing the I/O modules, they can be populated in any order. One but not both of the slots can be empty. The I/O modules must only be installed on the front of the unit, never in the connectivity slots on the back.

Warning: *The EMG must be powered off when installing or replacing the modules. Not powering off the device before changing the module will void the manufacturer warranty.*

Ethernet Switch Module

The Ethernet Switch module provides 4 LAN Ethernet ports.

EMG 8500 offers a user-replaceable Ethernet Switch module while the EMG 7500 offers an option with a built-in Ethernet switch which is not interchangeable.

The Ethernet switch ports are 10/100/1000 BASE-T for use with a conventional Ethernet network. Use standard RJ45-terminated cables, such as a Cat 5 or Cat 5e patch cable. The ports on the switch can automatically detect the type of cable configuration (MDI or MDI-X) and auto adjust. This means that you can use straight through twisted pair or crossover twisted pair cable for any of these connections.

The Ethernet Switch port LEDs display the following states:

- ◆ Green Light On: indicates a link at 1000 BASE-T
- ◆ Green Light Off: indicates a link at other speeds or no link
- ◆ Yellow/Orange Light On: indicates a link is established
- ◆ Yellow/Orange Light Blinking: indicates link activity

When installing the Ethernet Switch module in the EMG 8500, it must only be installed on the front of the unit in the I/O module bays. Bay 1 must be populated with an I/O module and Bay 2 must be populated with the Ethernet Switch module.

Warning: *The EMG must be powered off when installing or replacing the modules. Not powering off the device before changing the module will void the manufacturer warranty.*


Network Connections

Dual WAN Ethernet Port and Dual SFP Port

The EMG 8500 is equipped with two WAN Ethernet ports and two SFP ports. The EMG 7500 / EMG 7500W is equipped with two WAN Ethernet ports only.

The EMG network interfaces are 10/100/1000 BASE-T for use with a conventional Ethernet network as shown in [Figure 2-11](#). Use standard RJ45-terminated cables, such as a Category 5 or 6 patch cable. CAT5E or better cables are recommended for 1000 BASE-T. Network parameters must be configured before the EMG can be accessed over the network.

Figure 2-11 EMG 8500 Dual WAN Ethernet Ports



The 1 Gigabit-capable SFP port interface supports single or multi-mode fiber optic SFP transceiver modules as shown in [Figure 2-12](#). SFP transceiver modules are provided by users according to fiber mode and brand preferences. Lantronix offers SFP Transceivers (“modules”) for EMG 8500 edge management gateways and SLC 8000 console managers with fiber SFP ports. To learn more, go to <https://www.lantronix.com/products/sfp/>

The EMG 8500 unit will recognize two network connections. One connection must be either Eth1 or SFP1. The second connection must be either Eth2 or SFP2.

If a single mode and a multi-mode SFP module are both installed on the EMG 8500 unit, the device can be configured to utilize one mode at a time.


One possible use for the two WAN Ethernet ports is to have one port on a private, secure network and the other on a public, unsecured network.

WAN Ethernet and SFP Port LEDs

The WAN Ethernet and SFP port LED indicators are the following:

- ◆ Green LED - indicates link status
- ◆ Yellow LED - indicates activity status

Figure 2-12 EMG 8500 Dual SFP Ports



Connectivity Modules

User-replaceable connectivity modules apply to EMG 8500 only. The EMG 7500 / EMG 7500W connectivity modules are built-in and are not replaceable by the user.

EMG 8500 is equipped with two slots for user replaceable connectivity modules to be installed on the back of the unit. When installing the connectivity modules, they can be populated or swapped in any order. One or both of the slots can be empty. The connectivity modules must only be installed on the back of the unit, never in the I/O slots on the front.

Warning: *The EMG 8500 must be powered off when installing or replacing the modules. Not powering off the device before changing the module will void the manufacturer warranty.*

LTE Cellular Modem Module

One LTE/4G cellular modem may be installed in either connectivity module slot on the back of the EMG 8500 unit. See [Connectivity Module Installation](#).

The EMG 7500 is offered with the option of an internal LTE cellular modem.

The LTE cellular modem module supports one main antenna, one AUX antenna, and one GNSS antenna for geolocation. (The geolocation function is not active in the current release).

The LTE cellular modem module supports one micro SIM card, provided by the local subscribed Internet service provider (ISP). On the EMG 8500, the micro SIM card slot is located on the inside of the cellular modem module, as shown in [Figure 2-13](#). The EMG 8500 unit must be powered off before installing or replacing the micro SIM card.

On the EMG 7500, the micro SIM slot is located on the back of the unit, as shown in [Figure 2-7](#). The EMG 7500 does not have to be powered off before inserting or replacing the micro SIM card.

Figure 2-13 EMG 8500 LTE Cellular Modem Module



Wi-Fi Module

One Wi-Fi module may be installed in either connectivity slot on the back of the EMG 8500 unit. See [Connectivity Module Installation](#).

The EMG 7500W is offered with the option of a pre-installed Wi-Fi module. See [Figure 2-7](#).

The Wi-Fi module supports two antennas, labeled as Wi-Fi 1 and Wi-Fi 2. Both should be installed for proper operation.

Dialup Modem Module

One analog dialup modem module may be installed in either connectivity slot on the back of the EMG 8500 unit. See [Connectivity Module Installation](#).

The EMG 7500 is offered with the option of a pre-installed analog dialup modem module.

Front Panel LEDs

The two LEDs on the front panel of the EMG unit provide quick visual troubleshooting. [Table 2-14](#) describes the front panel LED indicators.

Table 2-14 LED Indicators

LED	Description	State and Color	Behavior
1 (top LED)	WAN Ethernet port	Solid Green	At least one of the WAN Ethernet ports has a link, or both ports are disabled.
		Solid Orange	Not applicable
		Blinking Red	Neither of the ports has a link.

LED	Description	State and Color	Behavior
2 (bottom LED)	Connectivity status	Solid Green	Indicates one of the following conditions: ◆ There are no connectivity modules installed ◆ An LTE modem module is installed and is disabled ◆ An LTE modem module is installed and has a link
		Solid Orange	An LTE modem module is installed but no SIM card is present
		Blinking Red	An LTE modem module is installed but does not have a link.

Both LEDs - Boot Sequence

During the boot sequence, the EMG will display the following LEDs:

- ◆ **Bootloader Starts** - Both LEDs change to green.
- ◆ **Kernel Initiation Complete, Applications Start** - the top LED remains green, the bottom LED changes to orange.
- ◆ **Zero Touch Provisioning (ZTP)** - if ZTP is initiated on one of the WAN Ethernet ports, the top LED will remain green, and the bottom LED will change to red. If a configuration is successfully acquired via ZTP and installed on the console manager, the bottom LED will flash off, red, off, red, off, red. After this the bottom LED will return to orange.
- ◆ **Boot Complete** - both LEDs change to provide WAN Ethernet port and connectivity module status.

Digital IO Port

The DIO port applies to EMG 8500 only.

The terminal block digital input relay output is located on the front panel of the EMG unit. It provides two digital inputs and one relay output (terminal block) for use with sensors. The DIO port requires an adapter, which is available and sold separately. [Figure 2-15](#) shows the DIO adapter installed on the EMG 8500 with the DIO port pin order and pin definition.

Figure 2-15 Digital I/O Port



Pin Number	Pin Definition
1	Relay Out
2	Relay In
3	Input1+
4	Input1-
5	Input2+
6	Input2-

The DIO connector description is provided below.

Connector	Description
Relay Output	Output supports 1A 24V
Inputs	Inputs accept voltage 0 to 30 VDC. ON: Max 30 VDC Min 2 VDC OFF: Max 0.7 VDC Min 0 VDC

3: EMG 8500 Installation

This chapter provides a high-level procedure for installing the EMG 8500 followed by more detailed information about the EMG connections and power supplies.

Caution: To avoid physical and electrical hazards, please read [Appendix B: Safety Information](#) before installing the EMG.

EMG 8500 Package Contents

The EMG 8500 package includes the following items. Verify and inspect the contents using the enclosed packing slip. If any item is missing or damaged, contact your place of purchase immediately.

Table 3-1 EMG 8500 Parts

Name
One EMG 8500 EDGE MANAGEMENT GATEWAY
RJ45 to DB9F Adapter
RJ45 to RJ45 Cat5 Cable, 6.6 ft (2m) straight-through RJ45 patch
RJ45 Loopback Adapter
External Universal AC (input: 100-240 Vac, 1.5 A, 47-63 Hz output: 12 Vdc, 8.34 A) power supply
North American Power cord - 110V AC power cord, 8 ft (2.43m), RoHS
Note: Power cords for international regions are available and sold separately.
Quick Start Guide

The following user replaceable device modules are available and sold separately.

Table 3-2 EMG 8500 User Replaceable Device Modules

Name
I/O Modules
EMG 8500 FRU, RS232 SERIAL 4-PORT (UART)
EMG 8500 FRU, USB 4-PORT
EMG 8500 FRU, ETHERNET SWITCH 4-PORT
Connectivity Modules
EMG 8500 FRU, LTE, US, Canada, EU
EMG 8500 FRU, LTE, APAC

Additional parts and accessories are available and sold separately. For details and purchasing information, refer to the next section, [Ordering Information](#).

- ◆ External DIO adapter
- ◆ ~~Wall mount kit~~

- ◆ Rail mount kit

Ordering Information

Go to <https://www.lantronix.com/products/lantronix-emg-8500/>.

User Supplied Items

To complete your installation you will need the following items:

- ◆ Medium size Phillips screwdriver to install the mounting brackets to the EMG unit, if applicable
- ◆ One or more serial devices that require network connectivity
- ◆ A serial cable for each serial device.
 - For RJ45 ports, you may use a straight-through RJ45 patch cable to connect to Cisco and Sun RJ45 serial console ports.
 - For USB ports, use a cable with a USB Type A connector
 - For information about Lantronix adapters, see [Appendix C: Adapters and Pinouts](#).
- ◆ An available connection to your network and an Ethernet cable. CAT5E or better cables are recommended for network connections that support rates of 1000 BASE-T.
- ◆ A working AC power outlet to power the unit using the included AC (90W, 100-240V, 50/60 Hz) power supply.
- ◆ If the LTE cellular modem is installed, a network SIM card (and data services) from a service provider

Customize an EMG 8500

Build any combination up to 8 managed console ports and up to two connectivity modules by following these steps:

1. Pick a baseline configuration:
 - ◆ I/O: 4 port RS-232 or 4 port USB or two 4 port RS-232 modules
 - ◆ Connectivity module: Zero or one cellular module
2. Add up to one I/O module or Ethernet switch, and up to two connectivity modules:
 - ◆ I/O: 4 port RS-232, 4 port USB, or 4 port Ethernet switch
 - ◆ Connectivity module: LTE cellular module, Wi-Fi module, or dialup modem
3. Protect the investment with various extended warranty and service options.

Hardware Specifications

Table 3-3 EMG 8500 Technical Specifications

Component	Description
Serial Interface (Device)	◆ Up to 8 RJ45-type 8-conductor connectors ➢ Up to two 4 port RJ45 I/O modules can be installed. ➢ These connectors have individually configurable standard and reversible pinouts. ◆ Speed software selectable (300 to 921600 baud) Note: Serial RJ45 device ports for the EMG are reversed by default.
USB 2.0 Interface (Device)	◆ Up to 8 USB type A (Host) connectors ➢ Up to two 4 port USB I/O modules can be installed. ◆ HS, FS, and LS ◆ Capable of providing VBUS 5V up to 100 mA per port, but not to exceed 400 mA total per 4 port USB I/O module. ◆ May be used with a USB-to-serial adapter to connect a serial device, if needed. Please contact Lantronix for the list of tested adapters. Caution: USB ports are designed for data traffic only. They are not designed for charging or powering devices. Over-current conditions on VBUS 5V may disrupt operations.
Serial Interface (Console)	◆ (1) RJ45-type 8-pin connector (DTE) ◆ Speed software selectable (300 to 921600 baud) ◆ LEDs: ➢ Green light ON indicates data transmission activity ➢ Yellow light ON indicates data receiving activity
Ethernet switch interface	◆ (1) Ethernet switch module can be installed in the front of the unit, providing 4 LAN ports.
Network Interface	◆ (2) 10/100/1000 BASE-T RJ45 WAN ports with LED indicators: ➢ Green light ON indicates a link at 1000 BASE-T. ➢ Green light OFF indicates a link at other speeds or no link. ➢ Yellow light ON indicates a link is established. ➢ Yellow light blinking indicates activity. OR ◆ (2) SFP ports to support standard fiber SFP transceiver modules (single or multi-mode) at speed 1 Gigabit. with LED indicators: ➢ Green light ON indicates a link is established. ➢ Green light OFF indicates no link. ➢ Yellow light steady ON indicates no activity. ➢ Yellow light blinking indicates activity. Note: Either Eth1 or SFP1 are active. Eth1 and SFP1 cannot both be active. The same applies to Eth2 and SFP2.
Connectivity Modules	◆ (2) connectivity slots to support 2 connectivity modules. ➢ One LTE/4G cellular modem ➢ One Wi-Fi module ➢ One dialup modem
Power	◆ Input: 100-240 VAC, 1.5 A, 47-63 Hz ◆ Output: 12 VDC, 8.34 A ◆ 12 VDC power supply shipped with unit
Dimensions (L x W x H)	212.6mm [8.37"] x 167.68mm [6.60"] x 43.21mm [1.70"], 1U
Weight	1.406 kg (3.10 lbs)

Component (continued)	Description
Temperature	- Operating: 0 to 50°C (32 to 122°F) - Storage: -20 to 80°C (-4 to 176°F)
Relative Humidity	- Operating: 10% to 90% non-condensing - Storage: 10% to 90% non-condensing
Front USB Port	(1) port, type A, host USB 2.0 (HS, FS, LS) for use with flash drive
Front Memory Card	(1) Secure Digital (micro SD) memory card slot supporting: - SD - SDHC
Internal Memory	Optional: 128 GB Flash internal storage
Front DIO Port	(1) Digital IO slot with two digital inputs and one relay output (terminal block)
LED Indicators	- Front panel upper LED (WAN Ethernet port link and activity) - Front panel lower LED (Connectivity link and activity)
Operating Atmosphere	 For use at altitudes no more than 2000 meters above sea level only.
Caution: EQUIPMENT IS FOR INDOOR USE ONLY!	 For use in non-tropical conditions only.

Physical Installation

The EMG module uses convection cooling to dissipate excess heat.

To install the EMG unit:

1. If you have purchased additional I/O, Ethernet Switch, or Connectivity modules, install these modules.

- ◆ See [I/O Module or Ethernet Switch Module Installation](#)
- ◆ See [Connectivity Module Installation](#).

Warning: *The EMG must be powered off when installing or replacing the modules. Not powering off the device before changing the module will void the manufacturer warranty.*


2. Mount the EMG unit.
 - ◆ If free-standing, attach the adhesive-backed rubber feet to the base of the EMG unit. Place the unit securely on a desktop or other flat horizontal surface.
 - ◆ If rack-mounted, mount the unit securely in a 19-inch rack. See [Rack Mount Installation](#).
 - ◆ If wall-mounted, mount the unit securely on a flat vertical surface. See [Wall Mount Installation](#).
3. Connect the serial device(s) to the EMG unit's device ports. See [Connecting to a Device Port](#).
4. Choose one of the following options:
 - ◆ To configure the EMG using the network, or to monitor serial devices on the network, connect at least one EMG WAN network port to a network. See [Connecting to Network Ports](#).

- ◆ To configure the EMG unit using a dumb terminal or a computer with terminal emulation, connect the terminal or PC to the front panel EMG console port. See [Connecting Terminals](#).
 - 5. Connect the power cord to power on the unit. See [Power Input](#).
 - 6. Wait approximately one minute for the boot process to complete.
- The first time the EMG boots, it attempts to get an IP address from DHCP. To configure the network settings, see [Chapter 5: Quick Setup](#).

Rack Mount Installation

[Figure 3-4](#) shows two possible rack mount configurations.

Figure 3-4 EMG 8500 Rack Mount Dimensions




1. Attach the brackets on the sides of the EMG unit using a screwdriver and the screws provided with the mounting kit.
2. Mount the unit securely in a 19-inch rack.

Warning: *Do not block the air vents on the sides of the EMG module. If you mount the EMG in an enclosed rack, we recommend that the rack have a ventilation fan to provide adequate airflow through the EMG unit.*

Wall Mount Installation

Figure 3-5 shows the wall mount and keyhole mount configuration.

Figure 3-5 EMG 8500 Wall Mount Dimensions



Wall Mount and Keyhole Mount Instructions

Walls Requiring Anchors

These instructions are for mounting the EMG to walls made of solid concrete, block, brick, or plasterboard.

(1) Wall mount:

1. Locate the place where you want to mount the unit and mark four holes using your EMG mount as a guide for the screws. See for the location of the screw holes.
2. Drill four 3/16 inch (4.8 mm) diameter holes at a depth of 1.25 inches (32 mm).
3. Insert the anchors until they are flush with the surface.
4. Thread four pan head top mount screws through the unit mount hole and through the anchor, and tighten them.

(2) Keyhole mount:

1. Locate the place where you want to mount the unit and mark two holes using your EMG mount as a guide for the screws. See for the location of the screw holes.
2. Drill two 3/16 inch (4.8 mm) diameter holes at a depth of 1.25 inches (32 mm).
3. Insert the anchors until they are flush with the surface.
4. Thread two pan head top mount screws through the unit mount hole and through the anchor, and reserve 0.08" to 0.12" (2-3 mm) clearance to the anchor surface.
5. Hang the EMG unit where both keyholes of wall mounts can go through the screw heads on the wall.

Walls Not Requiring Anchors

These instructions are for mounting the EMG to walls made of solid wood at least two (2) inches thick.

(1) Wall mount:

1. Locate the place where you want to mount the unit and mark four holes using your EMG mount as a guide for the screws. See for the location of the screw holes.
2. Drill four 3/16 inch (4.8 mm) diameter holes at a depth of 1.25 inches (32 mm).
3. Thread four pan head top mount screws through the unit mount hole and tighten them.

(2) Keyhole mount:

1. Locate the place where you want to mount the unit and mark two holes using your EMG mount as a guide for the screws. See for the location of the screw holes.
2. Drill two 3/16 inch (4.8 mm) diameter holes at a depth of 1.25 inches (32 mm).
3. Thread two pan head top mount screws through the unit mount hole and reserve 0.08" to 0.12" (2-3 mm) clearance to the wall surface.
4. Hang the EMG unit where both keyholes of wall mounts can go through the screw heads on the wall.

Connecting to a Device Port

You can connect almost any device that has a serial console port to a device port on the EMG unit for remote administration. The console port must support the RS-232C interface.

You may use a CAT5 cable, or a crossover cable if the reverse pinout function is not used.

Note: Many servers must either have the serial port enabled as a console or the keyboard and mouse detached. Consult the server hardware and/or software documentation for more information.

To connect to a serial RJ45 device port:

1. Connect one end of the cable to the device port.
2. Connect the other end of the cable to an RJ45 serial console port on the serial device or use a Lantronix serial console adapter to connect it to other port types.

Notes:

- ◆ See [Device Port Commands](#) to enable or disable reverse pinouts through the CLI.
- ◆ [Table 3-6](#) and [Table 3-7](#) provide additional information on reverse pinouts.
- ◆ See [Appendix C: Adapters and Pinouts](#) for information about Lantronix adapters.

Table 3-6 Console Port and Device Port - Reverse Pinout Disabled

Pin Number	Description
1	RTS (output)
2	DTR (output)
3	TXD (output)
4	Ground
5	Ground
6	RXD (input)
7	DSR (input)
8	CTS (input)

Table 3-7 Device Port - Reverse Pinout Enabled (Default)


Pin Number	Description
1	CTS (input)
2	DSR (input)
3	RXD (input)
4	Ground
5	Ground
6	TXD (output)
7	DTR (output)
8	RTS (output)

To connect to a USB device port:

1. Connect the USB type A connector of a USB cable to a device port.
2. Connect the other end of the USB cable to a USB console port.

Figure 3-8 shows a sample I/O module installation with one 4-port USB I/O module in Bay 1 and one 4-port RJ45 I/O module in Bay 2, and how the device ports correspond to the buttons on the Web Manager [Dashboard](#).

Figure 3-8 Sample Device Port Connections (Front Side)

**Connecting to Network Ports**

The WAN network ports allow remote access to the attached devices and the system administrative functions. Use a standard RJ45-terminated Ethernet patch cable to connect to the network port. A CAT5e or better cable is recommended for use with a link at 1000 BASE-T.

Connecting Terminals

The console port is for local access to the EMG and the attached devices. You may attach a dumb terminal or a computer with terminal emulation to the console port. The EMG console port uses RS-232C protocol and supports VT100 emulation. The default serial settings are:

- ◆ 9600 baud
- ◆ 8 bit data
- ◆ No parity
- ◆ 1 stop bit
- ◆ No flow control

To connect the console port to a terminal or computer with terminal emulation, Lantronix offers optional adapters that provide a connection between an RJ45 jack and a DB9 or DB25 connector. The console port is configured as DTE (non-reversed RJ45). See [Appendix C: Adapters and Pinouts](#) for more information.

To connect a terminal:

1. Attach the Lantronix adapter to your terminal (typically a PN 200.2066A adapter - see [Figure C-1](#)) or your PC's serial port (use PN 200.2070A adapter - see [Figure C-4](#)).
2. Connect the Cat 5 cable to the adapter, and connect the other end to the EMG console port.
3. Turn on the terminal or start your computer's communication program (e.g., PuTTY or TeraTerm Pro).
4. Once the EMG is running, press **Enter** to establish connection. You should see the model name and a login prompt on your terminal.
5. Log in with the default user name **sysadmin** and the last 8 characters of the Device ID (for newly manufactured units that come installed with 8.2.0.1 or later) or **PASS** (for all older units) as the password.

Note: The Device ID can be found on the product label on the unit or in the boot messages on the console.

Note: For security purposes, we recommend that you change the default password and choose a strong password.

Power Input

The EMG has a DC input jack connector for applying 9 to 30V DC. The EMG ships with an external 100 to 200VAC 50/60Hz to 12V DC power supply brick for supplying power to the DC input jack.

Warning: *Risk of serious electric shock! Disconnect the power cord before servicing the EMG.*


Warning: *Power cord shall be connected to a socket-outlet with earthing connection.*

Warning: *Risk of explosion if battery is replaced by an incorrect type. Dispose of expended battery in accordance with local disposal regulations.*

Note: This product is intended to be used with a UL Listed Optical Transceiver product, Rated 3.3Vdc or 5Vdc, Laser Class 1.

Note: To reduce potential safety issues, only the AC adapter provided with the product, a replacement AC adapter provided by Lantronix or agency, or an AC adapter purchased as an accessory from Lantronix or agency should be used with this product.

Figure 3-9 Power Input



Modular Expansion for I/O Module Bays

The EMG module configuration can be changed by adding or replacing I/O modules in the I/O module bays. When populating the bays, Bay 1 and Bay 2 may be populated in any order and one module may be left empty. The bays are ordered from left to right: Bay 1 is the slot next to the console port and USB port and Bay 2 is the slot to the right of Bay 1. See [Figure 3-8](#).

An Ethernet Switch module may be added, replacing one of the I/O modules. When installing an Ethernet Switch module, Bay 1 must be populated with an I/O module and Bay 2 must be populated with the Ethernet Switch module.

[Figure 3-10](#) shows the available I/O module configurations.

Any changes to the module configuration must be done while the EMG unit is powered off. To install a module in the I/O module bays, see [I/O Module or Ethernet Switch Module Installation](#).


Warning: *The EMG must be powered off when installing or replacing the modules. Not powering off the device before changing the module will void the manufacturer warranty.*

Warning: *Install the RJ45, USB, or Ethernet Switch module on the front only of the EMG unit. Do not insert any other module on the front of the EMG unit. Doing so may damage the EMG unit and will void the manufacturer warranty.*

Figure 3-10 Available I/O Module Configurations for EMG 8500

Examples of I/O Configurations		
Model	Ports	Final Configuration
		Bay 1 Bay2
Standard	4	
Customized	4	
Standard	8	 
Customized	8	 
Customized	8	 
Standard	8	 

-  Standard Model (RJ45 or USB)
-  RJ45 I/O Module
-  USB I/O Module
-  Ethernet Switch Module



I/O Module or Ethernet Switch Module Installation

The EMG module configuration can be changed by adding or replacing RJ45, USB, or Ethernet Switch modules in the I/O module bays.

Warning: *The EMG must be powered off when installing or replacing the modules. Not powering off the device before changing the module will void the manufacturer warranty.*

Warning: *Install the RJ45, USB, or Ethernet Switch module on the front only of the EMG unit. Do not insert any other module on the front of the EMG unit. Doing so may damage the EMG unit and will void the manufacturer warranty.*

To install a module in the I/O module bay:

1. Disconnect the power cord from the EMG unit and from the wall outlet.
2. On the front of the EMG unit, locate the module bay where the module will be inserted.
3. Unscrew the existing module or faceplate from the module bay with your fingers and carefully remove it from the module bay.
4. Insert the module into the module bay making sure the module sits completely and securely in

the housing.



5. The module will sit flush with the EMG chassis.



6. Tighten the screw on the module with your fingers. Be careful not to over tighten it.
7. To verify the new module is recognized, connect power to the EMG, wait for it to boot, and log into the Web Manager. The new module will be displayed in the Dashboard.

Modular Expansion for Connectivity Module Bays

The EMG module configuration can be changed by adding or replacing connectivity modules in the Connectivity module bays. Bay 1 and Bay 2 may be populated in any order and one or both bays may be left empty. The bays are ordered from left to right: Bay 1 is the slot on the left side of the back panel and Bay 2 is the slot to the right of Bay 1.


[Figure 3-11](#) shows a sample connectivity module configuration with one LTE module and how the network interfaces correspond to the buttons on the Web Manager Dashboard.

Any changes to the module configuration must be done while the EMG unit is powered off. To install a connectivity module, refer to [Connectivity Module Installation](#).

Warning: The EMG must be powered off when installing or replacing the modules. Not powering off the device before changing the module will void the manufacturer warranty.

Warning: Install the cellular, Wi-Fi, or dialup modem module on the back only of the EMG unit. Do not insert any other module on the back of the EMG unit. Doing so may damage the EMG unit and will void the manufacturer warranty.

Figure 3-11 Sample Connectivity Module Configuration (Back Side)



Connectivity Module Installation

The EMG module configuration can be changed by adding or replacing cellular, Wi-Fi, or dialup modem modules in the connectivity module bays.

Warning: The EMG must be powered off when installing or replacing the modules. Not powering off the device before changing the module will void the manufacturer warranty.

Warning: Install the cellular, Wi-Fi, or dialup modem module on the back only of the EMG unit. Do not insert any other module on the back of the EMG unit. Doing so may damage the EMG unit and will void the manufacturer warranty.

To install a module in the connectivity module bay:

1. Disconnect the power cord from the EMG unit and from the wall outlet.
2. On the back of the EMG unit, locate the module bay where the module will be inserted.
3. Unscrew the existing module or faceplate from the module bay with your fingers and carefully remove it from the module bay.
4. Insert the module into the module bay making sure the module sits completely and securely in

the housing.



5. The module will sit flush with the EMG chassis.



6. Tighten the screw on the module with your fingers. Be careful not to over tighten it.
7. Insert and screw in the antennas to the module with your fingers.
8. To verify the new module is recognized, connect power to the EMG, wait for it to boot, and log into the Web Manager. The new module will be displayed in the Dashboard.

Modem Installation

Note: Modem installation information applies when the dialup modem module is installed in the EMG unit.



Caution: TO REDUCE THE RISK OF FIRE, USE ONLY NO. 26 AWG OR LARGER (e.g., 24 AWG) UL LISTED OR CSA CERTIFIED TELECOMMUNICATION LINE CORD.

Attention: POUR RÉDUIRE LES RISQUES D'INCENDIE, UTILISER UNIQUEMENT DES CONDUCTEURS DE TÉLÉCOMMUNICATIONS 26 AWG AU DE SECTION SUPÉRIEURE.

Warning: RISK OF ELECTRICAL SHOCKS; DISCONNECT ALL POWER AND PHONE LINES BEFORE SERVICING



Caution: DEVICES INSIDE THE EQUIPMENT AND THE MODEM ARE ELECTROSTATIC -SENSITIVE; DO NOT HANDLE EXCEPT AT A STATIC FREE WORKPLACE.

4: EMG 7500 / EMG 7500W Installation

This chapter provides a high-level procedure for installing the EMG 7500 / EMG 7500W followed by more detailed information about the EMG connections and power supplies.

Caution: To avoid physical and electrical hazards, please read [Appendix B: Safety Information](#) before installing the EMG.

EMG 7500 Package Contents

The EMG 7500 / EMG 7500W package includes the following items. Verify and inspect the contents using the enclosed packing slip. If any item is missing or damaged, contact your place of purchase immediately.

Table 4-1 EMG 7500 Parts

Name
One EMG 7500 / EMG 7500W EDGE MANAGEMENT GATEWAY
RJ45 to DB9F Adapter
RJ45 to RJ45 Cat5 Cable, 6.6 ft (2m) straight-through RJ45 patch
RJ45 Loopback Adapter
External Universal AC (input: 100-240 Vac, 1.5 A, 47-63 Hz output: 12 Vdc, 8.34 A) power supply
North American Power cord - 110V AC power cord, 8 ft (2.43m), RoHS
Note: Power cords for international regions are available and sold separately.
EMG 7500 Quick Start Guide

Additional parts and accessories are available and sold separately. For details and purchasing information, refer to the next section [Ordering Information](#).

- ◆ Wall mount kit
- ◆ Rail mount kit

Ordering Information

Go to <https://www.lantronix.com/products/lantronix-emg-7500/>.

User Supplied Items

To complete your installation you will need the following items:

- ◆ Medium size Phillips screwdriver to install the mounting brackets to the EMG unit, if applicable
- ◆ One or more serial devices that require network connectivity
- ◆ A serial cable for each serial device.
 - For RJ45 ports, you may use a straight-through RJ45 patch cable to connect to Cisco and Sun RJ45 serial console ports.
 - For USB ports, use a cable with a USB Type A connector

- For information about Lantronix adapters, see [Appendix C: Adapters and Pinouts](#).
- ◆ An available connection to your Ethernet network and an Ethernet cable. CAT5E or better cables are recommended for 1000 BASE-T.
- ◆ An AC power outlet to power the unit using the included AC (90W, 100-240V, 50/60 Hz) power supply.
- ◆ If the LTE cellular modem is installed, a network SIM card (and data services) from a service provider

Hardware Specifications

Table 4-2 EMG 7500 Technical Specifications

Component	Description
Serial Interface (Device)	◆ Up to 8 RJ45-type 8-conductor connectors, on two 4-port RJ45 I/O modules ➢ These connectors have individually configurable standard and reversible pinouts. ◆ Speed software selectable (300 to 921600 baud) Note: Serial RJ45 device ports are reversed by default.
USB 2.0 Interface (Device)	◆ Up to 8 USB type A (Host) connectors, on two 4-port USB I/O modules ◆ HS, FS, and LS ◆ Capable of providing VBUS 5V up to 100 mA per port, but not to exceed 400 mA total per 4 port USB I/O module. ◆ May be used with a USB-to-serial adapter to connect a serial device, if needed. Please contact Lantronix for the list of tested adapters. Caution: USB ports are designed for data traffic only. They are not designed for charging or powering devices. Over-current conditions on VBUS 5V may disrupt operations.
Serial Interface (Console)	◆ (1) RJ45-type 8-pin connector (DTE) ◆ Speed software selectable (300 to 921600 baud) ◆ LEDs: ➢ Green light ON indicates data transmission activity ➢ Yellow light ON indicates data receiving activity
Network Interface	◆ (2) 10/100/1000 BASE-T RJ45 WAN ports with LED indicators: ➢ Green light ON indicates a link at 1000 BASE-T. ➢ Green light OFF indicates a link at other speeds or no link. ➢ Yellow light ON indicates a link is established. ➢ Yellow light blinking indicates activity.
Connectivity Modules	◆ One internal LTE/4G cellular modem ◆ One Wi-Fi module or one dialup modem (optional configuration)
Power	◆ Input: 100-240 VAC, 1.5 A, 47-63 Hz ◆ Output: 12 VDC, 8.34 A ◆ 12 VDC power supply shipped with unit
Dimensions	163mm [6.4in] x 145mm [5.7in] x 43mm [1.7in], 1U
Weight	2.5 lbs
Temperature	◆ Operating: 0 to 50°C (32 to 122°F) ◆ Storage: -20 to 80°C (-4 to 176°F)
Relative Humidity	◆ Operating: 10% to 90% non-condensing ◆ Storage: 10% to 90% non-condensing

Component (continued)	Description
Front USB Port	◆ (1) port, type A, host USB 2.0 (HS, FS, LS) for use with flash drive
Rear Memory Card	◆ (1) Secure Digital (micro SD) memory card slot supporting: ➢ SD ➢ SDHC
LED Indicators	◆ Front panel LED 1 (WAN Ethernet port link and activity) ◆ Front panel LED 2 (Connectivity link and activity)
Operating Atmosphere	 For use at altitudes no more than 2000 meters above sea level only.  For use in non-tropical conditions only.
Caution: EQUIPMENT IS FOR INDOOR USE ONLY!	

Physical Installation

The EMG unit uses convection cooling to dissipate excess heat.

To install the EMG unit:

- Mount the EMG unit.
 - ◆ If free-standing, attach the adhesive-backed rubber feet to the base of the EMG unit. Place the unit securely on a desktop or other flat horizontal surface.
 - ◆ If rack-mounted, mount the unit securely in a 19-inch rack. See [Rack Mount Installation](#).
 - ◆ If wall-mounted, mount the unit securely on a flat vertical surface. [Wall Mount Installation](#).
- Connect the serial device(s) to the EMG unit's device ports. See [Connecting to a Device Port](#).
- Choose one of the following options:
 - ◆ To configure the EMG using the network, or to monitor serial devices on the network, connect at least one EMG network port to a network. See [Connecting to Network Ports](#).
 - ◆ To configure the EMG unit using a dumb terminal or a computer with terminal emulation, connect the terminal or PC to the front panel EMG console port. See [Connecting Terminals](#).
- Connect the power cord to power on the unit. See [Power Input](#).
- Wait approximately one minute for the boot process to complete.

The first time the EMG boots, it attempts to get an IP address from DHCP. To configure the network settings, see [Chapter 5: Quick Setup](#).

Rack Mount Installation

Figure 4-3 shows two possible rack mount configurations. Figure 4-4 shows the rack mount screw placement.

Figure 4-3 EMG 7500 Rack Mount Configurations





Figure 4-4 EMG 7500 Rack Mount Screw Placement




1. Attach the brackets on the sides of the EMG unit using a screwdriver and the screws provided with the mounting kit.
2. Mount the unit securely in a 19-inch rack.

Warning: Do not block the air vents on the sides of the EMG module. If you mount the EMG in an enclosed rack, we recommend that the rack have a ventilation fan to provide adequate airflow through the EMG unit.

Wall Mount Installation

Figure 4-5 shows the wall mount and keyhole mount configuration.

Figure 4-5 Wall Mount Configuration



Wall Mount and Keyhole Mount Instructions

Walls Requiring Anchors

These instructions are for mounting the EMG to walls made of solid concrete, block, brick, or plasterboard with anchors.

(1) Wall mount:

1. Locate the place where you want to mount the unit and mark four holes using your EMG mount as a guide for the screws. See for the location of the screw holes.
2. Drill four 3/16 inch (4.8 mm) diameter holes at a depth of 1.25 inches (32 mm).
3. Insert the anchors until they are flush with the surface.
4. Thread four pan head top mount screws through the unit mount hole and through the anchor, and tighten them.

(2) Keyhole mount:

1. Locate the place where you want to mount the unit and mark two holes using your EMG mount as a guide for the screws. See for the location of the screw holes.
2. Drill two 3/16 inch (4.8 mm) diameter holes at a depth of 1.25 inches (32 mm).
3. Insert the anchors until they are flush with the surface.
4. Thread two pan head top mount screws through the unit mount hole and through the anchor, and reserve 0.08" to 0.12" (2-3 mm) clearance to the anchor surface.
5. Hang the EMG unit where both keyholes of wall mounts can go through the screw heads on the wall.

Walls Not Requiring Anchors

These instructions are for mounting the EMG to walls made of solid wood at least two (2) inches thick.

(1) Wall mount:

1. Locate the place where you want to mount the unit and mark four holes using your EMG mount as a guide for the screws. See for the location of the screw holes.
2. Drill four 3/16 inch (4.8 mm) diameter holes at a depth of 1.25 inches (32 mm).
3. Thread four pan head top mount screws through the unit mount hole and tighten them.

(2) Keyhole mount:

1. Locate the place where you want to mount the unit and mark two holes using your EMG mount as a guide for the screws. See for the location of the screw holes.
2. Drill two 3/16 inch (4.8 mm) diameter holes at a depth of 1.25 inches (32 mm).
3. Thread two pan head top mount screws through the unit mount hole and reserve 0.08" to 0.12" (2-3 mm) clearance to the wall surface.
4. Hang the EMG unit where both keyholes of wall mounts can go through the screw heads on the wall.

Connecting to a Device Port

You can connect almost any device that has a serial console port to a device port on the EMG unit for remote administration. The console port must support the RS-232C interface.

You may use a CAT5 cable, or a crossover cable if the reverse pinout function is not used.

Note: Many servers must either have the serial port enabled as a console or the keyboard and mouse detached. Consult the server hardware and/or software documentation for more information.

To connect to a serial RJ45 device port:

1. Connect one end of the cable to the device port.
2. Connect the other end of the cable to an RJ45 serial console port on the serial device or use a Lantronix serial console adapter to connect it to other port types.

Notes:

- ◆ See [Device Port Commands](#) to enable or disable reverse pinouts through the CLI.
- ◆ [Table 4-6](#) and [Table 4-7](#) provide additional information on reverse pinouts.
- ◆ See [Appendix C: Adapters and Pinouts](#) for information about Lantronix adapters.

Table 4-6 Console Port and Device Port - Reverse Pinout Disabled


Pin Number	Description
1	RTS (output)
2	DTR (output)
3	TXD (output)
4	Ground

Pin Number	Description
5	Ground
6	RXD (input)
7	DSR (input)
8	CTS (input)

Table 4-7 Device Port - Reverse Pinout Enabled (Default)

Pin Number	Description
1	CTS (input)
2	DSR (input)
3	RXD (input)
4	Ground
5	Ground
6	TXD (output)
7	DTR (output)
8	RTS (output)

Figure 4-8 shows the front side of an EMG 7500 with a 4-port RJ45 device port module.

Figure 4-8 EMG 7500 (Front Side)

To connect to a USB device port:

1. Connect the USB type A connector of a USB cable to a device port.
2. Connect the other end of the USB cable to a USB console port.

Connecting to Network Ports

The WAN network ports allow remote access to the attached devices and the system administrative functions. Use a standard RJ45-terminated Ethernet patch cable to connect to the network port. A CAT5e or better cable is recommended for use with a link at 1000 BASE-T.

Connecting Terminals

The console port is for local access to the EMG and the attached devices. You may attach a dumb terminal or a computer with terminal emulation to the console port. The EMG console port uses RS-232C protocol and supports VT100 emulation. The default serial settings are:

- ◆ 9600 baud
- ◆ 8 bit data
- ◆ No parity
- ◆ 1 stop bit
- ◆ No flow control

To connect the console port to a terminal or computer with terminal emulation, Lantronix offers optional adapters that provide a connection between an RJ45 jack and a DB9 or DB25 connector. The console port is configured as DTE (non-reversed RJ45). See [Appendix C: Adapters and Pinouts](#) for more information.

To connect a terminal:

1. Attach the Lantronix adapter to your terminal (typically a PN 200.2066A adapter - see [Figure C-1](#)) or your PC's serial port (use PN 200. adapter - see [Figure C-4](#)).
2. Connect the Cat 5 cable to the adapter, and connect the other end to the EMG console port.
3. Turn on the terminal or start your computer's communication program (e.g., PuTTY or TeraTerm Pro).
4. Once the EMG is running, press **Enter** to establish connection. You should see the model name and a login prompt on your terminal.
5. On a factory default EMG log in with the default user name **sysadmin** and the last 8 characters of the Device ID as the password.

Note: For security purposes, we recommend that you change the default password and choose a strong password.

Power Input

The EMG 7500 / EMG 7500W unit has a DC input jack connector for applying 9 to 30 VDC. The unit ships with an external AC (90W, 100-240V, 50/60 Hz) 12 VDC power supply. (See [EMG 7500 Package Contents](#).)


Warning: *Risk of serious electric shock! Disconnect the power cord before servicing the EMG.*

Figure 4-9 EMG 7500 / EMG 7500W Power Input



Pin assignments

- Pin 1: Input voltage 9-30 VDC
- Pin 2: reserved
- Pin 3: Ground
- Pin 4: Earth Ground



Modem Installation

Note: Modem installation information applies when the dialup modem module is installed in the EMG unit.



Caution: TO REDUCE THE RISK OF FIRE, USE ONLY NO. 26 AWG OR LARGER (e.g., 24 AWG) UL LISTED OR CSA CERTIFIED TELECOMMUNICATION LINE CORD.

Attention: POUR RÉDUIRE LES RISQUES D'INCENDIE, UTILISER UNIQUEMENT DES CONDUCTEURS DE TÉLÉCOMMUNICATIONS 26 AWG AU DE SECTION SUPÉRIEURE.

Warning: RISK OF ELECTRICAL SHOCKS; DISCONNECT ALL POWER AND PHONE LINES BEFORE SERVICING!



Caution: DEVICES INSIDE THE EQUIPMENT AND THE MODEM ARE ELECTROSTATIC -SENSITIVE; DO NOT HANDLE EXCEPT AT A STATIC FREE WORKPLACE.

5: Quick Setup

This chapter helps get the IP network port up and running, so you can administer the EMG using your network.

Recommendations

To set up the network connections, we suggest you do one of the following:

- ◆ Complete the Quick Setup (see [Figure 5-2](#)) on the web interface.
- ◆ SSH to the command line interface and follow the Quick Setup script on the command line interface.
- ◆ Connect to the console port and follow the Quick Setup script on the command line interface.

Note: The first time you power up the EMG unit, Eth1 tries to obtain its IP address via DHCP. If you have connected Eth1 to the network, and Eth1 is able to acquire an IP address, you can view this IP address by running the [Lantronix Provisioning Manager](#) application. If Eth1 cannot acquire an IP address, you cannot use Telnet, SSH, or the web interface to run Quick Setup.

IP Address

Your EMG must have a unique IP address on your network. The system administrator generally provides the IP address and corresponding subnet mask and gateway. The IP address must be within a valid range and unique to your network. If a valid gateway address has not been assigned the IP address must be on the same subnet as workstations connecting to the EMG over the network.

The following table lists the options for assigning an IP address to your EMG unit.

Table 5-1 Methods of Assigning an IP Address

Method	Description
DHCP	A DHCP server automatically assigns the IP address and network settings. The EMG is DHCP-enabled by default. With the Eth1 network port connected to the network, and the EMG unit powered up, Eth1 acquires an IP address. At this point, you can use SSH or use the web interface to connect to the EMG.
BOOTP	Non-dynamic predecessor to DHCP.
Serial port login to command line interface	You assign an IP address and configure the EMG unit using a terminal or a PC running a terminal emulation program to the EMG serial console port connection.

Lantronix Provisioning Manager

You may use the Lantronix Provisioning Manager application to locate a device and view its properties and details such as its IP address. Lantronix Provisioning Manager is a free utility program provided by Lantronix that discovers, configures, upgrades, and manages Lantronix devices. It can be downloaded from the Lantronix website at <https://www.lantronix.com/products/lantronix-provisioning-manager/>. For instructions on using the application, see the Lantronix Provisioning Manager online help.

To install Lantronix Provisioning Manager:

1. Download the latest version of Lantronix Provisioning Manager from <https://www.lantronix.com/products/lantronix-provisioning-manager/>.
2. In most cases, you can simply extract the application from the archive and run the executable.

To access EMG using Lantronix Provisioning Manager:

Note: For detailed instructions, see the Lantronix Provisioning Manager [online help](#).

1. Launch Lantronix Provisioning Manager:
2. If this is the first time you have launched Lantronix Provisioning Manager, you may need to proceed through an initial setup.
3. Locate the EMG in the device list. The device's firmware version, serial number, IP address, and MAC address will be shown. Additional information can be obtained by clicking the three dot menu and clicking **Get Device Info**.
4. In order to perform operations on the EMG such as upgrading the firmware, updating the configuration, or uploading to the file system, click the checkbox next to the device, click the menu button at the top and select an operation.

Method #1 Quick Setup on the Web Page

After the unit has an IP address, you can use the [Quick Setup](#) page to configure the remaining network settings. This page displays the first time you log into the EMG only. Otherwise, the EMG [Home](#) page displays.

To complete the Quick Setup page:

1. Open a web browser (Firefox, Chrome or Internet Explorer web browsers with the latest browser updates).
2. In the URL field, type `https://` followed by the IP address of your EMG.

Note: The web server listens for requests on the encrypted (HTTPS) port (port 443).

- Log in using `sysadmin` as the user name and the last 8 characters of the Device ID (for newly manufactured units that come installed with 8.2.0.1 or later) or `PASS` (for older units) as the password. The first time you log in to the EMG unit, the [Quick Setup](#) page automatically displays.

Note: If the Device ID is not set, the default system password is the last 8 characters of the serial number.

Figure 5-2 Quick Setup

LANTRONIX[®] EMG851000

Logout Host: `emgfcf0` User: `sysadmin` Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance **Quick Setup**

Quick Setup [Help?](#)

Welcome to the Lantronix Edge Management Gateway

Below are basic settings that it is recommended you configure before using the Lantronix Edge Management Gateway.
If these settings are OK, click the checkbox below and select the Apply button.

☐ Accept default Quick Setup settings

Network Settings

Eth1 Settings: ☒ Obtain from DHCP ☐ Obtain from BOOTP ☐ Specify:

IP Address: Subnet Mask:

The EMG has two Ethernet ports, Eth1 and Eth2.
By default, both Eth1 and Eth2 are configured for DHCP.

Default Gateway:

Hostname: `emgfcf0`

Note: The hostname will be used as the prompt in the Command Line Interface.

Domain:

Date & Time Settings

Change Date/Time: ☐

Date: `August` `8` `2019`

Time: `06` `14` `pm`

Time Zone: `GMT`

Administrator Settings

The `sysadmin` user has complete privileges for EMG administration.
The default password is 'PASS'.

Sysadmin Password:

Retype Password:

- To accept the defaults, select the **Accept default Quick Setup settings** checkbox on the top portion of the page and click the **Apply** button at the bottom of the page. Otherwise, continue with step 5.

Note: Once you click the **Apply** button on the [Quick Setup](#) page, you can continue using the web interface to configure the EMG further.

- Enter the following settings:

Network Settings

Note: Configurations with the same IP subnet on multiple interfaces (Ethernet or PPP) are not currently supported.

Network Setting	Description
Eth 1 Settings	◆ Obtain from DHCP: Acquires IP address, subnet mask, hostname and gateway from the DHCP server. (The DHCP server may not provide the hostname gateway, depending on its setup.) This is the default setting. If you select this option, skip to Gateway. ◆ Obtain from BOOTP: Lets a network node request configuration information from a BOOTP "server" node. If you select this option, skip to Gateway. ◆ Specify: Lets you manually assign a static IP address, generally provided by the system administrator.
IP Address (if specifying)	◆ Enter an IP address that is unique and valid on your network. There is no default. ◆ Enter all IP addresses in dot-quad notation. Do not use leading zeros in the fields for dot-quad numbers less than 100. For example, if your IP address is 172.19.201.28, do not enter 028 for the last segment octet. Note: Currently, the EMG does not support configurations with the same IP subnet on multiple interfaces (Ethernet or PPP).
Subnet Mask	If specifying an IP address, enter the subnet mask for the network on which the EMG unit resides. There is no default.
Default Gateway	The IP address of the router for this network. There is no default.
Hostname	The default host name is emgXXXX, where XXXX is the last 4 characters of the hardware address of Ethernet Port 1. There is a 64-character limit (contiguous characters, no spaces). Note: The host name becomes the prompt in the command line interface.
Domain	If desired, specify a domain name (for example, support.lantronix.com). The domain name is used for host name resolution within the EMG. For example, if abcd is specified for the SMTP server, and mydomain.com is specified for the domain, if abcd cannot be resolved, the EMG unit attempts to resolve abcd.mydomain.com for the SMTP server.

Date & Time Settings


Date & Time Setting	Description
Change Date/Time	Select the checkbox to manually enter the date and time at the EMG unit's location.
Date	From the drop-down lists, select the current month, day, and year.
Time	From the drop-down lists, select the current hour and minute.
Time Zone	From the drop-down list, select the appropriate time zone.

Administrator Settings

Administrator Setting	Description
Sysadmin Password	To change the password (e.g., from the default) enter a Sysadmin Password of up to 64 characters. <i>Note: As a security measure, we recommend that you change the default sysadmin password initially and then change the password periodically.</i>
Retype Password	Re-enter the Sysadmin Password above in this field as a confirmation.


6. Click the **Apply** button to save your entries.

Figure 5-3 Quick Setup Completed in Web Manager



If Quick Setup has already been run the standard Home page will display.

Figure 5-4 Home



Welcome to the Lantronix Edge Management Gateway



Method #2 Quick Setup on the Command Line Interface

If the EMG does not have an IP address, you can connect a dumb terminal or a PC running a terminal emulation program (VT100) to access the command line interface. (See [Connecting Terminals](#).) If the unit has an IP address, you can use SSH or Telnet to connect to the EMG unit.

By default, Telnet is disabled and SSH is enabled. To enable Telnet, use the [Figure 8-1 Services > SSH/Telnet/Logging](#).

To complete the command line interface Quick Setup script:

1. Do one of the following:
 - With a serial terminal connection, power up, and when the command line displays, press **Enter**.
 - With a network connection, use an SSH client or Telnet program (if Telnet has been enabled) to connect to `xx.xx.xx.xx` (the IP address in dot quad notation), and press **Enter**. You should be at the login prompt.
2. Enter `sysadmin` as the user name and press **Enter**.
3. Enter the last 8 characters of the Device ID (for newly manufactured units that come installed with 8.2.0.1 or later) or `PASS` as the password and press **Enter**. The first time you log in, the Quick Setup script runs automatically. Normally, the command prompt displays.

Note: If the Device ID is not set, the default system password is the last 8 characters of the serial number.

Figure 5-5 Beginning of Quick Setup Script

```
Welcome to the Lantronix Edge Management Gateway
Model Number: EMG851000
```

Quick Setup will now step you through configuring a few basic settings.

The current settings are shown in brackets ('[]').
You can accept the current setting for each question by pressing
<return>.

4. Enter the following information at the prompts:

Note: To accept a default or to skip an entry that is not required, press **Enter**.

CLI Quick Setup Settings	Description
Configure Eth1	Select one of the following: ◆ (1) obtain IP Address from DHCP: The unit will acquire the IP address, subnet mask, hostname, and gateway from the DHCP server. (The DHCP server may or may not provide the gateway and hostname, depending on its setup.) This is the default setting. ◆ (2) obtain IP Address from BOOTP: Permits a network node to request configuration information from a BOOTP "server" node. ◆ (3) static IP Address: Allows you to assign a static IP address manually. The IP address is generally provided by the system administrator.

CLI Quick Setup Settings	Description
IP Address (if specifying)	An IP address that is unique and valid on your network and in the same subnet as your PC. There is no default. If you selected DHCP or BOOTP, this prompt does not display. Enter all IP addresses in dot-quad notation. Do not use leading zeros in the fields for dot-quad numbers less than 100. For example, if your IP address is 172.19.201.28, do not enter 028 for the last octet. Note: Configurations with the same IP subnet on multiple interfaces (Ethernet or PPP) are not currently supported.
Subnet Mask	The subnet mask specifies the network segment on which the EMG resides. There is no default. If you selected DHCP or BOOTP, this prompt does not display.
Default Gateway	IP address of the router for this network. There is no default.
Hostname	The default host name is emgXXXX, where XXXX is the last 4 characters of the hardware address of Ethernet Port 1. There is a 64-character limit (contiguous characters, no spaces). Note: The host name becomes the prompt in the command line interface.
Domain	If desired, specify a domain name (for example, support.lantronix.com). The domain name is used for host name resolution within the EMG unit. For example, if abcd is specified for the SMTP server, and mydomain.com is specified for the domain, if abcd cannot be resolved, the EMG attempts to resolve abcd.mydomain.com for the SMTP server.
Time Zone	If the time zone displayed is incorrect, enter the correct time zone and press Enter . If the entry is not a valid time zone, the system guides you through selecting a time zone. A list of valid regions and countries displays. At the prompts, enter the correct region and country.
Date/Time	If the date and time displayed are correct, type n and continue. If the date and time are incorrect, type y and enter the correct date and time in the formats shown at the prompts.
Sysadmin password	Enter a new sysadmin password. Note: As a security measure, we recommend that you change the default sysadmin password initially and then change the password periodically.

After you complete the Quick Setup script, the changes take effect immediately.

Figure 5-6 Quick Setup Completed in CLI

```
Welcome to the Lantronix Edge Management Gateway
Model Number: EMG851000
```

Quick Setup will now step you through configuring a few basic settings.

```
The current settings are shown in brackets ('[]').
You can accept the current setting for each question by pressing
<return>.
```

```
____ Ethernet Port and Default Gateway ____
The EMG851000 has two ethernet ports, Eth1 and Eth2.
By default, both ports are configured for DHCP.
Configure Eth1: (1) obtain IP Address from DHCP
                (2) obtain IP Address from BOOTP
```

```

(3) static IP Address

Enter 1-3: [1]

The EMG851000 can be configured to use a default gateway.
Enter gateway IP Address: [none]

____Hostname____
The current hostname is 'emgfcf0', and the current domain is
'<undefined>'.
The hostname will be shown in the CLI prompt.
Specify a hostname: [emgfcf0]
Specify a domain: [<undefined>]

____Time Zone____

The current time zone is 'GMT'.
Enter time zone: [GMT]

____Date/Time____
The current time is Wed Jul 3 14:23:24 2019
Change the current time? [n]

____Sysadmin Password____
Enter new password: [<current password>]

Quick Setup is now complete.

For a list of commands, type 'help'.

[emgfcf0]>

```

Next Step

After completing quick setup on the EMG, you may want to configure other settings. You can use the web page or the command line interface for configuration.

- ◆ For information about the web and the command line interfaces, go to [Chapter 6: Web and Command Line Interfaces](#).
- ◆ To continue configuring the EMG unit, go to [Chapter 7: Networking](#).

Limiting Sysadmin User Access

For security purposes, full administrative access to the EMG via the default sysadmin local user account can be limited to only the front console port of the EMG device.

These steps will prevent any local users from logging in, restrict the default sysadmin local user to the front console port, and allow a user with administrative rights to login, as long as remote authentication is working.

To configure limited sysadmin user access:

1. Enable the Sysadmin access limited to Console Port option on the Local/Remote Users web page.
2. Enable a remote authentication method (such as TACACS+ or LDAP) and configure the remote authentication method to be first in the order of methods used.
3. Create a remote user account with full administrative rights.
4. Clear the **Attempt next method on authentication rejection** check box on the Authentication Methods web page.

6: Web and Command Line Interfaces

The EMG offers a web interface (Web Manager) and a command line interface (CLI) for configuring the EMG unit.

Note: See [Chapter 5: Quick Setup](#) for instructions on configuring basic network settings using the Web Manager and CLI quick setup.

Web Manager

A Web Manager allows the system administrator and other authorized users to configure and manage the EMG using most web browsers (Firefox, Chrome, Safari or Internet Explorer web applications with the latest browser updates). The EMG unit provides a secure, encrypted web interface over TLS (transport layer security).

The following figure shows a typical web page for an EMG (model shown is EMG851300, with 4 RJ45 device ports and one 4-port Ethernet switch):

Figure 6-1 Web Page Layout

Logout Button

LANTRONIX[®] EMG851300

Host: emgfcf0
User: sysadmin

Select port for: ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Dashboard

Icons

Help Button

Options

Entry Fields and Options

Network Settings

Ethernet Interfaces

Eth1 Settings:

- ☐ Disabled
- ☐ Obtain from DHCP
- ☐ Obtain from BOOTP
- ☒ Specify:

IP Address:

Subnet Mask: 255.255.0.0

IPv6 Address: (Static)

IPv6 Address: (Link Local)

Mode: Auto

MTU: 1500

Active Port: RJ45

HW Address: 00:80:a3:8b:fc:f0

Multicast: 239.255.255.251

Eth1 Link: Up

Enable IPv6: ☐

IP Forwarding: ☐

IPv6 Forwarding: ☐

Eth2 Settings:

- ☐ Disabled
- ☒ Obtain from DHCP
- ☐ Obtain from BOOTP
- ☐ Specify:

IP Address:

Subnet Mask:

IPv6 Address: (Static)

IPv6 Address: (Link Local)

Mode: Auto

MTU: 1500

Active Port: RJ45

HW Address: 00:80:a3:8b:fc:f1

Multicast: 224.0.0.1

Eth2 Link: Up

Reverse Path Filter: ☐

Ethernet Bonding: Disable

[Ethernet Bonding Status](#)

[SFP NIC Info & Diagnostics](#)

Hostname & Name Servers

Hostname: emgfcf0

Note: The hostname will be used as the prompt in the Command Line Interface.

Domain:

DNS Servers (active are green)

#1:

#2:

#3:

Prefer IPv4 DNS Records: ☒

TCP Keepalive Parameters

Start Probes: 600 secs

Number of Probes: 5

Interval: 60 secs

	Rx				Tx		
	Bytes	Packets	Errors	Multicast	Bytes	Packets	Errors
Eth1	99658501	810764	0	0	21422282	107893	0
Eth2	0	0	0	0	5772456	17443	0

The web page has the following components:


- ◆ **Tabs:** Groups of settings to configure.
- ◆ **Options:** Below each tab are options for specific types of settings.

Note: Only those options for which the currently logged-in user has rights display.

◆ Dashboard

The Dashboard buttons allow you to view and configure EMG ports and interfaces. The appearance of the dashboard will vary according to the I/O and connectivity modules installed in the EMG and the type of network interface installed. See [System Features](#).

Figure 6-2 Sample Dashboard



The dashboard buttons are defined below:

	Cellular connectivity settings for the LTE cellular module (if installed). See Cellular Modem Settings on page 100 .
	DIO port settings. See DIO Port on page 246 .
	Internal modem settings (if installed). See Internal Modem on page 242 .
	Wi-Fi connectivity settings for the Wi-Fi module (if installed). See Wireless Settings on page 107 .
	USB device (flash drive or modem) plugged into the front panel USB connector. See Chapter 9: USB/SD Card Port .
	SD card settings. See Chapter 9: USB/SD Card Port .
	Network settings for the WAN Ethernet port. See Network Port Settings on page 83 .
	Network settings for the SFP transceiver port. See Network Port Settings on page 83 .
	Device port settings for RJ45 device ports (if installed). Only ports to which the currently logged-in user has rights are enabled. See Device Ports - Settings on page 218 .
	Device port settings for USB device ports (if installed). Only ports to which the currently logged-in user has rights are enabled. See Device Ports - Settings on page 218 .



Ethernet Switch LAN port settings (if installed). Only ports to which the currently logged-in user has rights are enabled. See [Ethernet Switch on page 121](#).

- ◆ **Dashboard Options:** Options for use with the device port buttons.
 - Select a port and the **Configuration** option: displays the [Device Ports > Settings \(1 of 2\)](#) page.
 - Select a port and the **WebSSH** option: displays the WebSSH window for the device port - if Web SSH is enabled, and if SSH is enabled for the device port.
 - Select a port and the **Connected Device** option: allows access to supported devices such as remote power managers (RPMs) and/or SensorSoft temperature and humidity probes connected to the device port.
- ◆ **Entry Fields and Options:** Allow you to enter data and select options for the settings.

Note: For specific instructions on completing the fields on the web pages, see Chapters 7 through 15.

- ◆ **Apply Button:** The Apply button (not shown in [Figure 6-1 Web Page Layout](#)) on each web page makes the changes immediately and saves them so they will be there when the EMG is rebooted.
- ◆ **Icons:** The icon bar above the Main Menu has icons that display the following:
 - Home page.
 - Information about the EMG unit and Lantronix contact information.
 - Configuration site map.
 - Status of the EMG.
- ◆ **Help Button:** Provides online Help for the specific web page.

Logging in

Only the system administrator or users with web access rights can log into the Web Manager. More than one user at a time can log in, but the same user cannot log in more than once.

To log in to the Web Manager:

1. Open a web browser.
2. In the URL field, type `https://` followed by the IP address of your EMG.
3. To configure the EMG unit, use `sysadmin` as the user name and the last 8 characters of the Device ID (for newly manufactured units that come installed with 8.2.0.1 or later) or `PASS` (for all older units) as the password. (These are the default values.)

Note: If the Device ID is not set, the default system password is the last 8 characters of the serial number.

Note: The system administrator may have changed the password using one of the Quick Setup methods in the previous chapter.

The [Quick Setup](#) page displays automatically the first time you log in. Subsequently, the Home page displays. (If you want to display the [Quick Setup](#) page again, click **Quick Setup** on the main menu.)

Logging Out

To log off the EMG web interface:

1. Click the **Logout** button located on the upper left part of any Web Manager page. You are brought back to the login screen when logout is complete.

Web Page Help

To view detailed information about an EMG web page:

1. Click the **Help** button to the right of any Web Manager page. Online Help contents will appear in a new browser window.

Command Line Interface

A command line interface (CLI) is available for entering all the commands you can use with the EMG. In this user guide, after each section of instructions for using the web interface, you will find a link to the equivalent CLI commands. You can access the command line interface using Telnet, SSH, or a serial terminal connection.

Note: By default, Telnet is disabled and SSH is enabled. To enable Telnet, use the [Services > SSH/Telnet/Logging](#) web page, a serial terminal connection, or an SSH connection. (See [Chapter 8: Services](#).)

The sysadmin user and users with full administrative rights have access to the complete command set, while all other users have access to a reduced command set based on their permissions.

Logging In

To log in to the EMG command line interface:

1. Do one of the following:
 - With a serial terminal connection, power up, and when the command line displays, press **Enter**.
 - If the EMG already has an IP address (assigned previously or assigned by DHCP), Telnet (if Telnet has been enabled) or SSH to `xx.xx.xx.xx` (the IP address in dot quad notation) and press **Enter**. The login prompt displays.
2. To log in as the system administrator for setup and configuration, enter `sysadmin` as the user name and press **Enter**.
3. Enter the last 8 characters of the Device ID (for newly manufactured units that come installed with 8.2.0.1 or later) or `PASS` as the password and press **Enter**. The first time you log in, the Quick Setup script runs automatically. Normally, the command prompt displays. (To display the Quick Setup script again, use the `admin quicksetup` command.)

Note: If the Device ID is not set, the default sysadmin password is the last 8 characters of the serial number.

Note: The system administrator may have changed the password using one of the Quick Setup methods in the previous chapter.

To log in any other user:

1. Enter your EMG user name and press **Enter**.
2. Enter your EMG password and press **Enter**.

Logging Out

To log out of the EMG command line interface, type `logout` and press **Enter**.

Command Syntax

Commands have the following format:

`<action> <category> <parameter(s)>`

where

`<action>` is `set`, `show`, `connect`, `admin`, `diag`, or `logout`.

`<category>` is a group of related parameters whose settings you want to configure or view. Examples are `ntp`, `deviceport`, and `network`.

`<parameter(s)>` is one or more name-value pairs in one of the following formats:

<code><parameter name> <aa bb></code>	User must specify one of the values (aa or bb) separated by a vertical line (). The values are in all lowercase and must be entered exactly as shown. Bold indicates a default value.
<code><parameter name> <Value></code>	User must specify an appropriate value, for example, an IP address. The parameter values are in mixed case. Square brackets [] indicate optional parameters.

Command Line Help

- ◆ For general Help and to display the commands to which you have rights, type: `help`
- ◆ For general command line Help, type: `help command line`
- ◆ For release notes for the current firmware release, type: `help release`
- ◆ For more information about a specific command, type `help` followed by the command. For example: `help set network` or `help admin firmware`

Tips

- ◆ Type enough characters to identify the action, category, or parameter name uniquely. For parameter values, type the entire value. For example, you can shorten:

```
set network port 1 state static ipaddr 122.3.10.1 mask 255.255.0.0
```

to

```
se net po 1 st static ip 122.3.10.1 ma 255.255.0.0
```

- ◆ Use the Tab key to automatically complete action, category, or parameter names. Type a partial name and press **Tab** either to complete the name if only one is possible, or to display the possible names if more than one is possible. Following a space after the preceding name, Tab displays all possible names.
- ◆ Should you make a mistake while typing, backspace by pressing the Backspace key and/or the Delete key, depending on how you accessed the interface. Both keys work if you use VT100 emulation in your terminal access program when connecting to the console port. Use the left and right arrow keys to move within a command.
- ◆ Use the up and down arrows to scroll through previously entered commands. If desired, select one and edit it. You can scroll through up to 100 previous commands entered in the session.
- ◆ To clear an IP address, type 0.0.0.0, or to clear a non-IP address value, type `CLEAR`.
- ◆ When the number of lines displayed by a command exceeds the size of the window (the default is 25), the command output is halted until the user is ready to continue. To display the next line, press **Enter**, and to display the page, press the space bar. You can override the number of lines (or disable the feature altogether) with the `set cli` command.

General CLI Commands

The following commands relate to the CLI itself.

To configure the current command line session:

```
set cli scscommands <enable|disable>
```

Allows you to use Lantronix Secure Console Server (SCS)-compatible commands as shortcuts for executing commands:

Note: Settings are retained between CLI sessions for local users and users listed in the remote users list.

Table 6-3 SCS Commands

SCS Commands	Commands
info	'show sysstatus'
version	'admin version'
reboot	'admin reboot'
poweroff	'admin shutdown'
listdev	'show deviceport names'
direct	'connect direct deviceport'
listen	'connect listen deviceport'
clear	'set locallog clear'
telnet	'connect direct telnet'
ssh	'connect direct ssh'

To set the number of lines displayed by a command:

```
set cli terminallines <disable|Number of lines>
```

Sets the number of lines in the terminal emulation (screen) for paging through text one screenful at a time, if the EMG unit cannot detect the size of the terminal automatically.

```
set cli allusers <enable|disable>
```

To globally enable or disable the terminallines feature for all users. This command can only be run by the sysadmin user or a user who has full administrative rights.

To show current CLI settings:

```
show cli
```

To view the last 100 commands entered in the session:

```
show history
```

To clear the command history:

```
set history clear
```

To view the rights of the currently logged-in user:

```
show user
```

Note: For information about user rights, see [Chapter 14: User Authentication](#).

Table 6-4 CLI Keyboard Shortcuts

Keyboard Shortcut	Description
Control + [a]	Move to the start of the line.
Control + [e]	Move to the end of the line.
Control + [b]	Move back to the start of the current word.
Control + [f]	Move forward to the end of the next word.
Control + [u]	Erase from cursor to the beginning of the line.
Control + [k]	Erase from cursor to the end of the line.

7: Networking

This chapter explains how to set the following network settings for the EMG using the web interface or the CLI:

- ◆ [Network Port Settings](#)
- ◆ [Cellular Modem Settings](#)
- ◆ [Wireless Settings](#)
- ◆ [Ethernet Switch](#)
- ◆ [VLANs](#)
- ◆ [DHCP](#)
- ◆ [IP Filter](#)
- ◆ [Routing](#)
- ◆ [Forwarding](#)
- ◆ [VPN Settings](#)
- ◆ [Performance Monitoring](#)

Requirements

If you assign a different IP address from the current one, it must be within a valid range and unique to your network. If a valid gateway address has not been assigned the IP address must be on the same subnet as workstations connecting to the EMG over the network.

To configure the unit, you need the following information:

Eth1	IP address:	_____	-	_____	-	_____	-	_____
	Subnet mask:	_____	-	_____	-	_____	-	_____
Eth2	IP address (optional):	_____	-	_____	-	_____	-	_____
	Subnet mask (optional):	_____	-	_____	-	_____	-	_____
Gateway:		_____	-	_____	-	_____	-	_____
DNS:		_____	-	_____	-	_____	-	_____

Network Port Settings

Network parameters determine how the EMG unit interacts with the attached network. Use this page to set the following basic configuration settings for the network ports (Eth1 and Eth2), configure advanced network settings, and configure a [Fail-over Device](#) and [Virtual Interfaces](#).

The EMG supports the following types of network interfaces:

- ◆ RJ-45 ports, as one of the user-selectable active ports on the EMG. In the web UI port banner bar, these are represented as **E1** and **E2**. These ports can be configured for speeds of 10Mbit, 100 Mbit or 1000 Mbit, at half-duplex or full-duplex. The RJ45 Ethernet LEDs display the following states:
 - **Green Light On:** indicates a link at 1000 BASE-T
 - **Green Light Off:** indicates a link at other speeds, or no link
 - **Yellow Light On:** indicates a link is established
 - **Yellow Light Blinking:** indicates link activity
- ◆ A variety of SFP modules, as one of the user-selectable active ports on the EMG. In the web UI port banner bar, these are represented as **F1** and **F2**, in a variety of colors.
 - **F1**: Single mode 1000 BASE-LX optical SFPs
 - **F1**: Multi mode 1000 BASE-SX optical SFPs
 - **F1**: RJ45 1000 BASE-T SFPs
 - **F1**: A port with no SFP module is shown in white.
 - **F1**: A port with an unknown SFP module

The SFP Ethernet LEDs are located between the two SFP module slots; the LEDs for Ethernet 1 are on the left, and the LEDs for Ethernet 2 are on the right. They display the following states:

- **Green Light On:** indicates a link is established
- **Green Light Off:** indicates no link
- **Yellow Light On:** indicates no link activity
- **Yellow Light Blinking:** indicates link activity

These ports are fixed at 1000 Mbit full-duplex. If Eth1 or Eth2 is configured to use SFP as the active port, at boot the console output display et0 Link Up: 10HD or et1 Link Up: 10HD before the system has configured the SFP Ethernet ports at 1000Mbit full-duplex. Note that in some vendor's RJ45 1000 BASE-T transceivers, the RX LOS is internally ground, so the link status feature may fail.

To enter settings for one or both network ports:

1. Click the **Network** tab and select the **Network Settings** option. The [Network > Network Settings \(1 of 2\)](#) and [Network > Network Settings \(2 of 2\)](#) displays.

Figure 7-1 Network > Network Settings (1 of 2)

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings Switch VLANs DHCP IP Filter Routing Forwarding VPN Security Perf Monitoring

Network Settings

[Virtual Interfaces >](#)
[Hostname & Name Servers >](#)

Ethernet Interfaces

Eth1 Settings:

☐ Disabled
☐ Obtain from DHCP
☐ Obtain from BOOTP
☒ Specify:

IP Address:
Subnet Mask:
IPv6 Address:
(Static)
IPv6 Address:
(Link Local)
Mode:
MTU:
Active Port:
HW Address: **00:80:a3:8b:fc:f0**
Multicast: **239.255.255.251**
224.0.0.1
Eth1 Link: **Up**

Enable IPv6: ☐
IP Forwarding: ☐
IPv6 Forwarding: ☐

Eth2 Settings:

☐ Disabled
☒ Obtain from DHCP
☐ Obtain from BOOTP
☐ Specify:

IP Address:
Subnet Mask:
IPv6 Address:
(Static)
IPv6 Address:
(Link Local)
Mode:
MTU:
Active Port:
HW Address: **00:80:a3:8b:fc:f1**
Multicast: **224.0.0.1**
Eth2 Link: **Down**

Reverse Path Filter: ☐
Ethernet Bonding:

[Ethernet Bonding Status >](#)
[SFP NIC Info & Diagnostics >](#)

	Rx				Tx			
	Bytes	Packets	Errors	Multicast	Bytes	Packets	Errors	
Eth1	214915011	2326433	0	0	55543312	202489	0	
Eth2	0	0	0	0	0	0	0	

The fail-over gateway is used if an IP address accessible through the default gateway fails to return one or more pings. Before configuring the Fail-over settings, the Default Gateway must be configured and applied (saved) to the EMG settings.

Gateway

Default:
IPv6 Default:
Precedence: ☒ Eth1/Eth2 DHCP-Acquired
☐ Default
Eth1/Eth2 DHCP-Acquired: **none**

Fail-over Settings

Fail-over Count, Last Time: None, Never
Fail-back Count, Last Time: None, Never
Fail-over Gateway IP Address:
IP Address to Ping to Trigger Fail-over:
Ethernet Port for Ping: ☒ Eth1 ☐ Eth2 ☐ Ethernet Bond ☐ Cell
Delay between Pings: seconds
Number of Failed Pings:
Fail-over Port: ☒ Eth2

Figure 7-2 Network > Network Settings (2 of 2)

[TCP Keepalive Parameters](#)
 Start Probes: seconds
 Number of Probes:
 Interval: seconds

Fail-Over Cellular Gateway Configuration

Fail-over Device: ▼

APN of Mobile Carrier:

Admin Login:

Admin Password:

Change Admin Password: ☐

New Admin Password: Retype:

Reboot Gateway When Making Changes: ☐

Advanced Cellular Gateway Configuration

SIM Card PIN Lock: ☐

PIN # for SIM Card: Retype:

SIM PUK: Retype:

SIM Username:

SIM Password:

Dial-Up String:

Roaming: ☐

Passthrough Mode: ☐ Ethernet IP:

Cellular DHCP: ☐

This section is for external gateways accessible over the Eth2 Ethernet port only.

[Fail-Over Cellular Gateway Status](#) >

Fail-Over Cellular Gateway Firmware

Update Firmware: ☐

Functional Firmware Filename:

Radio Firmware Filename:

Load Firmware via: ▼

Load Cellular Gateway Firmware Options

USB Port: ☒ Port U1

FTP/SFTP/SCP Server:

Path:

Login:

Password:

Retype Password:

Note: The SFP NIC Info & Diagnostics link brings you to the [Network Settings > SFP NIC Information & Diagnostics](#) page.

Figure 7-3 Network Settings > SFP NIC Information & Diagnostics

LANTRONIX® EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings IP Filter Routing VPN Security Perf Monitoring FQDN List

Network - SFP NIC Information & Diagnostics Help?

Eth1 SFP Module: 1000BASE-LX Single Mode (Vendor: Fiberstore PN: SFP1G-EX-55 Rev: A0)
 Eth2 SFP Module: 1000BASE-LX Single Mode (Vendor: FiberStore PN: SFP1G-ZX-55 Rev: A)

SFP Diagnostic Information							
Port	Temp		Voltage	Current	Output Power	Input Power	LOS TX Fault
Eth1	36.53 degC/97.76 degF		3.2058V	23.800mA	0.5475mW	0.5622mW	No No
Eth2	48.42 degC/119.15 degF		3.1902V	20.000mA	1.0741mW	0.0000mW	Yes No

[Back to Network Settings](#)

2. Enter the following information:

Ethernet Interfaces (Eth1 and Eth2)

Note: Configurations with the same IP subnet on multiple interfaces (Ethernet or PPP) are not currently supported.

Eth1 Settings or Eth2 Settings	◆ Disabled: If selected, disables the network port. ◆ Obtain from DHCP: Acquires IP address, subnet mask, hostname and gateway from the DHCP server. (The DHCP server may not provide the hostname gateway, depending on its setup.) This is the default setting. If you select this option, skip to Gateway. ◆ Obtain from BOOTP: Lets a network node request configuration information from a BOOTP "server" node. If you select this option, skip to Gateway. ◆ Specify: Lets you manually assign a static IP address, generally provided by the system administrator.
IP Address (if specifying)	Enter an IP address that will be unique and valid on your network. There is no default. Note: Enter all IP addresses in dot-quad notation. Do not use leading zeros in the fields for dot-quad numbers less than 100. For example, if your IP address is 172.19.201.28, do not enter 028 for the last segment octet. Note: Currently, the EMG unit does not support configurations with the same IP subnet on multiple interfaces (Ethernet or PPP).
Subnet Mask	If specifying an IP address, enter the network segment on which the EMG unit resides. There is no default.

IPv6 Address (Static)	Address of the port in IPv6 format. Note: The EMG supports IPv6 connections for the following services: the web, SSH, Telnet, remote syslog, SNMP, NTP, LDAP, Kerberos, RADIUS, TACACS+, connections to device ports, and diagnostic ping. IPv6 addresses are written as 8 sets of 4-digit hexadecimal numbers separated by colons. There are several rules for modifying the address. For example: 1234:0BCD:1D67:0000:0000:8375:BADD:0057 may be shortened to 1234:BCD:1D67::8375:BADD:57.
IPv6 Address (Global)	IPv6 address with global scope that is generated by address auto configuration. The address is generated from a combination of router advertisements and MAC address to create a unique IPv6 address. This field is read only. Note: This field will not appear in the absence of an IPv6 global address.
IPv6 Address (Link Local)	An IPv6 address that is intended only for communications within the segment of a local network. This field is read only.
Mode	Select the direction, duplex mode (full duplex or half-duplex), and speed (10, 100, or 1000 Mbit) of data transmission. The default is Auto, which allows the Ethernet port to auto-negotiate the speed and duplex with the hardware endpoint to which it is connected.
MTU	Specifies the maximum transmission unit (MTU) or maximum packet size of packets at the IP layer (OSI layer 3) for the Ethernet port. When fragmenting a datagram, this is the largest number of bytes that can be used in a packet. The minimum MTU size is 108 bytes (to conform with RFC 2460) and the maximum size is 1500 bytes.
Active Port	Selects either the RJ45 port or the SFP port as the active Ethernet port. Selecting SFP requires that a SFP transceiver module be inserted into the appropriate SFP slot. When switching from RJ45 to SFP or vice versa, any active network connections may be disrupted or broken.
HW Address	Displays the hardware address of the Ethernet port.
Multicast	Displays the multicast address of the Ethernet port.
Enable IPv6	Select this box to enable the IPv6 protocol. If changed, the EMG unit will need to reboot. Enabled by default.
IP Forwarding	If enabled, IP forwarding enables IPv4 network traffic received on one interface (Eth1, Eth2, or an external/USB modem attached to the EMG unit with an active PPP connection) to be transferred out another interface (any of the above). The default behavior (if IP forwarding is disabled) is for network traffic to be received but not routed to another destination. Enabling IP forwarding is required if you enable Network Address Translation (NAT) for any device port modem or USB/ISDN modem. IP forwarding allows a user accessing the EMG over a modem to access the network connected to Eth1 or Eth2.
IPv6 Forwarding	If enabled, IPv6 forwarding enables IPv6 network traffic received on one interface (Eth1, Eth2, or an external/USB modem attached to the EMG unit with an active PPP connection) to be transferred out another interface (any of the above). The default behavior (if IP forwarding is disabled) is for network traffic to be received but not routed to another destination.
SFP NIC Info & Diagnostics (Link)	Clicking the link brings you to the Network Settings > SFP NIC Information & Diagnostics page showing information and diagnostics about the SFP connection port, temperature, voltage, current, output power, input power, LOS, and TX fault. Click Back to Network Settings to return to the Network Settings page.

Reverse Path Filter	Select this option to allow the Reverse Path Filter mode, which is defined in RFC 3704. In this mode, each incoming packet is tested against the forward information base (FIB), and if the network interface is not the best reverse path, the packet check will fail and failed packets are discarded.
Ethernet Bonding	Ethernet 1 and Ethernet 2 can be bonded to support redundancy (Active Backup), aggregation (802.3ad), and load balancing. The Ethernet Bonding status link displays detailed information about the bonding interface when bonding is enabled. Disabled by default. If Ethernet Bonding is enabled, assigning individual IP Addresses to Device Ports is not supported. <i>Note: If bonding is enabled, it is recommended that Eth1 and Eth2 be configured with the same subnet as different subnets may result in poor network performance.</i>
Ethernet Bonding Status (Link)	Click the link to access Ethernet bonding status information. Click Back to Network Settings link to return to the Network Settings page.

Gateway

Default	IP address of the IPv4 router for this network. All network traffic that matches the Eth1 IP address and subnet mask is sent out Eth1. All network traffic that matches the Eth2 IP address and subnet mask is sent out Eth 2. If you set a default gateway, any network traffic that does not match Eth1 or Eth2 is sent to the default gateway for routing. <i>Note: If a fail-over gateway is configured, Default Gateway must be configured for fail-over and fail-back to work properly (gateways acquired via DHCP can change or be removed). Only Eth1 is supported as the primary interface in a Fail-over configuration.</i> For EMG with an internal cellular modem, if you configure Default Gateway to be the same as the IP address of the cellular modem acquired via DHCP (see Cellular Modem Settings), when the IP address of the cellular modem changes, the IP address of Default Gateway will be automatically updated to be the same as the IP address the cellular modem acquires via DHCP.
Eth1/Eth2 DHCP-Acquired (display only)	Gateway acquired by DHCP for Eth1 or Eth2.
WLAN DHCP-Acquired (display only)	Gateway acquired by DHCP for the WLAN client.
Cellular Acquired (display only)	Gateway acquired by DHCP for the Cellular modem.
Precedence	Indicates which of the gateways take precedence (used as the default route). Available options are Eth1/Eth2 DHCP-Acquired, Default, WLAN DHCP-Acquired (if WLAN module is installed) and Cellular Acquired (if cellular modem installed). The default is Eth1/Eth2 DHCP-Acquired Gateway. If the Eth1/Eth2 DHCP Gateway is selected and both Eth1 and Eth2 are configured for DHCP, the console manager gives precedence to the gateway acquired via Eth1. If the Precedence gateway becomes unreachable, the console manager will not install one of the other gateways as the default gateway; this must be manually configured by the user.
IPv6 Default	Indicates the IP address of the IPv6 router for this network.

Fail-Over Settings

Fail-over Gateway IP Address	An alternate IP address of the router for this network, to be used if an IP address usually accessible through the default gateway fails to return one or more pings. Note: the Fail-over Gateway is not supported when DHCP is used on the primary interface because fail-back needs a consistent IP address to use for updating the routing table. Note: If a fail-over gateway is configured, the Default Gateway must be configured for fail-over and fail-back to work properly. The gateways acquired via DHCP can be changed or be removed. Only Eth1 is supported as the primary interface in a Fail-over configuration. When Eth2 is used as Fail-over Port, the Fail-over Gateway IP Address must be in the same subnet as the Eth2 network. This restriction is ignored if the failover device is Sierra ES450 and IP Passthrough Mode is enabled. When an internal modem is used as the fail-over port, the Fail-over Gateway IP Address should be set to the Remote IP address for the PPP connection. For information about internal modem, see Internal Modem. When a cellular modem or WLAN is used as Fail-over Port, the Fail-over Gateway IP Address option should be set to the IP address of the cellular or WLAN interface. See Fail-over Port for specific requirements for configuring each type of port/interface. When cellular modem is set as the fail-over port and is configured for DHCP, whenever the IP address of the cellular modem changes, the IP address of the Fail-over Gateway will be automatically updated to be the same as the new cellular modem IP address.
IP Address to Ping to Trigger Fail-over	IP address to ping to determine whether to use the fail-over gateway.
Ethernet Port for Ping	Ethernet port to use for the ping. Ethernet Bond interface can be selected only when the Ethernet Bonding is in active-backup mode.
Delay between Pings	Number of seconds between pings. The default is 3.
Number of Failed Pings	Number of pings that fail before the EMG uses the fail-over gateway. The default is 10.

Fail-over Port	The network interface to use for fail-over. The Fail-over Gateway IP Address should either be accessible via this interface or assigned directly to this interface. Select Eth2 (the default), Cellular if a Cellular modem FRU is installed, WLAN if a Wi-Fi FRU is installed or Internal Modem if a Internal modem is installed. When Internal Modem is selected, the Internal Modem should be configured as follows: ◆ State: Dial-on-Demand ◆ Mode: PPP ◆ PPP Mode: Local and Remote IPs ◆ Dial-out Number set to the appropriate analog phone number ◆ Remote/Dial-out Login and Password set to the appropriate authentication tokens ◆ The Modem Timeout can be either disabled or enabled. When a fail-over happens, the EMG will automatically dial-out and establish a PPP connection over the phone line, and configure the default gateway so that traffic will be routed over the PPP connection. If the Modem Timeout is disabled, the PPP connection will remain up the entire time the network is in fail-over mode; at fail-back the PPP connection will be torn down and the dial-out will be terminated. If the Modem Timeout is enabled, the PPP connection remain up until no network traffic is received for the timeout specified; then the PPP connection will be torn down and the dial-out will be terminated (the PPP connection will automatically re-establish as needed during fail-back). When viewing fail-over status in the UIs, while the dial-out and PPP connection are being established, the UI will display fail-over in progress; once the PPP connection is established, the remote IP address of the connection will be displayed. When WLAN is selected, the WLAN client should be enabled with a profile that allows the EMG to connect to a WLAN network.

TCP Keepalive Parameters

Start Probes	Number of seconds the EMG unit waits after the last transmission before sending the first probe to determine whether a TCP session is still alive. The default is 600 seconds (10 minutes).
Number of Probes	Number of probes the EMG sends before closing a session. The default is 5.
Interval	The number of seconds the EMG unit waits between probes. The default is 60 seconds.

Fail-Over Cellular Gateway Configuration

Fail-over Device	Note: This section is for external gateways accessible over the Eth2 Ethernet port only. To use EMG's internal cellular modem as the fail-over gateway, see Cellular Modem Settings. Select an integrated external device to be used as the fail-over gateway. Currently the Lantronix PW XC HSPA+ Cellular Gateway. Lantronix G520 Series (G52x) Cellular Gateway, and the Sierra Wireless ES450 Cellular Gateway are supported. When using an internal cellular modem as the fail-over gateway, the Fail-over Device should be set to None. The HSPA+ gateway must be configured in gateway mode before it can be used as the fail-over gateway. It is recommended that the HSPA+ Cellular Connection Mode be set to On Demand, which will leave the link quiescent until an application attempts to make use of the cellular network connection. It is also recommended that the SNTP protocol be disabled, as On Demand mode uses the egress traffic as a trigger. The console manager automatically disables UPnP on the HSPA+ gateway. If PIN or PUK is required by HSPA but not supplied by console manager then a syslog message and a non fatal error message will be generated. The Lantronix G520 Series (G52x) gateway must be configured before it can be used as the fail-over gateway. The default admin user password must be changed to a new password, and the DHCP server must be disabled. For factory reset device, you need to first login as root and default password as L@ntr0n1x. Please note after factory reset, the G52x WebGUI will show the default user as admin; you need to delete it and enter the username as root. Once you login as root with default password as L@ntr0n1x, you can change the password for root user and set a password for admin user. After you save and apply, the G52x WebGUI will re-direct to login page where you can login as admin or root. The Sierra gateway must be properly provisioned before first use by initializing the APN of the installed SIM card. When the IP Passthrough Mode is disabled, the Sierra gateway connected to the second ethernet port (Eth2) of EMG, and assigning a static IP address to the EMG port so that it is in the same subnet as that of the IP address of the Sierra gateway. Use the console CLI or web GUI to set the APN of the SIM card. After setting the APN, power cycle the Sierra gateway and allow it to reboot completely. The default IP addresses are as follows: Lantronix PW XC HSPA+: 192.168.0.1 Lantronix G52x Series: 192.168.1.1 Sierra Wireless ES450: 192.168.13.31 The failover feature requires that both Ethernet ports be configured with a static IP address (if IP Passthrough Mode is not supported or disabled). Using DHCP on one of the Ethernet ports may overwrite the default route, interfering with fail-over and fail-back. IP Passthrough Mode is currently supported only for Sierra Wireless ES450 gateway. If the IP Passthrough Mode is enabled on the Sierra ES450 then the second ethernet port of the console server should be configured for DHCP and the Sierra ES450's DHCP server should be in "Auto" mode with starting and ending IP address of the IP pool set to "0.0.0.0".

Fail-over Device, continued	Note: The commands sent to the fail-over device to retrieve status and update the configuration are shown in the syslog (messages may be displayed under Network syslog; at the Debug level). If there are errors retrieving status or updating the configuration, check messages in the Network syslog, the device administrator login/password, connectivity to the device and the firmware version of the fail-over device. The minimum required firmware version for the HSPA+ gateway is 8.1.0.0 and for the Sierra Wireless ES450 gateway is 4.9.2 and for the Lantronix G520 Series (G52x) gateway is 2.1.0.0. For the HSPA+ gateway, if the firmware is updated and new items are added to the status output by the gateway, the new items will automatically be displayed on the console manager. When the console manager sends an updated configuration to the fail-over device, it is recommended to check the console manager syslog, even if the console manager indicates that the update was successful. Responses from the fail-over device indicating that the device needs to be rebooted for configuration changes to take affect may also be in the syslog. The configuration will be resent to the device if any of the fail-over device settings are changed, or the selected fail-over device is changed from None to one of the supported fail-over device types When a fail-over or fail-back occurs, running applications such as VPN tunnel and ConsoleFlow will be restarted.
APN of Mobile Carrier	For the HSPA+, Sierra and Lantronix G520 Series (G52x) gateways, configure the Access Point Name for the mobile carrier. May have up to 256 characters.
Admin Login and Password/Retype	For the selected Fail-over Device, the administrator login and password used to retrieve status from the device and send configuration updates to the device. The login may have up to 32 characters, and the password may have up to 64 characters. The Admin Password displays the current password masked. Default login credentials of the Lantronix PW HSPA+: Admin login name: admin Admin password: PASS Default login credentials of the Sierra Wireless ES450: Admin login name: user Admin password: 12345 Default login credentials of the Lantronix G520 Series (G52x): Admin login name: admin Admin password: No default password, current G52x working password
Change Admin Password (check box)	Select this check box if you wish to update the admin password for the selected gateway Fail-over Device .
New Admin Password/Retype	For the selected Fail-over Device, the administrator password can be changed on the gateway. The password may have up to 64 characters. To change the Admin Password, click the Change Admin Password checkbox and enter the new password in the New Admin Password and Retype fields. Changing the HSPA+ Admin password will save the password on the EMG for status and configuration queries to the HSPA+ gateway. The password must match what is stored on the HSPA+ gateway. Changing the Sierra Admin password will save the password on the EMG for status and configuration queries to the Sierra gateway. The new password will also be configured on the Sierra gateway. The Sierra gateway login must be set as 'user'. Changing the G520 Series (G52x) password will save the password on the console manager for status and configuration queries to the Lantronix G520 Series (G52x) gateway; the new password will also be configured on the Lantronix G520 Series (G52x) gateway. The Lantronix G520 Series (G52x) gateway login must be set as 'admin'.

Reboot Gateway When Making Changes	Select this check box if you wish to reboot the selected fail-over device when making changes.
Fail-Over Cellular Gateway Status (link)	Clicking the link opens the Fail-Over Cellular Gateway status window, showing status and statistics about the fail-over gateway. Click Back to Network Settings to return to the Network Settings page.

Advanced Cellular Gateway Configuration

SIM Card PIN Lock (check box)	For the HSPA+, Sierra and Lantronix G520 Series (G52x) gateways, enable a lock so that the SIM card used by the gateway cannot be used by anyone who does not have the PIN.
Pin # for SIM Card/ Retype	For the HSPA+, Sierra and Lantronix G520 Series (G52x) gateways, the PIN number for the SIM card used by the gateway. May have up to 8 characters. SIM status in case of Lantronix G520 Series (G52x) gateway is not verified in SLC, SLC directly forwards the request to Lantronix G520 Series (G52x) gateway.
SIM PUK/Retype	For the HSPA+ and Lantronix G520 Series (G52x) gateways, the SIM Personal Unblocking Key (PUK). May have up to 16 characters. The Sierra gateway does not have this feature. HSPA+ does not store PUK in its configuration. It is required when incorrect PIN is entered for 3 times, otherwise HSPA+ will ignore PUK. SIM status in case of Lantronix G520 Series (G52x) gateway is not verified in SLC, SLC directly forwards the request to Lantronix G520 Series (G52x) gateway.
SIM Username	For the HSPA+ and Lantronix G520 Series (G52x) gateways, enter the username for dial up to the cellular carrier, if required. May have up to 64 characters. The Sierra gateway does not have this feature.
SIM Password	For the HSPA+ and Lantronix G520 Series (G52x) gateways, enter the password for dial up to the cellular carrier, if required. May have up to 64 characters. The Sierra gateway does not have this feature.
Dial-up String	For the HSPA+ and Lantronix G520 Series (G52x) gateways, enter the modem string used for making a connection to the carrier. May have up to 64 characters. The Sierra gateway does not have this feature. The Lantronix G520 Series (G52x) gateway supports only three values pap, chap or none.
Roaming	For the HSPA+ gateway, enable or disable network roaming. The Sierra gateway does not have this feature.
Passthrough Mode	For the Sierra ES450 gateway, select the IP Passthrough Mode check box to allow the Sierra ES450 gateway to pass its WAN IP address to the selected Ethernet interface of SLC. The Sierra ES450 gateway will get rebooted on enabling or disabling this option. The IP passthrough mode is also supported in fail-over/fail-back scenario for a consistent IP and gateway. The fail-over feature does not handle IP changes in the fail-over gateway IP address for IP passthrough configurations. If there is a communication failure with the Sierra ES450 on setting or unsetting Passthrough related parameters (such as Passthrough Mode, Cellular DHCP or Ethernet IP) with Eth2 set to DHCP, to workaround this issue: first retry the configuration with a static IP setting for Eth2 and then subsequently change the Eth2 mode to DHCP. The Lantronix G520 Series (G52x) gateway does not support this feature.
Ethernet IP	Ethernet IP address of the Sierra ES450 gateway. This is used in conjunction with Passthrough Mode to remotely configure the Sierra ES450 options. If IP passthrough mode is disabled then this IP address will be ignored and IP address of the alternate gateway field will be used to configure Sierra ES450. The Lantronix G520 Series (G52x) gateway does not support this feature.

Cellular DHCP	For the Sierra ES450 gateway, use this option in conjunction with Passthrough Mode to enable or disable the DHCP server. The Sierra ES450 gateway will get rebooted whenever you enable or disable this option. The Lantronix G520 Series (G52x) gateway does not support this feature.

Fail-Over Cellular Gateway Firmware

Note: The HSPA+ or Sierra fail-over device must be selected in order for you to be able to update the firmware.

Update Firmware (check box)	Select this option to update firmware on the HSPA+ gateway, Sierra gateway or on Lantronix G520 Series (G52x) gateway. The Functional Firmware file and the Radio Firmware file (required for the Sierra gateway only) will be transferred to the EMG using the method selected by the Load Firmware via option. Once the file(s) have been transferred to the EMG, the EMG will initiate the firmware update on the gateway. The Lantronix G520 Series (G52x) gateway firmware upgrade may take 3 to 6 minutes.
Functional Firmware Filename	Enter the name of the firmware filename exactly as it is represented.
Radio Firmware Filename	Enter the name of the radio firmware filename exactly as it is represented.
Load Firmware via	Select the method to load the firmware from the options in the drop-down menu. Options are: FTP, SFTP, SCP, USB, SD Card, and HTTPS. FTP is the default. ◆ If you select HTTPS, the Upload File link becomes active. Select the link to open a popup window that allows you to browse to a firmware update file to upload. ◆ If you select NFS, the mount directory must be specified. Note: Connections available depend on the model of the EMG unit.

Load Cellular Gateway Firmware Options

USB Port	The USB Port selection becomes active when you choose to Load Firmware via USB. EMG provides one USB port called U1 in the interface. The firmware files must be stored in the top level directory of the USB flash drive.
FTP/SFTP/SCP Server	Enter the IP address or host name of the server used for obtaining the firmware files. May have up to 64 alphanumeric characters; may include hyphens and underscore characters.
Path	Enter the path on the server for obtaining firmware update files.
Login	Enter the user login for the FTP/SFTP/SCP server to verify access. May be blank.
Password/ Retype Password	Enter the FTP/SFTP/SCP user password. Retype the password in the Retype Password field.

To save your entries, click the **Apply** button. **Apply** makes the changes immediately and saves them so they will persist when the EMG is rebooted.

Ethernet Counters

The [Network > Network Settings \(1 of 2\)](#) page displays statistics for each of the EMG Ethernet ports since boot-up. The system automatically updates them.

	Rx				Tx		
	Bytes	Packets	Errors	Multicast	Bytes	Packets	Errors
Eth1	62165901	546159	0	0	20230163	84196	0
Eth2	1850	20	0	0	106774	411	0

Note: For Ethernet statistics for a smaller time period, use the `diag perfstat` command.

Network Commands

Go to [Network Commands](#) to view CLI commands which correspond to the web page entries described above.

Hostname & Name Servers

To configure the hostname and name servers:

1. On the Network Settings page, click the **Hostname & Name Servers** link. The following page appears:

Figure 7-4 Hostname & Name Servers

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings Switch VLANs DHCP IP Filter Routing Forwarding VPN Security Perf Monitoring

Hostname & Name Servers Help ?

[Back to Network Settings](#)

Hostname

Hostname:

Note: The hostname will be used as the prompt in the Command Line Interface.

Domain:

DNS Servers

#1:

#2:

#3:

#4:

#5:

#6:

#7:

#8:

#9:

#10:

Prefer IPv4 DNS Records: ☒

DNS Source IPv4 Address:

DNS Source IPv6 Address:

IP Address:

FQDN:

FQDN List

Hosts/FQDN List	
No	FQDN

2. Enter the following information:

Hostname	The default host name is emgXXXX, where XXXX is the last 4 characters of the hardware address of Ethernet Port 1. There is a 64-character limit (contiguous characters, no spaces). The host name becomes the prompt in the command line interface.
Domain	If desired, specify a domain name (for example, support.lantronix.com). The domain name is used for host name resolution within the EMG unit. For example, if abcd is specified for the SMTP server, and mydomain.com is specified for the domain, if abcd cannot be resolved, the EMG attempts to resolve abcd.mydomain.com for the SMTP server.
DNS Servers #1-10	Configure up to ten name servers. The console manager will send queries to any of the upstream servers it knows about and tries to favor servers that are known to be up.
DHCP-Acquired DNS Servers (view only)	Displays the IP address of the DNS servers if automatically assigned by DHCP over Eth1, Eth2, VPN, WiFi WLAN client or Cellular.

Prefer IPv4 DNS Records	If enabled, IPv4 DNS records will be preferred when DNS hostname lookups are performed. Otherwise IPv6 records will be preferred (when IPv6 is enabled). Enabled by default.
DNS Source IPv4 Address	The Source IPv4 Address can be used to configure which interface (and source IPv4 address) is used for sending DNS packets. By default, the source IPv4 address for sending DNS traffic is not specified, and the source IPv4 address of a DNS packet is selected according to the routing table. The DNS Source IPv4 Address parameter can be used to select the IPv4 address of Eth1, Eth2, VEth1 or VEth2 as the source IPv4 address (the default is none). Before selecting an interface, make sure the interface is enabled and has a valid IPv4 address.
DNS Source IPv6 Address	The DNS Source IPv6 Address can be used to configure which interface (and source IPv6 address) is used for sending DNS packets. By default, the source address for sending DNS traffic is not specified, and the source address of a DNS packet is selected according to the routing table. DNS Source IPv6 Address can be used to select the IPv6 address of Eth1, Eth2, VEth1 or VEth2 as the source IPv6 address for packets sent to all DNS servers defined with an IPv6 address. Before selecting an interface, make sure the interface is enabled and has a valid IPv6 address.

FQDN List

Use the FQDN List (FQDN stands for fully qualified domain name) to add static hostname entries to the local hosts table so that the EMG can resolve hostnames that are not resolved via DNS.

To add/edit/delete hosts:

1. On the Network Settings page, click the **Hostname & Name Servers** link. The page as shown in [Figure 7-4](#) appears.
2. At the FQDN List section, enter the following information:
 - To add a Host, enter the **IP address**, **FQDN**, and click **Add/Edit Hosts**. The IP address and hostname displays in the Hosts/FQDN List. You may add up to 15 hosts.
 - To edit a Host entry, select the radio button next to the host in the Hosts/FQDN List, change the IP address or FQDN fields as desired, and click **Add/Edit Hosts**.
 - To delete a Host, select the radio button next to the host in the Hosts/FQDN List and click **Delete Host**.
3. Click **Apply**.

Virtual Interfaces

The EMG supports two Ethernet virtual interfaces (**VEth1** and **VEth2**). These interfaces act similar to a real physical interface (with a user-assigned IPv4 address and netmask, and optionally an IPv6 address). **VEth1** and **VEth2** are reachable via the physical Eth1 or Eth2 interface. The interfaces are "virtual" in that they exist in software only. Virtual interfaces can serve as a "device" IPv4 or IPv6 address, which in a network topology can be different than the **Eth1** or **Eth2** IPv4 or IPv6 address.

In addition to acting as an independent "device" IP address, virtual interfaces can be selected as the interface to bind with, or virtual interface IPv4 addresses can be selected as the source IP address for outgoing connections or protocols :

- ◆ **SSH out connections:** CLI SSH out connections using the `connect direct ssh` command can select which interface to use with the `iface` parameter.
- ◆ **NTP packets:** by default, no interface is defined for NTP traffic and all available network addresses are available for processing NTP packets. The **Source IPv4 Address** parameter can be used to select only one interface for processing NTP packets for all NTP servers defined with an IPv4 address or a name which resolves to an IPv4 address. The **Source IPv6 Address** parameter can be used to select only one interface for processing NTP packets for all NTP servers defined with an IPv6 address or a name which resolves to an IPv6 address. See [Date and Time](#) for more details.
- ◆ **Remote Syslog packets:** by default, the source IP address for sending syslog messages is not specified, and the source IPv4 address or source IPv6 address is selected according to the routing table. The **Source IPv4 Address** parameter can be used to configure which interface (and source IPv4 address) is used for sending syslog messages to IPv4 servers. The **Source IPv6 Address** parameter can be used to configure which interface (and source IPv6 address) is used for sending syslog messages to IPv6 servers. See [SSH/Telnet/Logging](#) for more details.
- ◆ **SNMP outbound traffic (traps):** by default, no source IP address is defined for SNMP traffic; the console manager will use the IP address of the interface through which the SNMP trap packet is sent (based on the routing table). The Traps Source IPv4 Address parameter can be used to configure the interface (and which source IPv4 address) is used for sending SNMP traps to NMS servers defined with an IPv4 address or a name which resolves to an IPv4 address. The Traps Source IPv6 Address parameter can be used to configure the interface (and which source IPv6 address) is used for sending SNMP traps to NMS servers defined with an IPv6 address or a name which resolves to an IPv6 address. See [SNMP](#) for more details.
- ◆ **DNS packets:** by default, no source interface or IP address is defined for DNS traffic; the console manager will use the IP address of the interface through which the DNS UDP packet is sent (based on the routing table). The **DNS Source IPv4 Address** parameter can be used to set the source IPv4 address of all DNS packets sent to DNS servers defined with an IPv4 address. The **DNS Source IPv6 Address** parameter can be used to set the source IPv6 address of all DNS packets sent to DNS servers defined with an IPv6 address. See [Network Port Settings](#) for more details.
- ◆ **TACACS+ Authentication packets:** by default, no source interface or IP address is defined for TACACS+ traffic; the console manager will use the IP address of the interface through which the TACACS+ TCP packet is sent (based on the routing table). The **Source IPv4 Address** parameter can be used to set the source IPv4 address of packets sent to all TACACS+ servers defined with an IPv4 address or a name which resolves to an IPv4 address. The **Source IPv6 Address** parameter can be used to set the source IPv6 address of packets sent to all TACACS+ servers defined with an IPv6 address or a name which resolves to an IPv6 address. See [TACACS+](#) for more details.

It is highly recommended that an IP address / subnet for VEth1 and VEth2 be different than the IP address / subnet for Eth1 and Eth2. Configuring VEth1 or VEth2 with the same IP address / subnet as Eth1 or Eth2 may cause the console manager to become unreachable.

To utilize a virtual interface on the console manager, other devices on the network may need to create routing rules, such as a static route, so that network traffic can be routed to the virtual interface via one of the SLC 8000's network attached physical interfaces, such as Eth1, Eth2, or Modem PPP network interfaces. For example, in this configuration on the console manager:

```
Eth1 : 192.168.84.100/24
Gateway : 192.168.84.1
VEth1 : 192.168.44.100/24
```

Another device on the 192.168.84.0/24 network (for example 192.168.84.2) would need to add a static route so that traffic between 192.168.84.2 and 192.168.44.100 can be routed. For example, for Linux devices, this command would be issued on 192.168.84.2:

```
ip route add 192.168.44.100/32 via 192.168.84.100
```

To configure a virtual interface:

1. On the **Network Settings** page, click the **Virtual Interfaces** link. The Virtual Interface Settings configuration page is displayed.

LANTRONIX® EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for: ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings Switch VLANs DHCP IP Filter Routing Forwarding VPN Security Perf Monitoring FQDN List

Virtual Interface Settings [Help ?](#)

Note: it is highly recommended that an IP address/subnet for VETH1 and VETH2 be different than the IP address/subnet for Eth1 and Eth2. Configuring VETH1 or VETH2 with the same IP address/subnet as Eth1 or Eth2 may cause the EMG to become unreachable.

Virtual Interface 1 Settings: ☒ Disabled ☐ Enabled

IP Address:

Subnet Mask:

IPv6 Address:

Virtual Interface 2 Settings: ☒ Disabled ☐ Enabled

IP Address:

Subnet Mask:

IPv6 Address:

2. Enter the following information for one or both virtual interface ports:

Virtual Interface 1/ Virtual Interface 2 Settings	◆ Disabled: If selected, disables the virtual interface. Defaults are VETH1 and VETH2 disabled. ◆ Enabled: If selected, Allows the user to manually assign a static IP address and netmask for the virtual interface, and bring the interface up.
IP Address	An IPv4 address that will be unique and valid on your network. There is no default. Note: Enter all IP addresses in dot-quad notation. Do not use leading zeros in the fields for dot-quad numbers less than 100. For example, if your IP address is 172.19.201.28, do not enter 028 for the last segment.
Subnet Mask	The network segment for the IP address. There is no default.
IPv6 Address	Address of the Virtual Interface in IPv6 format. IPv6 addresses are written as 8 sets of 4-digit hexadecimal numbers separated by colons. For example, 1234:0BCD:1D67:0000:0000:8375:BADD:0057 may be shortened to 1234:BCD:1D67::8375:BADD:57. The IPv6 address will require a /bit mask prefix at the end of the address, 1234:0BCD:1D67:0000:0000:8375:BADD:0057/64

3. To save your entries, click the **Apply** button. Apply makes changes effective immediately and saves them so they will be configured when the console manager is rebooted.

Virtual Interface Commands

Go to [Virtual Interface Commands](#) to view CLI commands which correspond to the web page entries described above.

Cellular Modem Settings

The EMG supports the use of one internal LTE cellular modem installed in the EMG unit. The Cellular Settings web page allows the user to configure parameters that determine how the EMG cellular modem network behaves.

When using a SIM from Verizon, it is highly recommended that the carrier be set so that the Verizon firmware is used instead of the Generic firmware. Use the `set cellular carrier` CLI command to select the Verizon carrier image.

This web page also contains parameters to update the cellular modem firmware. For EMG7500 models, this is the preferred method for updating cellular modem firmware. For EMG8500 models, the preferred method for updating firmware is via Firmware over the Air (FOTA). For detailed instructions, see [Firmware Over the Air \(FOTA\)](#).

To complete the Cellular Settings page:

1. Click the **Network** tab and select the **Cellular Modem** option. The following page displays:

Figure 7-5 Network > Cellular Modem Settings Page

LANTRONIX[®] EMG852201

Host: emgeec User: sysadmin

Select port for: ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Logout

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings Cellular Modem IP Filter Routing VPN Security Perf Monitoring FQDN List

Cellular Settings [Help?](#)

Cellular Interface

Cell Settings: ☐ Disabled ☒ Obtain from DHCP

IP Address:

Subnet Mask:

	Rx				Tx		
	Bytes	Packets	Errors	Multicast	Bytes	Packets	Errors
Cell	1224	4	0	0	1847	9	0

Cellular Modem Configuration [Cellular Status >](#)

APN of Cellular Carrier:

Clear Predefined APN: ☐

Preferred Network:

Reboot Modem: ☐

Cell Network Username:

Cell Network Password: Retype Cell Network Password:

Cell Network Auth:

Roaming: ☐

SIM Card PIN Lock: ☐

PIN # for SIM Card: Retype:

IPv6: ☐

MTU:

Cellular Modem Firmware

Update Firmware: ☐

Modem Firmware Filename: [Upload File >](#)

PRI Carrier Filename: [Upload File >](#)

Load Firmware via:

Load Cellular Modem Firmware Options

FTP/SFTP/SCP Server:

Path:

Login:

Password:

Retype Password:

Apply

2. Enter the following information:

Cellular Interface

Cell Settings	Disabled: If selected, disables the cellular interface. Default is enabled for DHCP. Obtain from DHCP: Acquires IP address and subnet mask from DHCP. If the cellular modem is configured for DHCP and is used as the Fail-over Gateway, when the IP address of the cellular modem changes, the IP address of the Fail-over Gateway will be automatically updated to be the same as the new cellular modem IP address. If the DHCP IP address is used as the Local IP Address of VPN, when the IP address of the cellular modem changes, the IP address of Local IP Address of VPN will be automatically updated to be the same as the new cellular modem IP address.
IP Address	(view only) An IP address acquired via DHCP.
Subnet Mask	(view only) The network segment acquired via DHCP.

Cellular Modem Configuration

APN of Cellular Carrier	Configure the Access Point Name for the cellular carrier. May have up to 256 characters.
Clear Predefined APN	Sets the PDP context to an empty APN and tries to detect and set the APN automatically; e.g., any predefined APN will be cleared and any APN configured with APN of Cellular Carrier will be overridden, and the console manager will try to perform the initial LTE connection without an APN. This can be a more reliable way to connect as more networks will reject an incorrect APN rather than no APN. Disabled by default. Note: If Enabled, the EMG boot time will increase by about 30 seconds. This option should only be utilized if the cellular operator specifically requires it.
Preferred Network	Select the preferred Radio network. The available options are AUTO , 4G , and 3G . The default option is AUTO .
Reboot Modem	Select this option to restart the cellular modem. It is recommended that the modem be restarted after firmware update, after changing the state of the SIM Card PIN Lock, and after changing the PIN # for SIM Card.
Cellular Network Username and Password	The login and password for connecting to the cellular carrier, if required. The login may have up to 32 characters, and the password may have up to 64 characters. The Cellular Network Password displays the current password masked.
Cell Network Auth	Specify the type of authentication to be used for connecting to the cellular carrier. This is to be configured only if your carrier has setup the APN with a user name and password. The authentication type specifies the security protocol to be used for sending your user name and password to the server to establish a connection. The supported protocols are PAP (Password Authentication Protocol) and CHAP (Challenge Handshake Authentication Protocol), with CHAP considered to be more secure.
Roaming	Enable or disable network roaming. Disabled by default.
SIM Card PIN Lock	Enable a lock so that the SIM card used by the cellular gateway cannot be used by anyone who does not have the PIN.
PIN # for SIM Card	The PIN number for the SIM card used by the gateway. May have up to 8 characters.

IPv6	Enable or disable IPv6 support. Disabled by default. Some cellular connections may not acquire an IPv4 address if IPv6 is enabled.
MTU	Specifies the Maximum Transmission Unit (or Maximum Packet Size) of packets at the IP layer (OSI layer 3) for the cellular connection. When fragmenting a datagram, this is the largest number of bytes that can be used in a packet. The minimum MTU size is 108 bytes (to conform with RFC 2460) and the maximum size is 1500 bytes. Changing this value may improve cellular connections.

Cellular Modem Firmware

Update Firmware	Select this option to update firmware on the cellular modem. The Modem Firmware file and the PRI Carrier file will be transferred to the console manager using the method selected by the Load Firmware via option. Once the file have been transferred to the console manager, the console manager will initiate the firmware update on the gateway.
Modem Firmware Filename	The name of the cellular modem firmware upgrade file. Use Linux binary file <code>.cwe</code> for firmware upgrade. <i>Note: You must upgrade the carrier PRI file whenever you upgrade the firmware of the cellular modem.</i>
PRI Carrier Filename	You must upgrade the carrier PRI file whenever you upgrade the firmware of the cellular modem.
Load Firmware via	The method of loading the firmware. The available options are: FTP , SFTP , SCP (Secure copy protocol), USB , and HTTPS . The Upload File link is available only if you select HTTPS . Select the link to open a window that allows you to browse to the firmware update file that you want to upload. By default, FTP is selected.

Load Cellular Modem Firmware Options

FTP/SFTP/SCP Server	The IP address or host name of the server used for obtaining updates and saving or restoring configurations. May have up to 64 alphanumeric characters; may include hyphens and underscores.
Path	The default path on the server for obtaining firmware update files and getting and putting configuration save files.
Login	The user id for accessing the server. May be blank.
Password/Retype Password	The user password of the server.

- To save your entries, click the **Apply** button. **Apply** makes the changes immediately and saves them so they will persist when the EMG is rebooted.

Cellular Status

The following items are displayed in the Cellular Status:

- ◆ Link State: the modem interface link state
- ◆ Packet Data Connection State: the cellular data connection state
- ◆ Cellular Counters: the number of bytes received and transferred through the cellular interface
- ◆ Revision: the modem firmware version
- ◆ MEID: the modem equipment identifier

- ◆ IMEI: the International Mobile Equipment Identity number of the modem
- ◆ IMEI SV: the International Mobile Equipment Identity software version
- ◆ FSN: the Factory Serial Number of the modem
- ◆ +GCAP: the capabilities of the modem, for example, GSM communications
- ◆ +CGDCONT: the packet data protocol context of the modem, for example, **1,"IP","m2m.com.attz","0.0.0.0",0,0,0,0** indicates the modem is using IP protocol with the APN set to m2m.com.attz and is using DHCP addressing
- ◆ Current Time: the number of seconds since the modem booted
- ◆ Temperature: the modem temperature in Celsius
- ◆ Reset Counter: the number of times the modem has been software reset
- ◆ Mode: indicates if the modem is online with the cellular network
- ◆ System mode: current cellular mode, such as LTE
- ◆ PS state: the packet service attach status
- ◆ LTE band: current band being used by the modem
- ◆ LTE bw: current band frequency
- ◆ LTE Rx chan: receive channel in use
- ◆ LTE Tx chan: transfer channel in use
- ◆ LTE CA state: carrier aggregation assignment
- ◆ EMM state: EPS Mobility Management state
- ◆ RRC state: Radio Resource Control state
- ◆ IMS reg state: IP Multimedia Subsystem state
- ◆ PCC RxM RSSI / RSRP (dBm): Main antenna Received Signal String Indicator and Reference Signal Received Power level
- ◆ PCC RxM RSSI / RSRP (dBm): Secondary antenna Received Signal String Indicator and Reference Signal Received Power level
- ◆ Tx Power: Transmit power
- ◆ TAC: Tracking Area Code
- ◆ RSRQ (dB) / Cell ID: Reference Signal Received Quality and cellular identifier
- ◆ SINR (dB): Signal to Interference & Noise Ratio
- ◆ Uptime: the same value shown in **Current Time** in different format
- ◆ SIM lock status: the current SIM lock status on the cellular modem
- ◆ Network Operator: the carrier configured on the cellular modem
- ◆ Network Auth Mode: the authentication mode (PAP, CHAP or none) configured on the cellular modem
- ◆ Roaming: the roaming state configured on the cellular modem
- ◆ FW 1 / FW 2 / FW 3 / FW 4 / Max FW images / Active FW image: the firmware images that are loaded in the modem and which firmware slot is being used
- ◆ PRI FF: the carrier firmware images that are loaded in the modem

- ◆ Current & Preferred Images: the preferred and current firmware and carrier images

Firmware Over the Air (FOTA)

This section contains information on how to update the cellular modem radio firmware via FOTA. This process requires a [Sierra Wireless AirVantage](#) account. Any EMG can only be registered to one AirVantage account. The cellular modem serial number (FSN) and IMEI (International Mobile Equipment Identity number) are required. The FOTA process takes anywhere from 10 minutes up to a few hours, depending on connectivity. Note that the process and screenshots of the AirVantage portal UI described here may change at any time.

To update cellular firmware over the air:

1. Create an account on [Sierra Wireless AirVantage](#) cloud-based management and register an EMG device. This will require entering the modem serial number (FSN) and IMEI (International Mobile Equipment Identity number of the modem), which can be found with the CLI command `show cellular` or the Cellular Modem Status web page.

Register AirPrime EM/MC74 Series

Type: EM7455

Serial Number:

IMEI/ESN:

Name:

☐ Pre-configure system

or


1. Select the Type of AirPrime Module you want to register
2. Provide the IMEI and Serial Number of your System
3. Switch on your System
4. In the modem check that communications with AirVantage Platform are configured:
 - "AT+WDSC=3,x"(x being the frequency of connection in minutes), then
 - "AT+WDSS=1,1"
5. At first connection the AirVantage Platform will synchronize your new system

Enter the required information and give the EMG a name, then click **Register**. This will indicate a query to the EMG to gather information. Once the registration is complete, the device will display at the bottom of the page.


Registered systems					
All systems					
	EMG7500-Glenn98FC	25 minutes ago	ID: 359073065774428	Type: EM7455	
	EMG7500-Glenn	6 hours ago	ID: 359073066424155	Type: EM7455	
	EM8500 Self test	2 years ago	ID: 359073066423827	Type: EM7455	

2. Enable FOTA mode on the EMG. It is recommended to limit other activity on the EMG while the firmware update is performed. To enable FOTA mode on the EMG, run the `set cellular fota enable` CLI command. This will place the cellular modem in a mode where it can communicate with AirVantage cloud. This command will return a status indicating if it was able to successfully configure the modem. The EMG will then reach out to AirVantage and communicate basic information; at the completion of this process, the information in the Registered systems table should update to show that it has communicated with the EMG.
3. Synchronize the EMG with AirVantage cloud. In the AirVantage portal, select **Upgrade**, then **Systems** to display the devices that can be managed. At the bottom of the page, select the

EMG device that was just registered.



This will open a new page with detailed information about the EMG device, with a **System Communication** pane at the top that shows the last time the device was communicated with, and a System Info section containing a Synchronization button. Click this button to Synchronize the current state of the EMG with the portal. The **Synchronize System** progress bar will indicate when the synchronization is complete; afterwards the System Info panel will be updated (a manual refresh may be required) with telemetry data from the EMG device. This will include the Current Operator, which should match the EMG device cellular provider.



4. Initiate the FOTA Firmware Update. In the screen above, click the firmware download arrow (circled in black) to initiate the firmware upgrade; this displays the popup shown on the lower right. The firmware version that will be sent to the cellular modem can be selected. Typically

this will be the default selection of **Upgrade to the latest firmware**, however you may want to choose a different version based on what the current firmware version is on the EMG device, which can be viewed with the CLI command `show cellular` or the **Cellular Modem Status** web page:

Current & Preferred Images:

```
preferred fw version:    02.33.03.00
preferred carrier name:  GENERIC
preferred config name:   GENERIC_002.072_000
preferred subpri index:  000
current fw version:      02.33.03.00
current carrier name:    GENERIC
current config name:     GENERIC_002.072_000
current subpri index:    000
```

A different firmware version can be selected with the **Upgrade to another firmware (Advanced)** option along with the **Firmware** dropdown. Once the firmware version is selected, click on the **Upgrade Firmware** button to initiate the firmware update. The **Install application** progress bar will display the upgrade status (a manual refresh may be required). The upgrade may take from 10 minutes up to a few hours, depending on cellular connectivity. At the completion of the upgrade, the new firmware version will be visible in the cellular status on the EMG.

If the firmware update does not complete, it may need to be restarted, or the EMG may need to be rebooted and the process beginning with step 1 or 2 may need to be repeated.

5. Disable FOTA and the connection to AirVantage. Once the firmware update is complete, the FOTA mode and connection should be disabled by running the `set cellular fota disable` CLI command.

Cellular Modem Commands

Go to [Cellular Modem Commands](#) to view CLI commands which correspond to the web page entries described above.

Wireless Settings

Wireless Overview

Wireless networking is supported only in EMG. The EMG can be configured as a wireless station (client) or an access point (AP), but not both simultaneously. Both configurations act as a network interface with a single IP address assigned to it, supporting the same applications that are accessible over the other network interfaces. The AP is enabled by default with Open security, for the primary purpose of initial setup and configuration of the EMG (this requires the usual login credentials to gain access to the EMG UI). Once initial configuration is complete, the AP should be reconfigured with stronger security settings or disabled.

To update the WiFi firmware, see [Wireless Firmware](#) and for troubleshooting, see [Troubleshooting](#).

WiFi Regulatory Domain

The WiFi regulatory domain can be changed on the main Wireless Setting page. Supported regions are: FCC (United States), IC (Industry Canada), CN (China), JP (Japan), KCC (Korea),

ETSI (Europe without EN 300 440 support), EN440 (Europe with EN 300 440 support), AU (Australia) and WW (World Mode).

Warning: *This is an Advanced Configuration parameter. Each time the region is changed it is programmed into the radio, which can be done a maximum of ~10 times; use care when changing the region. There are no visible counters showing how many times it has been changed. After the tenth change, the region code remains stuck on the tenth setting permanently.*

Access Point

The EMG access point is enabled by default, with Open security. This allows a wireless device to connect to the EMG for initial configuration of the EMG, instead of using connections that require a cabled connection. The default SSID is **Lantronix_EMGxxxx**, where **xxxx** is the last 4 characters of the Ethernet port Eth1 MAC address.

Warning: *After logging into the EMG, you should enable AP security and re-associate with new security settings.*

The access point will allow WiFi devices to connect to the EMG and access all functions, similar to how users on a wired network connect to the EMG via Ethernet ports Eth1 or Eth2. A maximum of 5 clients can connect simultaneously to the access point. A DHCP server will assign IP addresses to the clients.

The access point supports WPA or WPA2 for security, with CCMP for AES in Counter mode with CBC-MAC (preferred), TKIP for Temporal Key Integrity Protocol.

Wireless Client

Configuring the EMG to connect to a WLAN network as a client requires a WLAN profile, which is a set of configuration parameters that will enable the EMG to connect and authenticate to a WLAN network. The EMG supports up to 4 WLAN profiles, with a priority assigned to each profile. The matching network with the highest priority value will be selected for the client connection. Profiles can be created manually by entering the SSID and authentication parameters. Profiles can also be created with Quick Connect which will scan for wireless networks within range and present a list of networks; any detected network can be selected and added as a WLAN profile along with the required authentication information.

The wireless client can connect to a WLAN network using WEP authentication (Open or Shared with 64 bit or 128 bit encryption), or WPA/WPA2 authentication (PSK or 802.1X/Enterprise with AES/CCMP or TKIP encryption).

802.1X is an enterprise class access protocol for protecting networks via authentication. There are three components to 802.1X authentication:

- ◆ A supplicant, or client, which requires authentication (the EMG).
- ◆ An authenticator, or access point, which acts as a proxy for the client, and restricts the client's communication with the authentication server.
- ◆ An authentication server (usually RADIUS), which decides whether to accept the client's request for network access.

Extensible Authentication Protocol (EAP) is used to pass the authentication information between the supplicant (the EMG) and the authentication server. The EAP type handles and defines the authentication. The access point acting as authenticator is only a proxy to allow the supplicant and the authentication server to communicate. The EMG supports the following EAP protocols:

- ◆ **LEAP:** Lightweight Extensible Authentication Protocol (LEAP) uses dynamic WEP keys and mutual authentication with a modified version of MS-CHAP between the EMG and a RADIUS server.
- ◆ **EAP-TLS:** uses TLS and Public key Infrastructure (PKI) to set up authentication with a RADIUS server. This method requires the use of a client-side certificate for communicating with the server.
- ◆ **EAP-TTLS:** uses TTLS (Tunneled Transport Layer Security) and server-side certificates to set up authentication between the EMG and a RADIUS server. The actual authentication is, however, performed using passwords.
- ◆ **PEAP:** Protected EAP uses server-side public key certificates to authenticate the EMG with a RADIUS server. PEAP authentication creates an encrypted TLS tunnel between the EMG and the server. The exchange of information is encrypted and stored in the tunnel ensuring the user credentials are kept secure.
- ◆ **FAST:** Flexible Authentication via Secure Tunneling uses Protected Access Credential (PAC) for verifying clients on the network. Instead of using a certificate to achieve mutual authentication, FAST authenticates by means of a PAC (Protected Access Credential) stored on the EMG, which can be managed dynamically by the authentication server. The PAC can be provisioned (distributed one time) to the client either manually or automatically. Manual provisioning is delivery to the client via disk or a secured network distribution method. Automatic provisioning (used on the EMG) is an in-band distribution.

This table summarizes the features of each EAP protocol:

EAP Protocol Feature	TLS	TTLS	PEAP	FAST	LEAP
Client-side certificate required	yes	no	no	no (PAC)	no
Server-side certificate required	yes	yes	yes	no (PAC)	no
WEP key management	yes	yes	yes	yes	yes
Rogue AP detection	no	no	no	yes	yes
Authentication attributes	Mutual	Mutual	Mutual	Mutual	Mutual
Deployment difficulty	Difficult (because of client certificate deployment)	Moderate	Moderate	Moderate	Moderate
WiFi Security	Very High	High	High	High	High (when strong passwords are used)

Wireless Firmware

The Wireless radio firmware can be updated if necessary. Normally, it is updated along with the new EMG releases in conjunction with updating the wireless driver. The firmware consists of a pair of files ending with **.bin** and **.db**.

The Update WiFi Firmware page allows the user to upload a new version of firmware, or to reset to the current firmware version that is the default firmware for the current EMG release. Updating the firmware or resetting the firmware requires a reboot in order for the change to take effect.

To update the WiFi firmware:

1. Click the **Network** tab and select the **Wireless Settings** option. Click the **Update WiFi Firmware** link. The **Update WiFi Firmware** page appears.

Figure 7-6 Update WiFi Firmware

LANTRONIX® EMG851100

Logout Host: emgfcbb User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings Cellular Modem Wireless Settings IP Filter Routing VPN Security Perf Monitoring FQDN List

Update WiFi Firmware [Help?](#)

Radio FW Version: 5.4.27.5
Driver Version: 7.1.0.9

Note: Updating or resetting firmware requires a reboot to take effect.

Reset Firmware: ☐
Update Firmware: ☒

WiFi Firmware File: [Upload File >](#) FTP/SFTP/SCP Server:

WiFi DB File: [Upload File >](#) Path:

Load Firmware via: **FTP** Login:

Password:
Retype Password:

[Apply](#)

2. Enter the following information:

Reset Firmware	Allows you to reset the WiFi firmware to the factory default version.
Update Firmware	Allows you to update the WiFi firmware. The EMG unit reboots after you apply the update.
WiFi Firmware File	Displays the name of the WiFi firmware (.bin) file. The Upload File link associated with this field is only available when you select HTTPS as the method to load the WiFi firmware.
WiFi DB File	Displays the name of the WiFi database (.db) file. The Upload File link associated with this field is only available when you select HTTPS as the method to load the WiFi firmware.
Load Firmware via	Allows you to select a method to load the WiFi firmware. The available options are FTP , SFTP , SCP , USB , SD Card , and HTTPS . By default, FTP is selected.

FTP/SFTP/SCP Server	The IP address or host name of the server used for obtaining updates, saving, or restoring configurations. It may consist of 64 alphanumeric characters, hyphens, and underscores.
Path	The default path on the server for obtaining firmware update files.
Login/ Password/Retype Password	The user login credentials of the server.

3. Click **Apply**.

Troubleshooting

Under rare conditions, it may be necessary to reset the WiFi interface if the EMG reports that the device **wlan0** (wireless client device) or **ap0** (access point device) cannot be found. The CLI command `diag wlan reset` can be used for this purpose.

Wireless Client Settings

The EMG can be configured as a wireless client or an access point. This page describes how to configure the EMG to be a client; the wireless client is disabled by default.

From this page, the user can:

- ◆ Configure the WiFi mode: wireless client, access point, or disabled.
- ◆ Configure and view the status of the wireless client network interface, including interface counters.
- ◆ Configure WLAN profiles required by the wireless client to connect to a WLAN network, either by manually creating a profile or by Quick Connect. Open, WEP, WPA/WPA2 (including 802.1X/Enterprise) authentication is supported.
- ◆ View the log for the wireless client.
- ◆ Access the web page to configure and view the status of the wireless access point.

Configuring the EMG to connect to a WLAN network requires a WLAN profile, which is a set of configuration parameters that will enable the EMG to connect and authenticate to a WLAN network. The EMG supports up to 4 WLAN profiles, with a priority assigned to each profile. The matching network with the highest priority value will be selected for the client connection. Profiles can be created manually by entering the SSID and authentication parameters. Profiles can also be created with Quick Connect which will scan for wireless networks within range and present a list of networks with service set identifier (SSID), basic service set identifier (BSSI), channel number, received signal strength indication (RSSI), and Security Suite; any detected network can be selected and added as a WLAN profile along with the required authentication information.

Note: *Until the WLAN client finds a network that matches one of the WLAN profiles, it will be periodically scanning to look for a network. This background scanning may interfere with manual scans initiated from the web UI or CLI; when this happens the message 'SCAN' command failed, client is currently scanning, please try again. is displayed.*

To configure the wireless mode:

1. Click the **Network** tab and select the **Wireless Settings** option. The following page displays:

Figure 7-7 Network > Wireless Settings

LANTRONIX® EMG752020

Logout Host: **Emg8300R13** User: **sysadmin** Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings Wireless Settings IP Filter Routing VPN Security Perf Monitoring FQDN List

Wireless Settings [Help?](#)

Wireless Mode: ☒ Wireless Client ☐ Wireless Access Point ☐ Disabled

Wireless Region: Korea

Wireless Client Interface

WLAN Settings: ☐ Obtain from DHCP ☒ Specify:

IP Address: 172.19.100.8

Subnet Mask: 255.255.0.0

DHCP Acquired Gateway: **None**

DHCP Acquired Primary DNS: **None**

DHCP Acquired Secondary DNS: **None**

IPv6 Address: (Static)

IPv6 Address: (Global) 2001:db80:ac13:d91e:c2e

IPv6 Address: (Link Local) fe80::c2ee:40ff:fe43:3180/64

MTU: 1500

HW Address: c0:ee:40:43:31:80

Link State: Up

Connection Status: Connected

Connected at: 02/26/20 12:17:45.888894

BSSID: 2c:5a:0f:4a:8d:ab

SSID: pat_cisco3800_5ghz_radius

Authentication: WPA2-WPA Mixed Mode/802.1X-EAP-TTLS

Pairwise Cipher: CCMP

Group Cipher: CCMP

Frequency Band: 5G (Ch: 44)

Signal: -47 dBm

[Configure Access Point](#)

[Configure WLAN Profiles](#)

[WLAN Scan/Quick Connect](#)

Note: the WLAN scan may take up to 1 minute.

[View Wireless Interface Log](#)

Note: IPv6 settings require IPv6 to be enabled on the [Network Settings](#) page.

Interface Counters

	Rx				Tx		
	Bytes	Packets	Errors	Multicast	Bytes	Packets	Errors
WLAN	69399452	414220	0	0	87514653	689035	0

2. Enter the following information:

Wireless Mode	Select the mode that WiFi should operate in. Wireless Client: If selected, enables the EMG to act as a wireless client of a WLAN network. In order to connect to a WLAN network, a WLAN profile for that network needs to exist and be enabled. The default is for the wireless client to be disabled Wireless Access Point: If selected, enables the access point to scan for wireless clients and allow them to connect and authenticate to the EMG. The default is for the access point to be enabled. The access point cannot be enabled if the wireless client is enabled. Disabled: If selected, disables the wireless client and the access point.

3. To save, click **Apply**.

To configure the wireless client:

1. Enter the following information:

WLAN Settings	Select how an IP address is assigned to the wireless client: if Obtain from DHCP is selected, the EMG will acquire an IP address and subnet mask from the access point it connects to. If Specify is selected, the user can enter an IP address and subnet mask that is on the same subnet as the access point.
DHCP Acquired Gateway	(read only) Displays any gateway acquired from the access point the wireless client connects to. This gateway can be set as the default gateway for the EMG by configure the gateway precedence in the Network Port Settings .
DHCP Acquired Primary/Secondary DNS	(read only) Displays any DNS servers acquired from the access point the wireless client connects to.
IPv6 Address (Static)	Enter the IPv6 address for the wireless client. This requires that IPv6 be enabled in the Network Port Settings .
IPv6 Address (Link Local)	(read only) Displays the link local IPv6 address for the wireless client. This requires that IPv6 be enabled in the Network Port Settings .
MTU	Specifies the Maximum Transmission Unit (or Maximum Packet Size) of packets at the IP layer (OSI layer 3) for the wireless client. When fragmenting a datagram, this is the largest number of bytes that can be used in a packet. The minimum MTU size is 108 bytes (to conform with RFC 2460) and the maximum size is 1500 bytes.
HW Address	(read only) Displays the MAC address of the wireless client.
Link State	(read only) Displays the link status (up and running, or down) of the wireless client interface.
Connection Status	(read only) Displays the status of the wireless client - connected to a WLAN network, or disconnected.
Connected/Disconnected at	(read only) displays the time at which the wireless connected or disconnected from the WLAN network.
WLAN Network Information	(read only) If the wireless client is connected to a WLAN network the BSSID, SSID, Frequency Band, Signal, Pairwise Cipher, Group Cipher and Key Management for the WLAN network are displayed.

2. To save, click **Apply**.

Interface Counters

This table shows statistics for data received by and transferred from the wireless client interface.

Interface Counters							
	Rx				Tx		
	Bytes	Packets	Errors	Multicast	Bytes	Packets	Errors
WLAN	69799672	415660	0	0	87516783	689053	0

Wireless Interface Log

Click the **View Wireless Interface Log** link to see diagnostic information for the wireless client.

WLAN Profiles

In order to connect to a WLAN network, a WLAN profile for that network needs to exist and be enabled. This section describes how to manually create a profile; see also [Quick Connect](#).

The EMG supports up to 4 WLAN profiles, with a priority assigned to each profile. The matching network with the highest priority value will be selected for the client connection.

To create a WLAN profile:

1. Click the **Configure WLAN Profiles** link.
2. The WLAN Profiles page displays a list of profiles along with the profile SSID and State. If the wireless client is connected, the active profile will display next to the Profile Name.

Figure 7-8 Network > Wireless Settings > WLAN Profiles

LANTRONIX® EMG752020

Logout Host: Emg8300R13 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings Wireless Settings IP Filter Routing VPN Security Perf Monitoring FQDN List

WLAN Profiles [Help?](#)

Default Profile: ☒ A default profile allows network scanning without a custom profile enabled.

[Add Profile](#) [View / Edit Profile](#) [Delete Profile](#)

WLAN Custom Profiles			
Profile Name	SSID	Priority	State
pat_cisco3800_5ghz_radiustt1s2	pat_cisco3800_5ghz_radius	1	Enabled ☐

[Back to Wireless Settings](#) [Apply](#)

3. To add a new profile click **Add Profile**, or to edit an existing profile, select a profile and click **View/Edit Profile** button.

4. Enter the following information:

Profile Name	Profile name, up to 32 characters long. Valid characters are letters, numbers, space (), dash (-), period (.) and underscore (_).
Network Name (SSID)	Enter the Service Set Identifier or network name for the WLAN network. The SSID can contain up to 32 characters (the characters '/', '\', '"' and ' ' are not allowed).
State	The state of the profile; only Enabled profiles can be used to connect to a WLAN network.
Priority	The priority of the profile, which is a number from 1 to 4. When choosing a profile to connect with, profiles with higher priority values are given precedence over priorities with lower priority values.
Security Suite	Select the security suite used by the profile: None: Select this to connect to a WLAN network with no security, e.g. an open network that does not require a security token or password. WEP: Select this to connect to a WLAN network that uses Wired Equivalent Privacy security. WEP is a simple and efficient security mode, encrypting the data using the RC4 algorithm with either 64 bit encryption or 128 bit encryption. However, WEP has become more vulnerable due to advances in hacking technology. State-of-the-art equipment can find WEP keys in a few minutes. WPA2/WPA Mixed Mode: select this to connect to a WLAN network that uses WiFi Protected Access (WPA) security or WiFi Protected Access II (WPA2) security. The EMG will accept either protocol when connecting to an access point (WPA2 will be preferred over WPA). The keys used by WPA and WPA2 are 256 bit, and the data is encrypted with Temporal Key Integrity Protocol (TKIP) or Counter Mode CBC-MAC Protocol (CCMP), an AES encryption suite. WPA2 with CCMP encryption is the preferred security suite, as it offers the greatest level of security.

WEP Security Parameters	If the WEP security suite is selected, these authentication parameters can be selected and configured: Authentication: Select Open for a connection that establishes without first checking for matching encryption keys (if keys do not match, data may be dropped or become garbled and prevent connectivity on the IP level), or Shared for a connection that compares encryption keys of both parties as a form of authentication (if mismatches occur, no connection establishes). Note: Open authentication requires a passphrase; this passphrase is used to encrypt the data, and is not used for authentication. Key Type: For WEP Shared authentication, select the type of key required for the WLAN network: Passphrase for an ASCII password, or Hex for a 40 bit or 104 bit hexadecimal key. Key Size: For WEP Shared authentication, select the size of key required for the WLAN network: 40 bit for 64 bit WEP, or 104 bit for 128 bit WEP. If you use a 40 bit key size, you need a key that is 5 ASCII characters or 10 hex characters long; the 24 bit initialization vector (IV) is added to the 40 bit long key to produce a 64 bit key. If you use a 104 bit key size, you need a key that is 13 ASCII characters or 26 hex characters long; the 24 bit initialization vector is added to the 104 bit long key to produce a 128 bit key. The initialization vector is not user configurable. Passphrase / Retype Passphrase: For WEP Shared authentication with Passphrase, enter the ASCII passphrase required to authenticate the connection. For Key Size of 40 bits, the passphrase must be 5 characters. For Key Size of 104 bits, the passphrase must be 13 characters. All printable characters may be used in the passphrase. Transmit Key Index: For WEP Shared authentication with Hex keys, select which of the 4 hex keys to use to encrypt the data that is transmitted. For interoperability with some systems, this index must be set to 1. Key 1-4: For WEP Shared authentication with Hex keys, enter at least 1 and up to 4 hexadecimal keys. The keys should be exactly 10 hexadecimal characters for 64 bit WEP, and exactly 26 hexadecimal characters for 128 bit WEP. The Show Keys checkbox can be used to display the masked key.

WPA/WPA2 Security Parameters	If WPA2/WPA Mixed Mode security suite is selected, these authentication parameters can be selected and configured: Authentication: Select PSK for a connection where the same key must be configured on both on the EMG side and on the access point side, or IEEE 802.1X for a connection that is authenticated with a RADIUS server that is part of the network. The RADIUS server matches the credentials sent by the EMG with an internal database. If IEEE 802.1X is selected under authentication type, see the IEEE 802.1X Parameters below for configuring WPA2 enterprise authentication. Key Type: For WPA/WPA2 PSK authentication, select the type of key required for the WLAN network: Passphrase for an ASCII password, or Hex for a 64 character hexadecimal key. Passphrase / Retype Passphrase: For WPA/WPA2 PSK authentication with Passphrase, enter the passphrase required to authenticate the connection. The minimum length of passphrase is 8 characters and the maximum length is 63 characters. All printable characters may be used in the passphrase. Key: For WPA/WPA2 PSK authentication with Hex keys, enter the hexadecimal key. The key should be exactly 64 hexadecimal characters. The Show Keys checkbox can be used to display the masked key. Encryption: For WPA/WPA2 PSK authentication, select the type of encryption - CCMP (preferred), TKIP or Any.
IEEE 802.1X Parameters	802.1X uses enterprise class authentication to grant access to secure networks. There are 3 components to 802.1X: ◆ A supplicant, or client, which requires authentication (the EMG). ◆ An authenticator, or access point, which acts as a proxy for the client, and restricts the client's communication with the authentication server. ◆ An authentication server (usually RADIUS), which decides whether to accept the client's request for network access. If IEEE 802.1X is selected for Authentication, these parameters can be selected and configured: IEEE 802.1X EAP Protocol: Select one of the following Extensible Authentication Protocol (EAP) protocols to use for authentication with the RADIUS server. With EAP, the keys used for authentication are negotiated and changed automatically, offering a greater level of security over PSK authentication where the keys are stored on the device on each side of a connection. LEAP: Lightweight Extensible Authentication Protocol (LEAP) uses dynamic WEP keys and mutual authentication with a modified version of MS-CHAP between the EMG and a RADIUS server. EAP-TLS: uses TLS and Public key Infrastructure (PKI) to set up authentication with a RADIUS server. This method requires the use of a client-side certificate for communicating with the server. EAP-TTLS: uses TTLS (Tunneled Transport Layer Security) and server-side certificates to set up authentication between the EMG and a RADIUS server. The actual authentication is, however, performed using passwords.

**IEEE 802.1X Parameters,
continued**

PEAP: Protected EAP uses server-side public key certificates to authenticate the EMG with a RADIUS server. PEAP authentication creates an encrypted TLS tunnel between the EMG and the server. The exchange of information is encrypted and stored in the tunnel ensuring the user credentials are kept secure.

FAST: Flexible Authentication via Secure Tunneling uses Protected Access Credential (PAC) for verifying clients on the network. Instead of using a certificate to achieve mutual authentication, FAST authenticates by means of a PAC (Protected Access Credential) stored on the EMG, which can be managed dynamically by the authentication server. The PAC can be provisioned (distributed one time) to the client either manually or automatically. Manual provisioning is delivery to the client via disk or a secured network distribution method. Automatic provisioning (used on the EMG) is an in-band distribution.

LEAP Configuration: Enter a **User Name** and **Password** that can be authenticated by the RADIUS server. The User Name and Password can be up to 63 characters long, and all printable characters are supported.

EAP-TLS Configuration: Enter a **User Name** that can be authenticated by the RADIUS server. The User Name can be up to 63 characters long, and all printable characters are supported. Provide a client side certificate with a **Certificate** file, **Private Key** file and **Authority Certificate** file. The server side certificate can be validated by setting **Validate Certificate** to **Enabled** (requires an Authority Certificate); validating server the certificate is highly recommended. Certificate filenames must be unique across all profiles, otherwise certificates for one profile may be overwritten by certificates for another profile. If certificates are used, when saving and restoring configurations, it is recommended that the configuration be saved with SSL Certificates and the configuration be restored with the saved certificates. The Certificate Authority and Certificate are in PEM format (the Certificate Authority may have one or more trusted CA certificates), eg:

```
-----BEGIN CERTIFICATE-----
(certificate in base64 encoding)
-----END CERTIFICATE-----
```

The Key File is in PEM format, eg:

```
-----BEGIN RSA PRIVATE KEY-----
(private key in base64 encoding)
-----END RSA PRIVATE KEY-----
```

EAP-TTLS Configuration: Enter a **User Name** and **Password** that can be authenticated by the RADIUS server. The User Name and Password can be up to 63 characters long, and all printable characters are supported. Select the **EAP TTLS Inner Authentication** used in the TLS tunnel, which can be **EAP-MSCHAPv2**, **MSCHAPv2**, **MSCHAP**, **CHAP**, **PAP** or **EAP-MD5**.

IEEE 802.1X Parameters, continued	PEAP Configuration: Enter a User Name and Password that can be authenticated by the RADIUS server. The User Name and Password can be up to 63 characters long, and all printable characters are supported. Select the PEAP Inner Authentication used in the TLS tunnel, which can be EAP-MSCHAPv2, EAP-TLS or EAP-MD5. If EAP-TLS is selected for Inner Authentication, a client side certificate with a Certificate file, Private Key file and Authority Certificate file must be provided (see EAP-TLS Configuration for certificate file formats). Certificate filenames must be unique across all profiles, otherwise certificates for one profile may be overwritten by certificates for another profile. FAST Configuration: Enter a User Name and Password that can be authenticated by the RADIUS server. The User Name and Password can be up to 63 characters long, and all printable characters are supported. Select the FAST Inner Authentication, which can be MSCHAPv2, GTC or EAP-MD5. If Inner Authentication is set to MSCHAPv2, select FAST Provisioning, which controls in-line provisioning of the PAC (Protected Access Credential): Authenticated (requires a server certificate), Unauthenticated (requires no server certificate), or Both.

5. To save, click **Apply**.

Quick Connect

Quick Connect simplifies adding WLAN profiles by scanning the wireless network, and displaying all of the networks that are detected with the SSID, BSSID, Frequency and Channel, Signal and Security Suite for each network. Selecting the link for any channel will display a WLAN profile page with fields to fill in the appropriate authentication tokens (for example the passphrase or key for a network with WPA2 security). Refer to the configurable items for WLAN Profiles for a description of the fields on the Quick Connect web page.

Note: For networks that are detected that do not broadcast the SSID, the scan will display [No SSID broadcast].

Wireless Access Point Settings

Wireless networking is supported on EMG models only. The EMG can be configured as a wireless client or an access point. This page describes how to configure the EMG to be an access point, which is enabled by default. The access point will allow WiFi devices to connect to the EMG and access all functions, similar to how users on a wired network connect to the EMG via Ethernet ports Eth1 or Eth2. A maximum of 5 clients can connect simultaneously to the access point. A DHCP server will assign IP addresses to the clients.

As the access point is enabled by default, a wireless device can be used for initial configuration of the EMG, instead of using connections that require a cabled connection, such as the console port or Ethernet Ports.

To configure the wireless access point:

1. On the Wireless Settings page, click the **Configure Access Point** link.
2. The following page is displayed.

Figure 7-9 Network > Wireless Settings > Access Point Settings

LANTRONIX® EMG752020

Logout Host: Emg8300R13 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings Wireless Settings IP Filter Routing VPN Security Perf Monitoring FQDN List

Wireless Access Point Settings

State: **Enabled** [Refresh](#)

Network Name (SSID): [View Access Point Log](#)

SSID Broadcast: ☒ Enabled ☐ Disabled

Channel Selection: ☒ Auto ☐ Manual, Enter channel number:

Security Suite: ☒ None ☐ WPA ☐ WPA2

Encryption:

Passphrase:

Retype Passphrase:

IP Address:

Subnet Mask:

DHCP Pool Start IP Address:

DHCP Pool End IP Address:

Access Point Interface Details

ifindex	8
wdev	0x2
addr	c0:ee:40:43:31:81
ssid	Lantronix_EMGfd2a
type	AP
wiphy	0
channel	1 (2412 MHz), width: 20 MHz (no HT), center1: 2412 MHz
txpower	20.00 dBm

Active Client List

Click on MAC Address for more information

MAC Address	IP Address

Interface Counters

	Rx				Tx		
	Bytes	Packets	Errors	Multicast	Bytes	Packets	Errors
ap0	0	0	0	0	576	6	0

3. Enter the following information:

State	Displays the current state of the access point. Enabled: If selected, enables the access point to scan for wireless clients. The default is enabled. The access point cannot be enabled if the wireless client is enabled. Disabled: If selected, disables the access point.
Network Name (SSID)	Enter the Service Set Identifier or network name for the access point. The SSID can contain up to 32 characters (the characters '/', '\', '"' and ' ' are not allowed). The default SSID is Lantronix_EMGxxxx, where xxxx is the last 4 characters of the Ethernet port Eth1 MAC address.
SSID Broadcast	If enabled, the EMG will broadcast its SSID in the beacons that are sent out. Enabled by default.

Channel Selection	Select the channel through which the access point will operate: Auto allows the radio to select a channel; or Manual allows the user to specify the channel on which the access point will operate.
Security Suite	Select the authentication method for connecting to the access point: None for no security (not recommended), WPA for WiFi Protected Access, or WPA2 for WiFi Protected Access II security with AES-CCMP encryption.
Encryption	When the Security Suite is set to WPA or WPA2 , this selects the encryption used: CCMP for AES in Counter mode with CBC-MAC (preferred), TKIP for Temporal Key Integrity Protocol, or Any for both CCMP and TKIP.
Passphrase/Retype Passphrase	If WPA or WPA2 is selected for the Security Suite , enter the password to connect to the access point.
IP Address	Specifies the IP address of the access point.
Subnet Mask	Specifies the network segment of the access point.
DHCP Pool Start/End IP Address	The access point provides DHCP addresses to clients that connect to the access point. The DHCP Pool specifies the starting and ending IP address of the addresses (maximum of 5 clients can connect to the access point). These addresses must be in the same subnet as the IP address of the access point.

4. To save, click **Apply**.

Active Client List

This table shows the list of clients currently connected to the access point. Click on a MAC Address to view more information about the client.

Interface Counters

This table shows statistics for data received by and transferred from the access point.

Ethernet Switch

The EMG supports an integrated managed Ethernet Switch that can be used to connect network devices to the console manager. This switch can be used as a management LAN to provide secure access to these network devices. [VLANs](#) can be used to group a subset of switch ports into a logical network, and DHCP services are available to provide IP addresses and other network information to devices connected to the switch.

The default IP address and subnet mask on the Ethernet Switch is 192.168.10.1 / 255.255.255.0. The IP address and subnet mask on the Ethernet switch can be changed via the DHCP settings.

The Ethernet Switch port LEDs display the following states:

- ◆ Green Light On: indicates a link at 1000 BASE-T
- ◆ Green Light Off: indicates a link at other speeds, or no link
- ◆ Yellow/Orange Light On: indicates a link is established
- ◆ Yellow/Orange Light Blinking: indicates link activity

On console server models with a managed Ethernet Switch installed, the user can:

- ◆ Configure Ports and View Status: configure the speed and duplex on each port, and see the link status
- ◆ View Port Statistics: view frame statistics (errors, unicast, broadcast, etc) and frame details (undersize, collisions, etc.)
- ◆ View MAC address table: view static and dynamic MAC address table entries

To configure a switch port:

1. Click the **Network** tab and select the **Switch** option. The following page displays:

Figure 7-10 Network > Ethernet Switch

LANTRONIX® EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings Switch VLANs DHCP IP Filter Routing Forwarding VPN Security Perf Monitoring FQDN List

Ethernet Switch [Help?](#)

The Ethernet switch IP address can be updated via the [DHCP](#) web page. [Refresh](#) [Switch Details](#) [MAC Address Table](#)

Port Status Configure						
No	Name	VLAN Membership	State	Link Status	MDI-X Status	Select
1	Switch-Port-1	1	Enabled	Down	Down	☐
2	Switch-Port-2	1	Enabled	Down	Down	☐
3	Switch-Port-3	1	Enabled	Down	Down	☐
4	Switch-Port-4	1	Enabled	Down	Down	☐

Port Rx/Tx Frame Statistics Refresh							
		Good (bytes)	Errors	Unicast	Broadcast	Multicast	Pause
1	Rx	0	0	0	0	0	0
	Tx	0		0	0	0	0
2	Rx	0	0	0	0	0	0
	Tx	0		0	0	0	0
3	Rx	0	0	0	0	0	0
	Tx	0		0	0	0	0
4	Rx	0	0	0	0	0	0
	Tx	0		0	0	0	0

Port Frame Details Port: 1 Refresh								
Rx	Undersize	0	Tx	Deferred	0	All	64 Octets	0
	Fragments	0		Collisions	0		65-127 Octets	0
	Oversize	0		Single Collision	0		128-255 Octets	0
	Jabber	0		Multiple Collisions	0		256-511 Octets	0
	RxErr	0		Excessive Collisions	0		512-1023 Octets	0
	FCSErr	0		Late	0		1024-Max Octets	0
			FCSErr	0				

2. Select a port in the **Port Status** table, and select **Configure**. The **Ethernet Switch - Configure Port** page is displayed.

Figure 7-11 Network > Switch > Configure Port Settings

The screenshot shows the LANTRONIX EMG851300 web interface. At the top, there's a header with the logo and a port selection grid. Below the header, there's a navigation bar with tabs like Network, Services, User Authentication, Devices, Maintenance, and Quick Setup. The main content area is titled 'Ethernet Switch - Configure Port'. It shows configuration options for Port 1: Name (Switch-Port-1), Enabled (checked), Mode (Auto), and MDI-X (Auto). An 'Apply' button is at the bottom.

3. Complete the following:

Name	User definable name for the port. The name can be up to 30 characters long and contain letters, numbers, underscore, hyphen and period.
Enabled	Select this box to enable the port and allow devices to connect to it. Enabled by default.
Mode	Select the direction (Full-Duplex or Half-Duplex) and speed (10, 100, or 1000 Mbit) of data transmission. The default is Auto , which allows the Ethernet port to auto-negotiate the speed and duplex with the hardware endpoint to which it is connected.
MDI-X	MDI & MDI-X are types of Ethernet interfaces (both physical and electrical/optical) in a computer network used to carry transmission. They must be connected using the right twisted pair cable so that the transmission pair on one end is linked to the receiving pair on the other end, and vice versa. In general, MDI ports connect to MDI-X ports via straight-through twisted pair cabling, and for MDI to MDI or MDI-X to MDI-X connections, crossover twisted pair cables are deployed. Each port in the switch can be configured for Manual MDI (connect a port to a device by using a straight through cable), Manual MDI-X (swap the port's transmit and receive pairs), or Auto (the port will detect if the connection requires a crossover and automatically chooses MDI or MDI-X to properly match the other end of the link - so it does not matter if a straight through or crossover cable is used). The default setting is Auto. The MDI-X column in the Port Status table shows the current operational MDI-X mode for each port.

4. Click **Apply** to save the port settings.

Port Statistics

Rx - Good	The sum of lengths of good frames received, e.g., the sum of lengths of Rx - Unicast, Rx - Broadcast, Rx - Multicast and Rx - Pause.
Rx - Errors	The sum of lengths of bad frames received, e.g., the sum of lengths of Rx - Undersize, Rx - Fragments, Rx - Oversize, Rx - Jabber, Rx - RxErr and Rx - FCSErr.
Rx - Unicast	The number of good frames received that have a Unicast destination MAC address.

Rx - Broadcast	The number of good frames received that have a Broadcast destination MAC address.
Rx - Multicast	The number of good frames received that have a Multicast destination MAC address. This does not include frames counted in Rx - Pause nor does it include frames counted in Rx - Broadcast.
Rx - Pause	The number of good frames received that have a Pause destination MAC address. This includes Priority Flow Control (PFC) Pause frames.
Tx - Good	The sum of lengths of all Ethernet frames sent.
Tx - Unicast	The number of frames sent that have a Unicast destination MAC address.
Tx - Broadcast	The number of frames sent that have a Broadcast destination MAC address.
Tx - Multicast	The number of frames sent that have a Multicast destination MAC address. This does not include frames counted in Tx - Pause nor does it include frames counted in Tx - Broadcast.
Tx - Pause	The number of Flow Control frames sent. This includes Pause and Priority Flow Control (PFC) Pause frames.
Tx - Pause	The number of good frames received that have a Pause destination MAC address. This includes Priority Flow Control (PFC) Pause frames.
Rx - Undersize	Total frames received with a length of less than 64 octets but with a valid FCS.
Rx - Fragments	Total frames received with a length of less than 64 octets and an invalid FCS.
Rx - Oversize	Total frames received with a length of more than MaxSize octets but with a valid FCS.
Rx - Jabber	Total frames received with a length of more than MaxSize Octets but with an invalid FCS.
Rx - RxErr	Total frames received with an RxErr signal from the PHY. This includes 10 GE MAC Termination Errors.
Rx - FCSErr	Total frames received with a CRC error not counted in Rx - Fragments, Rx - Jabber or Rx - RxErr.
Tx - Deferred	The total number of successfully transmitted frames that experienced no collisions but are delayed because the medium was busy during the first attempt. This counter is applicable in half-duplex only.
Tx - Collisions	The number of collision events seen by the MAC not including those counted in Single, Multiple, Excessive, or Late. This counter is applicable in half-duplex only.
Tx - Single Collision	The total number of successfully transmitted frames that experienced exactly one collision. This counter is applicable in half-duplex only.
Tx - Multiple Collisions	The total number of successfully transmitted frames that experienced more than one collision. This counter is applicable in half-duplex only.
Tx - Excessive Collisions	The number frames dropped in the transmit MAC because the frame experienced 16 consecutive collisions. This counter is applicable in half-duplex only.
Tx - Late	The number of times a collision is detected later than 512 bits-times into the transmission of a frame. This counter is applicable in half-duplex only.

Tx - FCSErr	The number of frames transmitted with an invalid FCS. Whenever a frame is modified during transmission (e.g., to add or remove a tag) the frame's original FCS is inspected before a new FCS is added to a modified frame. If the original FCS is invalid, the new FCS is made invalid too and this counter is incremented. This can occur because frames with a bad FCS are allowed into the switch.
All - 64 Octets	Total frames received and/or transmitted with a length of exactly 64 octets, including those with errors.
All - 65-127 Octets	Total frames received and/or transmitted with a length of between 65 and 127 octets inclusive, including those with errors.
All - 128-255 Octets	Total frames received and/or transmitted with a length of between 128 and 255 octets inclusive, including those with errors.
All - 256-511 Octets	Total frames received and/or transmitted with a length of between 256 and 511 octets inclusive, including those with errors.
All - 512-1023 Octets	Total frames received and/or transmitted with a length of between 512 and 1023 octets inclusive, including those with errors.
All - 1024-Max Octets	Total frames received and/or transmitted with a length of between 1024 and MaxSize octets inclusive, including those with errors. MaxSize (the jumbo frame size) is 10240 bytes.

Switch Commands

Go to [Switch Commands](#) to view CLI commands which correspond to the web page entries described above.

VLANs

Some console server models support an integrated managed Ethernet Switch that can be used to connect network devices to the console manager. This switch can be used as a management LAN to provide secure access to these network devices. VLANs (Virtual LANs) are supported on the switch to provide a way to group together a subset of devices that share a physical LAN into a logical network, isolating the traffic for each group. On EMG models (with 4 switch ports) 2 VLANs are supported.

The console manager supports Port Membership VLANs; in other words, each VLAN is defined by a list of switch ports that are members of the VLAN. The switch port that is connected to the console manager CPU (port 0) can be included in any VLAN. For ingress traffic, the VLAN ID must be included in the Ethernet frame; if the VLAN ID matches in its number the tagged membership of the switch port, the frame will be accepted, otherwise it will be discarded.

By default, each Ethernet switch has one VLAN (ID #1) that includes all ports as untagged members (e.g., no VLAN tag in the Ethernet frame) of VLAN #1. Each switch can be configured with additional VLANs with VLANs (1 for EMG models). Each VLAN is configured with:

- ◆ **VLAN ID** - unique identifier for the VLAN ID (2-4095)
- ◆ **User defined VLAN name** - custom name for the VLAN (up to 30 characters, valid characters are digits, letters, hyphen and underscore)
- ◆ **Port membership list** - the list of switch ports that belong to a VLAN. Ports can be a member of more than one VLAN. The switch port that is connected to the console manager CPU (port 0) can be included in any VLAN.

- ◆ **Forwarding Information DB (FID)** - The FID maps learned MAC addresses to ingress port VLAN IDs. Multiple databases are used to isolate MAC addresses by VLAN or by port so the same MAC address can appear multiple times in the address database with different port mappings. The console manager uses a FID mechanism to isolate the address databases from each other. The Forwarding Information DB (FID) ID (range 0-255) indicates which FID is associated with a VLAN.

To configure a VLAN:

1. Click the **Network** tab and select the **VLANs** option. The following page displays:

The screenshot shows the LANTRONIX EMG851300 web interface. At the top, there's a header with the device name and a status bar showing port configurations (DIO, U1, E1, E2, 1, 2, 3, 4). Below the header is a navigation menu with tabs: Network, Services, User Authentication, Devices, Maintenance, and Quick Setup. Under the 'Network' tab, there's a sub-menu with links: Network Settings, Switch, VLANs, DHCP, IP Filter, Routing, Forwarding, VPN, Security, Perf Monitoring, and FQDN List. The 'VLANs' page is displayed, showing configuration fields for VLAN ID #1 (Default), Name (Default), Forwarding Information DB (0), and Port Membership (0-4). An 'Apply' button is at the bottom.

2. Complete the following:

VLAN ID	Read only for VLAN ID #1 Unique VLAN Identifier for VLAN in the range 2-4095
Name	User definable name for the VLAN. The name can be up to 30 characters long and contain letters, numbers, underscore, hyphen and period.
Forwarding Information DB	The FID identifier in the range 0-255.
Port Membership	Enter a list of switch ports that are a member of the VLAN, as a comma separated list of individual port numbers or ranges of port numbers. For example 0,2-4.

3. Click **Apply** to save the VLAN settings.

VLAN Commands

Go to [Switch Commands](#) to view CLI commands which correspond to the web page entries described above.

DHCP

On models with an Ethernet Switch installed, the console manager can provide DHCP services to clients connected to the Ethernet Switch. By default DHCP is disabled. Two DHCP modes are supported:

- ◆ **DHCP Server:** DHCP Server provides IP addresses and other networking parameters to devices connected to the Ethernet Switch that are running DHCP clients. The server can provide IP address, subnet mask, primary DNS IP address, secondary DNS IP address, gateway and domain. Lease times are given in hours, up to a maximum of 14 days.
- ◆ **DHCP Relay:** DHCP Relay forwards DHCP packets between devices connected to the Ethernet Switch and DHCP servers that are accessible via one of the other interfaces (Eth1, Eth2, cellular, or WiFi). This allows hosts connected to the Ethernet Switch to acquire IP addresses from a DHCP server already in service and reachable on the network. Because DHCP is a broadcast-based protocol, by default its packets do not pass from devices connected to the Ethernet Switch to other subnets. A DHCP relay agent receives any DHCP broadcasts on the Ethernet Switch and forwards them via unicast to DHCP servers on a different subnet. Since the DHCP servers are located on a different subnet they may need routes back to the Ethernet Switch that is requesting DHCP addresses on behalf of its connected clients. DHCP Relay can be configured to use one or two DHCP servers.

To configure DHCP:

1. Click the **Network** tab and select the **Switch** option. The following page displays:

Figure 7-12 Network > DHCP

LANTRONIX® EMG851300

Logout Host: emgcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings Switch VLANs DHCP IP Filter Routing Forwarding VPN Security Perf Monitoring FQDN List

DHCP Help ?

Ethernet Switch (Eth3) Network

Switch IP Address: 192.168.10.1

Switch Subnet Mask: 255.255.255.0

Ethernet Switch DHCP

Mode: Disabled ▼

Server Settings Status & Client List >

DHCP Pool Start IP Address:

DHCP Pool End IP Address:

Primary DNS IP Address:

Secondary DNS IP Address:

Gateway:

Domain:

Lease Time (hours): 24

Relay Settings

Server #1 IP Address:

Server #2 IP Address:

Apply

2. Complete the following:

Switch IP Address	The internal IP address assigned to the Ethernet Switch.
Switch Subnet Mask	The internal subnet mask assigned to the Ethernet Switch.
Mode	Select the type of DHCP service for devices connected to the Ethernet Switch: Server to run a DHCP server that provides IP addresses to clients, or Relay to relay DHCP requests between devices and a DHCP server on the network.

DHCP Server Settings

Note: Changing any DHCP server option will clear all DHCP client leases from the table maintained by the console manager.

DHCP Pool Start IP Address / DHCP Pool End IP Address	The beginning IP address and ending IP address for the pool of IP addresses that are distributed to DHCP clients on the Ethernet Switch. The pool IP addresses should be in the same subnet as the Ethernet Switch IP address / subnet mask.
Primary / Secondary DNS IP Address	An optional primary and secondary DNS IP address that may be provided to DHCP clients on the Ethernet Switch.

Gateway	An optional gateway (default router) IP address that may be provided to DHCP clients on the Ethernet Switch.
Domain	An optional domain that may be provided to DHCP clients on the Ethernet Switch. Maximum length is 64 characters.
Lease Time	The lease duration that will be provided in a DHCP Lease Offer to a DHCP client. The default is 24 hours. Lease times in the range of 1 hour to 336 hours (14 days) may be specified.

DHCP Relay Settings

Note: *IP Forwarding must be enabled if a DHCP client uses unicast (instead of broadcast) to communicate with a DHCP server.*

Server #1 IP Address	The IP address of the first DHCP server to send DHCP requests to, when DHCP Relay mode is enabled.
Server #2 IP Address	The IP address of the second DHCP server to send DHCP requests to, when DHCP Relay mode is enabled. If a second DHCP server is specified, DHCP requests will be sent to both Server #1 and Server #2 at the same time.

3. Click **Apply** to save the DHCP settings.
4. When DHCP server mode is enabled, click **Status & Client List** to see status and the current list of DHCP clients and their lease times.

DHCP Commands

Go to [DHCP Commands](#) to view CLI commands which correspond to the web page entries described above.

IP Filter

IP filters (also called a rule set) act as a firewall to allow or deny an individual MAC address or individual or a range of IP addresses, ports, and protocols. When a network connection is configured to use an IP filter, all network traffic through that connection is compared, in order, to the rules of that filter. Network traffic may be allowed to pass, it may be dropped (without notice), or it may be rejected (sends back an error packet) depending upon the rules of that filter rule set.

The administrator uses the [Network > IP Filter](#) page to view, add, edit, delete, and map IP filters.

Warning: *IP filters configuration is a feature for advanced users. Adding and enabling IP filter sets incorrectly can disable access to your EMG unit.*

Viewing IP Filters

You can view a list of filters and a table showing how each filter is mapped to an interface.

To view a list of IP filters:

1. Click the **Network** tab and select the **IP Filter** option. The following page displays:

Figure 7-13 Network > IP Filter

LANTRONIX[®] EMG851000

Logout Host: emgcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings IP Filter Routing VPN Security Perf Monitoring FQDN List

IP Filter [Help ?](#)

Enable IP Filter: ☐ [IP Filter Status >](#)

Packets Dropped: 0 Packets Rejected: 0

Test Timer: ☒ No ☐ Yes, minutes (1-120): Use the Test Timer to verify the IP Filter Rulesets; IP Filter will automatically be disabled when the Test Timer expires.

Time Remaining: 0 minutes

Add Ruleset Edit Ruleset Delete Ruleset

Map Ruleset to Interface: Delete Mapping

IP Filter Rulesets	
Name	

IP Filter Mappings	
Interface	Ruleset

Apply

Mapping Rulesets

The administrator can assign an IP Filter Rule set to a network interface (Eth1 or Eth2), a modem connected to a device port, a USB modem, or an LTE modem, dialup modem, or Wi-Fi interface, if any of those connectivity modules are installed.

To map a ruleset to a network interface:

1. Click the **Network** tab and select the **IP Filter** option. The [Network > IP Filter](#) page displays.
2. Select the IP filter rule set to be mapped.
3. From the **Interface** drop-down list, select the desired network interface and click the **Map Ruleset** button. The Interface and rule set display in the IP Filter Mappings table.

To delete a mapping:

1. Click the **Network** tab and select the **IP Filter** option. The [Network > IP Filter](#) page displays.
2. Select the mapping from the list and click the **Delete Mappings** button. The mapping no longer displays.
3. Click the **Apply** button.

Enabling IP Filters

On the [Network > IP Filter](#) page, you can enable all filters or disable all filters.

Note: *There is no way to enable or disable individual filters.*

To enable IP filters:

1. Enter the following:

Enable IP Filter	Select the Enable IP Filter checkbox to enable all filters, or clear the checkbox to disable all filters. Disabled by default.
Packets Dropped	Displays the number of data packets that the filter ignored (did not respond to). View only.
Packets Rejected	Displays the number of data packets that the filter sent a “rejected” response to. View only.
Test Timer	Timer for testing IP Filter rulesets. Select No to disable the timer. Select Yes, minutes (1-120) to enable the timer and enter the number of minutes the timer should run. The timer automatically disables the IP Filters when the time expires. Note: <i>If the console manager is rebooted before the timer expires, IP Filters will still be enabled when the console manager reboots; it is recommended that the Test Timer (and optionally IP Filters) be disabled before reboot.</i>
Time Remaining	Indicates how many minutes are left on the timer before it expires and IP Filters disabled. View only.

Configuring IP Filters

The administrator can add, edit, delete, and map IP filters.

Note: A configured filter has no effect until it is mapped to a network interface.
See [Mapping Rulesets on page 130](#).

To add an IP filter:

1. On the [Network > IP Filter](#) page, click the **Add Ruleset** button. The following page displays:

Figure 7-14 Network > IP Filter Ruleset (Adding/Editing Rulesets)

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings Switch VLANs DHCP IP Filter Routing Forwarding VPN Security Perf Monitoring

Network - IP Filter Ruleset Help ?

Ruleset Name: Number of Rules: 2

Rule Parameters

IPv4 Address(es):

Subnet Mask:

(or)

IPv6 Address(es):

(or)

MAC Address:

Protocol:

Port Range:

Action: ☒ Drop ☐ Reject ☐ Accept

Rules (in order of precedence)

0.0.0.0/0;All;;Drop
0::0/0;All;;Drop

Generate rule to allow service:

☒ BOOTP/DHCP	☐ Telnet	☐ HTTP	☐ FTP
☐ DNS	☐ SNMP	☐ NIS	☐ SFTP
☐ RIP	☐ SMTP	☐ LDAP	☐ TFTP
☐ NTP	☐ NFS	☐ RADIUS	☐ VPN
☐ Syslog	☐ SMB/CIFS	☐ Kerberos	☐ LDP
☐ SSH	☐ HTTPS	☐ TACACS+	☐ EMG Logging

[Back to IP Filter](#)

Rulesets can be added or updated on this page.

2. Enter the following:

Ruleset Name	Name that identifies a filter; may be composed of letters, numbers, and hyphens only. (The name cannot start with a hyphen.) Example: FILTER-2

Rule Parameters

IP Address(es)	Specify a single IP address to act as a filter. Example: 172 . 19 . 220 . 64 – this specific IP address only
Subnet Mask	Specify a subnet mask to determine how much of the address should apply to the filter. Example: 255 . 255 . 255 . 255 to specify the whole address should apply.
IPv6 Address(es)	Specify a single IPv6 address with subnet mask (prefix) to act as a filter, or specify a range of IPv6 addresses if the range cannot be defined by an IPv6 address and subnet mask (prefix). Example: 1234:0BCD:1D67:0000:0000:8375:BADD:0057/64
MAC Address	Specify a single MAC address to act as a filter. Example: 10:7d:1a:33:5c:e1
Protocol	Select the type of protocol through which the filter will operate. The default setting is All .
Port Range	Enter a range of destination TCP or UDP port numbers to be tested. An entry is required for TCP, TCP New, TCP Established, and UDP, and is not allowed for other protocols. Separate multiple ports with commas. Separate ranges of ports by colons. Examples: ◆ 22 – filter on port 22 only ◆ 23,64,80 – filter on ports 23, 64 and 80 ◆ 23:64,80,143:150 – filter on ports 23 through 64, port 80 and ports 143 through 150
Action	Select whether to Drop , Reject , or Allow communications for the specified IP address, subnet mask, protocol, and port range. Drop ignores the packet with no notification. Reject ignores the packet and sends back an error message. Allow permits the packet through the filter.
Clear	Click the Clear button to clear any Rule Parameter information set above.
Generate rule to allow service	You may wish to “punch holes” in your filter set for a particular protocol or service. For instance, if you have configured your NIS server and wish to create an opening in your filter set, select the NIS option and click the Add Rule button. This entry adds a new rule to your filter set using the NIS -configured IP address. Other services and protocols added automatically generate the necessary rule to allow their use.

- Click the right arrow  button to add the new rule to the bottom of the Rules list box on the right. A maximum of 256 rules can be created for each ruleset.
- To remove a rule from the filter set, highlight that line and click the left  arrow. The rule populates the rule definition fields, allowing you to make minor changes before reinserting the rule. To clear the definition fields, click the **Clear** button.
- To change the order of priority of the rules in the list box, select the rule to move and use the up  or down  arrow buttons on the right side of the filter list box.
- To save, click the **Apply** button. The new filter displays in the menu tree.

Note: To add another new filter rule set, click the **Back to IP Filter** link to return to the [Network > IP Filter](#) page.

Updating an IP Filter

To update an IP filter rule set:

1. From the [Network > IP Filter](#) page, the administrator selects the IP filter rule set to be edited and clicks the **Edit Ruleset** button to return to the [Network > IP Filter Ruleset \(Adding/Editing Rulesets\)](#) page (see [Figure 7-14](#)).
2. Edit the information as desired and click the **Apply** button.

Deleting an IP Filter

To delete an IP filter rule set:

1. On the [Network > IP Filter](#) page, the administrator selects the IP filter rule set to be deleted and clicks the **Delete Ruleset** button.

IP Filter Commands

Go to [IP Filter Commands](#) to view CLI commands which correspond to the web page entries described above.

Routing

The Routing feature allows you to define static routes and, for networks using Routing Information Protocol (RIP)-capable routes, to enable the RIP protocol to configure the routes dynamically. Up to 64 IPv4 static routes and 64 IPv6 static routes can be configured.

To configure routing (RIP and IPv4 static routes):

1. Click the **Network** tab and select the **Routing** option. The following page displays:

Figure 7-15 Network > Routing

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings Switch VLANs DHCP IP Filter Routing Forwarding VPN Security Perf Monitoring FQDN List

Routing Help ?

Enable RIP: ☐ RIP Version: ☐ 1 ☒ 2 ☐ 1 and 2 The Routing Table can be viewed with the [IP Routes Report](#) >

Enable Static Routing: ☐ [IPv6 Static Routing](#) >

To edit or delete a static route, select the radio button in the right column below.

IP Address:
Subnet Mask:
Gateway:

IPv4 Static Routes			
No	IP Address	Subnet Mask	Gateway

2. Enter the following:

Dynamic Routing

Enable RIP	Select to enable Dynamic Routing Information Protocol (RIP) to assign routes automatically. Disabled by default.
RIP Version	Select the RIP version. The default is 2 .

Static Routing and IPv4 Static Routes

Enable Static Routing	Select to manually configure IPv4 or IPv6 static routes. The system administrator usually provides the routes. Disabled by default.

IP Address / Subnet Mask / Gateway	Used to manually configure a single IPv4 static route. ◆ To add a static route, enter the IP Address, Subnet Mask, and Gateway for the route and click the Add/Edit Route button. The route displays in the IPv4 Static Routes table. ◆ To edit a static route, select the radio button to the right of the route, change the IP Address, Subnet Mask, and Gateway fields as desired, and click the Add/Edit Route button. ◆ To delete a static route, select the radio button to the right of the route and click the Delete Route button.

3. Click the **Apply** button.

Note: To display the routing table, status or specific report, see the section, [Status/Reports](#).

IPv6 Static Routing

To configure routing (IPv6 static routes):

1. Click the **Network** tab and select the **Routing** option.
2. Click the IPv6 Static Routing link to navigate to the Routing - IPv6 Static Routes page.

The screenshot shows the LANTRONIX EMG851300 web interface. At the top, there's a header with the device name and a status bar showing various indicators. Below the header is a navigation menu with tabs like Network, Services, User Authentication, Devices, Maintenance, and Quick Setup. The 'Network' tab is selected, and the 'Routing' option is chosen from the sub-menu. The main content area is titled 'Routing - IPv6 Static Routes'. It contains a form for adding or editing routes with fields for 'IPv6 Address' and 'IPv6 Gateway'. A note specifies that link-local IPv6 gateways must contain a scope identifier. There are buttons for 'Add/Edit IPv6 Route', 'Delete IPv6 Route', and 'Apply'. On the right, there's a table titled 'IPv6 Static Routes' with columns for 'No', 'IPv6 Address', and 'IPv6 Gateway'. A help link is also present.

3. Enter the following information:

IPv6 Address / IPv6 Gateway	Used to manually configure a single IPv4 static route. ◆ To add a static route, enter the IPv6 Address (including prefix/mask bits), and IPv6 Gateway for the route and click the Add/Edit IPv6 Route button. IPv6 addresses are written as 8 sets of 4-digit hexadecimal numbers separated by colons, followed by a forward slash and mask bits, for example 1234:0BCD:1D67:0000:0000:8375:BADD:0057/64. After adding the route it will be displayed in the IPv6 Static Routes table. Note: link-local gateways must be appended with a scope identifier, for example %eth1 or %eth2. ◆ To edit a static route, select the radio button to the right of the route, change the IPv6 Address and prefix/mask bits, and IPv6 Gateway fields as desired, and click the Add/Edit IPv6 Route button. ◆ To delete a static route, select the radio button to the right of the route and click the Delete IPv6 Route button.

4. Click the **Apply** button.

5. Navigate back to the Routing page.

Enable Static Routing	On the Routing page, select this option to manually configure IPv4 or IPv6 static routes. The system administrator usually provides the routes. The default is disabled.

6. Click **Apply**.

Routing Commands

Go to [Routing Commands](#) to view CLI commands which correspond to the web page entries described above.

Forwarding

Port Forwarding can be used to configure a port on the Eth1 or Eth2 Ethernet interface to listen for incoming TCP connections, and redirect the traffic to an IP address:TCP Port on the Ethernet Switch or the local subnet. This allows network traffic on one interface to be securely routed to another network (including devices connected directly to the EMG Ethernet Switch). For example, a port forwarding connection can be configured to route traffic between a browser and a unique TCP Port on Eth1 to port 443 of a device connected to the Ethernet Switch. This direct port to port forwarding does not support applications requiring dynamic port redirection.

Note: When the web server is enabled, it listens on port 443 for all interfaces (Eth1, Eth2, WLAN, Cellular, etc) for incoming connections. It listens on interfaces even if they are disabled in the [Web Server settings](#) (the connection to a disabled interface is blocked and logged by the web server). In order to use port 443 for the incoming TCP port the web server must be disabled.

To create a new forwarding connection:

1. Click the **Network** tab and select the **Forwarding** option. The following page displays:

Figure 7-16 Network > Forwarding

LANTRONIX[®] EMG851321

Logout Host: emgfdc User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings Cellular Wireless Switch DHCP IP Filter Routing Forwarding VPN Security Perf Monitoring FQDN List

Forwarding Connections Help ?

Configure a port on an Ethernet or Cellular interface to listen for incoming connections and redirect traffic to an IP address:Port on the Ethernet switch or local subnet.

Forward: Ethernet Port: TCP Port

Ethernet Port: ☒ 1 ☐ 2 ☐ Cellular

Incoming TCP Port:

to: IP Address: Port

IP Address:

Outgoing TCP Port:

To modify a connection, select the connection, edit the fields above and select 'Configure'. To terminate a connection, select the radio button in the right column below and select 'Terminate'.

Current Forwarding Connections			Configure	Terminate	Keep Connection: ☐	Restart
Interface:Port	IP Address:Port	Time				

- Complete the following:

Ethernet Port	Select which port to create the listening connection on: Select 1 for Eth1, 2, for Eth2, or Cellular for the cellular connection.
Incoming TCP Port	Enter a unique (currently unused) TCP port to listen on. The Diagnostics Netstat tool can be used to view all in-use TCP ports.
IP Address	The IP address to route the traffic to.
Outgoing TCP Port	The TCP Port to route the traffic to. This should be a TCP port that is opening and listening on the device.

- To create a new connection, click **Create New Connection**. After returning to the Forwarding page, the new connection will be shown in the **Current Forwarding Connections** table at the bottom.

Note: In the CLI "show connections" output, an extra SSH In connection to the console manager will be shown for each forwarding connection - this is the SSH tunnel for the port forwarding connection.
- To edit an existing connection, click the checkbox in the right column in the **Current Forwarding Connections** table. This will fill in the text fields at the top with the current settings. Change the settings as needed and then click **Configure**. This will tear down the current connection and restart it with the new settings. After returning to the Forwarding page, the updated connection will be shown in the **Current Forwarding Connections** table at the bottom. The connection will persist across reboots until it is terminated.
- To terminate an existing connection, click the checkbox in the right column in the **Current Forwarding Connections** table. Select the **Keep Connection** checkbox to suspend the connection (it can be restarted later using the **Restart** button). Click **Terminate**. This will tear down and remove the connection.

VPN Settings

This page can be used to create a Virtual Private Network (VPN) tunnel to the EMG for secure communication between the EMG unit and a remote host or gateway. The EMG supports IPSec tunnels using Encapsulated Security Payload (ESP). The EMG unit supports host-to-host, net-to-net, host-to-net, and roaming user tunnels.

Note: To allow VPN tunnel access if the EMG firewall is enabled, traffic to UDP ports 500 and 4500 from the remote host should be allowed, as well as protocol ESP from the remote host.

The EMG provides a strongSwan-based VPN implementation (version 5.8.4). The EMG UI provides access to a subset of the strongSwan configuration options, and also allows [upload](#) of a custom `ipsec.conf` file, which gives an administrator access to most strongSwan configuration options. For more information on strongSwan, see <https://www.strongswan.org> and the [strongSwan Documentation site](#). A list of Internet Key Exchange [IKEv1](#) and [IKEv2](#) cipher suites is available on the strongSwan Wiki. [NAT Traversal](#) is handled automatically without any special configuration. VPN related routes are installed in a separate table and can be viewed in the detailed VPN status or in the IP Routes table.

When a tunnel is up, the amount of data passed through the tunnel can be viewed in the status with the bytes_i (bytes input) and bytes_o (bytes output) counters. An example of the VPN status is below (the status will vary depending on the authentication, subnets and algorithms used). For example, the status displays the IP addresses on either side of the tunnel (192.168.1.103 and 220.41.123.45), the type of authentication (pre-shared key authentication), the algorithms in use (IKEv1 Aggressive and 3DES_CBC/HMAC_MD5_96/PRF_HMAC_MD5/MODP_1024), when the tunnel will be rekeyed/SA Lifetime (rekeying in 7 hours), the bytes in and out (131 bytes_i (1 pkt, 93s ago), 72 bytes_o (1 pkt, 94s ago)), a dynamic address assigned to the console manager side of the tunnel (child: dynamic and 172.28.28.188), and the subnets on both sides of the tunnel (172.28.28.188/32 == 10.3.0.0/24 10.81.101.0/24 10.81.102.0/24 10.81.103.0/24).

Connections:

```
MyVPNConn: 192.168.1.103...220.41.123.45 IKEv1 Aggressive,
dpddelay=30s
MyVPNConn: local: [vpnid] uses pre-shared key authentication
MyVPNConn: local: [vpnid] uses XAuth authentication: any with XAuth
identity 'gfountain'
MyVPNConn: remote: [220.41.123.45] uses pre-shared key
authentication
MyVPNConn: child: dynamic == 0.0.0.0/0 TUNNEL, dpdaction=restart
Security Associations (1 up, 0 connecting):
MyVPNConn[1]: ESTABLISHED 26 minutes ago,
192.168.1.103[vpnid]...220.41.123.45[220.41.123.45]
MyVPNConn[1]: IKEv1 SPIs: 62c06b5b5fc3c5de_i* 74300552060118f6_r,
pre-shared key+XAuth reauthentication in 2 hours
MyVPNConn[1]: IKE proposal: 3DES_CBC/HMAC_MD5_96/PRF_HMAC_MD5/
MODP_1024
MyVPNConn{1}: INSTALLED, TUNNEL, reqid 1, ESP in UDP SPIs: c6b71deb_i
95f877ec_o
MyVPNConn{1}: 3DES_CBC/HMAC_MD5_96/MODP_1024, 131 bytes_i (1 pkt, 93s
ago), 72 bytes_o (1 pkt, 94s ago), rekeying in 7 hours
MyVPNConn{1}: 172.28.28.188/32 == 10.3.0.0/24 10.81.101.0/24
10.81.102.0/24 10.81.103.0/24
```

The EMG loads a subset of the available [strongSwan plugins](#). If an option is given in a custom ipsec.config file that requires a plugin that is not loaded by the EMG, this may cause an error during tunnel negotiation. The loaded plugins can be viewed in the VPN Status when the VPN tunnel is enabled.

Sample ipsec.conf files are provided in the EMG online help files for a variety of tunnel configurations and peers. The strongSwan Wiki also provides a variety of [usable examples](#) and [sample configurations](#), in addition to interoperability recommendations.

Depending on the VPN configuration, it may be necessary to enable IP Forwarding or to add static routes; in some cases traffic may not be passed through the tunnel without enabling IP Forwarding or static routes. Refer to the VPN routing table that is displayed with the VPN status.

A watchdog program is automatically run when the VPN tunnel is enabled. This program will detect if the VPN tunnel goes down (for reasons other than the user disabling the tunnel). The watchdog program will:

- ◆ Generate a syslog message when the tunnel goes up or down
- ◆ If traps are enabled, send a slcEventVPNTunnel SNMP trap when the tunnel goes up or down
- ◆ If an email address is configured in the VPN configuration, send an email when the tunnel goes up or down
- ◆ If enabled, automatically restart the VPN tunnel

When using VPN with Network Fail-over, the Local IP Address should not be configured for the VPN tunnel. This will allow strongSwan to automatically determine the IP address on the local (console manager) side of the tunnel based on the network configuration during both fail-over and fail-back.

VPN tunnels over an console manager Ethernet interfaces that is configured with an MTU less than 256 may experience issues (traffic loss, etc).

To set up a VPN connection:

1. Click the **Network** tab and select the **VPN** option. The following page displays:

Figure 7-17 Network > VPN (1 of 2)


EMG851000

Logout
Host: **emgfcf0**
User: **sysadmin**

Select port for:
☒ Configuration
☐ WebSSH (DP only)
☐ Connected Device (DP only)

U1 E1 1 3
S0 E2 2 4

Network Services User Authentication Devices Maintenance Quick Setup

[Network Settings](#) [IP Filter](#) [Routing](#) [VPN](#) [Security](#) [Perf Monitoring](#) [FQDN List](#)

VPN

Help ?

Enable VPN Tunnel: ☐
Current Tunnel Status: **Down**

Name:

Remote Peer:

Remote Id:

Remote Subnet(s):

Remote Source IP:

Local IP Address:

Local Id:

Local Subnet(s):

Local Source IP:

[View Detailed Status >](#)
[View VPN Logs >](#)
[View EMG and Remote Peer RSA Public Key >](#)
[View X.509 Certificates >](#)

IKE Negotiation: ☒ Main Mode ☐ Aggressive Mode

IKE Version:

IKE Encryption: Authentication: DH Group:

ESP Encryption: Authentication: DH Group:

☒ RSA Public Key ☐ Pre-Shared Key ☐ X.509 Certificate

RSA Public Key for Remote Peer:

Figure 7-18 Network > VPN (2 of 2)

Pre-Shared Key: Retype Pre-Shared Key:

Certificate Authority for Remote Peer: [Upload File >](#)

Certificate File for Remote Peer: [Upload File >](#)

Certificate Authority for Local Peer: [Upload File >](#)

Certificate File for Local Peer: [Upload File >](#)

Key File for Local Peer: [Upload File >](#)

SA Lifetime:

XAUTH Client: ☐

XAUTH Login:

XAUTH Password: Retype Password:

Cisco Unity: ☐

Mode Config: ☒ Pull ☐ Push

Force Encapsulation: ☐

Dead Peer Detection: ☐ No ☒ Yes, Delay: seconds

Dead Peer Detection Timeout:

Dead Peer Detection Action:

Custom ipsec.conf

Uploaded Configuration: [Upload File >](#) [View Configuration >](#)

[Download Configuration](#)

[Apply](#)

2. Enter the following:

Enable VPN Tunnel	Select to create a tunnel. Disabling this option will terminate any currently running tunnel. Note: The VPN peer that sends the first packet in tunnel bringup is the initiator or client; the VPN peer that listens for and responds to the first packet is the responder or server. In general, the responder / server side should be started before the initiator / client side. If it is desired to have the console manager VPN tunnel automatically reconnect when the remote peer disconnects and then reconnects, the console manager side of the tunnel should be started first so that it will act as a responder or server. If the console manager side of the tunnel is started after the remote peer, the console manager will act as a initiator / client, and may not automatically reconnect when the remote peer disconnects and is brought back up.
Only start VPN tunnel in network fail-over mode	Select to start the VPN tunnel only in network fail-over mode. When this option is selected, the VPN tunnel will not start if the network fail-over parameters are not configured, and the network is not in fail-over mode. Whenever there is a network fail-over, the VPN tunnel will automatically start, and when network fail-back happens, the VPN tunnel will automatically go down. If this feature is enabled but the network fail-over parameters are not configured, this setting will be ignored and the VPN tunnel will be started normally and run continuously. By default, this option is disabled.
Name	The name assigned to the tunnel. Required to create a tunnel.

Remote Peer	The IP address or FQDN of the remote host's public network interface. The special value of any can be entered to signify an address to be filled in by automatic keying during negotiation. The console manager will act as a responder/server.
Remote Id	How the remote host should be identified for authentication. The Id is used to select the proper credentials for communicating with the remote host.
Remote Subnet(s)	One or more allowed subnets behind the remote host, expressed in CIDR notation (IP address/mask bits). If multiple subnets are specified, the subnets should be separated by a comma. Up to 10 local subnets supported. Configured subnets of the peers may differ, the protocol narrows it to the greatest common subnet. In IKEv1, this may lead to problems with other implementations. Make sure to configure identical subnets in such configurations. If the remote subnet is not defined, it will be assumed that the remote end of the connection goes to the remote peer only.
Remote Source IP	The internal source IP to use in a tunnel(Virtual IP). Currently the accepted values are config , CIDR Notation , IP Address Range or poolname . If the value is config on the responder side, the initiator must propose an address which is then echoed back. The supported address pools are expressed as CIDR notation and IP Address range as - or the use of an external IP address pool using poolname is the name of the IP address pool used for the lookup.
Local IP Address	In the IP address of the EMG (local) side of the tunnel, specifically the public-network interface. If the IP address is not given, the value %any will be used in the <code>ipsec.conf</code> file (this is the default). It signifies that the IP address will be filled (by automatic keying) during negotiation. If EMG initiates the connection setup the routing table will be queried to determine the correct local IP address. In case the EMG is responding to a connection setup then any IP address that is assigned to a local interface will be accepted. For EMG with a cellular modem, if Local IP Address is configured to be the same as the IP address of the cellular modem acquired via DHCP; whenever the IP address of the cellular modem changes, the Local IP Address of the VPN tunnel will be automatically updated to be the same as the new cellular modem IP address. Note: ◆ <i>This features is only available when the Tunnel Restart option is selected.</i> ◆ <i>If Local IP Address is set to the IP address of a network interface that acquires its IP address from DHCP, we recommend you to configure DHCP to always assign the same IP address to the interface. Otherwise, if the interface is assigned with a new IP address, the VPN tunnel will stop working. To fix this issue, you will have to update the Local IP Address and restart the tunnel.</i>
Local Id	How the EMG should be identified for authentication. The Id is used by the remote host to select the proper credentials for communicating with the EMG.

Local Subnet(s)	One or more subnets behind the EMG, expressed in CIDR notation (IP address/mask bits). If multiple subnets are specified, the subnets should be separated by a comma. Up to 10 local subnets supported. Configured subnets of the peers may differ, the protocol narrows it to the greatest common subnet. In IKEv1, this may lead to problems with other implementations. Make sure to configure identical subnets in such configurations. If the local subnet is not defined, it will be assumed that the local end of the connection goes to the console manager only.
Local Source IP	The internal source IP to use in a tunnel (Virtual IP). Currently the accepted values are config4, config6 or Valid IP Address. With config4 and config6 an address of the given address family will be requested explicitly. If an IP address is configured, it will be requested from the responder, which is free to respond with a different address.
IKE Negotiation	The Internet Key Exchange (IKE) protocol is used to exchange security options between two hosts who want to communicate via IPSec. The first phase of the protocol authenticates the two hosts to each other and establishes the Internet Security Association Key Management Protocol Security Association (ISAKMP SA). The second phase of the protocol establishes the cryptographic parameters for protecting the data passed through the tunnel, which is the IPSec Security Association (IPSec SA). The IPSec SA can periodically be renegotiated to ensure security. The IKE protocol can use one of two modes: Main Mode, which provides identity protection and takes longer, or Aggressive Mode, which provides no identity protection but is quicker. With Aggressive Mode, there is no negotiation of which cryptographic parameters will be used; each side must give the correct cryptographic parameters in the initial package of the exchange, otherwise the exchange will fail. If Aggressive Mode is used, the IKE Encryption, IKE Authentication, and IKE DH Group must be specified.
IKE Version	IKE Version settings to be used. Currently the accepted values are IKEv1, IKEv2 and Any. Default is IKEv2. Any uses IKEv2 when initiating but will accept any protocol version while responding. It is recommended that any IKE Encryption or ESP Encryption parameters that are selected be supported by the IKE Version that is used. Refer to the list of IKEv1 and IKEv2 cipher suites for more information.
IKE Encryption	The type of encryption, 3DES, AES, AES192 or AES256, used for IKE negotiation. Any can be selected if the two sides can negotiate which type of encryption to use. Note: If IKE Encryption, Authentication and DH Group are set to Any, default cipher suite(s) will be used. If the console manager acts as an initiator, the tunnel will use a default IKE cipher of aes128-sha256-ecp256 (for IKEv1). For IKEv2 or when the console manager is the responder in tunnel initiation, it will propose a set of cipher suites and will accept the first supported proposal received from the peer.
IKE Authentication	The type of authentication, SHA2_256, SHA2_384, SHA2_512, SHA1, or MD5, used for IKE negotiation. Any can be selected if the two sides can negotiate which type of authentication to use.
IKE DH Group	The Diffie-Hellman Group, 2 (modp1024), 5 (modp1536), 14 (modp2048), 15 (modp3072), 16 (modp4096), 17 (modp6144), 18 (modp8192) or 19 (ecp256) can be used for IKE negotiation. Any can be selected if the two sides can negotiate which Diffie-Hellman Group to use.

ESP Encryption	The type of encryption, 3DES, AES, AES192 or AES256, used for encrypting the data sent through the tunnel. Any can be selected if the two sides can negotiate which type of encryption to use. Note: If ESP Encryption, Authentication and DH Group are set to Any, default cipher suite(s) will be used. If the console manager acts as an initiator, the tunnel will use a default ESP cipher of aes128-sha256 (for IKEv1). For IKEv2 or when the console manager is the responder in tunnel initiation, it will propose a set of cipher suites and will accept the first supported proposal received from the peer. The proposal sent from the remote peer and the proposal used by the console manager can be viewed in the VPN logs. If there is no match between the two sets of proposals, the tunnel will fail with the message no matching proposal found, sending NO_PROPOSAL_CHOSEN. If a matching proposal is found, tunnel negotiation will proceed. Below is an example of no matching proposal in the log messages: <pre> charon: 04[CFG] received proposals: ESP:AES_CBC_128/HMAC_SHA2_256_128/ECP_256/ NO_EXT_SEQ charon: 04[CFG] configured proposals: ESP:AES_CBC_128/AES_CBC_192/ AES_CBC_256/ HMAC_SHA2_256_128/ HMAC_SHA2_384_192/ HMAC_SHA2_512_256/ HMAC_SHA1_96/AES_XCBC_96/ NO_EXT_SE charon: 04[IKE] no matching proposal found, sending NO_PROPOSAL_CHOSEN </pre>
ESP Authentication	The type of authentication, SHA2_256, SHA2_384, SHA2_512, SHA2_256_96, SHA1, or MD5, used for authenticating data sent through the tunnel. Any can be selected if the two sides can negotiate which type of authentication to use.
ESP DH Group	The Diffie-Hellman Group, 2 (modp1024), 5 (modp1536), 14 (modp2048), 15 (modp3072), 16 (modp4096), 17 (modp6144), 18 (modp8192) or 19 (ecp256) can be used for the key exchange for data sent through the tunnel. Any can be selected if the two sides can negotiate which Diffie-Hellman Group to use. Note: PFS is automatically enabled by configuring ESP Encryption to use a DH Group (ESP Encryption without a DH Group will disable PFS); see Perfect Forward Secrecy below.

Authentication	The type of authentication used by the host on each side of the VPN tunnel to verify the identity of the other host. ◆ For RSA Public Key, each host generates a RSA public-private key pair, and shares its public key with the remote host. The RSA Public Key for the EMG (which has 4096 bits) can be viewed at either the web or CLI. ◆ For Pre-Shared Key, each host enters the same passphrase to be used for authentication. ◆ For X.509 Certificate, each host is configured with a Certificate Authority certificate along with a X.509 certificate with a corresponding private key, and shares the X.509 certificate with the remote host. The following error message appears whenever the X.509 certificate expires: "Expired" Before using RSA Public Key authentication, select Generate EMG RSA Key to generate the EMG's RSA public/private key pair. This RSA key can be regenerated at any time. Local IP Address must be set so that the RSA Key of the EMG unit can be matched with the IP address assigned to the EMG side of the tunnel. If you do not set the Local IP Address, %any will be used as an identifier to look for the RSA Key, and the authentication will fail with a message indicating that the configuration uses unsupported authentication. <i>Note: strongSwan does not support IKEv1 aggressive mode with Pre-Shared Key authorization without XAUTH enabled. A hash of the pre-shared key is transmitted in clear-text. An attacker can capture this hash and run an offline brute-force attack against it. If a tunnel is initiated with this configuration the log message Aggressive Mode PSK disabled for security reasons will be displayed, and a tunnel will not be initiated. It is possible to override this behavior, but it is not recommended.</i>
RSA Public Key for Remote Peer	If RSA Public Key is selected for authentication, the remote peer's public key can be uploaded or deleted. If a public key has been uploaded this field will display key installed. The peer RSA public key must be in Privacy Enhanced Mail (PEM) format, e.g.: <pre>-----BEGIN PUBLIC KEY----- (certificate in base64 encoding) -----END PUBLIC KEY-----</pre>
Pre-Shared Key	If Pre-Shared Key is selected for authentication, enter the key.
Retype Pre-Shared Key	If Pre-Shared Key is selected for authentication, re-enter the key.
Certificate Authority for Remote Peer	A certificate can be uploaded to the EMG unit for peer authentication. The certificate for the remote peer is used to authenticate the EMG to the remote peer, and at a minimum contains the public certificate file of the remote peer. The certificate may also contain a Certificate Authority file; if the Certificate Authority file is omitted, the EMG may display "issuer cacert not found" and "X.509 certificate rejected" messages, but still authenticate. The Certificate Authority file and public certificate File must be in PEM format, e.g.: <pre>-----BEGIN CERTIFICATE----- (certificate in base64 encoding) -----END CERTIFICATE-----</pre>
Certificate File for Remote Peer	

Certificate Authority for Local Peer	A certificate can be uploaded to the EMG unit for peer authentication. The certificate for the local peer is used to authenticate any remote peer to the EMG, and contains a Certificate Authority file, a public certificate file, and a private key file. The public certificate file can be shared with any remote peer for authentication. The Certificate Authority and public certificate file must be in PEM format, e.g.: <pre>-----BEGIN CERTIFICATE----- (certificat in base64 encoding) -----END CERTIFICATE-----</pre> The key file must be in RSA private key file (PKCS#1) format, eg: <pre>-----BEGIN RSA PRIVATE KEY----- (private key in base64 encoding) -----END RSA PRIVATE KEY-----</pre>
Certificate File for Local Peer	
Key File for Local Peer	
SA Lifetime	How long a particular instance of a connection should last, from successful negotiation to expiry, in seconds. Normally, the connection is renegotiated (via the keying channel) before it expires. The formula for how frequently rekeying (renegotiation) is done is: $\text{rekeytime} = \text{lifetime} - (\text{margintime} + \text{random}(0, \text{margintime} * \text{rekeyfuzz}))$ where the default margintime is 9m (or 540 seconds) and the default rekeyfuzz is 100%. For example, if the SA Lifetime is set to 3600 seconds (1 hour), how often the tunnel is rekeyed is calculated as: $\begin{aligned} \text{rekeytime minimum} &= 1\text{h} - (9\text{m} + 9\text{m}) = 42\text{m} \\ \text{rekeytime maximum} &= 1\text{h} - (9\text{m} + 0\text{m}) = 51\text{m} \end{aligned}$ So the rekeying time will vary between 42 minutes and 51 minutes. It is recommended that the SA Lifetime be set greater than 540 seconds; any values less than 540 seconds may require adjustments to the margintime and rekeyfuzz values (which can be set with a custom ipsec.conf file). Some peer devices (Cisco, etc) may require that the SA Lifetime be set to a minimum of 3600 seconds in order for the VPN tunnel to come up and rekeying to function properly. For more information see the strongSwan Expiry documentation.
XAUTH Client	If this is enabled, the EMG will send authentication credentials to the remote host if they are requested. XAUTH, or Extended Authentication, can be used as an additional security measure on top of the Pre-Shared Key or RSA Public Key. This is typically used with Cisco peers, where the Cisco peer is acting as an XAUTH server.
XAUTH Login (Client)	If XAUTH Client is enabled, this is the login used for authentication.
XAUTH Password/Retype Password	If XAUTH Client is enabled, this is the password used for authentication.
Cisco Unity	If enabled, sends the Cisco Unity vendor ID payload (IKEv1 only), indicating that the EMG is acting as a Cisco Unity compliant peer. This indicates to the remote peer that Mode Config is supported (an IKE configuration method that is widely adopted, documented here).

Mode Config	In remote access scenarios, it is highly desirable to be able to push configuration information such as the private IP address, a DNS server's IP address, and so forth, to the client. This option defines which mode is used: pull where the config is pulled from the peer (the default), or push where the config is pushed to the peer. Push mode is not supported with IKEv2.
Force Encapsulation	In some cases, for example when ESP packets are filtered or when a broken IPsec peer does not properly recognise NAT, it can be useful to force RFC-3948 encapsulation.
Dead Peer Detection	Sets the delay (in seconds) between Dead Peer Detection (RFC 3706) keepalives (R_U_THERE, R_U_THERE_ACK) that are sent for the tunnel (default 30 seconds). Dead Peer Detection can also be disabled.
Dead Peer Detection Timeout	Sets the length of time (in seconds) the EMG will idle without hearing either an R_U_THERE poll from the peer, or an R_U_THERE_ACK reply. The default is 120 seconds. After this period has elapsed with no response and no traffic, the EMG will declare the peer dead, remove the Security Association (SA), and perform the action defined by Dead Peer Detection Action .
Dead Peer Detection Action	When a Dead Peer Detection enabled peer is declared dead, the action that should be taken. Hold (the default) means the tunnel will be put into a hold status. Clear means the Security Association (SA) will be cleared. Restart means the SA will immediately be renegotiated.

Custom ipsec.conf Configuration	A custom ipsec.conf file can be uploaded to the EMG. This file can include any of the strongSwan options which are not configurable from the UIs. The <code>ipsec.conf</code> file should include one <code>conn <Tunnel Name></code> section which defines the tunnel parameters. An ipsec.conf file containing more than one <code>conn</code> section will be rejected for upload. When a custom ipsec.conf file has been uploaded to the console manager, any VPN options configured via the UIs (with the exception of authentication tokens, see below) are ignored, and the UIs will not display the options given in the custom ipsec.conf file. A description of the format of the ipsec.conf file as well as all strongSwan options is available here. The EMG uses strongSwan version 5.8.4, so not all options listed in the strongSwan ipsec.conf documentation will be supported by the EMG. Any authentication tokens (pre-shared keys, RSA keys, X.509 certificates) required by the custom ipsec.conf must be configured through the EMG UIs, and must be configured or installed before a tunnel is brought up with an uploaded ipsec.conf file. When a tunnel is started with a custom ipsec.conf file, the authentication tokens required for the <code>authby</code> parameter are verified to exist before the tunnel is started. For example, if <code>authby=rsasig</code>, the EMG will verify that the EMG RSA public/private key has been generated and that the peer RSA public key has been uploaded. To upload a custom ipsec.conf file, select the Upload File link next to the Uploaded Configuration field. The file name should not contain '/', '\', ':', '*', '?', '"', '<', '>', ' ' characters. To delete an uploaded custom ipsec.conf file, select the Delete Configuration File checkbox next to the Uploaded Configuration field. To view an uploaded custom ipsec.conf file, select the View Configuration link next to the Uploaded Configuration field. If a file has been uploaded it will be displayed; otherwise the auto-generated file will be displayed if it exists. The file is auto-generated when a tunnel is enabled (if a custom file has not been uploaded). To download the current in-use ipsec.conf file (either the ipsec.conf file automatically generated by the EMG or an uploaded custom ipsec.conf file), select the Download Configuration button. Downloading the ipsec.conf file automatically generated by the EMG is a good starting point for adding extra VPN options; the tunnel must be enabled in order for the EMG to auto-generate an ipsec.conf file that can be downloaded.
Tunnel Restart	If enabled, the watchdog program will automatically restart the VPN tunnel when the tunnel goes down. Initially, when the tunnel goes down, it will be restarted immediately. After the first restart, if the tunnel still fails to come up, the watchdog program will restart the tunnel periodically every X seconds, where X is the Dead Peer Detection Timeout plus 60 seconds, until the tunnel comes back up.
Email Address	Email address to receive email alerts when the tunnel goes up or down.

3. To save, click **Apply** button.

More Actions on the VPN page:

- ◆ To see details of the VPN tunnel connection, including the cryptographic algorithms used, select the **View Detailed Status** link.
- ◆ To see the last 200 lines of the logs associated with the VPN tunnel, select the **View VPN Logs** link.

- ◆ To see the RSA public key for the EMG (required for configuring the remote host if RSA Public Keys are being used), and the RSA public key for the remote peer, select the **View console manager and Remote Peer RSA Public Key** link.
- ◆ To see the X.509 Certificates for the local peer and the remote peer, select the **View X.509 Certificates** link.

Sample ipsec.conf Files

Sample ipsec.conf files are provided for a variety of tunnel setups and peers. In all examples, any left options are for the console manager/local side of the tunnel, and any right options are for the remote side of the tunnel.

- ◆ Cisco Pre-Shared Key / XAUTH / MODECFG / IKEv1
- ◆ Cisco ASA5525x Pre-Shared Key / IKEv1
- ◆ Cisco ASA5525x Pre-Shared Key / IKEv2
- ◆ Cisco ISR 2921 Pre-Shared Key / XAUTH / IKEv2

Cisco Pre-Shared Key / XAUTH / MODECFG / IKEv1

This configuration is an example of a remote access connection to a Cisco VPN server / responder that uses [XAUTH and MODECFG](#) to authenticate and push dynamic IP addresses and DNS servers to a VPN client. The use of aggressive mode requires that **ike** and **esp** algorithms be specified and exactly match what the Cisco server is expecting.

Console manager configuration

The pre-shared key and the XAUTH password need to be configured via the console manager UI.

```
conn Cisco
  keyexchange=ikev1
  ike=3des-md5-modp1024!
  esp=3des-md5-modp1024!
  aggressive=yes
  lifetime=28800s
  forceencaps=no
  authby=xauthpsk
  left=10.0.1.55
  leftsourceip=%config4
  leftid=@vpnid
  xauth=client
  xauth_identity=username
  modeconfig=pull
  right=220.41.123.45
  rightsubnet=0.0.0.0/0
  dpddelay=30
  dpdtimeout=120
  dpdaction=hold
  auto=start
  type=tunnel
```

Cisco ASA5525x Pre-Shared Key / IKEv1

This configuration is an example of a remote access connection to a Cisco ASA5525 VPN server / responder.

EMG configuration

The pre-shared key needs to be configured via the console manager UI.

```
conn ASA5525
  keyexchange=ikev1
  ike=aes-sha1-modp1536!
  esp=aes-sha1-modp1536!
  aggressive=yes
  lifetime=86400s
  forceencaps=no
  authby=secret
  left=%any
  leftsubnet=192.168.0.0/24
  modeconfig=pull
  right=192.168.1.130
  rightsubnet=192.168.3.0/24
  dpddelay=10
  dpdtimeout=5
  dpdaction=restart
  auto=start
  type=tunnel
```

Cisco configuration

Note: Main or aggressive mode is determined by the EMG side of the tunnel, and does not require any change in the Cisco configuration:

```
interface GigabitEthernet0/0
  nameif outside
  security-level 0
  ip address 192.168.1.130 255.255.255.0

interface GigabitEthernet0/3
  nameif inside security-level 100
  ip address 192.168.3.130 255.255.255.0

object-group network local-network
  network-object 192.168.3.0 255.255.255.0
object-group network remote-network
  network-object 192.168.0.0 255.255.255.0

access-list asa-router-vpn extended permit ip object-group local-network
object-group remote-network

route outside 192.168.0.0 255.255.255.0 192.168.1.204 1
route inside 192.168.3.250 255.255.255.255 192.168.3.250 1

crypto ipsec ikev1 transform-set ipsecvpn esp-aes esp-sha-hmac
```

```

crypto ipsec security-association pmtu-aging infinite

crypto map site2site 10
  match address asa-router-vpn
  set pfs group5
  set peer 192.168.1.204
  set ikev1 transform-set ipsecvpn
crypto map site2site interface outside

crypto ikev1 enable outside
crypto ikev1 policy 10
  authentication pre-share encryption aes
  hash sha
  group 5
  lifetime 86400

tunnel-group 192.168.1.204 type ipsec-l2l
tunnel-group 192.168.1.204 ipsec-attributes
  ikev1 pre-shared-key *****

```

Cisco ASA5525x Pre-Shared Key / IKEv2

This configuration is an example of a remote access connection to a Cisco ASA5525 VPN server / responder. The aggressive setting can be either **yes** or **no**; the Cisco ASA will honor the peer configuration.

Console manager configuration

The pre-shared key needs to be configured via the console manager UI.

```

conn ASA5525
  keyexchange=ikev2
  ike=3des-sha2_256-modp1536!
  esp=3des-sha2_256-modp1536!
  aggressive=no
  lifetime=86400s
  forceencaps=no
  authby=secret
  left=%any
  leftsubnet=192.168.0.0/24
  modeconfig=pull
  right=192.168.1.130
  rightsubnet=192.168.3.0/24
  dpddelay=0
  dpdtimeout=5
  dpdaction=restart
  auto=start
  type=tunnel

```

Cisco configuration

```
interface GigabitEthernet0/0
  nameif outside
  security-level 0
  ip address 192.168.1.130 255.255.255.0

interface GigabitEthernet0/3
  nameif inside security-level 100
  ip address 192.168.3.130 255.255.255.0

object-group network local-network
  network-object 192.168.3.0 255.255.255.0
  network-object 192.168.3.250 255.255.255.255
object-group network remote-network
  network-object 192.168.0.0 255.255.255.0
  network-object 192.168.0.222 255.255.255.255

access-list asa-router-vpn extended permit ip object-group local-network
object-group remote-network
access-list ASA-SLC-ACCESS extended permit ip object-group local-network
object-group remote-network

route outside 192.168.0.0 255.255.255.0 192.168.1.204 1
route inside 192.168.3.250 255.255.255.255 192.168.3.250 1

crypto ipsec ikev2 ipsec-proposal IPSECv2
  protocol esp encryption 3des
  protocol esp integrity sha-256
crypto ipsec security-association pmtu-aging infinite

crypto map CM 20
  match address ASA-SLC-ACCESS
  set pfs group5
  set peer 192.168.1.204
  set ikev2 ipsec-proposal IPSECv2
crypto map CM interface outside

crypto ikev2 policy 20
  encryption 3des integrity sha256
  group 5
  prf sha256
  lifetime seconds 86400
crypto ikev2 enable outside

tunnel-group 192.168.1.204 type ipsec-l2l
tunnel-group 192.168.1.204 ipsec-attributes
  ikev2 remote-authentication pre-shared-key *****
  ikev2 local-authentication pre-shared-key *****
```

Cisco ISR 2921 Pre-Shared Key / XAUTH / IKEv2

This configuration is an example of a remote access connection to a Cisco ISR2921 VPN server / responder.

Console manager configuration

The pre-shared key needs to be configured via the console manager UI.

```
conn ISR2921
  keyexchange=ikev2
  ike=aes-sha2_384-modp1536!
  esp=3des-sha2_384-!
  aggressive=no
  lifetime=86400s
  forceencaps=no
  authby=secret
  left=%any
  leftsubnet=192.168.0.0/24
  modeconfig=pull
  right=192.168.1.102
  rightsubnet=192.168.2.0/24
  dpddelay=0
  dpdtimeout=120
  dpdaction=restart
  auto=start
  type=tunnel
```

Cisco configuration

```
crypto ikev2 proposal PROP
  encryption aes-cbc-128
  integrity sha256
  group 2
crypto ikev2 policy ikev2policy
  proposal PROP
crypto ikev2 keyring KEYRING
  peer ALL
  address 0.0.0.0 0.0.0.0
  pre-shared-key local cisco123
  pre-shared-key remote cisco123

crypto ikev2 profile IKEv2_Profile
  match identity remote address 192.168.1.100 255.255.255.0
  identity local address 192.168.1.102
  authentication remote pre-share
  authentication local pre-share
  keyring local KEYRING

crypto isakmp policy 1
  encr aes
  authentication pre-share
```

```
group 2

crypto isakmp policy 5
  encr 3des
  authentication pre-share
  group 5

crypto isakmp policy 10
  lifetime 120
crypto isakmp key cisco123 address 192.168.1.100

crypto ipsec transform-set ISR esp-3des esp-sha384-hmac
  mode tunnel

crypto map CM 10 ipsec-isakmp
  set peer 192.168.1.100
  set transform-set ISR
  set ikev2-profile IKEv2_Profile
  match address VPN-TRAFFIC

crypto map IPSEC-SITE-TO-SITE 10 ipsec-isakmp
  set peer 192.168.1.100
  set transform-set ISR
  set pfs group2
  match address VPN-TRAFFIC
```

VPN Commands

Go to [VPN Commands](#) to view CLI commands which correspond to the web page entries described above.

Performance Monitoring

The EMG supports Performance Monitoring probes for analyzing network performance. Probes for DNS Lookup, HTTP Get, ICMP Echo, TCP Connect, UDP Jitter and UDP Jitter VoIP are supported. Up to 15 different probes can be configured. Each probe will run a series of operations, each of which sends a series of packets to a destination host. The EMG will measure how long it took to receive a response, and record the results. For each operation, the user can view the results for each packet (round trip times), or the accumulated statistics for all packets - minimum, average and maximum latency, and for jitter probes, minimum, average, maximum and standard deviation of the jitter delay. Dropped packets and other error conditions are recorded for each operation. This capability allows an administrator to analyze network efficiency across the network.

An operation consists of sending a specified number of packets to a destination host and optional port, with a specified amount of time between each packet. All results for each operation are stored in one data file, and the results can be viewed later. Accumulated statistics can also be pulled from the EMG via SNMP Gets.

Repository and Operations Kept: The EMG can be configured to store probe results on the local EMG storage, or an external USB thumb drive or SD card. The number of operations that can be stored per probe on the local EMG storage is 50 operations; for external USB thumb drive or SD, 200 operations can be stored per probe.

Responders: The EMG can act as a responder for probes that require a responder to answer packets that are sent from the EMG (UDP jitter, UDP jitter VoIP, UDP Echo and TCP Connect). The EMG UDP jitter responder can support packet responses for up to 15 UDP jitter or UDP jitter VoIP probes. The UDP Echo and TCP Connect can support packets responses for one UDP Echo or TCP Connect probe.

Jitter Probes and Clock Skew: For jitter probes, it is important to have both the sender and responder synchronized to a reliable NTP server. Significant clock skew can greatly affect jitter results, as timestamps are recorded in the sender probe and the responder, and these timestamps are used to measure one-way latency for the packets. At the start of each jitter operation, the clock skew between the sender and the responder will be output to the system log.

Compatibility with Cisco Responders: The EMG Performance Monitor sender is compatible with Cisco IP SLA responders (IOS versions 12.2 and 15.0) for jitter probes. The EMG uses a simplified version of the IP SLA v2 (Engine II) protocol to communicate with the Cisco IP SLA responders. This compatibility gives the administrator a large number of devices with which to measure network performance.

High Resolution Timers: Performance Monitoring requires that high resolution timers be enabled in order to generate accurate results down to the microsecond. The high resolution timers are disabled by default, and can be enabled on the [Maintenance > Firmware & Configurations](#) web page. A reboot is required if the setting is changed. Enabling high resolution timers may affect EMG performance.

To manage or view status for a Performance Monitoring probe:

1. Click the **Network** tab and select the **Perf Monitoring** option. The following page displays.

Figure 7-19 Network > Perf Monitoring

LANTRONIX® EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings IP Filter Routing VPN Security Perf Monitoring FQDN List

Performance Monitoring [Help?](#)

Number of operations kept for each probe: UDP Jitter Responder: ☐

Repository for operations: UDP Echo Responder: ☐ UDP Port:

TCP Connect Responder: ☐ TCP Port:

**Warning: high resolution timers are disabled;
high resolution timers are required for accurate Performance Monitoring results.**

[Refresh](#) [Add Probe](#) [Operations](#) [Latest RTT Results](#) [Latest Accumulated Statistics](#)

0 probe(s)							State: Restart Edit Probe Delete Probe
Id	Name	State	Start Time First Op	Finish Time Last Op	Error	Operations Comp/Total	

2. In the upper section of the page, modify the global Performance Monitoring settings:

Number of operations kept for each probe	Specifies the number of operation set files to keep for each probe. The limit for Local storage is 50 sets. The limit for external (USB or SD card) is 200 sets. While a probe is running, the operation set files will be automatically culled to remove the oldest operation set files.
Repository for operations	The repository where the operation set files will be kept - Local storage, a USB thumb drive inserted in the USB Port U1 , or the SD card slot. The data is stored in individual directories under a directory called "perfmon". Once probes have been run and operation set files have been generated, changing the repository will cause all of the existing files to be moved from the old repository directory to the new repository directory. It is recommended that the repository only be changed when probes are not actively running. If external storage is used for the repository, it is recommended that the external storage device not be removed from the EMG while probes are actively running.
UDP Jitter Responder	Starts the UDP Jitter responder to reply to UDP jitter or UDP jitter VoIP packets. The responder will listen on UDP port 1967 for control messages requesting to start individual responders on a specific UDP port. The EMG UDP jitter responder can support up to 15 UDP jitter senders.

UDP Echo Responder	Starts the UDP Echo responder on the port configured in UDP Port to reply to UDP echo packets. The EMG UDP Echo responder supports one UDP echo sender. When the UDP Echo responder is enabled, the EMG will verify that the responder UDP port is not being used by any other EMG processes, including port 1967 which is reserved for the UDP Jitter responder.
TCP Connect Responder	Starts the TCP Connect responder on the port configured in TCP Port to reply to TCP connect requests. The EMG TCP Connect responder supports one TCP connect sender. When the TCP Connect responder is enabled, the EMG will verify that the responder TCP port is not being used by any other EMG processes.

- Click the **Apply** button.
- In the lower section of the page, select a probe by clicking the radio button to the far right in the probe's row. The options that are available for that probe will be ungreyed. Select one of the following options:

Refresh	Refreshes the information on the Performance Monitoring page.
Add Probe	Displays the Performance Monitoring - Add/Edit Probe web page to add a new probe.
Operations	Displays a list of completed operations for the selected probe and allows the user to view either raw packet results or accumulated statistics for any operation.
Latest Results	Displays the latest raw packet results for the selected probe.
Latest Accumulated	Displays the latest accumulated statistics for the selected probe.
State: Restart	Allows the state of a probe to be controlled: the user can Restart a completed or running probe. When a probe is added, it will automatically start running, depending on how the probe start time is configured. Once a probe has run all of its configured operations, it will be in the "Complete" state. If the EMG is rebooted, all probes will automatically be restarted.
Edit Probe	Displays the Performance Monitoring - Add/Edit Probe web page to edit the currently selected probe.
Delete	Deletes the selected probe, after a confirmation.

The table at the bottom of the page lists information about completed and running probes.

Id	Unique identifier for the probe.
Name	Name assigned to the probe.
State	The current state of the probe: Complete if all operations have been run, or Running if there are still operations that need to be run.
Start Time First Op	The date and time that the first operation started.
Finish Time Last Op	The date time that the most recently completed operation finished.
Error	Any errors reported by the probe: ◆ NMT: the current repository is an external source, but the USB thumb drive or SD card is not mounted ◆ NDR: the repository directory for the probe does not exist ◆ OPF: failed to open an operation data file ◆ SCT: error initializing a socket ◆ CFG: error retrieving probe configuration ◆ EXP: probe start time has expired
Operations Comp/ Total	The number of operations that have been completed and the total number of operations that will be run.

Performance Monitoring - Add/Edit Probe

The [Performance Monitoring - Add/Edit Probe](#) web page allows a user to add a new Performance Monitoring probe or edit an existing Performance Monitoring probe.

To add a new probe or edit an existing probe:

1. Click the **Network** tab and select the Perf Monitoring option. The [Network > Perf Monitoring](#) page displays.
2. To add a new probe, in the lower section of the page, select the **Add Probe** link. To edit an existing probe, select a probe by clicking the radio button to the right in the probe's row, then select the **Edit Probe** button. In both cases, the following page displays.

Figure 7-20 Performance Monitoring - Add/Edit Probe

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Network Settings IP Filter Routing VPN Security Perf Monitoring FQDN List

Performance Monitoring - Add/Edit Probe [Help?](#)

[Back to Perf Monitoring](#)

Probe Type:

Name:

Number of Operations:

Frequency between Operations: seconds

Number of Packets:

Interval between Packets: msec

Timeout: msec

UDP Jitter VoIP Codec:

ICMP Ethernet Interface:

Start Time: ☒ Now ☐ At date/time:

☐ After waiting: hours minutes

Destination Host:

Destination Port:

Precision: ☒ milliseconds ☐ microseconds

Data Size: bytes

Verify Data: ☐

Type of Service (TOS):

DNS Name Server IP Address:

3. Modify the probe settings:

Probe Type	Select from one of the available probe types: ◆ DNS Lookup - Performs a DNS lookup on the hostname specified in the Destination Host using the Name Server. By default port 53 is always used as the Destination Port. ◆ HTTP Get - Performs an HTTP Get to the home (root) of the web server at the Destination Host and Destination Port. ◆ ICMP Echo - Sends ICMP Echo (ping) packets to the Destination Host. ◆ TCP Connect - Performs a TCP Connection to the Destination Host and Destination Port. ◆ UDP Echo - Sends UDP Echo packets to the Destination Host and Destination Port. ◆ UDP Jitter - Sends UDP jitter packets using a simplified version of the Cisco IP SLA v2 (Engine II) protocol to the Destination Host and Destination Port. ◆ UDP Jitter VoIP - Sends UDP jitter packets configured to simulate Voice over IP network traffic (VoIP) using a simplified version of the Cisco IP SLA v2 (Engine II) protocol to the Destination Host and Destination Port.
Name	Probe name, up to 40 characters long. Valid characters are letters, numbers, dashes (-), periods and underscores (_).
Number of Operations	Number of operations to perform for the probe. Probes can for a specific number of operations. The valid range is 1 - 1000, and the default is 100.
Frequency between Operations	Time between probe operations, in seconds. The valid range is 5 - 3600 seconds, and the default is 60 seconds.
Number of Packets	Number of packets to send for each probe. For DNS Lookup probes, this is the number of lookups to perform. For HTTP Get probes, this is the number of HTTP Gets to perform. For TCP Connect probes, this is the number of TCP connections to perform. The valid range is 1 - 1000 for the Local repository and 1 - 2000 for a USB or SD card repository. The default is 10 packets.
Interval between Packets	Interval between packets in milliseconds. The valid range is 10 - 5000 milliseconds, and the default is 500 milliseconds. For HTTP Get, DNS Lookup and TCP Connect probes, the timeout must be less than the interval due to a new socket being created and destroyed for each packet.
Start Time	Time to start the probe: Now starts the probe immediately; At date/time will start the probe at the specified date and time in the future; After waiting will start the probe after waiting a period of time that is less than 24 hours. When the EMG is rebooted, the probe will start according to the Start Time settings: (a) immediately if it set to Now , (b) at a date and time in the future if it is set to At date/time and the date and time is in the future, (c) after waiting a period of time if it is set to After waiting .
Destination Host	The hostname or IP address to send packets to. For DNS Lookup probes this is the hostname to lookup.
Destination Port	The TCP or UDP port to send packets to. For ICMP probes, the port setting is not used. For DNS Lookup probes, the destination port is always port 53. Port 1967 is reserved for the UDP jitter responder. The valid range is 1 - 65535.
Precision	The precision to view results in - milliseconds (the default) or microseconds. Jitter results are always displayed in milliseconds.

Data Size	The size in bytes to use for the payload portion of the packet - this size is in addition to the IPv4 header and the TCP, UDP or ICMP header. Any additional space in the packet that is not used by the protocol will be padded with random data that can be used for data verification (see below). This parameter is only supported for ICMP Echo, TCP Connect, UDP Echo, UDP Jitter, and UDP Jitter VoIP probes. The maximum payload for any probe is 1460 bytes. The minimum payload size for probes is: UDP Jitter VoIP G.729a codec probes - 32 bytes; all other UDP Jitter probes - 64 bytes; ICMP Echo probes - 18 bytes; TCP Connect probes - 1 bytes; UDP Echo probes - 4 bytes. If no data size is specified (e.g., it is set to zero), a default payload size will be used for the probes as follows: ◆ ICMP Echo - 56 bytes ◆ UDP Jitter VoIP G.729A - 32 bytes ◆ UDP Jitter (all others) - 64 bytes ◆ TCP Connect and UDP Echo - 256 bytes
Verify Data	If enabled, indicates that the EMG should verify if there is data corruption in the reply packets. This parameter is only supported for ICMP Echo, UDP Echo, UDP Jitter, and UDP Jitter VoIP probes.
Timeout	How long the EMG will wait for a packet to arrive, in milliseconds. If the packet arrives after the timeout it will be considered a Late Arrival error (see Table 7-21 Error Conditions Detected by Probes). The valid range is 10 - 1000, and the default is 200 msec.
UDP Jitter VoIP Codec	For UDP Jitter VoIP probes, the codec to simulate. The following codecs are available: ◆ G.729A - 32 byte packets sent 20 msec apart, 1000 packets per operation, 60 seconds between operations ◆ G.711 A-law - 172 byte packets sent 20 msec apart, 1000 packets per operation, 60 seconds between operations ◆ G.711 mu-law - 172 byte packets sent 20 msec apart, 1000 packets per operation, 60 seconds between operations The default values for the VoIP probes can be overridden to use different packet sizes, intervals, etc.
ICMP Ethernet Interface	For ICMP Echo probes, which Ethernet interface can be used for the probe: both interfaces, Ethernet Port 1, or Ethernet Port 2.
TOS (Type of Service)	Sets the IPv4 Type of Service field in the IPv4 header. This is available for UDP Jitter and UDP Jitter VoIP probes only. The range is 0 - 255, and the default value is 0.
DNS Name Server IP Address	For DNS Lookup probes, the IP address of the DNS name server to use for lookups.

4. Click the **Apply** button.

Performance Monitoring - Results

The Performance Monitoring - Operations page displays all of the operations that have been saved for a selected probe. The probe ID and name are shown at the top of the web page. From this page, the user may select any operation to view its round trip time (RTT) results, or the accumulated statistics for all round trip times in an operation.

An operation consists of sending a specified number of packets to a destination host and optional port, with a specified amount of time between each packet. All results for each operation are stored in one data file.

Round Trip Times

The results for each packet in an operation can be displayed with the **RTT Results** link. Each packet will be displayed with the packet start time and any error that resulted from sending the packet. For non-jitter probes, the total round trip time is displayed in either milliseconds or microseconds, depending on the probe's precision setting:

Round Trip Times (RTT)

Probe 1/ICMP, operation icmp_190709_154146.dat:

Pkt	Time	RT Time	Result
====	=====	=====	=====
1	19/07/09 15:41:46.469	0.717 msec	OK
2	19/07/09 15:41:46.972	0.556 msec	OK
3	19/07/09 15:41:47.482	0.443 msec	OK
4	19/07/09 15:41:47.992	0.423 msec	OK
5	19/07/09 15:41:48.501	0.472 msec	OK
6	19/07/09 15:41:49.011	0.439 msec	OK
7	19/07/09 15:41:49.521	0.444 msec	OK
8	19/07/09 15:41:50.031	0.375 msec	OK
9	19/07/09 15:41:50.541	0.427 msec	OK
10	19/07/09 15:41:51.051	0.442 msec	OK

For jitter probes, the source to destination and destination times are displayed in the probe's configured precision:

Round Trip Times (RTT)

Probe 4/test2-udp-jitter, operation udpjitter_190730_231540.dat:

Pkt	Time	Src To Dst Time	Dst To Src Time	Result
1	19/07/30 23:15:41.707	0.347 msec	0.043 msec	OK
2	19/07/30 23:15:42.208	0.327 msec	0.046 msec	OK
3	19/07/30 23:15:42.708	0.318 msec	0.041 msec	OK
4	19/07/30 23:15:43.209	0.313 msec	0.037 msec	OK
5	19/07/30 23:15:43.710	0.312 msec	0.043 msec	OK
6	19/07/30 23:15:44.210	0.350 msec	0.042 msec	OK
7	19/07/30 23:15:44.711	0.342 msec	0.075 msec	OK
8	19/07/30 23:15:45.212	0.342 msec	0.035 msec	OK
9	19/07/30 23:15:45.712	0.339 msec	0.069 msec	Late Arrival
10	19/07/30 23:15:46.213	0.327 msec	0.028 msec	OK

Accumulated Statistics

A summary of all round trip time and any error conditions is displayed. The display will vary for non-jitter and jitter results. For example, non-jitter accumulated results will show:

```
Latest Accumulated Statistics
Probe 1/ICMP, operation icmp_190709_154501.dat:
Operation Type:
    ICMP Echo to 172.19.100.17, Ethernet Port: both
    10 packets sent 500 ms apart, timeout 200 ms
Operation Start Time: 19/07/09 15:45:01.579
Last Packet RTT: 0.560 msec
Round Trip Time Results:
    Number of RTT: 10
    RTT Min/Avg/Max: 0.426/0.460/0.560 msec
Number of Successes: 10
Number of Errors: 0
    Lost Packet: 0 (0%)
    Out of Sequence: 0
    Late Arrival: 0
    Miscellaneous Error: 0
```

For jitter probes, positive (increasing latency) and negative (decreasing latency) statistics are shown, as well as the number of positive or negative jitter samples in each direction, and the sum and (and sum squared) of the positive or negative jitter times. These numbers give a summary of how much variation there was in latency times and if the variation was small or large.

```
Latest Accumulated Statistics
Probe 2/UDP-Jitter, operation udpjitter_190709_154422.dat:
Operation Type:
    UDP Jitter to 172.19.100.17:60606
    10 packets sent 500 ms apart, timeout 200 ms
Operation Start Time: 19/07/09 15:44:22.480
Last Packet RTT: 3249468.402 msec
Round Trip Time Results:
    Number of RTT: 10
    RTT Min/Avg/Max: 3249468.251/3249468.304/3249468.402 msec
One-way Latency Results:
    Number of samples: 10
    Source to Destination Min/Avg/Max: 3772218.020/3772218.074/
3772218.122 msec
    Destination to Source Min/Avg/Max: 3772217.466/3772217.526/
3772217.578 msec
Jitter, Source to Destination:
    Number of Samples: 9
    Positive and Negative Min/Avg/Max: 0/0/0 msec
    Positive Min/Avg/Max: 0/0/0 msec
    Positive Number Of/Sum of All/Sum of All Squared: 0/0/0 msec
    Negative Min/Avg/Max: 0/0/0 msec
    Negative Number Of/Sum of All/Sum of All Squared: 0/0/0 msec
Jitter, Destination to Source:
    Number of Samples: 9
    Positive and Negative Min/Avg/Max: 0/0/0 msec
```

```

Positive Min/Avg/Max: 0/0/0 msec
Positive Number Of/Sum of All/Sum of All Squared: 0/0/0 msec
Negative Min/Avg/Max: 0/0/0 msec
Negative Number Of/Sum of All/Sum of All Squared: 0/0/0 msec
Number of Successes: 10
Number of Errors: 0
  Lost Packet: 0 (0%)
  Out of Sequence: 0
  Late Arrival: 0
  Miscellaneous Error: 0

```

Table 7-21 Error Conditions Detected by Probes


The following error conditions are detected by the probes. Except where noted, the RTT results for a packet with errors will not be counted in the accumulated statistics.

Error Condition	Description
Timeout	A response was never received for the packet. These packets are listed as Lost Packets under the accumulated statistics.
Late Arrival	A response was received for a packet, but the response was received after the timeout configured for the probe. The EMG will wait at most 2 times the probe's timeout for late arrival packets. The RTT results will be included in the accumulated statistics.
Not Connected	A packet could not be sent because the connection to the destination host could not be established, or because the attempt to send the packet failed.
Sequence Error	A packet response was received with an unexpected sequence number. Possible reasons are: a duplicate packet was received, a response was received after it timed out, a corrupted packet was received and was not detected.
Verify Data Error	A response was received for a packet with payload data that does not match the expected data.
DNS Server Timeout	A DNS lookup could not be completed because the EMG could not connect to the DNS name server.
DNS Lookup Error	A DNS lookup failed - the requested hostname could not be resolved. This is not considered a protocol error, but rather an expected result, depending on the hostname being resolved. The RTT results will be included in the accumulated statistics.
TCP Connect Timeout	A TCP connect could not be completed because a connection to the TCP server could not be established.
HTTP Transaction Timeout	An HTTP Get that failed because no response was received from the HTTP server before the timeout expired.
HTTP Error	An HTTP Get succeeded, but the HTTP content (base page) that was downloaded had errors: missing "HTTP/" header string, missing "Connection: close" string, or response has an HTTP error code (the code was not 200/OK). This is not considered a protocol error. The RTT results will be included in the accumulated statistics.
Generic Error	Any error that does fall into any of the above error conditions.

To view results for a Performance Monitoring probe:

1. Click the **Network** tab and select the **Perf Monitoring** option. The [Network > Perf Monitoring](#) page displays.
2. Select a probe from the table in the lower part of the page and select the **Operations** link. The **Performance Monitoring - Operations** page displays.

Figure 7-22 Performance Monitoring - Operations



3. A table will list all available operations for the selected probe, with the most recent operation listed first. The table may be empty if no operations have been run for the probe or the operations for the probe have been deleted. Select an operation by clicking the radio button to the far right in the operation's row. Select one of the following options:

Refresh	Refreshes the information on the Performance Monitoring - Operations page.
RTT Results	Displays the round trip time (RTT) results for the selected operation in a separate window. The results show: ◆ the time that the packet was sent, ◆ the total round trip time for non-jitter probes or the source to destination time and destination to source time for jitter probes, and ◆ the status for the packet - OK/successful or an error condition. For more information, see Round Trip Times or Error Conditions Detected by Probes.
Accumulated Results	Displays the accumulated statistics for the selected operation in a separate window. The results show parameters used for the selected operation, and the minimum, average and maximum round trip times for all probes. For jitter probes, the results show minimum, average and maximum one way latency times, and jitter results for source to destination and destination to source. For probes, a summary of lost packets and error conditions is displayed.

Performance Monitoring Commands

Go to [Performance Monitoring Commands](#) to view CLI commands which correspond to the web page entries described above.

8: Services

System Logging and Other Services

Use the **Services** tab to:

- ◆ Configure the amount of data sent to the logs.
- ◆ Enable or disable SSH and Telnet logins.
- ◆ Enable a Simple Network Management Protocol (SNMP) agent.

Note: The EMG supports both MIB-II (as defined by RFC 1213) and a private enterprise MIB. The private enterprise MIB provides read-only access to all statistics and configurable items provided by the EMG unit. It provides read-write access to a select set of functions for controlling the EMG and device ports. See the MIB definition file for details.

- ◆ Identify a Simple Mail Transfer Protocol (SMTP) server.
- ◆ Configure an audit log.
- ◆ Configure NFS and CIFS shares.
- ◆ View the status of and manage the EMGs on the Secure Lantronix network.
- ◆ Set the date and time.
- ◆ Configure the web server.
- ◆ Configure the Percepixon client.

SSH/Telnet/Logging

To configure SSH, Telnet, and Logging settings:

1. Click the **Services** tab and select the **SSH/Telnet/Logging** option. The following page displays.

Figure 8-1 Services > SSH/Telnet/Logging

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

SSH/Telnet/Logging SNMP NFS/CIFS Secure Lantronix Network Date & Time Web Server Perception

SSH/Telnet/Logging Help ?

System Logging

Network Level:

Services:

Authentication:

Device Ports:

Diagnostics:

General:

Remote Server #1:

#2:

Source IPv4 Address:

Source IPv6 Address:

RPM Log Size: Kbytes

Other Log Size: Kbytes

Audit Log

Enable Log: ☒

Size: Kbytes

Include CLI Commands: ☐

Include in System Log: ☐

SSH

Enable Logins: ☒ Web SSH: ☐

Timeout: ☒ No ☐ Yes: minutes

Timeout Data Direction:

SSH Port:

Require SSH Public Key for Authentication: ☐ [SSH Algorithms >](#)

Telnet

Enable Logins: ☐

Note: Telnet is insecure.

Web Telnet: ☐

Timeout: ☒ No ☐ Yes: minutes

Timeout Data Direction:

Escape Sequence:

Outgoing Telnet: ☒

Web SSH/Web Telnet Settings

Terminal Buffer Size:

SMTP [View SMTP Log >](#)

Server:

Sender:

Note: '\$host' and '\$domain' will be substituted with hostname and domain.

Authentication Method:

Username or Email Address:

Password:

Retype Password:

Port:

Note: SMTP to port 25 is insecure.

Security:

Test Email: ☐

Email Address:

Comment:

Discovery Server

Enable Server: ☒

2. Enter the following settings:

System Logging

Note: Firmware version 9.0.0.0 and prior versions use syslog format defined by RFC3164. Firmware versions 9.1.0.0 and later use syslog format defined by RFC5424.

Alert Levels	Select one of the following alert levels from the drop-down list for each message category: ◆ Off: Disables this type of logging. ◆ Error: Saves messages that are output because of an error. ◆ Warning: Saves message output from a condition that may be cause for concern, in addition to error messages. This is the default for all message types. ◆ Info: Saves informative message, in addition to warning and error messages. ◆ Debug: Saves extraneous detail that may be helpful in tracking down a problem, in addition to information, warning, and error messages.
Network Level	Messages concerning the network activity, for example about Ethernet and routing.
Services	Messages concerning services such as SNMP and SMTP.
Authentication	Messages concerning user authentication.
Device Ports	Messages concerning device ports and connections.
Diagnostics	Messages concerning system status and problems.
General	Any message not in the categories above.
Remote Servers (#1 and #2)	The IPv4 or IPv6 address of the remote server(s) where system logs are stored. The system log is always saved to local EMG storage. It is retained through EMG unit reboots for files up to Other Log Size (see below). Saving the system log to a server that supports remote logging services (see RFC 3164) allows the administrator to save the complete system log history. Note: If the EMG is unable resolve the Remote Server hostnames or contact the Remote Servers to send syslog messages, the syslog messages that cannot be sent to a Remote Server may appear on the EMG console port.
RPM Log Size	The maximum size in Kbytes that RPM logs can grow to before they are pruned. When the file is pruned, it will be pruned to 50% of the RPM Log Size.
Other Log Size	The maximum size in Kbytes that all logs other than the RPM logs can grow to before they are pruned. When the file is pruned, it will be pruned to 50% of the Other Log Size.

Audit Log

Enable Log	Select to save a history of all configuration changes in a circular log. Disabled by default. The audit log is saved through EMG reboots.
Size	The log has a default maximum size of 50 Kbytes (approximately 500 entries). You can set the maximum size of the log from 1 to 500 Kbytes.
Include CLI Commands	Select to cause the audit log to include the CLI commands that have been executed. Disabled by default.
Include In System Log	If enabled, the contents of the audit log are added to the system log (under the General/Info category/level). Disabled by default.

SSH

Enable Logins	Enables or disables SSH logins to the EMG unit to allow users to access the CLI using SSH. Enabled by default. This setting does not control SSH access to individual device ports. (See Device Ports - Settings for information on enabling SSH access to individual ports.) Most system administrators enable SSH logins, which is the preferred method of accessing the system.

Web SSH	Enables or disables the ability to access the EMG command line interface or device ports (connect direct) through the Web SSH window. Disabled by default.
Timeout	If you enable SSH logins, you can cause an idle connection to disconnect after a specified number of minutes. Select Yes and enter a value of from 1 to 30 minutes.
Timeout Data Direction	If idle connection timeouts are enabled, this setting indicates the direction of data used to determine if the connection has timed out. Select the type of data direction: ◆ Both Directions ◆ Incoming Network ◆ Outgoing Network
SSH Port	Allows you to change the SSH login port to a different value in the range of 1 - 65535. The default is 22. Use of ports other than 22 that are less than 1025 is not recommended.
Require SSH Public Key for Authentication	If enabled, the remote user needs a public key in addition to a password to login to the console manager. This setting is disabled by default.
SSH Algorithms (link)	View and configure the active SSH algorithm list for the SSH server (see SSH Algorithms for more information).

Telnet

Enable Logins	Enables or disables Telnet logins to the EMG unit to allow users to access the CLI using Telnet. Disabled by default. This setting does not control Telnet access to individual device ports. (See Figure 10-4 Device Ports > Settings (1 of 2) for information on enabling Telnet access to individual ports.) You may want to keep this option disabled for security reasons.
Web Telnet	Enables or disables the ability to access the EMG command line interface or device ports (connect direct) through the Web Telnet window. Disabled by default.
Timeout	If you enable Telnet logins, you can cause an idle connection to disconnect after a specified number of minutes. Select Yes and enter a value of from 1 to 30 minutes.
Timeout Data Direction	If idle connection timeouts are enabled, this setting indicates the direction of data used to determine if the connection has timed out. Select the type of data direction: ◆ Both Directions ◆ Incoming Network ◆ Outgoing Network
Escape Sequence	A single character or a two-character sequence that causes the EMG unit to terminate a Telnet client. Currently the Escape Sequence is only used for Web Telnet sessions. The default value is Esc+T (escape key, then uppercase "T" performed quickly but not simultaneously). You would specify this value as \x1bT , which is hexadecimal (\x) character 27 (1B) followed by a T . A control character can be specified with the hexadecimal number for the control character; for example, Control-E can be specified as \x05 . Note that some browsers do not report key press events if Control is pressed for non-alphanumeric keys, so it is recommended to only use letters with Control character sequences.
Outgoing Telnet	Enables or disables the ability to create Telnet out connections.

Web SSH/Web Telnet Settings

Terminal Buffer Size	Number of lines in the Web SSH or Web Telnet terminal window that are available for scrolling back through output. Note: For tips on browser issues with Web SSH or Web Telnet, see Browser Issues .

SMTP

Server	IP address of your network's Simple Mail Transfer Protocol (SMTP) relay server. If an SMTP server is not specified, the EMG module will attempt to look up the MX record for the domain in the destination email addresses of outgoing emails.
Sender	The email address of the sender of outgoing emails. The string variables "\$host" and "\$domain" can be optionally included in the email sender name. They will be substituted with the configured device hostname and domain.
Authentication Method	Enables or disables SMTP authentication. Supported authentication methods are Automatic , Plain , CRAM-MD5 , and Login . If Automatic is selected, EMG will choose the best secure method that the SMTP server supports. This option is disabled by default. <i>Note: The Plain and Login methods send authentication data in cleartext over the network.</i>
Username or Email Address	User name for SMTP authentication. Up to 128 characters are accepted: forward slash (/), backward slash (\), single quote ('), and double quote (") characters are not allowed.
Password/Retype Password	Password for SMTP authentication. Up to 128 characters are accepted: forward slash (/), backward slash (\), single quote ('), and double quote (") characters are not allowed.
Port	The TCP port that the SMTP server listens to. Before the introduction of secure email (with StartTLS or TLS), port 25 was the standard port for SMTP. However, with the rise of spam, fewer email services use port 25 and now use port 465 for TLS and port 587 for StartTLS . The default port is 25.
Security	Enables TLS encrypted connections to the SMTP server. Select StartTLS to initiate a connection in unencrypted mode but switch to TLS if it can negotiate with the server, and select TLS to use only use encrypted connection mode with the server. This option is disabled by default.
Test Email	Select the check box to send a test email.
Email Address	Email address to send the test email.
Comment	In this field enter a comment (if desired).
View SMTP Log	Allows you to view SMTP logs.

Discovery Server

Enable Server	This protocol is used when the network is searched for Lantronix devices - see Secure Lantronix Network .

3. To save, click the **Apply** button.

SSH Algorithms

The SSH Algorithms link displays a list of the available SSH algorithms for the SSH server, which ones are currently enabled and allows the user to select algorithms to enable or disable. Changing the enabled algorithms automatically initiates a restart of the SSH server (terminating all existing SSH connections). Disabling some or all of particular algorithm type may prevent SSH clients from connecting to the console manager. In FIPS mode, the SSH algorithms cannot be changed; the algorithms are pre-configured to a set of FIPS approved algorithms.

The types of algorithms are as follows:

- ◆ **Cipher** - the symmetric cipher algorithm that encrypts data over a SSH connection.

- ◆ **MACs** - the message authentication code used to verify packet integrity.
- ◆ **KEX Algorithm** - the key exchange method used to create the secret key used by the symmetric cipher algorithm.
- ◆ **Host Key Algorithm** - used for creating public-private key pairs that authenticate computers in the SSH protocol. Note: the SSH server host keys algorithms (types) (e.g. the keys used to authenticate the server, versus keys used to authenticate users) do not include all of the listed Host Key Algorithms; a subset of the the Host Key algorithms are supported (rsa-sha2-512, rsa-sha2-256, ecdsa-sha2-nistp256, and ssh-ed25519). The Host Key Algorithms list is used to ensure insecure algorithms are not used in SSH client/server negotiation, regardless of whether the SSH server supports a particular type of host key algorithms.

SSH/Telnet/Logging Commands

Go to [Services Commands](#) to view CLI commands which correspond to the web page entries described above.

SNMP

Simple Network Management Protocol (SNMP) is a set of protocols for managing complex networks. The Management Information Base (MIB) defines the set of manageable objects in the device.

The EMG supports both MIB-II (as defined by RFC 1213) and a private enterprise MIB. The private enterprise MIB provides read-only access to all statistics and configurable items provided by the EMG. It provides read-write access to a select set of functions for controlling the EMG and device ports. See the MIB definition file for details. The EMG MIB definition file and the top level MIB file for all Lantronix products is accessible from the SNMP web page. The SLC8000 and EMG share the same MIB definition file, although not every object in the MIB applies to both models.

SLC supports SNMP v1, v2c and v3. It also supports SNMP v3 over TLS via TCP. For information, see [Version 3 TLS \(over TCP\)](#).

Note: *TLS via UDP is not supported.*

To configure SNMP:

1. Click the **Services** tab and select the **SNMP** option. The following page displays:

Figure 8-2 Services > SNMP (1 of 2)

LANTRONIX[®] EMG851300

Logout Host: **emgfcf0** User: **sysadmin** Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

SSH/Telnet/Logging SNMP NFS/CIFS Secure Lantronix Network Date & Time Web Server Perception

SNMP Help ?

Enable Agent: ☐ [Top Level MIB](#) [EMG MIB](#) [EMG MON MIB](#)

Enable v1: ☐

Enable v2c: ☒

Note: SNMP v1 and v2c are insecure.

Enable v3: ☐

Enable TLS: ☐ Port:

Enable Traps: ☐

Trap Version:

Enable Traps over TLS: ☐ Port:

Traps Source IPv4 Address:

Traps Source IPv6 Address:

NMS #1:

NMS #2:

Alarm Delay: seconds

Engine ID: **800000F4030080A38BFCF0**

Location:

Contact:

v1/v2c Communities

Read-Only:

Read-Write:

Trap:

Traps Enabled for Sending	
coldStart (1.3.6.1.6.3.1.1.5.1)	☒
linkDown (1.3.6.1.6.3.1.1.5.3)	☒
linkUp (1.3.6.1.6.3.1.1.5.4)	☒
authenticationFailure (1.3.6.1.6.3.1.1.5.5)	☒
slcEventPowerSupply (1.3.6.1.4.1.244.1.1.0.1)	☒
slcEventSysadminPassword (1.3.6.1.4.1.244.1.1.0.2)	☒
slcEventSLCShutdown (1.3.6.1.4.1.244.1.1.0.3)	☒
slcEventDevicePortData (1.3.6.1.4.1.244.1.1.0.4)	☒
slcEventDevicePortSLMData (1.3.6.1.4.1.244.1.1.0.5)	☒
slcEventDevicePortSLMConfig (1.3.6.1.4.1.244.1.1.0.6)	☒
slcEventDevicePortDeviceLowTemp (1.3.6.1.4.1.244.1.1.0.7)	☒
slcEventDevicePortDeviceHighTemp (1.3.6.1.4.1.244.1.1.0.8)	☒
slcEventDevicePortDeviceLowHumidity (1.3.6.1.4.1.244.1.1.0.9)	☒
slcEventDevicePortDeviceHighHumidity (1.3.6.1.4.1.244.1.1.0.10)	☒
slcEventDevicePortDeviceError (1.3.6.1.4.1.244.1.1.0.11)	☒
slcEventUSBAction (1.3.6.1.4.1.244.1.1.0.14)	☒
slcEventInternalTemp (1.3.6.1.4.1.244.1.1.0.13)	☒
slcEventDevicePortError (1.3.6.1.4.1.244.1.1.0.15)	☒
slcEventSDCardAction (1.3.6.1.4.1.244.1.1.0.16)	☒
slcEventNoDialToneAlarm (1.3.6.1.4.1.244.1.1.0.17)	☒
slcEventRPMAction (1.3.6.1.4.1.244.1.1.0.18)	☒
slcEventPingHostFails (1.3.6.1.4.1.244.1.1.0.19)	☒
slcEventDevicePortDeviceContactChanged (1.3.6.1.4.1.244.1.1.0.20)	☒
slcEventSFPAction (1.3.6.1.4.1.244.1.1.0.21)	☒
slcEventDevicePortAction (1.3.6.1.4.1.244.1.1.0.22)	☒
slcEventNetworkFailover (1.3.6.1.4.1.244.1.1.0.23)	☒
slcEventNetworkVPNTunnelAction (1.3.6.1.4.1.244.1.1.0.24)	☒
slcEventDIOPortAction (1.3.6.1.4.1.244.1.1.0.25)	☐
slcEventWireless (1.3.6.1.4.1.244.1.1.0.26)	☒
slcEventDHCP Server (1.3.6.1.4.1.244.1.1.0.27)	☐
slcEventIntrusionDetection (1.3.6.1.4.1.244.1.1.0.28)	☐
slcEventCellular (1.3.6.1.4.1.244.1.1.0.29)	☐
slcEventResourceUtilization (1.3.6.1.4.1.244.1.1.0.30)	☐
slcEventPowerOutletStateChange (1.3.6.1.4.1.244.1.1.0.31)	☐

SNMP Traps Sent/Fail: 0/0

Figure 8-3 Services > SNMP (2 of 2)

Version 3

Security: ☐ No Auth/No Encrypt
☒ Auth/No Encrypt
☐ Auth/Encrypt

Auth with:

Encrypt with:

<u>Version 3 Users</u>	<u>Read-Only</u>	<u>Read-Write</u>	<u>Trap</u>
User Name:	snmpuser	snmpwuser	snmptrapuser
Password:	*****	*****	*****
Retype Password:	*****	*****	*****
Passphrase:			
Retype Passphrase:			

Version 3 TLS (over TCP)

Client Certificate Fingerprint:

Certificate-Username Mapping: String:

Certificate Authority: [Upload File >](#)

Certificate File for Agent: [Upload File >](#)

Key File for Agent: [Upload File >](#)

Certificate File for Client/Traps: [Upload File >](#)

2. Enter the following:

Enable Agent	Enables or disables the Simple Network Management Protocol (SNMP) agent, which allows read-only access to the system. Disabled by default.
Top Level MIB (link)	Click the link to access the top level MIB file for all Lantronix products.
EMG MIB (link)	Click the link to access the EMG MIB definition file for EMGs.
EMG MON MIB (link)	Click the link to access the EMG monitor MIB definition file for EMGs.
Enable v1	If selected, SNMP version 1 (which uses the Read-Only and Read-Write Communities) is enabled. The default is disabled.
Enable v2c	If selected, SNMP version 2c (which uses the Read-Only and Read-Write Communities) is enabled. The default is enabled.
Enable v3	If selected, SNMP v3 is enabled. SNMP v3 uses configurable security parameters, Read-Only , Read-Write , and Trap user name and password for authentication. The default is disabled.
Enable TLS	When selected and SNMP v3 is enabled, SNMP v3 transmit data over TLS, which uses X.509 certificates for authentication. The default is disabled.
Port	Indicates the port number that the TLS agent listens to. The port number of the traps sent over TLS will be the next port number. For example, if the Enable TLS port is 10161, the Enable Traps over TLS port number will be 10162.

Enable Traps	Traps are notifications of certain critical events. Disabled by default. This feature is applicable when SNMP is enabled. Traps that the EMG unit sends include: ◆ coldStart (generic trap 0, OID 1.3.6.1.6.3.1.1.5.1) ◆ linkDown (generic trap 2, OID 1.3.6.1.6.3.1.1.5.3) ◆ linkUp (generic trap 3, OID 1.3.6.1.6.3.1.1.5.4) ◆ authenticationFailure (generic trap 4, OID 1.3.6.1.6.3.1.1.5.5) ◆ slcEventPowerSupply (1.3.6.1.4.1.244.1.1.0.1) ◆ slcEventSysadminPassword (1.3.6.1.4.1.244.1.1.0.2) ◆ slcEventSLCShutdown (1.3.6.1.4.1.244.1.1.0.3) ◆ slcEventDevicePortData (1.3.6.1.4.1.244.1.1.0.4) ◆ slcEventDevicePortSLMData (1.3.6.1.4.1.244.1.1.0.5) ◆ slcEventDevicePortSLMConfig (1.3.6.1.4.1.244.1.1.0.6) ◆ slcEventDevicePortDeviceLowTemp (1.3.6.1.4.1.244.1.1.0.7) ◆ slcEventDevicePortDeviceHighTemp (1.3.6.1.4.1.244.1.1.0.8) ◆ slcEventDevicePortDeviceLowHumidity (1.3.6.1.4.1.244.1.1.0.9) ◆ slcEventDevicePortDeviceHighHumidity (1.3.6.1.4.1.244.1.1.0.10) ◆ slcEventDevicePortDeviceError (1.3.6.1.4.1.244.1.1.0.11) ◆ slcEventUSBAction (1.3.6.1.4.1.244.1.1.0.14) ◆ slcEventInternalTemp (1.3.6.1.4.1.244.1.1.0.13) ◆ slcEventDevicePortError (1.3.6.1.4.1.244.1.1.0.15) ◆ slcEventSDCardAction (1.3.6.1.4.1.244.1.1.0.16) ◆ slcEventNoDialToneAlarm (1.3.6.1.4.1.244.1.1.0.17) ◆ slcEventDevicePortDeviceContactChanged (1.3.6.1.4.1.244.1.1.0.20) ◆ slcEventSFPAction (1.3.6.1.4.1.244.1.1.0.21) ◆ slcEventNoDialToneAlarm (1.3.6.1.4.1.244.1.1.0.17) ◆ slcEventRPMAction (1.3.6.1.4.1.244.1.1.0.18) ◆ slcEventPingHostFails (1.3.6.1.4.1.244.1.1.0.19) ◆ slcEventDevicePortDeviceContactChanged (1.3.6.1.4.1.244.1.1.0.20) ◆ slcEventSFPAction (1.3.6.1.4.1.244.1.1.0.21) ◆ slcEventDevicePortAction (1.3.6.1.4.1.244.1.1.0.22) ◆ slcEventNetworkFailover (1.3.6.1.4.1.244.1.1.0.23) ◆ slcEventVPNTunnel (1.3.6.1.4.1.244.1.1.0.24) ◆ slcEventDIOPortAction (1.3.6.1.4.1.244.1.1.0.25) ◆ slcEventWireless (1.3.6.1.4.1.244.1.1.0.26) ◆ slcEventDHCPsServer (1.3.6.1.4.1.244.1.1.0.27) ◆ slcEventIntrusionDetection (1.3.6.1.4.1.244.1.1.0.28) ◆ slcEventCellular (1.3.6.1.4.1.244.1.1.0.29) ◆ slcEventResourceUtilization (1.3.6.1.4.1.244.1.1.0.30) The EMG unit sends the traps to the host identified in the NMS #1 and NMS #2 field using the selected Trap Version. If Enable Traps over TLS is selected, TLS trap version is 3. For information on these traps, view the EMG enterprise MIB, which is available on the SNMP web page. Note: When the DSR signal drops on a device port, indicating that the attached cable has been disconnected or the attached device has been powered off, the EMG will log the event in the Device Ports system log and send a <code>slcEventDevicePortAction</code> SNMP trap. The log message and SNMP trap only occur if there is an active (connect direct or network connection) to the device port.
Trap Version	When traps are sent, which SNMP version to use when sending the trap: v1, v2c or v3. The default is v2c.
Enable Traps over TLS	If selected, the support for outgoing traps and incoming traps using SNMP v3 over TLS (which uses X.509 certificates for authentication) is enabled, and the default is disabled. You must select Enable TLS to enable traps over TLS, and set the Trap Version to v3.

Port	Indicates the port number of the traps sent over TLS. It is the port number preceding the Enable TLS port number. For example, if the Enable TLS port is 10161, the Enable Traps over TLS port number will be 10162.
Traps Source IPv4 Address	The Traps Source IPv4 Address can be used to configure the interface (and which source IPv4 address) is used for sending SNMP traps. By default, the source address for sending SNMP traps is not specified, and the source address of an SNMP trap packet is selected according to the routing table. Traps Source IPv4 Address can be used to select the IPv4 address of Eth1, Eth2, VEth1 or VEth2 as the source IPv4 address for packets sent to all NMS servers defined with an IPv4 address or a name which resolves to an IPv4 address. Before selecting an interface, make sure the interface is enabled and has a valid IPv4 address. <i>Note: the source IPv4 address for packets sent by the agent in response to SNMP GET packets will be the destination IP address of the packet that initiated the SNMP GET.</i>
Traps Source IPv6 Address	The Traps Source IPv6 Address can be used to configure the interface (and which source IPv6 address) is used for sending SNMP traps. By default, the source address for sending SNMP traps is not specified, and the source address of an SNMP trap packet is selected according to the routing table. Traps Source IPv6 Address can be used to select the IPv6 address of Eth1, Eth2, VEth1 or VEth2 as the source IPv6 address for packets sent to all NMS servers defined with an IPv6 address or a name which resolves to an IPv6 address. Before selecting an interface, make sure the interface is enabled and has a valid IPv6 address. <i>Note: the source IPv6 address for packets sent by the agent in response to SNMP GET packets will be the destination IP address of the packet that initiated the SNMP GET.</i>
NMS #1 (or #2)	When SNMP is enabled, an NMS (Network Management System) acts as a central server, requesting and receiving SNMP-type information from any computer using SNMP. The NMS can request information from the EMG and receive traps from the EMG unit. Enter the IPv4 or IPv6 address of the NMS server. At least NMS #1 is required if you selected Enable Traps .
Alarm Delay	Number of seconds delay between outgoing SNMP traps.
Engine ID	The unique SNMP engine identifier for the EMG. This identifier may be required by the NMS in order to received v3 traps.
Location	Physical location of the EMG (optional). Useful for managing the EMG unit using SNMP. Up to 20 characters.
Contact	Description of the person responsible for maintaining the EMG, for example, a name (optional). Up to 20 characters.

v1/v2c Communities

Read-Only	A string that SNMP agent provides. The Read-Only Community is used for SNMP v1 and v2c. The default is public .
Read-Write	A string that acts like a password for an SNMP manager to access the read-only data from the EMG unit SNMP, like a password for an SNMP manager to access the read-only data the EMG SNMP agent provides, and to modify data where permitted. The Read-Write Community is used for SNMP v1 and v2c. The default is private .
Trap	The trap used for outgoing generic and enterprise traps. Traps sent with the Event trigger mechanism still use the trap community specified with the Event action. The default is public .

Version 3

Security	Levels of security available with SNMP v3. ◆ No Auth/No Encrypt: No authentication or encryption. ◆ Auth/No Encrypt: Authentication but no encryption. (default) ◆ Auth/Encrypt: Authentication and encryption.
Auth with	For Auth/No Encrypt or Auth/Encrypt , the authentication method: ◆ MD5: Message-Digest algorithm 5 (default) ◆ SHA: Secure Hash Algorithm ◆ SHA2: Secure Hash Algorithm 2: SHA2_224, SHA2_256, SHA2_384, and SHA2_512
Encrypt with	Encryption standard to use: ◆ DES: Data Encryption Standard (default) ◆ AES: Advanced Encryption Standard ◆ AES192: Advanced Encryption Standard with 192-bit length ◆ AES256: Advanced Encryption Standard with 256-bit length

V3 User Read-Only

User Name	SNMP v3 is secure and requires user-based authorization to access EMG MIB objects. Enter a user ID. The default is snmpuser . Up to 20 characters.
Password/Retype Password	Password for a user with read-only authority to use to access SNMP v3. The default is SNMPPASS . Up to 20 characters.
Passphrase/Retype Passphrase	Passphrase associated with the password for a user with read-only authority. Up to 20 characters. If this is not specified it will default to the v3 Read-Only Password.

V3 User Read-Write

User Name	SNMP v3 is secure and requires user-based authorization to access EMG MIB objects. Enter a user ID for users with read-write authority. The default is snmprwuser . Up to 20 characters.
Password/Retype Password	Password for the user with read-write authority to use to access SNMP v3. The default is SNMPRWPASS . Up to 20 characters.
Passphrase/Retype Passphrase	Passphrase associated with the password for a user with read-write authority. Up to 20 characters. If this is not specified it will default to the v3 Read-Write Password.

V3 User Trap

User Name	SNMP v3 is secure and requires user-based authorization to access EMG unit MIB objects. Enter a user ID for users with authority to send traps. The default is snmptrapuser . Up to 20 characters.
Password/Retype Password	Password for the user with authority to send v3 traps. The default is SNMPTRAPPASS . Up to 20 characters.
Passphrase/Retype Passphrase	Passphrase associated with the password for a user with authority to send v3 traps. Up to 20 characters. If this is not specified it will default to the v3 Trap Password.

3. To save, click the **Apply** button.

Version 3 TLS (over TCP)

SNMP v3 over TLS requires three X.509 certificate files for authenticating the EMG SNMP agent with a client or tool that queries the agent for information. SNMP v3 also requires two X.509 certificate files for authenticating the EMG client application that issues traps with the NMS application that receives traps. The certificates required for the modes are:

- ◆ **For authenticating an EMG agent with a client or tool that queries the agent:** the certificate authority (or root) file, certificate file, and private key file are required.
- ◆ **For authenticating an EMG client application that issues traps with the NMS application that receives the traps:** certificate authority (or root) file and client (or trap) certificate file are required.

If the EMG is used in both the modes, the agent certificate file and client (or trap) certificate file must share the same the certificate authority (or root) file. All certificate files should be in PEM format, e.g.:

```
-----BEGIN CERTIFICATE-----
(certificate in base64 encoding)
-----END CERTIFICATE-----
```

Certificate fingerprints may be required by applications interfacing the SNMP applications of EMG when TLS is used. EMG will display the SHA1 and SHA256 fingerprint of the certificate authority and certificate files when they are uploaded into EMG. The fingerprint of the client certificate must also be configured when authenticating the EMG agent with a client or tool that queries the agent.

For information about generating a certificate authority (or root) file, agent (or server) certificate and key, and client certificate and key with OpenSSL, see [Creating a Certificate](#). We recommend that you set the message digest used when creating the certificates to SHA1 or SHA256, depending on the level of security required. To set the message digest used by OpenSSL, in step (1b) of the instructions referenced above, change `default` in the line below in `openssl.cnf` to either `sha1` or `sha256`.

```
default_md = default # use public key default MD
```

To configure TLS v3 (over TCP):

1. Click **Services** tab and select **SNMP**. The **SNMP** page appears.
2. In the **Version 3 TLS (over TCP)** section, enter the following:
3. To save, click **Apply**.

Client Certificate Fingerprint	Enter the SHA1 or SHA256 fingerprint of the certificate used by the client or tool that queries the EMG agent. For example, a SHA256 fingerprint is a string of 59 characters: D9:E5:DD:11:58:D2:DF:E0:D9:99:AE:A3:DB:57:24:21:A7:0A:20:5A

Certificate-Username Mapping / String	EMG requires a mapping from a field in the certificate used by the client or tool that queries the EMG agent to an SNMP v3 user name used internally by the EMG. This provides an extra layer of security to verify the client's identity. The EMG will extract the designated field from the certificate and match it with what is specified in String. Select among the following fields in the client certificate: ◆ User Name: The SNMP v3 user name. It does not need to be a field in the certificate. ◆ E-mail Address: The email address mentioned in the <code>subjectAltName</code> field of the certificate. ◆ FQDN: The DNS name mentioned in the <code>subjectAltName</code> field of the certificate. For example, <code>abc.lantronix.com</code>. ◆ IP Address: The IP address mentioned in the <code>subjectAltName</code> field of the certificate. For example, <code>10.0.1.150</code>. ◆ Common Name: The common name mentioned in the certificate. For example, "EMG" or "John Smith". By default, this option is selected. ◆ Any: Indicates that any of the <code>subjectAltName</code> fields in the certificate can be used. For example, if the common name in the certificate is "John Smith", select Common Name for Certificate-Username Mapping, and then enter John Smith in the String field.
Certificate Authority	Indicates the Certificate Authority used by the agent certificate and the client/traps certificate. Note: The certificate authority, agent certificate and client/traps certificate can be viewed by clicking the View link to the associated the filename. It will also display the SHA1 and SHA256 fingerprint of the certificate. All certificate files can be deleted by clicking the Delete Certificate Files check box.
Certificate File for Agent	The certificate file for the EMG agent.
Key File for Agent	The private key file for the EMG agent.
Certificate File for Client/Traps	The certificate file for the EMG agent that issues traps.

Services Commands

Go to [Services Commands](#) to view CLI commands which correspond to the web page entries described above.

NFS and SMB/CIFS

Use the [Services > NFS & SMB/CIFS](#) page if you want to save configuration and logging data onto a remote NFS server, or export configurations by means of an exported CIFS share.

Mounting an NFS shared directory on a remote network server onto a local EMG directory enables the EMG to store device port logging data on that network server. This configuration avoids possible limitations in the amount of disk space on the EMG unit available for the logging file(s). You may also save EMG configurations on the network server.

Similarly, use SMB/CIFS (Server Message Block/Common Internet File System), Microsoft's file-sharing protocol, to export a directory on the EMG as an SMB/CIFS share. The EMG unit exports a single read-write CIFS share called "public," with a subdirectory called `config`, which contains saved configurations and is read-write.

The share allows users to access the contents of the directory or map the directory onto a Windows computer. Users can also access the device port local buffers from the CIFS share.

To configure NFS and SMB/CIFS:

1. Click the **Services** tab and select the **NFS/CIFS** option. The following page displays:

Figure 8-4 Services > NFS & SMB/CIFS

LANTRONIX® EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services **User Authentication** Devices Maintenance Quick Setup

SSH/Telnet/Logging SNMP NFS/CIFS Secure Lantronix Network Date & Time Web Server PercepXion

NFS & SMB/CIFS Help?

NFS Mounts

	Remote Directory	Local Directory	Read-Write	Mount	Mounted	
#1:			☐	☐		Manage Files >
#2:			☐	☐		Manage Files >
#3:			☐	☐		Manage Files >

SMB/CIFS Share

The EMG can be configured to share a directory containing the system logs to a Microsoft Windows network. This directory can also be used for saving EMG configurations via [Firmware & Configurations >](#).

Share SMB/CIFS Directory: ☐

Network Interfaces: ☒ Eth1 (172.19.216.3) ☒ Eth2

CIFS User Password:

Retype Password:

Workgroup:

The SMB/CIFS share can be accessed by the 'cifsuser' login.

2. Enter the following for up to three directories:

NFS Mounts

Remote Directory	The remote NFS share directory in the format: nfs_server_hostname or ipaddr:/exported/path
Local Directory	The local directory on the EMG on which to mount the remote directory. The EMG unit creates the local directory automatically.
Read-Write	If enabled, indicates that the EMG can write files to the remote directory. If you plan to log port data or save configurations to this directory, you must enable this option.
Mount	Select the checkbox to enable the EMG unit to mount the file to the NFS server. Disabled by default.
Mounted	Indicates if the EMG was able to successfully mount the NFS share directory.

- Enter the following:

SMB/CIFS Share

Share SMB/CIFS directory	Select the checkbox to enable the EMG to export an SMB/CIFS share called “public.” Disabled by default.
Network Interfaces	Select the network ports from which the share can be seen. The default is for the share to be visible on both network ports.
CIFS User Password/Retype Password	Only one user special username (cifsuser) can access the CIFS share. Enter the CIFS user password in both password fields. The default user password is CIFSPASS . More than one user can access the share with the cifsuser user name and password at the same time.
Workgroup	The Windows workgroup to which the EMG unit belongs. Every PC exporting a CIFS share must belong to a workgroup. Can have up to 15 characters.

- To save, click the **Apply** button.
- Click the Firmware & Configurations link to access the [Firmware & Configurations](#) to save EMG configuration, as desired.

NFS and SMB/CIFS Commands

Go to [NFS and SMB/CIFS Commands](#) to view CLI commands which correspond to the web page entries described above.

Secure Lantronix Network

Use the **Secure Lantronix Network** option to view and manage Lantronix IT management (ITM) devices on the local subnet.

Note: Status and statistics shown on the web interface represent a snapshot in time. To see the most recent data, reload the web page.

To access Lantronix ITM devices on the local network:

1. Click the **Services** tab and select the **Secure Lantronix Network** option. The following page displays.

Figure 8-5 Services > Secure Lantronix Network

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for: ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

SSH/Telnet/Logging SNMP NFS/CIFS Secure Lantronix Network Date & Time Web Server Perception

Secure Lantronix Network [Help?](#)

Secure Lantronix Managers and Spiders on the local subnet.
Each host can be managed by selecting its IP address.

[Search Options](#)
[Refresh](#)

One moment while the network is searched....

Hostname	Model	IP Address/ Web Interface	FW Ver	SSH/ Telnet to CLI	Ports Click on bright green ports to Web SSH or Web Telnet.
					1 3 2 4
					1 3 2 4
					1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32
					1 3 5 7 9 11 13 15 2 4 6 8 10 12 14 16
					1 3 5 7 9 11 13 15 17 19 21 23 25 27 29 31 33 35 37 39 41 43 45 47 2 4 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 44 46 48

2. Access your device or device port through any of the methods below.

To directly access the web interface for a secure Lantronix device:

3. On the Secure Lantronix Network page, click the IP address of a specific secure Lantronix device to open a new browser page with the web interface for the selected device.
4. Log in as usual.

Figure 8-6 IP Address Login Page

LANTRONIX® EMG851331

Welcome to the EMG

Login to EMG851331

Login:

Password:


Login

© 2003-2021 Lantronix, Inc.

To directly access the CLI interface for a device:

1. Make sure that Web Telnet or Web SSH is enabled for the specific device.
2. On the Secure Lantronix Network page, click the **SSH** or **Telnet** link in the SSH/Telnet to CLI column directly beside the device you would like to access.
3. Click your mouse into the CLI login interface that appears and login. The CLI interface will indicate when your connection is established.
4. To terminate the session, use either the host's logoff command or use `^]` to terminate a Telnet session or `~.` to terminate an SSH session.


Figure 8-7 SSH or Telnet CLI Session



To directly access a specific port on a particular device:

1. You have two options:
 - **Dashboard**
Make sure the **WebSSH (DP only)** radio button directly beneath the Dashboard is selected and click the desired port number. The Dashboard is located on the upper right corner of each Web Manager page (see [Figure 6-1.](#)) The CLI login interface appears.

Note: WebTelnet is not available from the Dashboard. See [Dashboard](#) as the dashboard may vary in appearance.




- Secure Lantronix Page

Click the **Services** tab, then click the **Secure Lantronix Network** link (see [Figure 8-5](#).) Select the port you want to configure. Enabled port numbers are in bright green boxes and will allow you to select either a **WebSSH** or a **WebTelnet** session. The SSH or Telnet popup window appears depending on what is clicked.

Note: Port numbers that are disabled are in dark green boxes; clicking a disabled port number generates a popup window indicating the port is disabled (see [Figure 8-8](#) below.)

Figure 8-8 Disabled Port Number Popup Window



2. Click your mouse into the CLI login interface that appears (see [Figure 8-7](#)) and login. The CLI interface will indicate when your connection is established.
3. To terminate the session, use either the host's logoff command, or use ^] to terminate a Telnet session or ~. to terminate an SSH session.

Browser Issues

Please go to the [Lantronix Technical Resource Center](#) and view the Knowledge Base to learn about browser issues. r

To configure how secure Lantronix devices are searched for on the network:

1. Click the **Search Options** link on the top right of the [Services > Secure Lantronix Network](#) page. The following web page displays:

Figure 8-9 Services > Secure Lantronix Network - Search Options

LANTRONIX[®] EMG851300

Logout Host: emgcf0 User: sysadmin Select port for: ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

SSH/Telnet/Logging SNMP NFS/CIFS Secure Lantronix Network Date & Time Web Server Perception

Secure Lantronix Network - Search Options Help ?

Secure Lantronix Network Search: ☐ Local Subnet ☐ Manually Entered IP Address List ☒ Both

IP Address:

IP Address List
No IP Address

2. Enter the following:

Secure Lantronix Network Search	Select the type of search you want to conduct. ◆ Local Subnet performs a broadcast to detect secure Lantronix devices on the local subnet. ◆ Manually Entered IP Address List provides a list of IP addresses that may not respond to a broadcast because of how the network is configured. ◆ Both is the default selection.
IP Address	If you selected Manually Entered IP Address List or Both, enter the IP address of the secure Lantronix device you want to find and manage.

3. If you entered an IP address, click the **Add IP Address** button. The IP address displays in the IP Address List.
4. Repeat steps 2 and 3 for each IP address you want to add.
5. To delete an IP address from the IP Address List, select the address and click the **Delete IP Address** button.
6. Click the **Apply** button. When the confirmation message displays, click **Secure Lantronix Network** on the main menu. The [Services > Secure Lantronix Network](#) page displays the secure Lantronix devices resulting from the search. You can now manage these devices.

Troubleshooting Browser Issues

Depending on which browser you are using and what type of SSL certificate the EMG web server is configured with, there may be errors connecting to a Web SSH or Web Telnet session. These errors may be the standard browser error displayed for self-signed or untrusted certificates ("There is a problem with this website's security certificate." or "Your connection is not private.").

The SSL server that handles Web SSH and Web Telnet sessions is accessible on port 8000, instead of the standard port 443 for SSL connections. It is recommended that the EMG be configured to use a SSL certificate from a Certificate Authority to prevent issues accessing Web SSH and Web Telnet terminals. If your EMG web server is configured to use a self-signed or untrusted SSL certificate, refer to the notes below for how to work around this for various browsers.

When an EMG is configured with a SSL certificate that is either a wildcard certificate or associated with a specific name, in order to establish a Web SSH or Web Telnet session to the EMG unit, the unit must be able to successfully perform a reverse lookup on any IP address to which Web SSH or Web Telnet requests are sent. For example, if a unit is configured with a SSL certificate for the name "EMGXYZ.lantronix.com", and the unit website is being accessed in a browser with "https://EMGXYZ.lantronix.com", the unit needs to be configured with a name server that will allow the unit to perform a reverse lookup on the IP address associated with EMGXYZ.lantronix.com. Failure to perform a reverse lookup on a name may result in name mismatch errors in the browser when it attempts to open the Web SSH or Web Telnet window.

If you are unable to connect to a Web SSH or Web Telnet session for a reason other than a browser SSL certificate issue, restarting the SSL server on port 8000 may resolve the connection problem. This can be done by restarting the web server (with the CLI command `admin web restart`) or by disabling both Web SSH and Web Telnet on the [SSH/Telnet/Logging](#) web page, and then re-enabling them.

- ◆ **Chrome** - For the greatest ease of use with Web SSH and Web Telnet, when the EMG web server is using a self-signed SSL certificate, use the Chrome browser. When the user accepts the self-signed SSL certificate in the browser for the primary EMG website, the self-signed SSL certificate is accepted for all ports - including port 8000 - for the EMG website.
- ◆ **Firefox** - When accessing the EMG website with Firefox, and when the EMG web server is using a self-signed SSL certificate, accepting the self-signed SSL certificate in the browser for the primary EMG website will only accept the certificate for port 443. It will not accept the certificate for port 8000. This may result in a popup being displayed in the Web SSH or Web Telnet window indicating that the browser needs to accept a certificate. To accept the self-signed certificate for port 8000, go to Firefox -> Options (or Preferences) -> Advanced -> Certificates -> View Certificates -> Servers, and add an exception for the EMG IP address or hostname, with port 8000.
- ◆ **Internet Explorer** - When accessing the EMG website with Internet Explorer, and when the EMG web server is using a self-signed SSL certificate, Explorer will grant access to the Web SSH and Web Telnet terminals if (a) the host name or common name in the self-signed certificate matches the name (or IP address) being used to access the EMG website, and (b) Explorer has imported and trusted the self-signed certificate. A custom self-signed certificate with the EMG name can be generated via the [Web Server - SSL Certificate](#) web page or the `admin web certificate custom` CLI command.

Once the EMG web server has been configured to use the custom self-signed certificate, follow these steps for Internet Explorer to trust the custom certificate:

- ◆ In Internet Explorer, browse to the EMG website whose certificate you want to trust.
- ◆ When you see the message "There is a problem with this website's security certificate.", choose **Continue to this website (not recommended)**.
- ◆ In Internet Explorer, select **Tools -> Internet Options**.
- ◆ Select **Security -> Trusted Sites -> Sites**.
- ◆ Verify or fill in the EMG website URL in the **Add this website** field, click **Add**, and then **Close**.
- ◆ Close the **Internet Options** dialog with either **OK** or **Cancel**.
- ◆ Refresh the Internet Explorer web page with the EMG website.
- ◆ When you see the message "There is a problem with this website's security certificate", choose **Continue to this website (not recommended)**.
- ◆ Click on the red **Certificate Error** at the right of the URL address bar and select **View certificates**.

- ◆ In the dialog that displays, click on **Install Certificate**, then in the **Certificate Import Wizard**, click **Next**.
- ◆ On the next page select **Place all certificates in the following store**.
- ◆ Click **Browse**, select **Trusted Root Certification Authorities**, and click **OK**.
- ◆ Back in the **Certificate Import Wizard**, click **Next**, then **Finish**.
- ◆ If you get a **Security Warning** message box, click **Yes**.
- ◆ Dismiss the **Import was successful** message box with **OK**.
- ◆ In Internet Explorer, select **Tools -> Internet Options**.
- ◆ Select **Security -> Trusted Sites -> Sites**.
- ◆ Select the EMG website URL you just added, click **Remove**, then **Close**.
- ◆ Now shut down all running instances of Internet Explorer, and restart Internet Explorer.
- ◆ The EMG website's certificate should now be trusted.

Web SSH/Telnet Copy and Paste

There are security issues with letting a web page access the system clipboard, which is the main clipboard on a system that is shared between all applications. Because of this, browsers limit access to the system clipboard. The Web SSH and Web Telnet window provide copy and paste functionality via a right-click menu: the Copy option will copy what is highlighted in the Web SSH or Web Telnet window into an internal (non-system) clipboard, and the contents can be pasted into the Web SSH or Web Telnet window with the Paste command.

Support for copying and pasting content between the system clipboard and the Web SSH or Web Telnet window will vary from browser to browser. With the exception of Internet Explorer, most browsers will not allow highlighted content from the Web SSH or Web Telnet window to be copied to the system clipboard (Internet Explorer will display a prompt confirming the copy). Likewise, most browsers will not allow content from the system clipboard to be directly pasted into the Web SSH or Web Telnet window with the standard Control-V paste key sequence. With some browsers, the user will be able to use the Paste from browser option in the right-click menu to paste content from the system clipboard into a text field in a popup, and after hitting Enter, the content will be sent to the Web SSH or Web Telnet window.

Secure Lantronix Network Commands

Go to [SLC Network Commands](#) to view CLI commands which correspond to the web page entries described above.

Date and Time

Use the Date and Time page to specify the local date, time, and time zone at the EMG location, or enable the EMG unit to use NTP to synchronize with other NTP devices on your network. Note that changing the date/time and/or timezone, or enabling NTP may affect the user's ability to login to the web; if this happens, use the `admin web restart` command to restart the web server.

The `show ntp` command and Date and Time web page will display the current NTP status if NTP is enabled. The currently selected peer is marked with a "***", while additional peers designated acceptable for synchronization, but not currently selected, are marked with a "+". Peers marked * and + are included in the weighted average computation to set the local clock; the data produced by peers marked with other symbols are discarded. The columns displayed are:

- ◆ **remote:** Hostname or IP address of the configured upstream NTP server.
- ◆ **refid:** Identification of the time stream to which the NTP server is synchronized. If a refid of ".INIT." is displayed, the console manager has not received a response from the configured NTP server; this could be due to several reasons including (1) the NTP server is unreachable (2) the NTP server is down (3) IP filters rulesets are blocking NTP traffic.
- ◆ **st:** Stratum is a value representing the hierarchy of the upstream NTP servers. Higher values indicate NTP servers further away from the root time source. Values are relative, and can be set manually by an NTP server.
- ◆ **t:** Type of packet exchange used for NTP communication (usually "u" for unicast UDP (other values are m = multicast, b = broadcast, l = local, - = don't know)).
- ◆ **when:** Quantity of seconds which have elapsed since the last attempted poll of the configured upstream NTP server.
- ◆ **poll:** Interval in seconds which the console manager polls the configured NTP server.
- ◆ **reach:** An 8-bit shift register in octal (base 8), with each bit representing success (1) or failure (0) in contacting the configured NTP server. A value of 377 is 11111111 (base 2), which indicates that every query was successful during the last 8 poll intervals. This can be used to check whether the connection to the remote host is consistent or there are any intermittent losses which could potentially cause the system clock on your host to become unsynchronized. In the event when ≥ 8 polls have been made to the ntp server and reach is not 377, this could indicate that your server is not consistently reachable.
- ◆ **delay:** Round trip delay (in milliseconds) for communication between the configured NTP server and the console manager.
- ◆ **offset:** The offset (in milliseconds) between the time on the configured NTP server and the console manager. A value closer to 0 is ideal.
- ◆ **jitter:** The observed timing jitter or variation between clock pulses of time with the configured NTP server. A value closer to 0 is ideal.

The NTP uses the intersection algorithm, a modified version of Marzullo's algorithm, to select accurate time servers and is designed to mitigate the effects of variable network latency.

When NTP is initially enabled, it can take some time (possibly as long as 20 minutes) for the console manager clock to be synchronized with an NTP source. NTP first establishes that a time server is trusted, and then begins exchanging packets to synchronize the time. See [this explanation](#) for how time is synchronized.

To set the date and time:

1. Click the **Services** tab and select the **Date & Time** option. The following page displays:

Figure 8-10 Services > Date & Time

LANTRONIX® EMG851300

Logout Host: emgcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

SSH/Telnet/Logging SNMP NFS/CIFS Secure Lantronix Network Date & Time Web Server PercepXion

Date & Time Help?

Change Date/Time: ☐

Date: April 8 2025

Time: 06 : 39 : 24 am

Time Zone: GMT

Enable NTP: ☒ The EMG can synchronize its clock with a remote time server using NTP.

Current NTP status:

remote	refid	st	t	when	poll	reach	delay	offset	jitter
*LOCAL(0)	.LOCL.	10	1	5	64	377	0.000	+0.000	0.002

Synchronize via:

☒ Broadcast from NTP Server

☐ Poll NTP Server(s):

Public: ☒ NTP Pool: 0.pool.ntp.org (random)

Local: ☐

#1:

#2:

#3:

#4:

#5:

#6:

Local Server Authentication

Key Index	Authentication	Key Format	Key
#1: 1	disable	ASCII	
			Retype Auth Key:
#2: 1	disable	ASCII	
			Retype Auth Key:
#3: 1	disable	ASCII	
			Retype Auth Key:
#4: 1	disable	ASCII	
			Retype Auth Key:
#5: 1	disable	ASCII	
			Retype Auth Key:
#6: 1	disable	ASCII	
			Retype Auth Key:

Source IPv4 Address: None

Source IPv6 Address: None

Apply

2. Enter the following:

Change Date/Time	Select the checkbox to manually enter the date and time at the EMG location.
Date	From the drop-down lists, select the current month, day, and year.
Time	From the drop-down lists, select the current hour and minute.
Time Zone	From the drop-down list, select the appropriate time zone. For information on each timezone, see http://en.wikipedia.org/wiki/List_of_tz_database_time_zones

3. To save, click the **Apply** button.

To enable NTP synchronization:

1. Enter the following:

Enable NTP	Select the checkbox to enable NTP synchronization. NTP is disabled by default.
Current NTP status	Displays the current NTP status if NTP is enabled above.
Synchronize via	Select one of the following: ◆ Broadcast from NTP Server: Enables the EMG unit to accept time information periodically transmitted by the NTP server. This is the default if you enable NTP. ◆ Poll NTP Server: Enables the EMG to query the NTP Server for the correct time. If you select this option, complete one of the following: ➤ Local: Select this option if the NTP servers are on a local network, and enter the IPv4 or IPv6 address of up to six NTP servers. This is the default, and it is highly recommended. ➤ Public: Select this option if you want to use a public NTP server, and select the address of the NTP server from the drop-down list. This is not recommended because of the high load on many public NTP servers. All servers in the drop-down list are stratum-2 servers. (See www.ntp.org for more information.) Each public NTP server has its own usage rules --please refer to the appropriate web site before using one. Our listing them here is to provide easy configuration but does not indicate any permission for use.
Local Server Authentication	Any of the local servers can be configured to use NTP Authentication to verify that the local server is known and trusted. The NTP packets are authenticated with symmetric key authentication. The server should be configured with the same shared Key Index (or ID) and Key that is configured on the console manager. For each local server that uses NTP Authentication, configure the following: Key Index: This may also be called a Key ID. NTP servers and clients must use the same Key and Key Index to authenticate NTP packets. During the synchronization of time, the client requests the Key Index from the server and the server sends a response; if the Key Index is different, time will not be synchronized. The valid range is 1-65535 and the default Key Index is 1. Authentication: Select a message digest to enable authentication, or select disable for no NTP Authentication. The available message digest algorithms are AES128CMAC, RIPEMD160, SHA1 and MD5. Key Format: Select the format that the shared key will be entered in: ASCII or HEX. Key:/Retype Auth Key: Enter the shared key in either ASCII (up to 20 characters) or hexadecimal (up to 40 characters). The minimum key length for both ASCII and HEX is 8 characters.

Source IPv4 Address	The Source IPv4 Address can be used to configure which interface (and source IPv4 address) is used for receiving and sending NTP packets. By default, no interface is defined for NTP traffic and all available network addresses are available for processing NTP packets. The Source IPv4 Address parameter can be used to select only one interface for processing NTP packets for all NTP servers defined with an IPv4 address or a name which resolves to an IPv4 address. Select Eth1, Eth2, VEth1 or VEth2 (the default is none). Before selecting an interface, make sure the interface is enabled and has a valid IPv4 address.
Source IPv6 Address	The Source IPv6 Address can be used to configure which interface (and source IPv6 address) is used for receiving and sending NTP packets. By default, no interface is defined for NTP traffic and all available network addresses are available for processing NTP packets. The Source IPv6 Address parameter can be used to select only one interface for processing NTP packets for all NTP servers defined with an IPv6 address or a name which resolves to an IPv6 address. Select Eth1, Eth2, VEth1 or VEth2 (the default is none). Before selecting an interface, make sure the interface is enabled and has a valid IPv6 address.

2. To save, click the **Apply** button.

Date and Time Commands

Go to [Date and Time Commands](#) to view CLI commands which correspond to the web page entries described above.

Web Server

The Web Server supports all versions of the TLS protocol (TLSv1.0, TLSv1.1, TLSv1.2 and TLSv1.3), but due to security concerns, does not support any versions of the SSL protocol. TLSv1.0, TLSv1.1, and TLSv1.2 can be disabled. In addition to providing user access to the web interface, the web server also provides a [REST API](#) interface.

The Web Server page allows the system administrator to:

- ◆ Configure attributes of the web server, including supported TLS versions.
- ◆ View and terminate current web sessions (see [Web Server - Web Sessions](#)).
- ◆ Import a site-specific SSL certificate (see [Web Server - SSL Certificate](#)).
- ◆ View and configure the active cipher list for the current web server (see [Web Server - SSL Certificate](#)).

To configure the Web Server:

1. Click the **Services** tab and select the **Web Server** option. The following page appears:

Figure 8-11 Services > Web Server

LANTRONIX[®] EMG851300

Logout Host: emgcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

SSH/Telnet/Logging SNMP NFS/CIFS Secure Lantronix Network Date & Time Web Server Perception

Web Server Help ?

Timeout: ☐ No ☒ Yes, minutes (5-120): [Web Sessions >](#)

Enable TLS v1.0 Protocol: ☒ Note: TLS v1.0 is insecure. [SSL Certificate >](#)

Enable TLS v1.1 Protocol: ☒ Note: TLS v1.1 is insecure. [Web Ciphers >](#)

Enable TLS v1.2 Protocol: ☒ Note: TLS v1.3 is not available in FIPS mode.

Note: Changing TLS protocol requires a reboot or the CLI command "admin web restart".

Group Access:

Banner:

Note: Line feeds can be included in the banner with the '\n' character sequence.

Network Interfaces: ☒ Eth1 ☒ Eth2 ☒ VEth1 ☒ VEth2 ☒ PPP

Run Web Server: ☒ Setting can be changed via the CLI.

2. Enter the following fields:

Timeout	◆ Select No to disable Timeout. ◆ Select Yes, minutes (5-120) to enable timeout. Enter the number of minutes (must be between 5 and 120 minutes) after which the EMG web session times out. The default is 5. If the session times out, refresh the browser page and enter your user ID and password to open another web session. <i>Note: If you close the browser without logging off the EMG unit first, you will have to wait for the timeout time to expire. You can also end a web session by using the <code>admin web terminate</code> command at the CLI or by asking your system administrator to terminate your active web session.</i> ◆ To view or terminate current web sessions, click the Web Sessions link. See Web Server - Web Sessions. ◆ To view, import, or reset the SSL Certificate, click the SSL Certificate link. See Web Server - SSL Certificate.
Enable TLS v1.0 Protocol	By default, the web supports the TLS v1.0 protocol. Uncheck this to disable the TLS v1.0 protocol. Changing this option requires a reboot or restarting the web server with the CLI command <code>admin web restart</code> for the change to take effect.
Enable TLS v1.1 Protocol	By default, the web supports the TLS v1.1 protocol. Uncheck this to disable the TLS v1.1 protocol. Changing this option requires a reboot or restarting the web server with the CLI command <code>admin web restart</code> for the change to take effect.
Enable TLS v1.2 Protocol	By default, the web supports the TLS v1.2 protocol. Uncheck this to disable the TLS v1.2 protocol. Changing this option requires a reboot or restarting the web server with the CLI command <code>admin web restart</code> for the change to take effect.
Group Access	Specify one or more groups to allow access to the Web Manager user interface. If undefined, any group can access the web. If one or more groups are specified (groups are delimited by the characters ',' (comma) or ';' (semicolon)), then any user who logs into the web must be a member of one of the specified groups, otherwise access will be denied. Users authenticated via RADIUS may have a group (or groups) provided by the RADIUS server via the Filter-Id attribute that overrides the group defined for a user on the EMG. A group provided by a remote server must be either a single group or multiple groups delimited by the characters ',' (comma), ';' (semicolon), or '=' (equals) - for example "group=group1,group2;" or "group1,group2,group3".
Banner	Enter to replace default text displayed on the Web Manager home page after the user logs in. May contain up to 1024 characters. Blank by default. To create additional lines in the banner use the <code>\n</code> character sequence.
Network Interfaces	The interfaces that the web server is available on. By default, all interfaces - Eth1, Eth2, VEth1, VEth2, PPP (modems), Cellular (if installed), and WLAN and AP (if installed) - are enabled.
Run Web Server	If enabled, the web server will run and listen on TCP port 443. By default, the web server is enabled. This setting is read only in the web UI but can be configured in the CLI.

3. Click the **Apply** button to save.

Web Server - Web Sessions

The [Web Server - Web Sessions](#) page enables you to view and terminate current web sessions.

To view or terminate current web sessions:

1. On the **Services** tab, click the **Web Server** page and click the **Web Sessions** link to the right. The following page displays:

Figure 8-12 Web Server - Web Sessions

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

SSH/Telnet/Logging SNMP NFS/CIFS Secure Lantronix Network Date & Time Web Server Perception

Web Server - Web Sessions Help?

[Back to Web Server](#)

Current Web Sessions						Terminate
Id	User	Login Time	Idle Time	IP Address	Type	
1	sysadmin	04/08/25 05:44	0:00:00:00	172.19.100.94	Web	☐

2. To terminate, click the check box in the row of the session you want to terminate and click the **Terminate** button.
3. To return to the [Services > Web Server](#) page, click the **Back to Web Server** link.

Web Server - SSL Certificate

The [Web Server - SSL Certificate](#) page enables you to view and update SSL certificate information. The SSL certificate, consisting of a public/private key pair used to encrypt HTTP data, is associated with the web server. You can import a site-specific SSL certificate or generate a custom self-signed SSL certificate. The custom self-signed SSL certificates generated by the EMG use the SHA256 hash algorithm.

To reset, import, or generate an SSL Certificate:

1. On the **Services** tab, click the **Web Server** page and click the **SSL Certificate** link. The following page displays the current SSL certificate.

Figure 8-13 Web Server - SSL Certificate

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

SSH/Telnet/Logging SNMP NFS/CIFS Secure Lantronix Network Date & Time Web Server Perception

Web Server - SSL Certificate Help?

Current SSL Certificate

```

Current SSL Certificate:
Certificate:
  Data:
    Version: 1 (0x0)
    Serial Number:
      dd:2e:fe:b8:9f:06:0c:56
    Signature Algorithm: sha256WithRSAEncryption
    Issuer: C=US, ST=California, L=Irvine, O=Lantronix, CN=SLC
    Validity
      Not Before: Jun  6 14:09:05 2016 GMT
      Not After : Jun  4 14:09:05 2026 GMT
    Subject: C=US, ST=California, L=Irvine, O=Lantronix, CN=SLC
    Subject Public Key Info:
      Public Key Algorithm: rsaEncryption
      Public-Key: (2048 bit)
  
```

Reset to Default Certificate: ☐

Note: changing the SSL Certificate requires a reboot or restarting the web server for the update to take effect.

Import SSL Certificate: ☐ via: **HTTPS** ☐ Generate custom self-signed SSL Certificate: ☐

Root Filename: [Upload File](#)

Certificate Filename: [Upload File](#)

Key Filename: [Upload File](#)

Passphrase:

Retype Passphrase:

Host:

Login:

Path:

Password:

Retype Password:

Number of Bits: **2048**

Number of Days:

Country Name:

State or Province Name:

Locality Name:

Organization Name:

Organization Unit Name:

Hostname or Common Name:

Email Address:

Optional Challenge Password:

Retype Password:

[Back to Web Server](#)

2. If desired, enter the following:

Reset to Default Certificate	To reset to the default certificate, select the checkbox to reset to the default certificate. Unselected by default.
Import SSL Certificate	To import your own SSL Certificate, select the checkbox. Unselected by default.
Import via	From the drop-down list, select the method of importing the certificate (SCP, SFTP, or HTTPS). The default is HTTPS.

Root Filename	Filename of the imported root or intermediate Certificate Authority. If HTTPS is selected as the method for import, the Upload File link will be selectable to upload a certificate file. The certificate file should be in PEM format: -----BEGIN CERTIFICATE----- (root file in base64 encoding) -----END CERTIFICATE-----
Certificate Filename	Filename of the imported certificate. If HTTPS is selected as the method for import, the Upload File link will be selectable to upload a certificate file. The certificate file should be in PEM format: -----BEGIN CERTIFICATE----- (certificate in base64 encoding) -----END CERTIFICATE-----
Key Filename	Filename of the imported private key for the certificate. If HTTPS is selected as the method for import, the Upload File link will be selectable to upload a key file. The key file should be in PEM format: -----BEGIN RSA PRIVATE KEY----- (private key in base64 encoding) -----END RSA PRIVATE KEY-----
Passphrase / Retype Passphrase	Enter the passphrase associated with the SSL certificate if the private key is encrypted.
Host	Host name or IP address of the host from which to import the file.
Path	Path of the directory where the certificate will be stored.
Login	User ID to use to SCP or SFTP the file.
Password / Retype Password	Password to use to SCP or SFTP the file.
Generate custom self-signed SSL Certificate	To generate your own custom self-signed certificate with attributes specific to your site, select the checkbox. The SHA256 hashing algorithm will be used to generate the certificate. Unselected by default.
Number of Bits	The number of bits to use when generating the certificate: 2048, 3072 or 4096.
Number of Days	The number of days that the certificate can be used before it expires, up to 7500 days.
Country Name	The two letter country code for the custom certificate, e.g. "US" or "FR".
State or Province Name	The state or province for the custom certificate, e.g. "California". Must be at least 2 characters long.
Locality Name	The locality or city for the custom certificate, e.g. "Irvine". Must be at least 2 characters long.
Organization Name	The organization or company name for the custom certificate, e.g. "Lantronix". Must be at least 2 characters long.
Organization Unit Name	The unit name for the custom certificate, e.g. "Engineering" or "Sales". Must be at least 2 characters long.
Hostname or Common Name	The hostname or other name associated with the EMG the certificate is generated on, e.g., "emgxyz.engineering.lantronix.com". Must be at least 2 characters long.
Email Address	An optional email address to associate with the custom certificate.
Optional Challenge Password & Retype Password	An optional password use to encrypt the custom certificate.

3. Click the **Apply** button.

Note: You must restart the web server or reboot the EMG for the update to take effect.

4. To return to the [Services > Web Server](#) page, click the **Back to Web Server** link.

Web Server - Ciphers

The [Web Server - Ciphers List](#) displays a list of the available TLS ciphers suites for the web server, which ones are currently enabled and allows the user to select ciphers to enable or disable. Disabling ciphers may prevent some web clients from connecting to the console manager. In FIPS mode, the web ciphers cannot be changed; the ciphers are pre-configured to a set of FIPS approved ciphers.

The TLSv1.3 ciphers supported by the web server are TLS_AES_256_GCM_SHA384, TLS_CHACHA20_POLY1305_SHA256, and TLS_AES_128_GCM_SHA256. All TLSv1.3 ciphers are required to be enabled to be compliant with the TLSv1.3 protocol (see [RFC8446](#) for more information).

The TLSv1.0 protocol use SSLv3 ciphers, so the list of cipher suites that can be configured will include SSLv3 ciphers.

The columns in the Web Ciphers table are as follows:

- ◆ **Cipher** - Name of the cipher suite.
- ◆ **Protocol** - The minimum protocol version that the cipher suite supports, such as TLSv1.2. Note that this is not always the same as the protocol version in which the cipher suite was first defined because some cipher suites are backwards compatible with earlier protocol versions.
- ◆ **Key Exchange** - Key exchange method such as RSA, ECDHE, etc.
- ◆ **Authentication** - Authentication method such as RSA, etc.
- ◆ **Encryption** - Symmetric encryption method, with number of secret bits, such as AESGCM(128).
- ◆ **Message Digest** - Message digest, such as SHA256.

To view the current web ciphers for the current web settings:

1. On the **Services** tab, click the **Web Server** page, and click the **Web Ciphers** link. The **Web Server - Ciphers** page appears.
2. Select the cipher suites that are enabled for the web server.
3. Click **Apply**.

Figure 8-14 Web Server - Ciphers List

LANTRONIX[®] EMG851300

Host: emgfcf0
User: sysadmin

Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Logout **Network** **Services** **User Authentication** **Devices** **Maintenance** **Quick Setup**

SSH/Telnet/Logging SNMP NFS/CIFS Secure Lantronix Network Date & Time Web Server **Perception**

Web Server - Ciphers

Select the cipher suites that are enabled for the web server.
 TLSv1.3 ciphers cannot be disabled (see RFC8446).
 Changing the enabled ciphers requires a reboot or the CLI command "admin web restart".
 Disabling all non-TLSv1.3 ciphers may prevent the web server from running;
 it is recommended that at a minimum the AES256-GCM-SHA384 cipher be enabled.
 Cipher suites cannot be changed in FIPS mode; they are preset to FIPS approved algorithms.

[Back to Web Server](#)

☐ Select All Cipher Suites

Cipher	Protocol	Key Exchange	Authentication	Encryption	Message Digest
☒ TLS_AES_256_GCM_SHA384	TLSv1.3	Kx=any	Au=any	Enc=AESGCM(256)	Mac=AEAD
☒ TLS_CHACHA20_POLY1305_SHA256	TLSv1.3	Kx=any	Au=any	Enc=CHACHA20/POLY1305(256)	Mac=AEAD
☒ TLS_AES_128_GCM_SHA256	TLSv1.3	Kx=any	Au=any	Enc=AESGCM(128)	Mac=AEAD
☒ ECDHE-RSA-AES256-GCM-SHA384	TLSv1.2	Kx=ECDH	Au=RSA	Enc=AESGCM(256)	Mac=AEAD
☒ ECDHE-RSA-CHACHA20-POLY1305	TLSv1.2	Kx=ECDH	Au=RSA	Enc=CHACHA20/POLY1305(256)	Mac=AEAD
☒ ECDHE-ARIA256-GCM-SHA384	TLSv1.2	Kx=ECDH	Au=RSA	Enc=ARIAGCM(256)	Mac=AEAD
☒ ECDHE-RSA-AES128-GCM-SHA256	TLSv1.2	Kx=ECDH	Au=RSA	Enc=AESGCM(128)	Mac=AEAD
☒ ECDHE-ARIA128-GCM-SHA256	TLSv1.2	Kx=ECDH	Au=RSA	Enc=ARIAGCM(128)	Mac=AEAD
☒ ECDHE-RSA-AES256-SHA384	TLSv1.2	Kx=ECDH	Au=RSA	Enc=AES(256)	Mac=SHA384
☒ ECDHE-RSA-CAMELLIA256-SHA384	TLSv1.2	Kx=ECDH	Au=RSA	Enc=Camellia(256)	Mac=SHA384
☒ ECDHE-RSA-AES128-SHA256	TLSv1.2	Kx=ECDH	Au=RSA	Enc=AES(128)	Mac=SHA256
☒ ECDHE-RSA-CAMELLIA128-SHA256	TLSv1.2	Kx=ECDH	Au=RSA	Enc=Camellia(128)	Mac=SHA256
☒ ECDHE-RSA-AES256-SHA	TLSv1	Kx=ECDH	Au=RSA	Enc=AES(256)	Mac=SHA1
☒ ECDHE-RSA-AES128-SHA	TLSv1	Kx=ECDH	Au=RSA	Enc=AES(128)	Mac=SHA1
☒ AES256-GCM-SHA384	TLSv1.2	Kx=RSA	Au=RSA	Enc=AESGCM(256)	Mac=AEAD
☒ AES256-CCM	TLSv1.2	Kx=RSA	Au=RSA	Enc=AESCCM(256)	Mac=AEAD
☒ ARIA256-GCM-SHA384	TLSv1.2	Kx=RSA	Au=RSA	Enc=ARIAGCM(256)	Mac=AEAD
☒ AES128-GCM-SHA256	TLSv1.2	Kx=RSA	Au=RSA	Enc=AESGCM(128)	Mac=AEAD
☒ AES128-CCM	TLSv1.2	Kx=RSA	Au=RSA	Enc=AESCCM(128)	Mac=AEAD
☒ ARIA128-GCM-SHA256	TLSv1.2	Kx=RSA	Au=RSA	Enc=ARIAGCM(128)	Mac=AEAD
☒ AES256-SHA256	TLSv1.2	Kx=RSA	Au=RSA	Enc=AES(256)	Mac=SHA256
☒ CAMELLIA256-SHA256	TLSv1.2	Kx=RSA	Au=RSA	Enc=Camellia(256)	Mac=SHA256
☒ AES128-SHA256	TLSv1.2	Kx=RSA	Au=RSA	Enc=AES(128)	Mac=SHA256
☒ CAMELLIA128-SHA256	TLSv1.2	Kx=RSA	Au=RSA	Enc=Camellia(128)	Mac=SHA256
☒ AES256-SHA	SSLv3	Kx=RSA	Au=RSA	Enc=AES(256)	Mac=SHA1
☒ CAMELLIA256-SHA	SSLv3	Kx=RSA	Au=RSA	Enc=Camellia(256)	Mac=SHA1
☒ AES128-SHA	SSLv3	Kx=RSA	Au=RSA	Enc=AES(128)	Mac=SHA1
☒ CAMELLIA128-SHA	SSLv3	Kx=RSA	Au=RSA	Enc=Camellia(128)	Mac=SHA1
☒ SEED-SHA	SSLv3	Kx=RSA	Au=RSA	Enc=SEED(128)	Mac=SHA1

Apply

Admin Web Commands

Go to [Administrative Commands](#) ('admin web') to view CLI commands which correspond to the Web Server web page entries.

REST API

The REST API provides an interface to retrieve console manager configuration and status. Users must authenticate to the API before accessing information via the API. Authentication uses the same authentication methods that are enabled for the console manager (see [Authentication Methods](#)). A maximum of 20 simultaneous API sessions is supported.

Below is an example API session. Note: URLs and data sent in a payload may need to be encoded if it contains special characters; see [this link](#) for more information.

Authentication to the REST API returns a token used for the remainder of the API session:

```
$ curl -k -d '{ "login": "sysadmin", "password": "PASS" }' -X POST -H
"Content-Type: application/json" https://slc.mydomain.com/api/v1/login
{
  "token_id": "20642a56-99d5-4cd3-874a-7565ef5d3a37",
  "group": "Administrators",
  "authenticated": "Local Users",
  "link": "https://slc.mydomain.com/api/v1/login/token/20642a56-99d5-4cd3-
874a-7565ef5d3a37",
  "expiration": "00:30:00"
}
```

Discovering the APIs that are available:

```
$ curl -k --header "X-auth-token: 20642a56-99d5-4cd3-874a-7565ef5d3a37"
https://slc.mydomain.com/api/v1
console manager /api/v1 URIs:
/login
/version
/status
```

Full documentation is available in the web Services->Web Server online help

Retrieving version information:

```
$ curl -k --header "X-auth-token: 20642a56-99d5-4cd3-874a-7565ef5d3a37"
https://slc.mydomain.com/api/v1/version
{
  "model": "SLC8040",
  "num_ports": 40,
  "power_supply": "AC, 1 power supply",
  "num_front_usb_ports": 2,
  "internal_modem": "Not Installed",
  "serial_num": "0080A396431D",
  "firmware_version": "7.6.0.0R4",
  "firmware_updated": "Thu Apr 26 16:08:29 2018",
  "current_bank": 1,
  "bootloader_version": "2.0.0.0R8",
  "os_version": "IT Management Gateway OS 7.0",
  "memory_size": "512 MB",
  "flash_size": "512 MB",
  "eth1_macaddr": "00:80:a3:96:43:1d",
  "eth2_macaddr": "00:80:a3:96:43:1e",
}
```

```

"nic_board_type": "N/A",
"nic_board_version": "N/A",
"eth1_nic_sfp": "N/A",
"eth2_nic_sfp": "N/A",
"main_board_version": "080-542-R/330-298-R (Rev 2)",
"io_module_types": "RJ45-08, USB-16, USB-16",
"io_module_versions": "08SPB, 16UBA, 16UBA",
"site_tag": "San Jose SLC8000"
}

```

Terminating the API session:

```

$ curl -k -X DELETE --header "X-auth-token: 20642a56-99d5-4cd3-874a-7565ef5d3a37" https://slc.mydomain.com/api/v1/login/token/20642a56-99d5-4cd3-874a-7565ef5d3a37

```

PercepXion

PercepXion is a cloud or on-premise portal for the centralized management of multiple Lantronix ITM devices. A browser based interface (including mobile phone app support) allows an administrator to view status, send commands, view logs and charts and update firmware. Each Lantronix device can communicate with the cloud server or on-premise server, sending status updates and responding to commands sent by the server.

An EMG gateway requires a unique Device ID to communicate with the PercepXion portal. The ID is viewable in the PercepXion settings. If a device is not already pre-configured with the ID, the ID must be provisioned using Lantronix Provisioning Manager (LPM).

Changing the unit's timezone or making significant changes to the current date and time may cause issues with the PercepXion client's ability to connect to or send updates to the PercepXion server; restarting the client will resolve these issues. If the client reports authentication errors when trying to connect to the PercepXion server, the client may need to be restarted.

The PercepXion client follows a sequence of steps to connect to the PercepXion server, send status updates, check for firmware and configuration updates, and respond to commands from the server. This series of steps is the same each time the client starts - at EMG boot, or if the client is enabled. Any changes to the PercepXion Device ID, Registration settings or Messaging settings require the PercepXion client to be disabled and re-enabled for the changes to take effect.

1. Registration

The client will attempt to register to the **Registration Host** using the Project Tag and Device ID. If registration fails, the client will wait 30 seconds and retry. The client will retry until it is successful, or the client is disabled. Registration may fail if the Project Tag is invalid, the Device ID is invalid, the Registration Host name cannot be resolved, or the Registration Host is not reachable. Once registration is successful, **Status of Client** will display **Registered** with the date and time of registration.

Note: *The Registered date/time displayed in the EMG status may be different from the registered date/time shown in the PercepXion web UI. The EMG registered date/time is the most recent date and time that the EMG registered with the PercepXion server. The registered date and time shown in the PercepXion web UI is the first time that the EMG ever registered with the PercepXion server.*

2. Telemetry

After registration, the client will connect to the Telemetry Host (the hostname is provided during registration) and perform a telemetry handshake. This handshake may request that the client publish a set of statistics at regular intervals. If a telemetry handshake is successful, **Status of Client** will display **Telemetry Handshake** with the date and time of the handshake. Each time telemetry statistics are published, **Status of Client** will display **Telemetry Statistics** with the date and time the statistics were sent.

3. Messages and Status Updates

After the telemetry handshake, the client will connect to the **Messaging Host** to receive messages and publish status updates. If the connection fails, the client will wait 5 seconds and retry. The connection may fail if the Messaging Host name cannot be resolved, or the Messaging Host is not reachable. Once the connection is successful, Status of Client will display Messaging connected with the date and time the connection was established.

The client publishes status update messages (changes to device attributes) at the interval defined by Interval between Status Updates. Each time a status update is published, **Status of Client** will display **Status** with the date and time the status was sent. The client also accepts command messages from the PercepXion server to perform actions, such as reboot or shutdown. Each time a message is received, **Status of Client** will display **Message received** with the date and time the message was received.

4. Firmware and Configuration Updates

The client checks for firmware and configuration updates at the interval defined by **Interval between FW and Config Checks**. When the client checks for firmware or configuration updates, **Status of Client** will display **Checked for Content** with the date and time the check was performed. If a firmware update is found, it will be applied to the alternate (non-active) boot bank, and Status of Client will display **Firmware updated** with the date and time the firmware was updated. If a configuration update is found, it will be applied to the current boot bank, and **Status of Client** will display **Configuration restored** with the date and time the configuration was restored.

5. Web Terminal Connections

PercepXion allows users to make secure, encrypted connections via SSL/TLS to the CLI and device ports. This connection opens a web terminal session in a new browser tab in the PercepXion UI. The connection is terminated when the user closes the web terminal session. When a Web Terminal connection is initiated, **Status of Client** will display **Web Terminal Connection** with the date and time the connection was initiated. Web Terminal connections are also displayed in the Connections list in the EMG web UI and CLI. Currently paste in Web Terminal Sessions is limited to 500 lines. Some browsers may not support pasting more than 500 lines, as this may cause the Web Terminal session to be terminated. Changing the network parameters of a device via a web terminal session may result in the session being terminated if the changes affect the network interfaces or routing table.

6. Performance Monitoring Probes and Custom Scripts

PercepXion allows users to create Performance Monitoring Probes and Custom Scripts to run on the unit. When the client starts, it will request all probes and scripts that are defined to run on the unit. The status of the probes and scripts is displayed in the Status of Client. When a script run completes (either for a single manual run or a recurring scheduled run), the status of the script will be retained on the unit until a new script is initiated from PercepXion and the unit determines that the maximum number of PercepXion scripts per unit has been reached; at this time the oldest completed script will be deleted to accommodate the new script.

Note: *If a script is initiated from PercepXion to run on multiple ports on the unit, each script/port combination is a separate script "instance", and is counted separately in the total number of scripts running on the unit.*

7. Device Port Connection Status Digital Probes

The primary method for determining the PercepXion Device Port Connection Status is by reading the DSR status for the device port. For serial devices that do not set DSR, a digital probe can be enabled which will periodically send a newline (\n) character to the device, and the EMG will verify if a response is received from the device within approximately one second. If a response is received, the Device Port will be set to Connected; if no response is received, the Device Port status will be set to Disconnected. This feature is disabled by default for all device ports, and can be enabled for individual device ports via the CLI (the frequency that the newline character is sent can be configured). Digital probes that are enabled will only run while the PercepXion client is running. If a digital probe is enabled for a device that has set DSR, the digital probe will still run, but the results from the digital probe will be ignored when determining the Device Port Connection Status.

Note: *(a) the digital probe is an intrusive feature and can affect actions on the Device Port, depending on what is happening on the Device Port or what users are connected to the Device Port when the newline character is sent; (b) Device Ports may not generate a response to the newline character within approximately one second, and this may result in the Device Port Connection Status being set to Disconnected.*

8. CLI Commands

CLI commands can be issued to a set of console managers from PercepXion. CLI commands which require user input for a confirmation or prompt, or require some other user interaction ('connect direct' or diag commands) are not supported. Abbreviated commands are also not supported (e.g., "show network all" is supported, but "sh ne all" is not supported). Multiple CLI commands cannot be sent to the console manager in the same job.

To configure PercepXion settings:

1. Click the **Services** tab and select the **PercepXion** option. The following page displays.

Figure 8-15 Services > PercepXion

LANTRONIX® EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

SSH/Telnet/Logging SNMP NFS/CIFS Secure Lantronix Network Date & Time Web Server PercepXion

PercepXion Help?

PercepXion Client: ☒ Clear Update Log

Interval between status updates: minutes
Interval between FW and Config checks: hours

Firmware Updates via PercepXion: ☒
Configuration Updates via PercepXion: ☒
Reboot after Firmware Update: ☐
Allow Remote Connections: ☒
Audit Log Messages: ☒

Device Name:
Device Description:
Device ID:
S/N:
Remote Access CLI Timeout: seconds
Remote Access Device Port Timeout: seconds

Connect to: ☒ Cloud ☐ On-Premise

Cloud Settings

Registration Host:
Registration Port:
Use HTTPS for registration: ☒
Validate certificates with HTTPS: ☐
Messaging Services: ☒

On-Premise Settings

☒
☐
☒

Proxy Server Settings

Use Proxy: ☐
Proxy Type:
Proxy Host:
Proxy Port:
Proxy User Name:
Proxy Password:
Retype Password:

Apply

PercepXion Status:
Status of Client: running
Status of Web Control: not running
Initialized at: 11/02/23 02:03
Registration attempt (263) at: 11/03/23 08:28

2. Enter the following:

PercepXion Client	Enables or disables the PercepXion client. This option is enabled by default, unless an EMG is not configured with a Device ID. When the client is enabled, it will attempt to register with the Registration Host . If this is successful, the client will attempt to establish a connection with the Messaging Host . The General log (see SSH/Telnet/Logging on page 166) will contain messages about connections made to the Registration Host and Messaging Host. Status of Client displays the last time of actions performed by the client. Note that when the client is disabled, it may take as long as 30 seconds for the client to terminate, depending on what actions the client was performing at the time it was disabled.
Interval between status updates	Number of minutes between status updates sent from the client to the server. Valid values are 1 - 60 minutes. The default is 2 minutes.
Interval between FW and Config Checks	Number of hours between checks for firmware and configuration updates initiated by the server. Valid values are 1 - 72 hours. The default is 24 hours.
Firmware Updates via PercepXion	If enabled, firmware updates can be initiated by PercepXion for the EMG. The device will check for updates per the frequency defined by Interval between FW and Config Checks, and if a firmware update is found, the update will be downloaded to the device and applied to the alternate boot bank. The configuration from the current bank is always copied to the alternate boot bank during the firmware update. Enabled by default.
Configuration Updates via PercepXion	If enabled, configuration updates can be initiated by PercepXion for the EMG for both file based configuration updates (backup and restore) and configuration editor. The device will check for updates per the frequency defined by Interval between FW and Config Checks , and if a configuration update is found, the update will be downloaded to the device and applied to the current boot bank, and the EMG will be immediately rebooted. Enabled by default.
Reboot after Firmware Update	If enabled, the EMG will automatically reboot after a successful firmware update via PercepXion. Disabled by default.
Allow Remote Connections	If enabled, remote connections to the CLI and device ports (e.g. Connect) and remote connections to the Web UI (e.g. Web) from PercepXion will be allowed. Enabled by default. Remote connections may require popups to be enabled in the browser. If this option is disabled, the Connect button and Web button will not be enabled in the PercepXion UI for the device and its device ports (only Connect applies to device ports). Changing this option will always take effect immediately on the device (either allowing remote connections or blocking remote connections); however for the Connect button and Web button to appear correctly in the PercepXion UI (be enabled or disabled) after the value is changed, the PercepXion client must be restarted or a Telemetry handshake performed. Remote web UI sessions can be opened to the console manager or to another device on the same subnet as the console manager (see the Connect tab under the console manager details in PercepXion). A maximum of 10 web connections can be created under the PercepXion Connect tab, but only 3 connections can be enabled at a time. PercepXion web sessions are not affected by the Multiple Sysadmin Web Logins setting. Web SSH and Web Telnet functionality is not supported via PercepXion web sessions (PercepXion connections to the CLI and device ports are recommended instead.) Note: If a PercepXion web session is opened to the console manager login page and the user does not login, and a second session is opened within the same browser, the first session will become invalid (attempts to login in this session will display an error).

Audit Log Messages	If enabled, audit log entries added to the Audit Log (see Audit Log on page 168) on the console manager are pushed to PercepXion for viewing. Enabled by default.
Connect to	If Cloud is selected, the PercepXion client uses Cloud server settings. If On-Premise is selected it uses On-Premise server settings. Cloud is selected by default (e.g., by default the PercepXion active connection is Cloud).

Update Log

Clear Update Log	Clears the Firmware/Config updates log.

Device Attributes

Device Name	The device name displayed in the PercepXion server UI. Valid characters are alphanumeric characters, dash "-", and underscore "_". The default is the device type (EMG) with the last 4 characters of the Eth1 MAC address appended.
Device Description	Long description that is displayed in the PercepXion server UI.
Device ID	The unique device identifier. The ID is 32 alphanumeric characters. The ID may be provisioned using Lantronix Provisioning Manager (LPM). Contact Lantronix Tech Support for more information on LPM.
S/N	Displays the serial number.

Remote Access Idle Timeout

Remote Access CLI Timeout	Remote Access CLI Connection will be idle timed out after a specified number of seconds as defined in the Seconds field to the right. Enter a value from 1 to 1800 seconds. The default is 600 seconds.
Remote Access Device Port Timeout	Remote Access Device Port Connection will be idle timed out after a specified number of seconds as defined in the Seconds field to the right. Enter a value from 1 to 1800 seconds. The default is 600 seconds.

Registration Host

Registration Host	Hostname of the server the client registers with. The Host Name should start with api.
Registration Port	The TCP port on the Registration Host. Defaults to 443.
Use HTTPS for registration	If enabled, HTTPS (instead of HTTP) is used for registration. Enabled by default.
Validate certificates with HTTPS	If enabled, use a certificate authority to validate the HTTPS certificate. A certificate authority file can be uploaded on the Web Server page. Disabled by default.

Messaging Host

Messaging Services	If enabled, messaging services are used for status updates and commands. Enabled by default.

Proxy Server

Use Proxy	Enables or disables the use of a proxy server to act as a gateway between the Perception client and the Perception server. The Perception client must be disabled before changes can be made to the proxy settings.
Proxy Type	Type of protocol used to communicate with the proxy server - HTTP or SOCKS5.
Proxy Host	FQDN or IP address of the proxy server.
Proxy Port	Port that the proxy server will listen on. Default is 8080.
Proxy User Name	User name for proxy server authentication. Up to 64 characters are accepted.
Proxy Password	Password for proxy server authentication. Up to 64 characters are accepted.

3. To save, click **Apply**.

Perception Commands

Go to [Perception Commands](#) to view CLI commands which correspond to the web page entries described above.

9: USB/SD Card Port

This chapter describes how to configure SD cards, storage (thumb drive), and USB serial devices. A thumb drive or SD card is useful for firmware updates, saving and restoring configurations and for device port logging. See [Firmware & Configurations](#).

The EMG supports a variety of USB flash drives (thumb drives).

USB/SD Card Storage

The [Devices > USB / SD Card](#) page has a checkbox for both USB Access and SD card access. These checkboxes are a security feature to ensure that access to any USB device or the SD card is disabled if the box is unchecked. If unchecked, the EMG unit ignores any device plugged into the port.

To set up USB or SD card storage in the EMG:

1. Insert any of the supported storage devices into the USB port or the SD card slot on the front of the EMG unit. You can do this before or after powering up the EMG. If the first partition on the storage device is formatted with a file system supported by the EMG unit (ext2, FAT16 and FAT32), the card mounts automatically.
2. Log into the EMG unit and click **Devices**.
3. Click **USB / SD Card**. [Figure 9-1](#) shows the page that displays. Your storage device should display in the appropriate row of the USB ports / SD card table if you have inserted it. If it does not display and you have inserted it, refresh the web page.
4. View the USB/SD card information and options available on the page:

Port (view only)	Port on the EMG unit where the USB device or SD card is inserted.
Device (view only)	Type of USB device or SD card (modem or storage).
Type (view only)	Information read from USB device or SD card.
State (view only)	Indicates if the device is mounted, and if mounted, how much space is available.
USB Access (check box)	Check to enable USB Access . Uncheck to disable USB access.
SD Card Access (check box)	Check to enable SD Card Access . Uncheck to disable SD card access.

Figure 9-1 Devices > USB / SD Card

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Device Status Device Ports Console Port **USB / SD Card** RPMs Connections Xmodem Host Lists Scripts Sites

USB / SD Card [Help ?](#)

[USB Devices >](#)

USB Ports / SD Card				Configure
Port	Device	Type	State	
U1	storage	Lexar Media, Inc.	fat32, mounted, Size/Used/Avail 29.8G/22.2G/7.6G	☒
SD	storage	Ultra HS-SD/MMC2	not mounted	☐
Int SD	Storage	Internal SD Card		☐

USB Access: ☒
SD Card Access: ☒

[Apply](#)

If a USB device or SD Card has been inserted but is not visible in the table, please refresh the web page.

To configure the settings for a USB device or SD Card, select the radio button in the right column.

To configure a USB/SD card storage port:

1. Insert any of the supported storage devices into the USB port or the SD card slot on the front of the EMG unit.
2. Click the **USB/SD Card** tab. [Figure 9-1](#) shows the page that displays.
3. Click the radio button (on the far right) of a USB or SD card device storage port.
4. Click **Configure**.
 - [Figure 9-2](#) shows the page that displays if a USB storage device is inserted.
 - [Figure 9-3](#) shows the page that displays if an SD Card is inserted.

Figure 9-2 Devices > USB > Configure

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

USB / SD Card - Storage [Help?](#)

Port: **U1** Mount: ☐

Device: **Storage** Unmount: ☐

Type: **Lexar Media, Inc.** Format: ☐

State: **fat32, mounted, Size/Used/Avail 29.8G/22.2G/7.6G** Filesystem: ☒ Ext2 ☐ FAT16 ☐ FAT32 ☐ NTFS

Filesystem Check: ☐

[Manage Files on Storage Device](#)

Figure 9-3 Devices > SD Card > Configure

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

USB / SD Card - Storage [Help?](#)

Port: **SD** Mount: ☐

Device: **Storage** Unmount: ☐

Type: **Ultra HS-SD/MMC2** Format: ☐

State: **not mounted** Filesystem: ☒ Ext2 ☐ FAT16 ☐ FAT32 ☐ NTFS

Filesystem Check: ☐

[Manage Files on Storage Device](#)

5. Enter the following fields.

Mount	Select the checkbox to mount the first partition of the storage device on the EMG unit (if not currently mounted). Once mounted, a USB thumb drive or SD card is used for firmware updates, device port logging and saving/restoring configurations.

Unmount	To eject the USB thumb drive or SD card from the EMG unit , first unmount the thumb drive or SD card . Select the checkbox to unmount it. Warning: <i>If you eject a thumb drive or SD card from the EMG unit without unmounting it, subsequent mounts of a USB thumb drive or SD card in may fail, and you will need to reboot the device to restore thumb drive or SD card functionality.</i>
Format	Format will do the following: ◆ Unmount the USB/SD card device (if it is mounted), ◆ Remove all existing partitions, ◆ Create one partition, ◆ Format it with the selected filesystem ◆ Mount the device
Filesystem	Select Ext2 , FAT16 , FAT32 or NTFS, the filesystems the EMG supports.
Filesystem Check	Select to run a filesystem integrity check on the thumb drive. This is recommended if the filesystem does not mount or if the filesystem has errors.

6. Click **Apply**.
7. Click the **Manage Files on Storage Device** link to view and manage files on the selected USB thumb drive or SD Card. Files on the storage device may then be deleted, downloaded or renamed. See [Manage Files](#) for more information.

Manage Files

To manage files, perform the following steps.

1. Click the **Manage Files on the Storage Device** link on the [Devices > SD Card > Configure](#) page.

Figure 9-4 Firmware and Configurations - Manage Files

LANTRONIX® EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

Firmware & Configurations - Manage Files

[Back to USB / SD Card - Storage](#)

Name	Date/Time Saved	SSH Keys	SSL Certificate	Scripts	
System Volume Information	05/09/16 15:36:28	N/A	N/A	N/A	☐
.dropbox.device	03/07/17 12:57:04	N/A	N/A	N/A	☐
archive	07/10/19 10:51:54	N/A	N/A	N/A	☐
slcupdate-8.0.0.1R1.tgz	07/10/19 10:55:44	N/A	N/A	N/A	☐
slcupdate-8.0.0.1R1.tgz.md5sum	07/10/19 10:55:34	N/A	N/A	N/A	☐
slcupdate-8.1.0.0R6.tgz	07/10/19 10:55:24	N/A	N/A	N/A	☐
slcupdate-8.1.0.0R6.tgz.md5sum	07/10/19 10:55:14	N/A	N/A	N/A	☐

Delete File Download File Rename File New File Name:

Note: The **Delete**, **Download**, and **Rename** options are at the bottom of the page (Figure 9-4).

- To delete a file, click the check box next to the filename and click **Delete File**. A confirmation message displays.
- To download a file, click the **Download File** button. Select the file from the list.
- To rename a file, click the check box next to the filename and enter a new name in the New File Name field.
- Click **Rename File**.

USB Serial Settings

The console manager supports connecting USB serial devices to the front USB port. A user can interact with the device by logging into the CLI and performing a **connect direct** to the USB port, or by establishing a SSH, Telnet or TCP connection to the USB port. A maximum of 3 concurrent sessions to the port are allowed.

To enter serial settings for a USB:

- Insert any of the supported USB serial devices into the USB port on the front of the EMG unit. You can do this before or after powering up the console manager.
- Log into the EMG unit and click **Devices**.
- Click **USB / SD Card**. Figure 9-5 shows the page that displays. Your USB device should display in the appropriate row of the USB ports / SD card table. If it does not display and you have inserted it, refresh the web page.

Figure 9-5 Devices > USB/SD Card - Serial Port

LANTRONIX[®] EMG851300

Logout Host: emgfd02 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Status Device Ports Console Port USB/SD Card DIO Ports RPM Connections Xmodem Host Lists Scripts Sites Access Lists

USB / SD Card [Help?](#)

Port	Device	Type	State
U1	serial	N/A	N/A
SD	none	N/A	N/A
Int SD	Storage	Internal SD Card	

[Configure](#)

USB Access: ☒
SD Card Access: ☒

[Apply](#)

USB Devices [>](#)
If a USB device or SD Card has been inserted but is not visible in the table, please refresh the web page.
To configure the settings for a USB device or SD Card, select the radio button in the right column.

- Select the USB serial device from the USB Ports table and click **Configure**. The USB - Serial configuration page is displayed.

Figure 9-6 Devices > USB/SD Card > USB - Serial

LANTRONIX[®] EMG851300

Logout Host: emgfd02 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Status Device Ports Console Port USB/SD Card **DIO Ports** RPM Connections Xmodem Host Lists Scripts Sites Access Lists

USB - Serial [Help?](#)

Port: U1
Device: Serial
Type: N/A
State: N/A

Data Settings

Baud: 115200
Data Bits: 8
Parity: none
Stop Bits: 1
Flow Control: rts/cts

IP Settings

Service: ☒ None ☐ Telnet ☐ SSH ☐ TCP

Telnet Port: 2049 Authenticate: ☒
SSH Port: 3049 Authenticate: ☒
TCP Port: 4049 Authenticate: ☐

[Apply](#)

- Complete or view the following sections:

Data Settings

Baud	The speed with which the device port exchanges data with the attached serial device. From the drop-down list, select the baud rate. Most devices use 9600 for the administration port, so this is the default. Check the equipment settings and documentation for the proper baud rate.
Parity	Parity checking is a rudimentary method of detecting simple, single-bit errors. From the drop-down list, select the parity. The default is none.
Flow Control	A method of preventing buffer overflow and loss of data. The available methods include none, xon/xoff (software), and RTS/CTS (hardware). The default is none.
Data Bits	Number of data bits used to transmit a character. From the drop-down list, select the number of data bits. The default is 8 data bits.
Stop Bits	The number of stop bit(s) used to indicate that a byte of data has been transmitted. From the drop-down list, select the number of stop bits. The default is 1.

IP Settings

Service	The available connection services for this USB Port (Telnet, SSH, or TCP). Only one can be active at a time. The default is None.
Telnet Port	Telnet Port Telnet session port number to use if you selected Telnet. Defaults: ◆ USB Port U1: 2049 ◆ Range: 1025-65535
SSH Port	The SSH session port number to use if you selected SSH. Defaults: ◆ USB Port U1: 3049 ◆ Range: 1025-65535
TCP Port	The TCP (raw) session port number to use if you selected TCP. Defaults: ◆ USB Port U1: 4049 ◆ Range: 1025-65535
Authenticate	If selected, the console manager requires user authentication before granting access to the port. Authenticate is selected by default for Telnet Port and SSH Port, but not for TCP Port.

6. To save settings for just this port, click **Apply**.

USB Commands

Go to [USB Access Commands](#), [USB Device Commands](#), [USB Storage Commands](#), [USB Serial Commands](#), and [Internal Modem Commands](#) to view CLI commands which correspond to the web page entries described above.

SD Card Commands

Go to [SD Card Commands](#) to view CLI commands which correspond to the web page entries described above.

10: Device Ports

This chapter describes how to configure and use an EMG port connected to an external device, such as a server or a modem. This chapter also describes how to configure the console port. [Chapter 13: Connections](#) describes how to use the [Devices > Connections](#) web page to connect external devices and outbound network connections (such as Telnet or SSH) in various configurations.

For details on managing Remote Power Managers (RPMs), see [Chapter 11: Power Management](#).

For details on using scripts to automate tasks run on the CLI or device ports, see [Chapter 12: Scripts](#).

Connection Methods

A user can connect to a device port in one of the following ways:

1. Telnet or SSH to the Eth1 or Eth2 IP address, or connect to the console port, and log into the command line interface. At the command line interface, issue the `connect direct` or `connect listen` commands.
2. If Telnet is enabled for a device port, Telnet to `<Eth1 IP address>:<telnet port number>` or `<Eth2 IP address>:<telnet port number>`, where telnet port number is uniquely assigned for each device port.
3. If SSH is enabled for a device port, SSH to `<Eth1 IP address>:<ssh port number>` or `<Eth2 IP address>:<ssh port number>`, where ssh port number is uniquely assigned for each device port.
4. If TCP is enabled for a device port, establish a raw TCP connection to `<Eth1 IP address>:<tcp port number>` or `<Eth2 IP address>:<tcp port number>`, where tcp port number is uniquely assigned for each device port.
5. If a device port has an IP address assigned to it, you can Telnet, SSH, or establish a raw TCP connection to the IP address. For Telnet and SSH, use the default TCP port number (23 and 22, respectively) to connect to the device port. For raw TCP, use the TCP port number defined for TCP In to the device port according to the [Device Ports - Settings \(on page 218\)](#) section.
6. Connect a terminal or a terminal emulation program directly to the device port. If logins are enabled, the user is prompted for a username/password and logs into the command line interface.

For #2, #3, #4, #5, and #6, if logins or authentication are not enabled, the user is directly connected to the device port with no authentication.

For #1 and #6, if logins are enabled, the user is authenticated first, and then logged into the command line interface. The user login determines permissions for accessing device ports.

Permissions

There are three types of permissions:

1. **Direct (or data) mode:** The user can interact with and monitor the device port (`connect direct` command).
2. **Listen mode:** The user can only monitor the device port (`connect listen` command).

3. **Clear mode:** The user can clear the contents of the device port buffer (set locallog <port> clear buffer command).

The administrator and users with local user rights may assign individual port permissions to local users. The administrator and users with remote authentication rights assign port access to users authenticated by NIS, RADIUS, LDAP, Kerberos and TACACS+.

I/O Modules

The EMG module port configuration can be changed by adding or replacing I/O modules in the I/O module bays. Any changes to the I/O modules must be done while the unit is powered off. The following I/O module configurations are supported (Bay 1 is the leftmost bay when viewing the front of the EMG where the device ports are located):

Table 10-1 Supported I/O Module Configurations

Model	Bay 1	Bay 2
EMG8510xx	4 port RJ45 module	Empty
EMG8501xx	Empty	4 port RJ45 module
EMG8520xx	4 port USB module	Empty
EMG8502xx	Empty	4 port USB module
EMG8511xx	4 port RJ45 module	4 port RJ45 module
EMG8512xx	4 port RJ45 module	4-port USB module
EMG8521xx	4 port USB module	4 port RJ45 module
EMG8522xx	4 port USB module	4 port USB module

The number of device ports in the EMG can be expanded by adding a 4-port I/O module in Bay 2. The configurations listed above are the only valid configurations; if any other configuration is detected at boot, the EMG unit will still boot, disable use of the device ports, and provide indications in the boot messages, in the CLI and in the web that the I/O configuration is invalid. When an invalid configuration is corrected by reconfiguring the I/O modules into a valid configuration, after the EMG module is powered up and booted, the valid configuration will be detected and the EMG module ports can be used again.

See [Figure 10-2 Figure 10-2 Devices > Device Status](#).

Device ports in slot 1 are numbered 1-4 and device ports in slot 2 are numbered 5-8, even if slot 1 is empty.

Restoring Configurations

Restoring a configuration to the EMG will automatically adjust the number of device ports to reflect the number of ports in the EMG unit the configuration is being restored to.

Device Status

The [Devices > Device Status](#) page displays the status of the EMG ports, the USB port and SD card port.

1. Click the **Devices** tab and select the **Device Status** option. The following page displays:

Figure 10-2 Devices > Device Status

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

Device Status Help ?

Console Port: **Not Connected**

Device Port Status and Counters					
No	Name	DSR	Bytes Input/Output	Errors	Connection Status
1	Port-1	No	0/0	0	Idle
2	Port-2	No	0/0	0	Idle
3	Port-3	No	0/0	0	Idle
4	Port-4	No	0/0	0	Idle

USB Ports / SD Card			
Port	Device	Type	State
U1	storage	Lexar Media, Inc.	fat32, mounted, Size/Used/Avail 29.8G/22.2G/7.6G
SD Card	storage	Ultra HS-SD/MMC2	not mounted

Device Ports

On the [Devices > Device Ports](#) page, you can set up the numbering of Telnet, SSH, and TCP ports, view a summary of current port modes, and select individual ports to configure.

1. Click the **Devices** tab and select the **Device Ports** option. The following page displays:

Figure 10-3 Devices > Device Ports

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Status Device Ports Console Port USB/SD Card DIO RPM Outlets Connections Xmodem Host Lists Scripts Sites Access Lists

Device Ports Help ?

Telnet/SSH/TCP In Port Numbers

Renumber the Telnet In, SSH In or TCP In Port Number for all Device Ports.

Starting Telnet Port:

Starting SSH Port:

Starting TCP Port:

Auto-refresh Port Counters: ☐

Ports: Configure			
No	Name	Mode	Select
1	Port-1	Idle	☐
2	Port-2	Idle	☐
3	Port-3	Idle	☐
4	Port-4	Idle	☐

Current port numbering schemes for Telnet, SSH, and TCP ports display on the left. The list of ports on the right includes the individual ports and their current mode.

Note:

Icons that represent some of the possible modes include:

Idle	The port is not in use.
	The port is in data/text mode. Note: You may set up ports to allow Telnet access using the IP Setting per Device Ports - Settings .
	An external modem is connected to the port. The user may dial into or out of the port.
	Telnet in or SSH in is enabled for the device port. The device port is either waiting for a Telnet or SSH login or has received a Telnet or SSH login (a user has logged in).

To set up Telnet, SSH, and TCP port numbering:

1. Enter the following:

Telnet/SSH/TCP in Port Numbers

Starting Telnet Port	Each port is assigned a number for connecting via Telnet. Enter a number (1025-65528) that represents the first port. The default is 2000 plus the port number. For example, if you enter 2001, port 1 will be 2001 and subsequent 2000 ports are automatically assigned numbers 2001, 2002, and so on.
Starting SSH Port	Each port is assigned a number for connecting via SSH. Enter a number (1025-65528) that represents the first port. The default is 3000 plus the port number. For example, if you enter 3001, port 1 will be 3001 and subsequent 3000 ports are automatically assigned numbers 3001, 3002, and so on.

Starting TCP Port	Each port is assigned a number for connecting through a raw TCP connection. Enter a number (1025-65528) that represents the first port. The default is 4000 plus the port number. For example, if you enter 4001, port 1 will be 4001 and subsequent 4000 ports are automatically assigned numbers 4001, 4002, and so on. You can use a raw TCP connection in situations where a TCP/IP connection is to communicate with a serial device. For example, you can connect a serial printer to a device port and use a raw TCP connection to send print jobs to the printer over the network. Note: When using raw TCP connections to transmit binary data, or where the break command (escape sequence) is not required, set the Break Sequence of the respective device port to null (clear it).
Auto refresh Port Counters	Select to enable auto-refresh of the Device Port Status and Counters (bytes input, bytes output, etc) on the Device Ports Settings web page. Disabled by default.

Caution: Ports 1-1024 are RFC-assigned and may conflict with services running on the EMG. Avoid this range.

- Click the **Apply** button to save the settings.

To configure a specific port:

- You have two options:
 - Select the port from the ports list and click the **Configure** button. The [Device Ports > Settings \(1 of 2\)](#) page for the port displays.
 - Click the port number on the green bar at the top of each page.
- Continue with directions in the section, [Device Ports - Settings](#).

Device Port Global Commands

Go to [Device Port Commands](#) to view CLI commands which correspond to the web page entries described above.

Device Ports - Settings

On the [Device Ports > Settings \(1 of 2\)](#) page, configure IP and data (serial) settings for individual ports, and if the port connects to an external modem, modem settings as well.

To open the Device Ports - Settings page:

1. You have two options:

- **Dashboard**

Make sure the **Configuration** radio button directly beneath the [Dashboard](#) is selected and click the desired port number in the [Dashboard](#). The Dashboard is located on the upper right corner of each Web Manager page (see [Chapter 6: Web Manager](#).)



- **Device Ports Page**

Click the **Devices** tab and select the **Device Ports** option. Select the port you want to configure and then click the **Configure** button.

LANTRONIX® EMG851300

Logout Host: emgfcf0 User: sysadmin

Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Status Device Ports Console Port USB/SD Card DIO RPM Outlets Connections Xmodem Host Lists Scripts Sites Access Lists

Device Ports Help ?

Telnet/SSH/TCP In Port Numbers

Renumber the Telnet In, SSH In or TCP In Port Number for all Device Ports.

Starting Telnet Port:

Starting SSH Port:

Starting TCP Port:

Auto-refresh Port Counters: ☐

Ports: Configure			
No	Name	Mode	Select
1	Port-1	Idle	☐
2	Port-2	Idle	☐
3	Port-3	Idle	☐
4	Port-4	Idle	☐

The following page displays:

Figure 10-4 Device Ports > Settings (1 of 2)

EMG851000

Logout

Host: **emgfcf0**
User: **sysadmin**

Select port for
☒ Configuration
☐ WebSSH (DP only)
☐ Connected Device (DP only)

Network
Services
User Authentication
Devices
Maintenance
Quick Setup

[Device Status](#)
[Device Ports](#)
[Console Port](#)
[USB / SD Card](#)
[RPMs](#)
[Connections](#)
[Xmodem](#)
[Host Lists](#)
[Scripts](#)
[Sites](#)

Device Ports - Settings

Help?

Port: **1**
Mode: **Idle**
Name:

Detect Port Name: ☐
Detect Name Tokens:
Group Access:
Banner:
of Sessions Msg: ☐
Idle Timeout Msg: ☐
Connected Msg: ☒
New User Msg: ☐
Minimize Latency: ☐
Break Sequence:
Note: remove Break Sequence for Device Ports connected to raw binary connections.
View Port Log Seq:
View Port Log: ☐
Zero Port Counters: ☐

Logging & Events: [Settings](#)
Connected to:

Power Management: [Settings](#)

IP Settings

Telnet In: ☐ Port: Authentication: ☒
Telnet Timeout: ☒ Seconds: Data Direction:
Telnet Soft IAC Mode: ☐

SSH In: ☐ Port: Authentication: ☒
SSH Timeout: ☒ Seconds: Data Direction:
TCP In: ☐ Port: Authentication: ☐
TCP Timeout: ☒ Seconds: Data Direction:
IP Address/Netmask Bits:
Send Term String: ☐ Term String:

Data Settings

Baud:
Data Bits:
Stop Bits:
Parity:
Flow Control:

Modem Settings

State:
Mode: ☒ Text ☐ PPP
Use Sites: ☐
Initialization Script:
Modem Timeout: ☒ No ☐ Yes, seconds (1-9999):

[View Modem Log](#)
PPP Logging: ☐
PPP Debug: ☐

Figure 10-5 Device Ports > Settings (2 of 2)

Enable Logins: ☐
 Max Direct Connects:
 Show Lines On Connecting: ☒ No ☐ Yes, # of lines:
 USB Channel:

Hardware Signals

Check DSR on Connect: ☐
 Disconnect on DSR: ☐
 Assert DTR: ☒
 DTR Control:
 Reverse Pinout: ☒
 USB VBUS: ☒

Port Status and Counters	
DSR/CD	No
DTR	Yes
CTS	No
RTS	Yes
Bytes input	0
Bytes output	0
Framing errors	0
Parity errors	0
Overrun errors	0
Flow Control errors	0
Seconds since zeroed	11931

[Back to Device Ports](#)

Caller ID Logging: ☐ Modem Command:
 Dial-back Number: ☒ Local User Number ☐ Fixed Number:
 Dial-back Delay: seconds
 Dial-back Retries:

Text Mode

Timeout Logins: ☒ No ☐ Yes, minutes (1-30):
 Dial-in Host List: [Host Lists](#)

PPP Mode

Negotiate IP Address: ☒ Yes ☐ No Local IP:
 Remote IP:
 Authentication: ☒ PAP ☐ CHAP
 Host/User Name:
 CHAP Handshake: Secret/User Password:
 Retype Password:
 CHAP Auth Uses: ☒ CHAP Host ☐ Local Users
 Same authentication for Dial-in & Dial-on-Demand (DOD): ☒
 DOD Authentication: ☒ PAP ☐ CHAP
 Host/User Name:
 DOD CHAP Handshake: Secret/User Password:
 Retype Password:
 Enable NAT: ☐ **Note:** Enabling NAT requires [IP Forwarding](#) to be enabled.
 Dial-out Number:
 Remote/Dial-out Login:
 Remote/Dial-out Password: Retype:
 Restart Delay: seconds
 CBCP Server ☐
 Allow No Callback: ☐
 CBCP Client Type: ☒ Admin-defined Number ☐ User-defined Number

Apply Settings: to Device Ports:
Note: In addition to applying settings to the currently selected Device Port, all or some of the settings can also be applied to other Device Ports.

2. Enter the following:

Device Port Settings

Port	Displays number of port; displays automatically.
Mode	The status of the port; displays automatically.
USB Device	This field is only displayed for USB ports. If a USB device is connected to the device port, this displays the USB version, speed, and a short type description for the USB device. The EMG supports up to 8 USB type A (Host) devices at data rates of HS (480 Mbit/s), FS (12 Mbit/s) or LS (1.5 Mbit/s). Each port has VBUS 5V support of up to 100mA (but not to exceed 600mA total per 4-port USB I/O module). Drawing more than 150 mA on a USB device port will shut down the VBUS 5V. USB ports are designed for data traffic only, and are not designed for charging or powering devices. Overcurrent conditions may disrupt operations.
Name	The name of the port. Valid characters are letters, numbers, dashes (-), periods, and underscores (_).

Detect Port Name	If enabled, the EMG will attempt to detect the hostname of the device connected to the device port, and set the device port name to the detected hostname. Many devices use their hostname or another identifier as the device prompt, and the EMG can extract this name from the prompt using the Detect Name Tokens. If the device port name is set to the default value, when a user interacts with a device connected to a device port, the EMG will look for the device prompt and set the device port name. The device prompt must be output at least 3 times in a single session for the prompt to be detected and the name extracted from the prompt. Any characters that are not part of the allowed characters for the device port Name will be removed. If the device name is automatically detected, the name will be logged in the Device Ports log.
Detect Name Tokens	If Detect Port Name is enabled, the EMG will attempt to extract a hostname or other identifier from the device prompt, to use as the device port name. The EMG will extract any name between either the start of a line sent from the device up until one of the tokens, or any part of a prompt that does not include the tokens, as the device port name. For example, if the device prompt is set to [EMG431d]>, and the Detect Name Tokens include "[" and "]", the EMG will extract the identifier EMG431d and set it as the device port name. If the device prompt is set to myrouter>, and the Detect Name Tokens include ">", the EMG will extract the identifier myrouter and set it as the device port name.
Group Access	If undefined, any group can access the device port. If one or more groups are specified (groups are delimited by the characters ' ' (space), ',' (comma), or ';' (semicolon)), then any user who logs into the device port must be a member of one of the specified groups, otherwise access will be denied. Users authenticated via RADIUS may have a group (or groups) provided by the RADIUS server via the Filter-Id attribute that overrides the group defined for a user on the EMG unit. A group provided by a remote server must be either a single group or multiple groups delimited by the characters ' ' (space), ',' (comma), ';' (semicolon), or '=' (equals) - for example "group=group1,group2;" or "group1,group2,group3".
Banner	Text to display when a user connects to a device port by means of Telnet, SSH, or TCP. If authentication is enabled for the device port, the banner displays once the user successfully logs in. Blank is the default.
# of Sessions Msg	If enabled, a message will be displayed to a user when connecting to a device port that indicates how many users are currently connected to the device port. Disabled by default.
Idle Timeout Msg	If enabled, a message will be displayed to a user when their connection to a device port will be terminated soon due to the connection being idle. Disabled by default. Note: When the Idle Timeout Msg is enabled, the terminal application timeout values for Telnet, SSH and TCP should be set to a value greater than 15 seconds.
Connected Msg	If enabled, a message will be displayed to a user when they initially connect to a device port. Enabled by default.
New User Msg	If enabled, a message will be displayed to all the users connected to the device port when a new user connects to the same device port. Disabled by default.
Minimize Latency	Minimize device port latency by reducing read delays. This may improve communication efficiency in scenarios where a series of short messages are exchanged, but may increase central processing unit (CPU) utilization and decrease throughput in cases where large messages are transmitted. Disabled by default.

Break Sequence	A series of one to ten characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as \x1bB , which is hexadecimal (\x) character 27 (1B) followed by a B . See Key Sequences for notes on key sequence precedence and behavior.
View Port Log Seq	The key sequence used to view the Port Log while in Connect Direct mode. Non-printing characters can be specified by giving their hexadecimal code (see Break Sequence above). The default is Esc+V (\x1bV). See Key Sequences for notes on key sequence precedence and behavior.
View Port Log	Select to allow the user to enter the View Port Log Sequence to view the Port Log during Connect Direct mode. The default is disabled.
Zero Port Counters	Resets all of the numerical values in the Port Counters table at the bottom of the page to zero (0).
Logging & Events	Click the Settings link to configure file logging (see Device Ports - Logging and Events), email logging, local logging, and USB logging.
Power Management	Click the Settings link to configure power supplies for the device connected to this device port on the Device Ports - Power Management page.
Connected to	The type of device connected to the device port. Currently, the EMG unit supports Remote Power Managers (PDUs and UPSes) from 140+ vendors, as well as Sensorsoft devices. If the connected device is an RPM, the user can assign an RPM to the device port by either select an existing RPM (via the Select dropdown) or clicking the Add RPM link to configure a new RPM for the EMG. If an RPM is already assigned to the device port, the user can click on the Selected RPM link to view status and configuration for the RPM. If the connected device is a Sensorsoft device, the user can click on Device Commands to manage the Sensorsoft device. If the type of device connected to the device port is not listed, select Undefined . <i>Note: Sensorsoft temperature/humidity devices are supported with USB-to-serial adapters (ftdi/pl2303/cp210x) but are not supported for use with USB-to-Serial CDC_ACM devices.</i>

IP Settings

Telnet In	Enables access to this port through Telnet. Disabled by default.
SSH In	Enables access to this port through SSH. Disabled by default.
TCP in	Enables access to this port through a raw TCP connection. Disabled by default: <i>Note: When using raw TCP connections to transmit binary data, or where the break command (escape sequence) is not required, set the Break Sequence of the respective device port to null (clear it).</i>
Port	Automatically assigned Telnet, SSH, and TCP port numbers. You may override this value, if desired. The value must be unique on the EMG; for example, you cannot have two or more ports numbered 10001.
Authentication	If selected, the EMG unit requires user authentication before granting access to the port. Authenticate is selected by default for Telnet in and SSH in , but not for TCP in .
Telnet/SSH/TCP Timeout	Select the checkbox to cause an idle Telnet, SSH or TCP connection to disconnect after a specified number of seconds as defined in the Seconds field to the right.

Seconds	Enter a value from 1 to 3600 seconds if selecting the Telnet, SSH or TCP Timeout checkbox to the left. The default is 600 seconds. Note: When the Idle Timeout Msg is enabled, the terminal application timeout values for Telnet, SSH and TCP should be set to a value greater than 15 seconds.
Data Direction	If a Telnet, SSH or TCP connection has the idle Timeout enabled, this setting indicates the direction of data use to determine if the connection has timed out: incoming network data, outgoing network data, or data from both directions. The default is Both Directions for Telnet and SSH, and Incoming Network data for TCP.
Telnet Soft IAC Mode	When Telnet Soft IAC mode is enabled, the Telnet server will not block waiting for the initial Telnet protocol IAC option responses. An abbreviated list of IAC options will be sent to the client, including a request for client side Echoing. Disabled by default.
IP Address/Netmask Bits	IP address used for this device port so a user can Telnet, SSH, or establish a raw TCP connection to this address and connect directly to the device port. The optional netmask bits specify the netmask to use for the IP address. For example, for a netmask of 255.255.255.0 specify 24 bits. If the netmask bits are not specified, a default netmask used for the class of network that the IP address falls in will be used. For Telnet and SSH, the default TCP port numbers (22 and 23, respectively) are used to connect to the device port. For raw TCP, the TCP port number defined for TCP In to the device port is used. Note: If Ethernet Bonding is enabled, assigning individual IP Addresses to Device Ports is not supported. Note that the IP address will be bound to Eth1 only, so if Eth2 is connected and configured, and Eth1 is not, this feature will not work.
Send Term String/Term String	If Send Term String is enabled and a Term String is defined, when a network connection to a device port is terminated, the termination string is sent to the device connected to the device port. The string should be defined so that it sends the appropriate command(s) to the device to terminate any active user sessions, e.g. "logout" or "exit". The string may contain multiple commands separated by a newline ("n") character. This is a security mechanism used to close sessions that are inadvertently left open by users.

Data Settings

Note: Check the serial device's equipment settings and documentation for the proper settings. The device port and the attached serial device must have the same settings.

Baud	The speed with which the device port exchanges data with the attached serial device. From the drop-down list, select the baud rate. Most devices use 9600 for the administration port, so the device port defaults to this value. Check the equipment settings and documentation for the proper baud rate. The baud rate can also be set from the Power Management and Baud Rate menu. See the Device Ports - Power Management page.
Data Bits	Number of data bits used to transmit a character. From the drop-down list, select the number of data bits. The default is 8 data bits.
Stop Bits	The number of stop bit(s) used to indicate that a byte of data has been transmitted. From the drop-down list, select the number of stop bits. The default is 1.

Parity	Parity checking is a rudimentary method of detecting simple, single-bit errors. From the drop-down list, select the parity. The default is none .
Flow Control	A method of preventing buffer overflow and loss of data. The available methods include none , xon/xoff (software), and rts/cts (hardware). The default is none .
Enable Logins	For serial devices connected to the device port, displays a login prompt and authenticates users. Successfully authenticated users are logged into the command line interface. The default is disabled. This is the correct setting if the device port is the endpoint for a network connection.
Max Direct Connects	Enter the maximum number (1-15) of simultaneous connections for the device port. The default is 3.
Show Lines on Connecting	If enabled, when the user either does a <code>connect direct</code> from the CLI or connects directly to the port using Telnet or SSH, the EMG outputs up to 24 lines of buffered data as soon as the serial port is connected. For example, an EMG user issues a <code>connect direct device 1</code> command to connect port 1 to a Linux server. For example, if the user issues the <code>ls</code> command to display a directory on a Linux server, then exits the connection, the results of the <code>ls</code> will be stored in the buffer. When the user then issues another <code>direct connect device 1</code> , the last 24 lines of the <code>ls</code> command is displayed so the user can see what state the server was left in.
USB Channel	Applies to USB device ports only. When a dual channel USB device is connected to the device port, this allows the user to select which of the channels is the active channel used for all connections. Only one channel can be active at any time. Enter the number 1 or 2 . The default is 1 .

Hardware Signal Triggers

Note: When the DSR signal drops on a device port, indicating that the attached cable has been disconnected or the attached device has been powered off, the EMG will log the event in the Device Ports system log and send a `slcEventDevicePortAction` SNMP trap. The log message and SNMP trap only occur if there is an active (`connect direct` or network connection) to the device port.

Check DSR on Connect	If this setting is enabled, the device port only establishes a connection if DSR (Data Set Ready) is in an asserted state. DSR should already be in an asserted state, not transitioning to, when a connection attempt is made. Disabled by default unless dial-in, dial-out, or dial-back is enabled for the device port. Note: Applies to serial RJ45 device ports only.
Disconnect on DSR	If a connection to a device port is currently in session, and the DSR signal transitions to a de-asserted state, the connection disconnects immediately. Disabled is the default unless dial-in, dial-out, or dial-back is enabled for the device port. Note: Applies to serial RJ45 device ports only.
Assert DTR	By default, DTR (Data Terminal Ready) is asserted on a device port nearly all of the time (except momentarily when a port is opened for operations). Unchecking this option will deassert DTR, simulating a cable disconnection for the device that is connected to a device port. Note: Applies to serial RJ45 device ports only.

DTR Control	The type of DTR control feature. The options include: None, Toggle DTR, or Auto Enable DTR: None: No option selected. Toggle DTR: If enabled, when a user disconnects from a device port, DTR will be toggled. DTR will be de-asserted, and after a 2-second delay, will be re-asserted. This feature can be used when a serial connection requires DSR to be active for the attached device to connect. In this case, toggling DTR will end any active connection on the device. Auto Enable DTR: If enabled, DTR will be de-asserted and will remain de-asserted until the first connection (Connect Direct, Telnet, SSH, TCP In or ConsoleFlow Web Terminal Session) is established to the device port. At this time, DTR will be asserted. DTR will remain asserted as long as any connection exists to the device port. Once the last connection is terminated, DTR will be de-asserted. The Assert DTR setting is ignored if DTR Control is set to Auto Enable. Note: Applies to serial RJ45 device ports only.
Reverse Pinout	If enabled, swaps the positions of the serial lines, such that the direction of data or the signal is reversed. For instance, TX is swapped with RX. Enabling Reverse Pinout facilitates connections to Cisco and Sun style RS-45 console ports using a straight through Ethernet patch cable, without the need for a rolled cable or adapter. Enabled by default. Note: Applies to serial RJ45 device ports only. All Lantronix serial adapters are intended to be used with Reverse Pinout disabled.
USB VBUS	For USB Device Ports only. If enabled, the USB VBUS signal provides power to the USB device attached to a device port. Disabling VBUS will power down the device as long as it is bus-powered instead of self-powered. The VBUS 5V signal is up to 100 mA per port, but not to exceed 600mA total per USB I/O Module. Drawing more than 150 mA on a USB port will shut down the VBUS 5V. Caution: USB ports are designed for data traffic only. They are not designed for charging or powering devices. Over-current conditions on VBUS 5V may disrupt operations.

Modem Settings (Device Ports)

Note: Depending on the **State** and **Mode** you select, different fields are available.

State	Used if an external modem is attached to the device port. If enabling, set the modem to dial-out, dial-in, dial-back, dial-on-demand, dial-in/host list, dial-back & dial-on-demand, dial in & dial-on-demand, CBCP Server, and CBCP Client. Disabled by default. See Modem Dialing States for more information.
Mode	The format in which the data flows back and forth: ◆ Text: In this mode, the EMG assumes that the modem will be used for remotely logging into the command line. Text mode can only be used for dialing in or dialing back. Text is the default. ◆ PPP: This mode establishes an IP-based link over the modem. PPP connections can be used in dial-out mode (e.g., the EMG unit connects to an external network), dial-in mode (e.g., the external computer connects to the network that the EMG is part of), or dial-on-demand.
Use Sites	Enables the use of site-oriented modem parameters which can be activated by various modem-related events (authentication, outbound network traffic for dial-on-demand connections, etc.). Sites can be used with the following modem states: dial-in, dial-back, dial-on-demand, dial-in & dial-on-demand, dial-back & dial-on-demand, and CBCP server.

Initialization Script	Commands sent to configure the modem may have up to 100 characters. Consult your modem's documentation for recommended initialization options. If you do not specify an initialization script, the EMG unit uses a default initialization string of <pre>AT S7=45 SO=0 L1 V1 X4 &D2 &c1 E1 Q0.</pre> Note: We recommend that the modem initialization script always be preceded with AT and include E1 V1 x4 Q0 so that the EMG may properly control the modem. For information on AT commands, refer to the modem user guide, or do a web search for <code>at command set</code>. Serial modems may need to include &B1 in the modem initialization string to set the DTE rate to a fixed baud rate.
Modem Timeout	Timeout for all modem connections. Select Yes (default) for the EMG unit to terminate the connection if no traffic is received during the configured idle time. Enter a value of from 1 to 9999 seconds. The default is 30 seconds.
Caller ID Logging	Select to enable the EMG to log caller IDs on incoming calls. Disabled by default. Note: For the Caller ID AT command, refer to the modem user guide.
Modem Command	Modem AT command used to initiate caller ID logging by the modem. Note: For the AT command, refer to the modem user guide.
Dial-Back Number	Users with dial-back access can dial into the EMG gateway and enter their login and password. Once the EMG authenticates them, the modem hangs up and dials them back. Select the phone number the modem dials back on -a fixed number or a number associated with their login. If you select Fixed Number, enter the number (in the format 2123456789). The dial-back number is also used for CBCP client as the number for a user-defined number. See Device Ports - Settings for more information.
Dial-Back Delay	For dial-back and CBCP Server, the number of seconds between the dial-in and dial-out portions of the dialing sequence.
Dial-Back Retries	For dial-back and CBCP Server, the number of times the EMG unit will retry the dial-out portion of the dialing sequence if the first attempt to dial-out fails.

Modem Settings: Text Mode

Timeout Logins	If you selected Text mode, you can enable logins to time out after the connection is inactive for a specified number of minutes. The default is No. This setting is only applicable for text mode connections. PPP mode connections stay connected until either side drops the connection. Disabled by default.
Dial-in Host List	From the drop-down list, select the desired host list. The host list is a prioritized list of SSH, Telnet, and TCP hosts that are available for establishing outgoing modem connections or for connect direct at the CLI. The hosts in the list are cycled through until the EMG successfully connects to one. To establish and configure host lists, click the Host Lists link.

Modem Settings: PPP Mode

Negotiate IP Address	If the EMG unit and/or the serial device have dynamic IP addresses (e.g., IP addresses assigned by a DHCP server), select Yes. Yes is the default. If the EMG or the modem have fixed IP addresses, select No, and enter the Local IP (IP address of the port) and Remote IP (IP address of the modem).

Authentication	Enables PAP or CHAP authentication for modem logins. PAP is the default. With PAP, users are authenticated by means of the Local Users and any of the remote authentication methods that are enabled. With CHAP, the CHAP Handshake fields authenticate the user.
CHAP Handshake	The Host/User Name (for UNIX systems) or Secret/User Password (for Windows systems) used for CHAP authentication. May have up to 128 characters.
CHAP Auth Uses	For CHAP authentication, determines what is used to validate the CHAP host/user sent by the remote peer: either the CHAP Host defined for the modem, or any of the users in the Local Users list.
Same authentication for Dial-in & Dial-on-Demand (DOD)	Select this option to let incoming connections (dial-in) use the same authentication settings as outgoing connections (dial-on-demand). If this option is not selected, then the dial-on-demand connections take their authentication settings from the DOD parameter settings. If DOD Authentication is PAP , then the DOD CHAP Handshake field is not used.
DOD Authentication	Enables PAP or CHAP authentication for dial-in & dial-on-demand. PAP is the default. With PAP, users are authenticated by means of the Local Users and any of the remote authentication methods that are enabled. With CHAP , the DOD CHAP Handshake fields authenticate the user.
DOD CHAP Handshake	For DOD Authentication , enter the Host/User Name (for UNIX systems) or Secret/User Password (for Windows systems) used for CHAP authentication. May have up to 128 characters.
Enable NAT	Select to enable Network Address Translation (NAT) for dial-in and dial-out PPP connections on a per modem (device port or USB port) basis. Users dialing into the EMG access the network connected to Eth1 and/or Eth2. <i>Note: IP forwarding must be enabled on the Network > Network Settings (1 of 2) page for NAT to work. See Chapter 7: Networking.</i>
Dial-out Number	Phone number for dialing out to a remote system or serial device. May have up to 20 characters. Any format is acceptable.
Remote/Dial-out Login	User ID for dialing out to a remote system. May have up to 32 characters.
Remote/Dial-out Password	Password for dialing out to a remote system. May have up to 64 characters.
Retype	Re-enter remote/dial-out password for dialing out to a remote system. May have up to 64 characters.
Restart Delay	The number of seconds after the timeout and before the EMG unit attempts another connection. The default is 30 seconds.
CBCP Server Allow No Callback	For CBCP Server state, allows "No Callback" as an option in the CBCP handshake in addition to User-defined Number and Admin-defined Number.
CBCP Client Type	For CBCP Client, this selects the number that the client would like to use for callback - either a user-defined number passed to the server (specified by the Fixed Dial-back Number) or an administrator-defined number determined by the server based on the login that is PAP or CHAP authenticated.

3. To save settings for just this port, click the **Apply** button.
4. To save selected settings to ports other than the one you are configuring:
 - From the **Apply Settings** drop-down box, select none, a group of settings, or All.
 - In to **Device Ports**, type the device port numbers, separated by commas; indicate a range of port numbers with a hyphen (e.g., 2, 5, 7-10).

Note: It may take a few minutes for the system to apply the settings to multiple ports.

Port Status and Counters

Port Counters describe the status of signals and interfaces. EMG updates and increments the port counters as signals change and data flows in and out of the system. These counters help troubleshoot connections or diagnose problems because they give the user an overview of the state of various parameters. By setting them to zero and then re-checking them later, the user can view changes in status.

The chart in the middle of the page displays the flow control lines and port statistics for the device port. The system automatically updates these values. To reset them to zeros, select the **Zero port counters** checkbox in the IP Settings section of the page.

Note: Status and statistics shown on the web interface represent a snapshot in time. To see the most recent data, you must reload the web page, or enable Auto-refresh Port Counters on the Device Ports web page which will refresh the data every 10 seconds. The Stop Counters Refresh button can be used to temporarily disable the counters auto-refresh so that the page can be viewed/ scrolled or values updated (auto-refresh resumes when the page is reloaded).

Table 10-6 Port Status and Counters

Port Status and Counters	
DSR/CD	No
DTR	Yes
CTS	No
RTS	Yes
Bytes input	0
Bytes output	0
Framing errors	0
Parity errors	0
Overrun errors	0
Flow Control errors	0
Seconds since zeroed	11931

Stop Counters Refresh

Auto-refresh of Port Status or Counters in the CLI can be implemented with a simple script.

```
[slc]> set script import batch via cypypaste name dpCounterAutoRefresh
Please paste script; enter '.' (period) on a blank line to terminate
entry:
set cnt 5
while { $cnt >= 1 } {
    show portcounters deviceport 3
    sleep 5
    set cnt [expr $cnt - 1]
}
.
Batch script 'dpCounterAutoRefresh' imported.
[slc]> set script runcli dpCounterAutoRefresh
```

Device Ports - Power Management

In the Device Ports - Power Management page, configure power supplies that provide power to the device or server connected to the device port. Up to 4 power supplies can be configured, by selecting an RPM, an outlet on the RPM, and defining a unique name for the RPM/outlet pair. The RPM outlet pair can also be controlled (power cycled, turned on, turned off).

This page also allows the user to define the Power Management Sequence, which, when entered while the user is connected to a device port via the `connect direct` command, will display the Power Management and Baud Rate menu:

Power Management and Baud Rate Menu

RPM/outlet>>> trippOUT4 sentry3OUT15
A. Status E. Turn On H. Turn On
B. Help F. Turn Off I. Turn Off
C. Set Baud G. Power Cycle J. Power Cycle
D. Quit

This menu allows the administrator to query status and control any of the power supplies that provide power to the device connected to the device port and change the Baud Rate of the device port.

Note: *The Baud Rate can be configured while connected to a device port by entering the **Power Management Sequence**. This will display the **Power Management and Baud Rate** menu, which provides an option to set the Baud Rate.*

To configure power management settings for a device port:

1. Connect to a specific port on the **Devices > Device Ports** page according to instructions in [To open the Device Ports - Settings page](#).
2. Click the **Settings** link beside **Power Management** to access the [Device Ports - Power Management](#) page.

Figure 10-7 Device Ports - Power Management

LANTRONIX® EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

Device Ports - Power Management Help?

Port: 1
Name: Port-1

Power Management Sequence:

Select up to 4 RPM outlets which provide power for the device connected to this device port. Typing the Power Management Sequence while connected to a device port will display a menu for controlling each of the power supplies.

Managed Power Supplies

#1	RPM: select RPM	View Outlets >>
	Outlet:	<< Select Outlet
	Name:	
	State:	
	Action: None	
#2	RPM: select RPM	View Outlets >>
	Outlet:	<< Select Outlet
	Name:	
	State:	
	Action: None	
#3	RPM: select RPM	View Outlets >>
	Outlet:	<< Select Outlet
	Name:	
	State:	
	Action: None	
#4	RPM: select RPM	View Outlets >>
	Outlet:	<< Select Outlet
	Name:	
	State:	
	Action: None	

RPM Outlets

[Back to Device Port Settings](#)

3. Enter the following:

Power Management Sequence	A series of one to ten characters that will display the Power Management menu when connected to the device port. The default value is Esc+P (escape key, then uppercase "P"). This value is specified as <code>\x1bP</code>, which is hexadecimal (<code>\x</code>) character 27 (1B) followed by a P. See Key Sequences for notes on key sequence precedence and behavior.
RPM	For each managed power supply, select a RPM, most likely a PDU, which has outlets that can be individually controlled, and which provides power to the device connected to the device port. See Chapter 11: Power Management for details on managing Remote Power Managers with EMG.

Outlet	For each managed power supply, enter the outlet on the selected RPM. As an aid to selecting the outlet, click the View Outlets button, then select an outlet from the list and click the Select Outlet button. The managed power supply outlet number will be filled in, as well as the managed power supply outlet name if a name is listed for the outlet and one has not already been defined for the managed power supply. A unique name for the managed power supply name is required; this is what will be displayed on the Power Management menu.
Name	For each managed power supply, enter the name on the selected RPM. As an aid to selecting the name, click the View Outlets button, then select an outlet from the list and click the Select Outlet button. The managed power supply outlet number will be filled in, as well as the managed power supply outlet name if a name is listed for the outlet and one has not already been defined for the managed power supply. A unique name for the managed power supply name is required; this is what will be displayed on the Power Management menu.
State	Displays the current state of the outlet when the Device Ports - Power Management web page is loaded: on , off or unknown if the RPM does not provide status for individual outlets or the EMG was unable to obtain the status of the outlet.
Action	The action to take on the outlet: Cycle Power , On or Off .

4. To save, click **Apply**.

Device Port - Sensorsoft Device

Devices made by Sensorsoft are used to monitor environmental conditions.

1. Connect to a specific port on the **Devices > Device Ports** page according to instructions in [To open the Device Ports - Settings page](#).
2. In the **Connected to** drop-down menu above the IP Settings section of the [Device Ports > Settings \(1 of 2\)](#) page, select **Sensorsoft**.

Note: Sensorsoft temperature/humidity devices are supported with USB-to-serial adapters (ftdi/pl2303/cp210x) but not supported for use with USB-to-Serial CDC_ACM devices.

3. Click the **Device Commands** link. The following page displays:

Figure 10-8 Devices > Device Ports - Sensorsoft

LANTRONIX® EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

Device Ports - Sensorsoft

Sensorsoft Devices											
Dev Port	Device Port Name	Curr Temp	Low Temp	High Temp	Use °F	Humidity (%)	Low Humidity	High Humidity	Contact	Traps	Show Status
1	Port-1	0.0 °C	0	25	☐	0.0	0	100	N/A	☒	

[Back to Device Port Settings](#)


4. Select a port and enter or view the following information:

Dev Port	Displays the number of the EMG port.
Device Port Name	Displays the name of the EMG port.
Curr Temp	Current temperature (degrees Celsius) on the device the sensor is monitoring.
Low Temp	Enter the temperature (degrees Celsius) permitted on the monitored device below which the EMG sends a trap.
High Temp	Enter the temperature (degrees Celsius) permitted on the monitored device above which the EMG unit sends a trap.
Use °F	Display and set the temperature for this device in degrees Fahrenheit, instead of Celsius, which is the default.
Humidity (%)	Current relative humidity on the device the sensor is monitoring.
Low Humidity	Enter the relative humidity permitted on the device the sensor is monitoring below which the sensor sends a trap to the EMG.
High Humidity	Enter the highest relative acceptable humidity permitted on the device above which the sensor sends a trap to the EMG unit.
Contact	Displays the current contact closure status of the sensor, if supported by the connected Sensorsoft device. If the Sensorsoft device does not report a contact status, N/A will be displayed. If Traps are enabled for the Sensorsoft device, an <code>slcEventDevicePortDeviceContactChanged</code> trap will be sent when the contact state changes from Open to Closed and from Closed to Open.
Traps	Select to indicate whether the EMG unit should send a trap or configured Event Alert when the sensor detects an out-of-range configured threshold.

5. Click the **Apply** button.

6. To view the status detected by the Sensorsoft, click the **Show Status** link in the far right column of the table.

Figure 10-9 Sensorsoft Status



Device Port Commands

Go to [Device Port Commands](#) to view CLI commands which correspond to the web page entries described above.

Device Commands

Go to [Device Commands](#) to view CLI commands which correspond to the web page entries described above.

Interacting with a Device Port

Once a device port has been configured and connected to an external device such as the console port of an external server, the data received over the device port can be monitored at the command line interface with the `connect listen` command, as follows:

To connect to a device port to monitor it:

```
connect listen deviceport <Port # or Name>
```

In addition, you can send data out the device port (for example, commands issued to an external server) with the `connect direct` command, as follows:

To connect to a device port to monitor and/or interact with it, or to establish an outbound network connection:

```
connect direct <endpoint>
```

endpoint is one of:

```
deviceport <Port # or Name>
ssh <IP Address> [port <TCP Port>] [<SSH flags>]
```

where:

```
<SSH flags> is one or more of:
user <Login Name>
version <1|2>
command <Command to Execute>
tcp <IP Address> port <TCP Port>
telnet <IP Address> [port <TCP Port>]
udp <IP Address> port <UDP Port>
hostlist <Host List>
```

Notes: To escape from the `connect direct` command when the endpoint of the command is `deviceport`, `tcp`, or `udp` and return to the command line interface, type the escape sequence assigned to the currently logged in user. If the endpoint is `telnet` or `SSH`, logging out returns the user to the command line prompt.

To escape from the `connect listen` command, press any key. Setting up a user with an escape sequence is optional. For any NIS, LDAP, RADIUS, Kerberos, or TACACS+ user, or any local user who does not have an escape sequence defined, the default escape sequence is `Esc+A`.

When connecting to a USB device port, buffered data collected while there was no active connection to the device port may be displayed initially. This is due to clearing internal buffers in preparation for the new connection to the device port.

Device Ports - Logging and Events

The EMG products support port buffering of the data on the system's device ports as well as notification of receiving data on a device port. Port logging is disabled by default. You can enable more than one type of logging (local, NFS file, token and data detection, SD card, or USB port) at a time. The buffer containing device port data is cleared when any type of logging is enabled.

Local Logging

If local logging is enabled, each device port stores 256 Kbytes (approximately 400 screens) of I/O data in a true first-in, first-out (FIFO) buffer. You may view this data (in ASCII format) at the CLI with the `show locallog` command or on the [Devices > Device Ports - Logging & Events](#) page. Buffered data is normally stored in RAM and is lost in the event of a power failure if it is not logged using an NFS mount solution. If the buffer data overflows the buffer capacity, only the oldest data is lost, and only in the amount of overrun (not in large blocks of memory).

NFS File Logging

Data can be logged to a file on a remote NFS server. Data logged locally to the EMG is limited to 256 Kbytes and may be lost in the event of a power loss. Data logged to a file on an NFS server does not have these limitations. The system administrator can define the directory for saving logged data on a port-by-port basis and configure file size and number of files per port.

The directory path must be the local directory for one of the NFS mounts. For each logging file, once the file size reaches the maximum, a new file opens for logging. Once the number of files reaches the maximum, the oldest file is overwritten. The file naming convention is: <Device Port Number>_<Device Port Name>_<File number>.log.

Examples:

```
02_Port-2_1.log
02_Port-2_2.log
02_Port-2_3.log
02_Port-2_4.log
02_Port-2_5.log
```

USB and SD Card Logging

Data can be logged to a USB flash drive or the SD card slot on the front of the EMG unit and properly mounted. Data logged locally to the EMG is limited to 256 Kbytes and may be lost in the event of a power loss. Data logged to a USB flash drive or SD card does not have these limitations. The system administrator can define the file size and number of files per port. For each logging file, once the file size reaches the maximum, a new file opens for logging. Once the number of files reaches the maximum, the oldest file is overwritten. The file naming convention is: <Device Port Number>_<Device Port Name>_<File number>.log

Examples:

```
02_Port-2_1.log
02_Port-2_2.log
02_Port-2_3.log
02_Port-2_4.log
02_Port-2_5.log
```

Token/Data Detection

The system administrator can configure the device log to detect when a user-defined string or number of characters is received from the device, and automatically perform one or more actions: send a message to the system log, send an SNMP trap, send an email alert, send a string to the device, or control one of the power supplies associated with the device.

Syslog Logging

Data can be logged to the system log. If this feature is enabled, the data will appear in the Device Ports log, under the Info level. The log level for the Device Ports log must be set to Info for the data to be saved to the system log. See [Device Ports - Logging and Events](#).

To set logging parameters:

1. In the top section of the [Device Port Settings](#) page, click the **Settings** link in the Logging field. The following page displays:

Figure 10-10 Devices > Device Ports - Logging & Events

LANTRONIX® EMG851110

Host: **emgfcee**
User: **sysadmin**

Select port for: ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Logout

Network Services User Authentication Devices Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card DIO Ports RPMs Connections Xmodem Host Lists Scripts Sites

Device Ports - Logging & Events [Help?](#)

Port: **1**
Name: **Port-1**

For NFS File Logging, the directory to log to must reside on an external NFS server. Specify the local directory for the [NFS mount](#).

Token & Data Detection: ☐

Trigger on: ☒ Data Byte Count ☐ Token/Character String

Byte Threshold:

Token:

Actions

Syslog: ☐

SNMP Trap: ☐

Email: ☒

Email To:

Email Subject:

Send String to Device: ☐

String to Send:

Control Power Supply: ☐

Power Supply:

Power Action: ☒ Cycle Power ☐ Turn On ☐ Turn Off

See online help for how Delay parameters affect Actions.

Action Delay: seconds

Restart Delay: seconds

[Back to Device Port Settings](#)

☐ Apply settings to Device Ports:

Local Logging: ☐

Clear Local Log:

Log Viewing Attributes

Display: ☒ Tail ☐ Head

Number of Lines:

NFS File Logging: ☐

NFS Log to View: [View](#)

Directory to Log to:

Max Number of Files:

Max Size of Files: bytes

USB / SD Card Logging: ☐

Log to View: [View](#)

Log to: ☒ Port U1 ☐ SD Card ☐ Int SD Card

Max Number of Files:

Max Size of Files: bytes

Syslog Logging: ☐

Note: The logging level for the Device Ports log must be set to 'Info' to view Syslog entries for Device Port logging.

2. Enter the following:

Token & Data Detection

Token & Data Detection	Select to enable token and data detection on the selected device port, with a set of actions that can be enabled if a data trigger occurs. The default is disabled.
Trigger on	Select the method of triggering an action: ◆ Data Byte Count: A specific number of bytes of data. This is the default. ◆ Token/Character String: A specific pattern of characters, which you can define by a regular expression. Note: Token/Character String recognition may negatively impact the EMG unit's performance, particularly when regular expressions are used.

Byte Threshold	The number of bytes of data the port will receive before the EMG unit will capture log data and initiate the selected actions. The default is 100 bytes. In most cases, the console port of your device does not send any data unless there is an alarm condition. After the EMG unit receives a small number of bytes, it perceives that your device needs some attention. A threshold set to 30 characters means that as soon as the unit receives 30 bytes of data, it performs the actions that are selected for this port.
Token	The specific pattern of characters the EMG unit must recognize before initiating the actions configured for this port. The maximum is 100 characters. You may use a regular expression to define the pattern. For example, the regular expression "abc[def]g" recognizes the strings abcdg, abceg, abcfg. The EMG supports GNU regular expressions. For more information see: ◆ http://www.gnu.org/software/libc/manual/html_node/Regular-Expressions.html ◆ http://www.delorie.com/gnu/docs/regex/regex.html
Actions	Select one or more actions to perform if there is a data trigger: ◆ Syslog: A message is logged to the system log indicating what the data trigger was along with the initial portion of the data received. ◆ SNMP Trap: A slcEventDevicePortData trap will be sent to the NMS configured in the SNMP settings. ◆ Email: An email alert will be sent to the address configured for the device port. ◆ Send String to Device: A string will be sent to the device connected to the device port. ◆ Control Power Supply: The state of one or more of the device port power supplies can be changed.
Email to	The email address of the message recipient(s) for an email alert. To enter more than one email address, separate the addresses with a single space. You can enter a total of 128 characters.
Email Subject	A subject text appropriate for your site. May have up to 128 characters. The email subject line is pre-defined for each port with its port number. You can use the email subject to inform the desired recipients of the problem on a certain server or location (e.g., server location or other classification of your equipment). Note: The character sequence %d anywhere in the email subject is automatically replaced with the device port number.
String to Send	The string to send to the device connected to the device port. The string supports the following special characters: newline (" \n "), double quote (" \" "), single quote (" \' "), and escape (" \x1b "). You can enter a total of 128 characters.
Power Supply	The power supply that provides power to the device connected to the device port which to control. Select either all power supplies or an individual power supply.
Power Action	The action to perform on the selected power supply or power supplies - Cycle Power, Turn On or Turn Off.
Action Delay	A time limit of how long, in seconds, the device port will capture data after the data trigger is detected and before closing the log file (with a fixed internal buffer maximum capacity of 1500 bytes) and performing the selected actions. The default is 60 seconds.
Restart Delay	The number of seconds for the period of time, after performing the selected action, during which the device port will ignore additional characters received. The data will simply be ignored and not trigger additional actions until this time elapses. The default is 60 seconds.

Local Logging

Local Logging	If you enable local logging, each device port stores 256 Kbytes (approximately 400 screens) of I/O data in a true FIFO buffer. Disabled by default.
Clear Local Log	Select the checkbox to clear the local log.
View Local Log	Click this link to see the local log in text format.

Log Viewing Attributes

Display	Select to view either the beginning (Head) or end (Tail) of the log.
Number of Lines	Number of lines from the head or tail of the log to display.

NFS File Logging

NFS File Logging	Select the checkbox to log all data sent to the device port to one or more files on an external NFS server. Disabled by default.
NFS Log to View	Available log files in the selected NFS Directory to view.
Directory to Log to	The path of the directory where the log files will be stored. <i>Note: This directory must be a directory exported from an NFS server mounted on the EMG. Specify the local directory path for the NFS mount.</i>
Max Number of Files	The maximum number of files to create to contain log data to the port. These files keep a history of the data received from the port. Once this limit is exceeded, the oldest file is overwritten. The default is 10 .
Max Size of Files	The maximum allowable file size in bytes. The default is 2048 bytes. Once the maximum size of a file is reached, the EMG unit begins generating a new file.

USB / SD Card Logging

USB / SD Card Logging	Select to enable USB / SD card logging. A USB thumb drive or SD card must be loaded into one of the ports of the EMG and properly mounted. Disabled by default.
Log to View	Available log files in the selected USB / SD card slot to view.
Log To	Select the USB port, SD card, or internal SD card (if installed) to use for logging.
Max Number of Files	The maximum number of files to create to contain log data to the port. These files keep a history of the data received from the port. Once this limit is exceeded, the oldest file is overwritten. The default is 10.
Max Size of Files	The maximum allowable file size in bytes. The default is 2048 bytes. Once the maximum size of a file is reached, the EMG begins generating a new file. The default is 2048 bytes.

Syslog Logging

Syslog Logging	Select to enable system logging. <i>Note: The logging level for the device ports log must be set to Info to view Syslog entries for Device Port logging on the Services > SSH/Telnet/Logging page.</i>

Note: To apply the settings to additional device ports, in the Apply settings to Device Ports field, enter the additional ports, (e.g., 1-3, 5, 6)

- To apply settings to other device ports in addition to the currently selected port, select the **Apply** settings to Device Ports and enter port numbers separated by commas. Indicate a range of port numbers with a hyphen (e.g., 2, 5, 7-10), and separate ranges with commas.
- To save, click the **Apply** button.

Logging Commands

Go to [Logging Commands](#) to view CLI commands which correspond to the web page entries described above.

Console Port

The console port initially has the same defaults as the device ports. Use the [Devices > Console Port](#) page to change the settings, if desired.

To set console port parameters:

- Click the **Devices** tab and select **Console Port**. The following page displays:

Figure 10-11 Devices > Console Port

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Status Device Ports Console Port USB/SD Card DIO RPM Outlets Connections Xmodem Host Lists Scripts Sites Access Lists

Console Port Help ?

Status: **Not Connected**

Enable Access: ☒

Baud: 9600 ▼

Data Bits: 8 ▼

Stop Bits: 1 ▼

Parity: none ▼

Flow Control: none ▼

Timeout: ☒ No ☐ Yes, minutes:

Show Lines On Connecting: ☒ No ☐ Yes, number of lines: 24

Group Access:

Apply

- Change the following as desired:

Enable Access	Enables or disables console port access.
Baud	The speed with which the device port exchanges data with the attached serial device. From the drop-down list, select the baud rate. Most devices use 9600 for the administration port, so the console port defaults to this value.
Data Bits	Number of data bits used to transmit a character. From the drop-down list, select the number of data bits. The default is 8 data bits.

Stop Bits	The number of stop bits that indicate that a byte of data has been transmitted. From the drop-down list, select the number of stop bits. The default is 1 .
Parity	Parity checking is a rudimentary method of detecting simple, single-bit errors. From the drop-down list, select the parity. The default is none .
Flow Control	A method of preventing buffer overflow and loss of data. The available methods include none , xon/xoff (software), and rts/cts (hardware). The default is none .
Timeout	The number of minutes (1-30) after which an idle session on the console is automatically logged out. Disabled by default.
Show Lines on Connecting	If selected, when you connect to the console port with a terminal emulator, you will see the last lines output to the console, for example, the EMG boot messages or the last lines output during a CLI session on the console.
Group Access	If undefined, any group can access the console port. If one or more groups are specified (groups are delimited by the characters ' ' (space), ',' (comma), or ';' (semicolon)), then any user who logs into the console port must be a member of one of the specified groups, otherwise access will be denied. Users authenticated via RADIUS may have a group (or groups) provided by the RADIUS server via the Filter-Id attribute that overrides the group defined for a user on the EMG. A group provided by a remote server must be either a single group or multiple groups delimited by the characters ' ' (space), ',' (comma), ';' (semicolon), or '=' (equals) - for example "group=group1,group2;" or "group1,group2,group3".

3. Click the **Apply** button to save the changes.

Console Port Commands

Go to [Console Port Commands](#) to view CLI commands which correspond to the web page entries described above.

Internal Modem

The internal modem is an optional part. If the modem is installed, a message will be displayed when the unit boots:

```
Internal modem installed.
```

The presence of the modem will also be displayed in the CLI `admin version` command, the web [About EMG](#) page, and the System Configuration report. The internal modem provides a subset of the modem functionality available for modems connected to a Device Port and USB modems. If the internal modem is installed, the Internal Modem web page can be displayed by selecting the Internal Modem option from the main menu, or by selecting the **MD** button on the dashboard (see [Figure 6-2 Sample Dashboard](#)) on the upper right corner of the web page.

Note: *The internal modem only supports Dial-in, Dial-out, Dial-back and Dial-on-Demand.*

To enter settings for the internal modem:

1. From the **Devices** menu, select **Internal Modem**. The **Internal Modem** page displays.

Figure 10-12 Devices > Internal Modem

LANTRONIX® EMG851331

Logout Host: Emg_fd1e User: sysadmin

Select port for: ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card DIO Ports Internal Modem RPMs Connections Xmodem Host Lists Scripts Sites

Internal Modem Help?

State: Dial-on-Demand

Mode: ☐ Text ☒ PPP

Use Sites: ☐

Group Access:

Initialization Script:

Modem Timeout: ☒ No ☐ Yes, seconds (1-9999):

Caller ID Logging: ☐ Modem Command:

Check Dial Tone: ☐ No ☒ Yes, minutes (5-600):

Dial-back Number: ☒ Local User Number ☐ Fixed Number:

Dial-back Delay: seconds

Dial-back Retries:

Text Mode

Timeout Logins: ☒ No ☐ Yes, minutes (1-30):

PPP Mode

Negotiate IP Address: ☒ Yes ☐ No Local IP: Remote IP:

Authentication: ☒ PAP ☐ CHAP

Host/User Name:

CHAP Handshake: Secret/User Password: Retype Password:

CHAP Auth Uses: ☒ CHAP Host ☐ Local Users

Enable NAT: ☐ Note: Enabling NAT requires [IP Forwarding](#) to be enabled.

Dial-out Number:

Remote/Dial-out Login:

Remote/Dial-out Password: Retype:

Restart Delay: seconds

Apply

[View Modem Log >](#)

Modem Statistics

Tx bytes: N/A

Rx bytes: N/A

2. Complete or view the following sections:

- [Text Mode](#)
- [PPP Mode](#).

State	Indicates whether the internal modem is enabled. When enabling, set the modem to dial-out, dial-in, dial-back, and dial-on-demand. Disabled by default. For more information on the different dialing types, see Modem Dialing States .

Mode	The format in which the data flows back and forth. ◆ With Text selected, the EMG unit assumes that the modem will be used for remotely logging into the command line. Text mode is only for dialing in. This is the default. ◆ PPP establishes an IP-based link over the modem. PPP connections can be used in dial-out mode (e.g., the EMG unit connects to an external network) or dial-in mode (e.g., the external computer connects to the network that the EMG unit is part of), dial-back (dial-in followed by dial-out), CBCP server and CBCP client. When there is an active modem session, the PPP Tx and Rx bytes will be displayed at the top of the window.
Use Sites	Enables the use of site-oriented modem parameters which can be activated by various modem-related events (authentication, outbound network traffic for dial-on-demand connections, etc.). Sites can be used with the following modem states: dial-in, dial-back, dial-on-demand, dial-in & dial-on-demand, dial-back & dial-on-demand, and CBCP server. For more information see Sites.
Group Access	If undefined, any group can access the modem (text login only). If one or more groups are specified (groups are delimited by the characters ',' (comma) or ';' (semicolon)), then any user who logs into the modem must be a member of one of the specified groups, otherwise access will be denied. Users authenticated via RADIUS may have a group (or groups) provided by the RADIUS server via the Filter-Id attribute that overrides the group defined for a user on the EMG unit. A group provided by a remote server must be either a single group or multiple groups delimited by the characters ',' (comma), ';' (semicolon), or '=' (equals) - for example "group=group1,group2;" or "group1,group2,group3".
Initialization Script	Commands sent to configure the modem may have up to 100 characters. Consult your modem's documentation for recommended initialization options. If you do not specify an initialization script, the EMG uses a default initialization string of: <pre>AT S7=45 SO=0 L1 V1 X4 &D2 &c1 E1 Q0</pre> Note: We recommend that the modem initialization script always be pre-pended with AT and include E1 V1 x4 Q0 so that the EMG unit may properly control the modem.
Modem Timeout	Timeout for modem connections. Set Yes (default) for the EMG to terminate the connection if no traffic is received during the configured idle time. Enter a value of 1 to 9999 seconds.
Caller ID Logging	Select to enable the EMG unit to log caller IDs on incoming calls. Disabled by default.
Modem Command	Modem AT command used to initiate caller ID logging by the modem. Note: For the AT command, use +VCID=1 to enable Caller ID with formatted presentation, and use +VCID=2 to enable Caller ID with unformatted presentation. This is subject to subscribing to a Caller ID service for the modem line.
Check Dial Tone	If enabled, the EMG will periodically check the modem for a dial tone while waiting for a dial in (e.g., if the Modem State is set to Dial-in, or if the Modem State is set to Dial-back and the EMG unit is in the Dial-in portion of the sequence). The EMG unit can issue a trap or an event can be setup to notify the user if no dial tone is detected. Enabled by default (every 15 minutes).

Dial-back Number	Users with Dial-back can dial into the EMG unit and enter their login and password. Once the EMG unit authenticates them, the modem hangs up and dials them back . Select the phone number the modem dials back on: a fixed number or a number associated with their login. If you select Fixed Number, enter the number (in the format 2123456789). The dial-back number is also used for CBCP client as the number for a user-defined number. See CBCP Server and CBCP Client for more information.
Dial-back Delay	For dial-back and CBCP Server, the number of seconds between the dial-in and dial-out portions of the dialing sequence.
Dial-back Retries	For dial-back and CBCP Server, the number of times the EMG unit will retry the dial-out portion of the dialing sequence if the first attempt to dial-out fails.
Access List	For the dial-in state, a modem access list (or white list) that defines which phone numbers will be granted access to the console manager.

Text Mode

Timeout Logins	If you selected text mode, you can enable logins to time out after the connection is inactive for a specified number of minutes. The default is No . This setting only applies to text mode connections. PPP mode connections stay connected until either side drops the connection. Disabled by default.

PPP Mode

Negotiate IP Address	If the EMG and/or the serial device have dynamic IP addresses (e.g., IP addresses assigned by a DHCP server), select Yes. This is the default. If the EMG unit or the modem have fixed IP addresses, select No, and enter the Local IP (IP address of the internal modem) and Remote IP (IP address of the modem).
Authentication	Enables PAP or CHAP authentication for modem logins. PAP is the default. With PAP, users are authenticated by means of the Local Users and any of the remote authentication methods that are enabled. With CHAP, the CHAP Handshake fields authenticate the user.
CHAP Handshake	The Host/User Name (for UNIX systems) or Secret/User Password (for Windows systems) used for CHAP authentication. May have up to 128 characters.
CHAP Auth Uses	For CHAP authentication, determines what is used to validate the CHAP host/user sent by the remote peer: either the CHAP Host defined for the modem, or any of the users in the Local Users list.
Enable NAT	Select to enable Network Address Translation (NAT) for dial-in and dial-out PPP connections on a per modem (device port, USB port, or internal modem) basis. Users dialing into the EMG unit access the network connected to Eth1 and/or Eth2. Note: IP forwarding must be enabled on the Network Settings for NAT to work.
Dial-out Number	Phone number for dialing out to a remote system or serial device. May have up to 20 characters. Any format is acceptable.
Remote/Dial-out Login	User ID for authentication when dialing out to a remote system, or if a remote system requests authentication from the EMG module when it dials in. May have up to 32 characters.

Remote/Dial-out Password/ Retype	Password for authentication when dialing out to a remote system, or if a remote system requests authentication from the EMG unit when it dials in. May have up to 20 characters.
Restart Delay	The number of seconds after the timeout and before the EMG module attempts another connection. The default is 30 seconds.

3. Click **Apply**.

Internal Modem Commands

Go to [Internal Modem Commands](#) to view CLI commands which correspond to the web page entries described above.

DIO Port

DIO port applies to EMG 8500 only.


The front of the EMG unit has two Digital Inputs and one Relay Output. DIO ports can be used in Events as a trigger (inputs) or an action (relay output). Specifications for the DIO port:

- ◆ Two configurable inputs suitable for TTL input levels and tolerant up to 30VDC input voltage. The DIO inputs can be used to monitor the current status of any attached sensor.

On	Minimum: 2 VDC, Maximum: 30 VDC
Off	Minimum: 0 VDC, Maximum: 0.7 VDC

- ◆ One independently isolated mechanical form-C relay, supporting 1A 24V. When the relay is energized/turned on, the relay is closed, connecting both relay ports on the I/O connector through the relay. When the relay is turned off, the signal path is open, disconnecting the relay ports on the I/O connector.

DIO terminal block (in the UIs the ports are designated as Front #1, Front #2 and Front Relay):



To configure the DIO ports:

1. Change the following Front #1 and Front #2 Input port fields:

Name	The name of the port. Valid characters are letters, numbers, dashes (-), periods and underscores (_).

State	(view only) Displays the current state of the port: on or off.
Normal State	Defines the typical or normal state of the DIO Input port. This setting is used for Events.

2. Change the following Front Relay port fields:

Name	The name of the port. Valid characters are letters, numbers, dashes (-), periods and underscores (_).
State	(view only) Displays the current state of the port: on or off. The Change State check box and Off / On selection can be used to change the state of the port.
Normal State	Defines the typical or normal state of the Relay port. This setting is used for Events.
Wake State	The initial state of the relay port when the EMG boots.
Latch	Controls how a relay will be turned off if it is turned on as the result of an event trigger. If Latch is enabled, the user will need to explicitly turn off the relay when it is turned on as a result of an event. If Latch is disabled, the relay will automatically turn off after the trigger condition corrects itself and is no longer active.

3. To save, click **Apply**.

See [Events](#) for information on configuring events for the DIO ports.

DIO Commands

Go to [DIO Commands](#) to view CLI commands which correspond to the web page entries described above.

Xmodem

The EMG supports using the Xmodem, Ymodem, or Zmodem protocols to send and receive files across serial ports. An Xmodem repository on the EMG holds files that can be sent or have been received. In order to use one of the protocols, the device port that will be used must not be currently in use for any other purpose.

An example of sending a file with Zmodem to device port 3 using the CLI:

```
[emg431d]> set xmodem send 3 file update.bin protocol zmodem xfer binary
Starting Zmodem send of 117K file update.bin...
Sending: update.bin
Bytes Sent: 117988 BPS:919
```

Transfer complete

An example of receiving the same file with Zmodem from device port 4 using the CLI:

```
[emg431d]> se xmodem receive 4 protocol zmodem xfer binary
Starting Zmodem receive of file specified by protocol...
Receiving: update.bin.0
Bytes received: 117988/ 117988 BPS:937
```

Transfer complete

Note: When performing critical operations (such as firmware update over a serial connection) with Xmodem, Ymodem or Zmodem, it is recommended to use the CLI to send and receive files instead of the web interface, as web browsers may be subject to timeouts which can interrupt the operation. It is also recommended that any timeouts that may affect the CLI session be disabled so that the operation is not interrupted.

To manage the Xmodem repository, send files or receive files:

1. Click the **Devices** tab and select the **Xmodem** option. The Xmodem page displays:

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

Xmodem Help ?

Xmodem Files Repository. File(s): 0

Name	Date/Time Saved	Size (Kbytes)	
Delete File Rename File New File Name:			
Add Uploaded File to Repo File to Add: Upload File >			

Protocol: ☒ Xmodem ☐ Ymodem ☐ Zmodem

Receive File Name:

Device Port:

Transfer: ☒ Binary ☐ ASCII

Receive Overwrite: ☐

2. To upload a file to the repository, click the **Upload File** link and upload a file in the window that is displayed. Upload file size should not exceed 20 MB. The maximum length for the upload file name is 40 characters. The file name should not contain the following characters: forward slash '/', backslash '\', colon ':', asterisk '*', question mark '?', double quotation mark ("), less than symbol '<', greater than symbol '>', or the vertical bar symbol '|'. After upload is complete, the filename will appear in the **File to Add** field. Click the **Add Uploaded File to Repo** button to add the file to the repository. The maximum repository size is 25 MB.
3. To rename a file, select the box to the right of the file in the **Xmodem Files Repository** list, enter the new file name in the **New File Name** field, and click the **Rename File** button.
4. To delete a file, select the box to the right of the file in the **Xmodem Files Repository** list, and click the **Delete** button.
5. To send a file, select the box to the right of the file in the **Xmodem Files Repository** list, and complete the following fields:

Protocol	Select whether to use the Xmodem, Ymodem or Zmodem protocol. Xmodem is a very rudimentary protocol that sends files in 128 byte blocks, padding the resulting file if necessary. Ymodem and Zmodem expand upon Xmodem by including the file's name, size and time stamp as part of the protocol.
Device Port	Enter the device port number to send the file to. The device port that will be used must not be currently in use for any other purpose.
Transfer	Select whether to send the file as a binary file or an ASCII file.

6. Click the **Send File to Device Port** button. The send will be initiated, and the **Status** window can be opened to view the progress of the send. When the Xmodem protocol is used, the user will be prompted when to start the file receive with the message, "Give your local XMODEM receive command now."

Note: *Ymodem transfers may display a line at the end of a successful transfer such as, "Ymodem sectors/kbytes sent: 0/ 0k", however, the transfer is successful if "Transfer complete" is displayed and the bytes sent matches the size of the file.*

7. To receive a file, complete the following fields:

Protocol	Select whether to use the Xmodem, Ymodem or Zmodem protocol. Xmodem is a very rudimentary protocol that sends files in 128 byte blocks, padding the resulting file if necessary. Ymodem and Zmodem expand upon Xmodem by including the file's name, size and time stamp as part of the protocol.
Receive File Name	When Xmodem is used, enter the name to give the file that is received.
Device Port	Enter the device port number to receive the file from. The device port that will be used must not be currently in use for any other purpose.
Transfer	Select whether to receive the file as a binary file or an ASCII file.
Receive Overwrite	Select whether to overwrite files in the repository with the same name as the received file.

8. Click the **Receive File from Device Port** button. The receive will be initiated, and the **Status** window can be opened to view the progress of the receive. If a file with the same name already exists in the repository and Receive Overwrite is not enabled, the transfer will abort without overwriting the existing file.

Xmodem Commands

Go to [Xmodem Commands](#) to view CLI commands which correspond to the web page entries described above.

Host Lists

A host list is a prioritized list of SSH, Telnet, and TCP hosts available for establishing incoming modem connections or for the `connect direct` command on the CLI. The EMG unit cycles through the list until it successfully connects to one.

To add a host list:

1. Click the **Devices** tab and select the **Host Lists** option. The following page displays:

Figure 10-13 Devices > Host Lists

The screenshot shows the LANTRONIX EMG851000 web interface. The top navigation bar includes tabs for Network, Services, User Authentication, Devices, Maintenance, and Quick Setup. The 'Devices' tab is selected, and the 'Host Lists' option is chosen. The page displays a 'Host Lists' section with a table showing 'Id' and 'Name'. Below this, there are input fields for 'Host List Id', 'Host List Name', 'Retry Count', and 'Authentication'. There are also buttons for 'Clear Host List', 'Add Host List', and 'Edit Host List'. At the bottom, there are sections for 'Host Parameters' (Host, Protocol, Port, Escape Sequence) and a list of 'Hosts (in order of precedence)'.

2. Enter the following:

Note: To clear fields in the lower part of the page, click the **Clear Host List** button.

Host List Id	Displays after a host list is saved.
Host List Name	Enter a name for the host list.
Retry Count	Enter the number of times the EMG should attempt to retry connecting to the host list.
Authentication	Select to require authentication when the EMG unit connects to a host.

3. To add hosts, enter the following:

Host Parameters

Host	Name or IP address of the host.

Protocol	Protocol for connecting to the host (TCP, SSH, or Telnet).
Port	Port on the host to connect to.
Escape Sequence	The escape character used to get the attention of the SSH or Telnet client. It is optional, and if not specified, Telnet and SSH use their default escape character. For Telnet, the escape character is either a single character or a two-character sequence consisting of '^' followed by one character. If the second character is '?', the DEL character is selected. Otherwise, the second character is converted to a control character and used as the escape character. For SSH, the escape character is a single character. Note: When the Device Port Esc Sequence/ViewLog/PowerMenu Escape Sequence is configured, the following escape sequence precedent behavior can be expected: 1) Escape 2) PowerMenu 3) ViewLogs A clear/restart of the remaining escape events occurs when there is a match in any configured sequence. All the sequences should have unique sequence defined and user should avoid overlapping sequence strings. When detecting key sequences, after receiving the first character(s) of a sequence, the EMG will wait 3 or more seconds for the remaining characters, before timing out and sending all characters to the device. For example, if the Escape Sequence is ABCD, and the user types "AB", the EMG will wait at least 3 seconds for the next character ("C") before timing out and sending the "AB" characters to the device.

4. Click the right  arrow to add the host. The host displays in the Hosts box.
5. Repeat steps 3-4 to add more hosts to the host list.
6. Click the **Clear Host Parameters** button to clear fields before adding the next host.
7. You have the following options:
 - To remove a host from the host list, select the host in the Hosts box and click the left  arrow.
 - To give the host a higher precedence, select the host in the Hosts box and click the up  arrow.
 - To give the host a lower precedence, select the host in the Hosts box and click the down  arrow.
8. Click the **Add Host List** button. After the process completes, a confirmation message is displayed on the page.

To view or update a host list:

1. In the Host Lists table, select the host list and click the **View Host List** button. The list of hosts display in the Hosts box.

Figure 10-14 Devices >View Host Lists

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

Host Lists Help?

Host Lists	
Id	Name
1	test

[View Host List](#) [Delete Host List](#)

Host List Id: **1** [Clear Host List](#)

Host List Name: [Add Host List](#)

Retry Count: [Edit Host List](#)

Authentication: ☐

Host Parameters

Host: [Clear Host Parameters](#)

Protocol: [→](#)

Port: [←](#)

Escape Sequence:

Hosts (in order of precedence)

172.19.100.17;tcp/389;

[↑](#) [↓](#)

2. View or update the following:

Host List Id	View only. Displays after a host list is saved.
Host List Name	Enter a name for the host list.
Retry Count	Enter the number of times the EMG should attempt to retry connecting to the host list.
Authentication	Select to require authentication when the EMG unit connects to a host.

3. View, add, or update the host parameters:

Host	Name or IP address of the host.
Protocol	Protocol for connecting to the host (TCP, SSH, or Telnet).
Port	Port on the host to connect to EMG

Escape Sequence	The escape character used to get the attention of the SSH or Telnet client. It is optional, and if not specified, Telnet and SSH use their default escape character. For Telnet, the escape character is either a single character or a two-character sequence consisting of '^' followed by one character. If the second character is '?', the DEL character is selected. Otherwise, the second character is converted to a control character and used as the escape character. For SSH, the escape character is a single character.

4. You have the following options:
 - To add a host to the host list, click the right  arrow. The host displays in the Hosts box.
 - To remove a host from the host list, select the host in the Hosts box and click the left  arrow.
 - To give the host a higher precedence, select the host in the Hosts box and click the up  arrow.
 - To give the host a lower precedence, select the host in the Hosts box and click the down  arrow.
5. Click the **Edit Host List** button. After the process completes, a confirmation message is displayed on the page.

To delete a host list:

1. Select the host list in the Host Lists table.
2. Click the **Delete Host List** button. After the process completes, a confirmation message is displayed on the page.

Host List Commands

Go to [Host List Commands](#) to view CLI commands which correspond to the web page entries described above.

Sites

A site is a group of site-oriented modem parameters (or modem profile) that can be activated by various modem-related events (authentication on dial-in, outbound network traffic for a dial-on-demand connection, etc.). The site parameters will override parameters that are configured for a modem.

To use sites with a modem, create one or more sites (described below), then enable Use Sites for the modem. Sites can be used with the following modem states: dial-in, dial-back, CBCP Server, dial-on-demand, dial-in & dial-on-demand, and dial-back & dial-on-demand. For more information on how sites are used with each modem state, see [Modem Dialing States](#).

To add a site:

1. Click the **Devices** tab and select the **Sites** option. The Sites page displays:

Figure 10-15 Devices > Sites

The screenshot shows the LANTRONIX EMG851000 web interface. At the top, there's a header with the LANTRONIX logo and 'EMG851000'. Below it, a navigation bar contains tabs: Network, Services, User Authentication, **Devices**, Maintenance, and Quick Setup. The 'Devices' tab is active, and the 'Sites' option is selected. The Sites page displays a table with columns 'Id' and 'Name'. To the right of the table are buttons for 'View Site' and 'Delete Site'. Below the table, there are configuration fields for a new site. The 'Site Id' is set to 0. The 'Site Name' field is empty. The 'Port' section has radio buttons for 'None', 'Internal Modem', 'Device Port', and 'USB Port U1'. The 'Login/CHAP Host' field is empty. The 'CHAP Secret' and 'Retype' fields are empty. The 'Authentication' section has radio buttons for 'PAP' and 'CHAP'. The 'Timeout Logins' section has radio buttons for 'No' and 'Yes', with a 'minutes' field. The 'Negotiate IP Address' section has radio buttons for 'Yes' and 'No', with 'Local IP' and 'Remote IP' fields. The 'Static Route' section has fields for 'Static Route IP Address', 'Static Route Subnet Mask', and 'Static Route Gateway'. The 'Dial-out' section has fields for 'Dial-out Number', 'Dial-out Login', 'Dial-out Password', and 'Retype Password'. The 'Dial-back' section has fields for 'Dial-back Number', 'Allow Dial-back', 'Dial-back Delay' (15 seconds), 'Dial-back Retries' (3), 'Modem Timeout' (No/Yes), and 'Restart Delay' (30 seconds). The 'CBCP Server' section has radio buttons for 'CBCP Server', 'Allow No Callback', and 'Enable NAT'.

2. In the lower section of the page, enter the following:

Note: To clear fields in the lower part of the page, click the **Reset Site** button.

Site Id (view only)	Displays after a site is created.
Site Name	Enter a name for the site.
Port	Select the port: None , Internal Modem , Device Port , or USB Port U1 the site is assigned to. For dial-on-demand sites, a port must be selected. For any other sites, the port selection can be set to None . See Modem Dialing States .
Login/CHAP Host	The login name (for PAP authentication) or CHAP host (for CHAP authentication) associated with this site. If a modem has sites enabled and the authentication is successful at dial-in (for modem states dial-in, dial-back, CBCP server, dial-in & dial-on-demand, or dial-back & dial-on-demand), and the name that was authenticated matches the Login/CHAP Host, the site parameters will be used for the remainder of the modem connection.
CHAP Secret/Retype	The CHAP secret associated with this site. If a modem has sites enabled and CHAP authentication enabled, then at dial-in, if the remote server sends a name in the CHAP challenge response that matches the CHAP host of a site, the CHAP secret for the site will be used to authenticate the CHAP challenge response sent by the remote server.
Authentication	The type of authentication, PAP or CHAP , for which this site is applicable. On dial-in authentication, only sites with the authentication type that matches the authentication type configured for the modem will be used to try to find a matching site.
Timeout Logins	For text dial-in connections, the connection can time out after the connection is inactive for a specified number of minutes.
Negotiate IP Address	If the EMG and the remote server should negotiate the IP addresses for each side of the PPP connection, select Yes. Select No if the address of the EMG unit (Local IP) and remote server (Remote IP) need to be specified.
Static Route IP Address	The Static Route IP Address, Subnet Mask and Gateway must be configured for dial-on-demand sites. The EMG will automatically dial-out and establish a PPP connection when IP traffic destined for the network specified by the static route needs to be sent. Note: Static Routing must be enabled on the Network - Routing page for dial-on-demand connections.
Static Route Subnet Mask	The subnet mask for a dial-on-demand connection.
Static Route Gateway	The gateway for a dial-on-demand connection.
Dial-out Number	The dial-out number must be specified for dial-on-demand sites. This indicates the phone number to dial when the EMG unit needs to send IP traffic for a dial-on-demand connection.
Dial-out Login	User ID for authentication when dialing out to a remote system, or when a remote system requests authentication from the EMG unit when it dials in. May have up to 32 characters. This ID is used for authenticating the EMG during the dial-out portion of a dial-back (including CBCP server) and dial-on-demand.
Dial-out Password	Password for authentication when dialing out to a remote system, or if a remote system requests authentication from the EMG unit when it dials in. May have up to 64 characters
Re-type Password	Re-enter password for dialing out to a remote system. May have up to 64 characters.

Dial-back Number	The phone number to dial on callback for text or PPP dial-back connections. A site must successfully authenticate, have Allow Dial-back enabled and have a Dial-back Number defined in order for the site to be used for callback.
Allow Dial-back	If enabled, the site is allowed to be used for dial-back connections.
Dial-back Delay	For dial-back and CBCP Server, the number of seconds between the dial-in and dial-out portions of the dialing sequence.
Dial-back Retries	For dial-back and CBCP Server, the number of times the EMG unit will retry the dial-out portion of the dialing sequence if the first attempt to dial-out fails.
Modem Timeout	Timeout for dial-in and dial-on-demand PPP connections. Select Yes (default) for the EMG to terminate the connection if no traffic is received during the configured idle time. Enter a value of from 1 to 9999 seconds. The default is 30 seconds.
Restart Delay	The number of seconds after the modem timeout and before the EMG unit attempts another connection. The default is 30 seconds.
CBCP Server Allow No Callback	For a CBCP Server site, allows "No Callback" as an option in the CBCP handshake in addition to User-defined Number and Admin-defined Number.
Enable NAT	Select to enable Network Address Translation (NAT) for PPP connections. <i>Note: IP forwarding must be enabled on Network Port Settings for NAT to work.</i>

3. Click the **Add Site** button.

To view or update a site:

1. In the **Sites** table, select the site and click the **View Site** button. The site attributes are displayed in the bottom half of the page.
2. Update any of the site attributes.
3. Click the **Edit Site** button.

To delete a site:

1. Select the site in the Sites table.
2. Click the Delete Site button.

Site Commands

Go to [Site Commands](#) to view CLI commands which correspond to the web page entries described above.

Access Lists

An access list, also known as a white list, is a list of phone numbers that will be granted access during the modem dial-in process. An access list can contain up to 100 phone numbers. This feature requires the Caller ID service be enabled for the phone line by the TelCo provider, and modem **Caller ID Logging** is enabled with a directive to enable caller ID for the modem in the Caller ID Logging **Modem Command**. This directive is usually **AT+VCID=1** (refer to the AT command set for your modem).

The access list can be configured with two options for responding to a phone number that is not in the access list: hang up the call or ignore the call. If the access list is configured for ignore, the console manager dialing process will wait until the other side of the call hangs up (if the other side

never hangs up, this can result in dial-in access to the console manager being blocked until the administrator resolves this issue).

A maximum of 20 access lists can be created.

To use an access list with a modem, create one or more access lists (described below), then assign the access list to the console manager internal modem or an external USB modem.

To add an access list:

1. Click the Devices tab and select the **Access Lists** option. The Access Lists page displays.

LANTRONIX® EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Status Device Ports Console Port USB/SD Card DIO Ports RPM Connections Xmodem Host Lists Scripts Sites Access Lists

Access Lists Help ?

Access Lists	
Id	Name
Total Access List(s): 0	

[View Access List](#) [Delete Access List](#)

A list of allowed phone numbers can be used to control dial-in access to an internal modem or USB modem.

Access List Id: 0 [Clear Access List](#)

Access List Name: [Add Access List](#)

Response: [Edit Access List](#)

Phone Number: [Clear Phone Number](#)

[Allowed Phone Numbers](#)

2. In the lower section of the page, enter the following:

Note: To clear fields in the lower part of the page, click **Clear Access List**.

Access List Id (view only)	Displays after an access list is created.
Access List Name	Enter a name for the access list. Valid characters are letters, numbers, hyphen and underscore. The maximum length is 40 characters.
Response	The response to phone numbers that dial-in and are not on the access list: Hang Up or Ignore . If the access list is configured for ignore, the console manager dialing process will wait until the other side of the call hangs up (if the other side never hangs up, this can result in dial-in access to the console manager being blocked until the administrator resolves this issue).

Allowed Phone Numbers	The list of phone numbers that are allowed to dial into a modem. Each access list must contain at least one phone number, and can have up to a maximum of 100 numbers. Enter numbers in the Phone Number field and click the right arrow to add numbers to the list. Click numbers in the list and use the left arrow to remove numbers from the list. The Clear Phone Number field will clear the contents of the Phone Number field.

3. Click the **Add Access List** button.

To view or update an access list:

1. In the Access Lists table, select the access list and click the **View Access List** button. The access list attributes are displayed in the bottom half of the page.
2. Update any of the access list attributes.
3. Click the **Edit Access List** button.

To delete an access list:

1. Select the access list in the Access Lists table.
2. Click the **Delete Access List** button.

Access List Commands

Go to [Access List Commands](#) to view CLI commands which correspond to the web page entries described above.

Modem Dialing States

This section describes how each modem state that supports sites operates when sites are enabled.

Dial In

The EMG waits for a peer to call the EMG unit to establish a text (command line) or PPP connection.

- ◆ For text connections, the user will be prompted for a login and password, and will be authenticated via the currently enabled authentication methods (Local Users, NIS, LDAP, etc). The site list will be searched for a site that (a) the **Login/CHAP Host** matches the name that was authenticated, (b) **Authentication** is set to **PAP**, and (c) the **Port** is set to **None** or matches the port the modem is on.
If a matching site is found, the **Timeout Logins** parameter configured for the site will be used for the rest of the dial-in connection instead of the **Timeout Logins** parameter configured for the modem. Once authenticated, a CLI session will be initiated, and the user will remain connected to the EMG until they either logout of the CLI session, or (if **Timeout Logins** is enabled) the CLI session is terminated if it has been idle.
- ◆ For PPP connections, the user will be authenticated via PAP or CHAP (determined by the **Authentication** setting for the modem). For PAP, the Local/Remote User list will be used to

authenticate the login and password sent by the PPP peer, and the site list will be searched for a site that (a) the **Login/CHAP Host** matches the name that was authenticated, (b) **Authentication** is set to PAP, and (c) the **Port** is set to **None** or matches the port the modem is on. For CHAP, the site list will be searched for a site that (a) the **Login/CHAP Host** and **CHAP Secret** match the name and secret sent in the CHAP Challenge response by the PPP peer, (b) **Authentication** is set to CHAP, and (c) the **Port** is set to **None** or matches the port the modem is on. If the remote peer requests PAP or CHAP authentication from the EMG unit, the **Remote/Dial-out Login** and **Remote/Dial-out Password** configured for the modem (not the site) will be provided as authentication tokens.

If a matching site is found, its **Negotiate IP Address**, **NAT**, and **Modem Timeout** parameters will be used for the rest of the dial-in connection instead of the parameters configured for the modem. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the **Negotiate IP Address** setting). The PPP connection will stay active until no IP traffic is sent for **Modem Timeout** seconds.

Dial-back

The EMG waits for a peer to call the EMG unit, establishes a text (command line) or PPP connection, authenticates the user, and if the EMG is able to determine a dial-back number to use, hangs up and calls the dial-back number to establish either a text or PPP connection.

- ◆ For text connections, the user will be prompted for a login and password, and will be authenticated via the currently enabled authentication methods (Local Users, NIS, LDAP, etc). The site list will be searched for a site that (a) the **Login/CHAP Host** matches the name that was authenticated, (b) **Authentication** is set to PAP, and (c) the **Port** is set to **None** or matches the port the modem is on.
If a matching site is found, its **Timeout Logins**, **Dial-back Number**, **Allow Dial-back**, and **Dial-back Delay** parameters will be used for the rest of the dial-back connection instead of the parameters configured for the modem. Once the remote server is authenticated, if **Allow Dial-back** is enabled for the site and a **Dial-back Number** is defined, the EMG unit will hang up and wait **Dial-back Delay** seconds before initiating the dial-back. The EMG will dial, prompt the user again for a login and password, and a CLI session will be initiated. The user will remain connected to the EMG unit until they either logout of the CLI session, or (if **Timeout Logins** is enabled) the CLI session is terminated if it has been idle.
- ◆ For PPP connections, the user will be authenticated via PAP or CHAP (determined by the **Authentication** setting for the modem). For PAP, the Local/Remote User list will be used to authenticate the login and password sent by the PPP peer, and the site list will be searched for a site that (a) the **Login/CHAP Host** matches the name that was authenticated, (b) **Authentication** is set to PAP, and (c) the **Port** is set to **None** or matches the port the modem is on. For CHAP, the site list will be searched for a site that (a) the **Login/CHAP Host** and **CHAP Secret** match the name and secret sent in the CHAP Challenge response by the PPP peer, (b) **Authentication** is set to CHAP, and (c) the **Port** is set to **None** or matches the port the modem is on. If the remote peer requests PAP or CHAP authentication from the EMG, the **Remote/Dial-out Login** and **Remote/Dial-out Password** configured for the modem (not the site) will be provided as authentication tokens.
If a matching site is found, its **Dial-back Number**, **Allow Dial-back**, **Dial-back Delay**, **Dial-out Login**, **Dial-out Password**, **Negotiate IP Address**, **NAT**, and **Modem Timeout** parameters will be used for the rest of the dial-back connection instead of the parameters configured for the modem. Once the remote server is authenticated, if **Allow Dial-back** is enabled for the site and a **Dial-back Number** is defined, the EMG unit will hang up and wait **Dial-back Delay** seconds before initiating the dial-back. The EMG will dial, and if the remote peer requests PAP or CHAP authentication, provide the **Dial-out Login** and **Dial-out Password** as authentication tokens. Once authenticated, a PPP session will be established

using either negotiated IP addresses or specific IP addresses (determined by the **Negotiate IP Address** setting).

Dial-on-demand

The EMG unit automatically dial outs and establishes a PPP connection when IP traffic destined for a remote network needs to be sent. It will remain connected until no data packets have been sent to the peer for a specified amount of time.

When this modem state is initiated, the EMG searches the site list for all sites that (a) have a **Dial-out Number** defined, (b) have a **Static Route IP Address**, **Static Route Subnet Mask** and **Static Route Gateway** defined, and (c) the **Port** matches the port the modem is on. A dial-on-demand connection will be started for each, waiting for IP traffic destined for a remote network.

When IP traffic needs to be sent, the EMG unit dials the appropriate **Dial-out Number** for the site, and if the remote peer requests PAP or CHAP authentication, provides the **Dial-out Login** and **Dial-out Password** as authentication tokens. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the **Negotiate IP Address** setting). The PPP connection will stay active until no IP traffic is sent for **Modem Timeout** seconds. Once the timeout has expired, the PPP connection will be terminated and will not be reestablished for at least **Restart Delay** seconds.

Dial-in & Dial-on-demand

A modem is configured to be in two modes: answering incoming calls to establish a PPP connection, and automatically dialing out to establish a PPP connection when IP traffic destined for a remote network needs to be sent. When either event occurs (an incoming call or IP traffic destined for the remote network), the other mode will be disabled.

- ◆ For Dial-in, the user will be authenticated via PAP or CHAP (determined by the **Authentication** setting for the modem). For PAP, the Local/Remote User list will be used to authenticate the login and password sent by the PPP peer, and the site list will be searched for a site that (a) the **Login/CHAP Host** matches the name that was authenticated, (b) **Authentication** is set to PAP, and (c) the **Port** is set to **None** or matches the port the modem is on. For CHAP, the site list will be searched for a site that (a) the **Login/CHAP Host** and **CHAP Secret** match the name and secret sent in the CHAP Challenge response by the PPP peer, (b) **Authentication** is set to CHAP, and (c) the **Port** is set to **None** or matches the port the modem is on. If the remote peer requests PAP or CHAP authentication from the EMG, the **Remote/Dial-out Login** and **Remote/Dial-out Password** configured for the modem (not the site) will be provided as authentication tokens.
If a matching site is found, its **Negotiate IP Address**, **NAT**, and **Modem Timeout** parameters will be used for the rest of the dial-in connection instead of the parameters configured for the modem. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the **Negotiate IP Address** setting). The PPP connection will stay active until no IP traffic is sent for **Modem Timeout** seconds.
- ◆ For Dial-on-Demand, the EMG unit searches the site list for all sites that (a) have a **Dial-out Number** defined, (b) have a **Static Route IP Address**, **Static Route Subnet Mask** and **Static Route Gateway** defined, and (c) the **Port** matches the port the modem is on. A dial-on-demand connection will be started for each, waiting for IP traffic destined for a remote network. When IP traffic needs to be sent, the EMG dials the appropriate **Dial-out Number** for the site, and if the remote peer requests PAP or CHAP authentication, provides the **Dial-out Login** and **Dial-out Password** as authentication tokens. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the **Negotiate IP Address** setting). The PPP connection will stay active until no IP traffic is sent for **Modem Timeout** seconds. Once the timeout has expired, the PPP connection will be terminated and will not be reestablished for at least **Restart Delay** seconds.

Dial-back & Dial-on-demand

A modem is configured to be in two modes: answering incoming calls to initiate a dial-back, and automatically dialing out to establish a PPP connection when IP traffic destined for a remote network needs to be sent. When either event occurs (an incoming call or IP traffic destined for the remote network), the other mode will be disabled.

- ◆ For Dial-back, the user will be authenticated via PAP or CHAP (determined by the **Authentication** setting for the modem). For PAP, the Local/Remote User list will be used to authenticate the login and password sent by the PPP peer, and the site list will be searched for a site that (a) the **Login/CHAP Host** matches the name that was authenticated, (b) **Authentication** is set to PAP, and (c) the **Port** is set to **None** or matches the port the modem is on. For CHAP, the site list will be searched for a site that (a) the **Login/CHAP Host** and **CHAP Secret** match the name and secret sent in the CHAP Challenge response by the PPP peer, (b) **Authentication** is set to CHAP, and (c) the **Port** is set to **None** or matches the port the modem is on. If the remote peer requests PAP or CHAP authentication from the EMG unit, the **Remote/Dial-out Login** and **Remote/Dial-out Password** configured for the modem (not the site) will be provided as authentication tokens. If a matching site is found, its **Dial-back Number**, **Allow Dial-back**, **Dial-back Delay**, **Dial-out Login**, **Dial-out Password**, **Negotiate IP Address**, **NAT**, and **Modem Timeout** parameters will be used for the rest of the dial-back connection instead of the parameters configured for the modem. Once the remote server is authenticated, if **Allow Dial-back** is enabled for the site and a **Dial-back Number** is defined, the EMG will hang up and wait **Dial-back Delay** seconds before initiating the dial-back. The EMG unit will dial, and if the remote peer requests PAP or CHAP authentication, provide the **Dial-out Login** and **Dial-out Password** as authentication tokens. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the **Negotiate IP Address** setting).
- ◆ For Dial-on-Demand, the EMG searches the site list for all sites that (a) have a **Dial-out Number** defined, (b) have a **Static Route IP Address**, **Static Route Subnet Mask** and **Static Route Gateway** defined, and (c) the **Port** matches the port the modem is on. A dial-on-demand connection will be started for each, waiting for IP traffic destined for a remote network. When IP traffic needs to be sent, the EMG unit dials the appropriate **Dial-out Number** for the site, and if the remote peer requests PAP or CHAP authentication, provides the **Dial-out Login** and **Dial-out Password** as authentication tokens. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the **Negotiate IP Address** setting). The PPP connection will stay active until no IP traffic is sent for **Modem Timeout** seconds. Once the timeout has expired, the PPP connection will be terminated and will not be reestablished for at least **Restart Delay** seconds.

CBCP Server and CBCP Client

Callback Control Protocol (CBCP) is a PPP option that negotiates the use of callback where the server, after authenticating the client, terminates the connection and calls the client back at a phone number that is determined by the CBCP handshake. For more information on CBCP, see <http://technet.microsoft.com/en-us/library/cc957979.aspx>. CBCP is used primarily by Microsoft PPP peers. CBCP supports two options for determining the number to dial on callback: the client can specify a user-defined number for the server to dial on callback, or the client can request the server use an administrator-defined number to dial on callback. Optionally, some servers may also allow "no callback" as an option.

CBCP Server

The EMG waits for a client to call the EMG unit, establishes a PPP connection, authenticates the user, and negotiates a dial-back number with the client using CBCP. If the EMG is able to determine a dial-back number to use, it hangs up and calls the dial-back number.

When a call is received, a PPP connection is established, and the user will be authenticated via PAP or CHAP (configured with the **Authentication** setting). For PAP, the Local/Remote list will be used to authenticate the login and password sent by the PPP peer. For CHAP, the **CHAP Handshake Host/User Name** and **Secret/User Password** will be used to authenticate CHAP Challenge response sent by the PPP peer. If the remote peer requests PAP or CHAP authentication from the EMG unit, the **Remote/Dial-out Login** and **Remote/Dial-out Password** will be provided as authentication tokens. Once authenticated, the CBCP handshake with the client determines the number to use for dial-back. The EMG unit will present the client with the available options: if the authenticated user is a Local/Remote User with **Allow Dial-back** enabled and a Dial-back Number defined, the administrator-defined option is allowed; if this is not the case, the user-defined number is allowed. Additionally, if **CBCP Server Allow No Callback** is enabled, the client can also select no callback (the PPP connection established at dial-in will remain up). The client will select from the available callback options. If the EMG unit can determine a dial-back number to use, it will hang up and wait **Dial-back Delay** seconds before initiating the dial-back (if the dial-back fails, the EMG will try **Dial-back Retries** times to dial-back). The EMG unit will call back the previously authenticated remote peer, and if the remote peer requests PAP or CHAP authentication, provide the **Remote/Dial-out Login** and **Remote/Dial-out Password** as authentication tokens. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the **Negotiate IP Address** setting).

CBCP Client

The EMG unit will dial out to a CBCP server, establish a PPP connection, negotiate a callback number with the server using CBCP, terminate the connection, and wait for the server to call back. The EMG unit dials the **Dial-out Number**, and if the remote peer requests PAP or CHAP authentication, provides the **Remote/Dial-out Login** and **Remote/Dial-out Password** as authentication tokens. Once authenticated, the CBCP handshake with the server determines the number to use for dial-back. The EMG device will request the type of number defined by **CBCP Client Type** - either an Admin-defined Number (the CBCP server determines the number to call) or a User-defined Number (the EMG unit will provide the **Fixed Dial-back Number** as the number to call). If the CBCP handshake is successful, the EMG unit will terminate the PPP connection, hang up, and wait for the server to dial back. When the remote server calls back the EMG unit and the PPP connection is established, the user will be authenticated via PAP or CHAP (configured with the **Authentication** setting). For PAP, the Local/Remote list will be used to authenticate the login and password sent by the PPP peer. For CHAP, the **CHAP Handshake Host/User Name** and **Secret/User Password** will be used to authenticate CHAP Challenge response sent by the PPP peer. Once authenticated, a PPP session will be established using either negotiated IP addresses or specific IP addresses (determined by the **Negotiate IP Address** setting).

Notes:

- ◆ *In a state where the modem will be answering a call, the modem should always be configured for manual answer, not auto answer.*
- ◆ *When answering a call, the EMG unit answers after the 2nd ring.*
- ◆ *Any text or PPP connection can be terminated by setting the modem state to disabled.*

Key Sequences

The default values for the various key sequences (Escape Sequence, Break Sequence, View Port Log Sequence, Power Menu Sequence) are set to different key sequences, and it is recommended that they always be set to different key sequences so that the EMG can properly handle each of the functions accessed by the key sequence while connected to a device.

For example, if the View Port Log Sequence is set to the same sequence as the Power Menu Sequence, and this sequence is typed while connected to a device port, both the Power Menu and the option to display Port Log will be displayed, with the Power Menu taking precedence and processing user input.

If any of the key sequences are set to the same value, the precedence used to process the key sequences is:

- ◆ Escape Sequence
- ◆ Power Management Sequence
- ◆ View Port Log Sequence

It is also recommended that the key sequences not share a significant amount of overlap other than the first character. For example, if the View Port Log Sequence is set to **ABCD** and the Power Management Sequence is set to **ABCE**, the first three characters of both sequences are the same - this is not recommended.

When any portion of key sequences overlap, typing a complete escape sequence for one of the sequences will reset recognition of the other sequences back to the beginning of the key sequence. For example, with the default View Port Log sequence of **ESC-V** and the default Power Management sequence of **ESC-P**, if the user types "ESC-V" and views the port log and then returns to interacting with the device, they need to type "ESC-P" to view the Power Menu, and not just "P".

When detecting key sequences, after receiving the first character(s) of a sequence, the EMG will wait 3 or more seconds for the remaining characters, before timing out and sending all characters to the device. For example, if the Escape Sequence is **ABCD**, and the user types "AB", the EMG will wait at least 3 seconds for the next character ("C") before timing out and sending the "AB" characters to the device.

11: Power Management

Integrated PDU Management

The console manager supports a single integrated external PDU to manage power for devices that may (or may not be) connected to the console manager via a serial port. This feature allows the administrator to view outlet status, turn outlets on or off, reboot outlets, view outlet current, set outlet wake (power on) state, and view PDU status. Multiple integrated external PDUs are not supported.

Integrated PDUs are connected to the console manager via a Device Port or USB Port (U1 or U2). Supported integrated PDUs:

- ◆ Synaccess [SP-1004A Switched Pro+ ATS PDU](#)
- ◆ Synaccess [SP-1004B Single Phase Switched ATS PDU](#)
- ◆ APC [APC7900B NetShelter Rack PDU Switched 1U](#)
(Note: in rare cases controlling the APC PDU may require resetting the PDU to synchronize with the APC PDU state; when this is required the message "cannot login to the PDU; try again after one minute." is displayed.)

To setup a PDU for management via the console manager:

1. Connect the console port of the PDU to the desired serial port (front USB, USB device port or RJ45 device port) on the console manager.
2. On the console manager, configure the serial port settings to be compatible with the serial settings for the PDU console port. Use the CLI command **connect direct** to verify that the serial connection is correctly configured. See **PDU Port** below for more details.
3. In the Power Outlets settings, select the appropriate **PDU Model**, configure the **PDU Port** selected in step 2, and enter the PDU login credentials with **PDU Login** and **PDU Password**.
4. CLI **show power** or the web UI **Power Outlets** page should now display the status of the PDU outlets. Note that there will be a delay displaying the page while the PDU is queried.

At boot, the console manager will configure the on/off state and wakeup mode for each outlet on the PDU to match what is configured in the console manager Power Outlets configuration.

To manage an integrated PDU:

1. Click **Devices > Outlets** option (it may take a few moments for the console manager to query the PDU for status).

2. The following page displays:


EMG851300



[Logout](#)
Host: **emgfcf0**
User: **sysadmin**

Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

[Network](#)
[Services](#)
[User Authentication](#)
[Devices](#)
[Maintenance](#)
[Quick Setup](#)

[Status](#)
[Device Ports](#)
[Console Port](#)
[USB/SD Card](#)
[DIO](#)
[RPM](#)
[Outlets](#)
[Connections](#)
[Xmodem](#)
[Host Lists](#)
[Scripts](#)
[Sites](#)
[Access Lists](#)

Power Outlets

[Help ?](#)

PDU Model: ☒ None ☐ SP-1004A ☐ SP-1004B ☐ APC7900B
PDU Port: **USB Port U1**
PDU Login:
PDU Password:
Retype Password:
Current Level for all Outlets: **Unknown (PDU Model set to None)**

Outlet: P1	Status: Unknown Name: PowerOutlet-1 Description: Power Outlet 1 Current: Unknown	Power State: ☐ On ☒ Off Wakeup Mode: ☐ On ☒ Off ☐ Last State Reboot: ☐
Outlet: P2	Status: Unknown Name: PowerOutlet-2 Description: Power Outlet 2 Current: Unknown	Power State: ☐ On ☒ Off Wakeup Mode: ☐ On ☒ Off ☐ Last State Reboot: ☐
Outlet: P3	Status: Unknown Name: PowerOutlet-3 Description: Power Outlet 3 Current: Unknown	Power State: ☐ On ☒ Off Wakeup Mode: ☐ On ☒ Off ☐ Last State Reboot: ☐
Outlet: P4	Status: Unknown Name: PowerOutlet-4 Description: Power Outlet 4 Current: Unknown	Power State: ☐ On ☒ Off Wakeup Mode: ☐ On ☒ Off ☐ Last State Reboot: ☐
Outlet: P5	Status: Unknown Name: PowerOutlet-5 Description: Power Outlet 5 Current: Unknown	Power State: ☐ On ☒ Off Wakeup Mode: ☐ On ☒ Off ☐ Last State Reboot: ☐
Outlet: P6	Status: Unknown Name: PowerOutlet-6 Description: Power Outlet 6 Current: Unknown	Power State: ☐ On ☒ Off Wakeup Mode: ☐ On ☒ Off ☐ Last State Reboot: ☐
Outlet: P7	Status: Unknown Name: PowerOutlet-7 Description: Power Outlet 7 Current: Unknown	Power State: ☐ On ☒ Off Wakeup Mode: ☐ On ☒ Off ☐ Last State Reboot: ☐
Outlet: P8	Status: Unknown Name: PowerOutlet-8 Description: Power Outlet 8 Current: Unknown	Power State: ☐ On ☒ Off Wakeup Mode: ☐ On ☒ Off ☐ Last State Reboot: ☐

3. Configure the following fields:

PDU Model	Select the model of the integrated PDU. The console manager will automatically determine what PDU features are available to the administrator based on the selected model. Supported models are SP-1004A , SP-1004B and APC7900B .
PDU Port	Select the RJ45 or USB Device Port or USB Port (U1, or U2 on console managers that have 2 USB ports) which is connected to the console port of the PDU. The default value is USB Port U1. It is recommended that the serial settings for the PDU Port be configured with the correct serial settings for the PDU console port. For Synaccess PDUs, the default USB console port and RJ45 Port A settings are Baud Rate: 115200, Data Bits: 8, Stop Bits: 1, Parity: None, Hardware Handshaking: None. For APC PDU, the default USB console port and RJ45 Port A settings are Baud Rate: 9600, Data Bits: 8, Stop Bits: 1, Parity: None, Hardware Handshaking: None (RJ45 Port A must be placed in COM mode before it can be used for PDU management via the console manager). In order to control or monitor a PDU, a user must have rights and permissions to access the configured USB or serial PDU port. For example, for USB Port U1, a user must have USB user permissions as well as U1 data ports rights.
PDU Login	The user login that will be used to access the PDU CLI for commands and status. There is no default value; however if the PDU Login is not defined when the PDU Model is changed from None to a supported model, the default administrator username for the selected model will be auto-filled in for the PDU Login. The maximum length is 32 characters and valid characters are letters, numbers, !, @, #, \$, % and ^. For Synaccess PDUs, the default username is admin. For APC PDU, the default username is apc.
PDU Password	The user password that will be used to access the PDU CLI for commands and status. There is no default value; however if the PDU Password is not defined when the PDU Model is changed from None to a supported model, the default administrator password for the selected model will be auto-filled in for the PDU Password. The maximum length is 64 characters and valid characters are letters, numbers, !, @, #, \$, % and ^. For Synaccess PDUs, the default password for the admin username is admin. For APC PDU, the default password for the apc username is apc.
Current Level for All Outlets	The total load carried by the outlets in Amps. If the PDU Model is set to None , this will be blank. If there is an issue communicating with the PDU due to incorrect serial settings or login credentials, this will be displayed as Unknown along with an error message.

4. For each outlet, configure:

Outlet	Displays the number of the outlet being configured.
Status	Displays the current state of the outlet as reported by the integrated PDU. If there is an issue communicating with the PDU due to incorrect serial settings or login credentials, this will be displayed as Unknown .
Name	User-configurable name identifying the outlet. If the PDU supports configuring a name for each outlet, this value will be pushed to the PDU configuration. The outlet name can be up to 20 characters long and may contain alphanumeric characters, hyphen "-", period ".", or underscore "_" (this name length and character set may be more restrictive than what is supported on the integrated PDU).
Description	User-configurable text describing the outlet. The description can be up to 50 characters long and can contain any characters.

Current (some models)	Displays the load, in Amps, for the outlet as reported by the integrated PDU. If there is an issue communicating with the PDU due to incorrect serial settings or login credentials, this will be displayed as Unknown . If per-outlet current status is not available for the selected PDU model, this field will show N/A. For Synaccess PDUs, only the SP-1004A supports per-outlet current status, and APC7900B PDU does not support per-outlet current status.
Power State	Select whether the power should be on or off. Note that a Power State change and Reboot cannot be performed at the same time. If the PDU Model is changed from None to a supported model, the default Power State will be set to reflect the default state for the selected model. For Synaccess PDUs, the factory default setting for outlets is On. For APC7900B PDU, the factory default setting for outlets is On. If a PDU is connected to the console manager which is not in a factory default state, it may take multiple changes to outlet power states to synchronize the console manager configuration with the PDU configuration.
Wakeup Mode	Select whether, after a reboot, the power state for the outlet should be on, off, or returned to the state it was in before the reboot. For APC7900B PDU, the wakeup mode setting for outlet is not supported.
Reboot	To power cycle the outlet, select the checkbox. Note that a Power State change and Reboot cannot be performed at the same time. On outlet reboot APC7900B PDU makes the outlet's power state to On.

5. To save, click **Apply**.

Power Commands

Go to [Power Commands](#) to view CLI commands which correspond to the web page entries described above.

Remote Power Managers

The EMG supports managing remote power managers (RPMs) for devices from over 140 vendors. The RPM can be either a power distribution unit (PDU) or uninterruptible power source/supply (UPS), and can be managed via SNMP, serial port, network and USB connections. The RPMs web page displays a list of all currently managed RPMs with an overview of their current status, with options to control and view detailed status for each RPM, depending on its supported capabilities.

Network and SNMP managed RPMs are disabled in FIPS mode. The only action that can be performed on a network or SNMP managed RPM in FIPS mode is that it can be deleted via the CLI.

For notes on optimizing the management of specific devices, see [Optimizing and Troubleshooting RPM Behavior](#).

Devices - RPMs

To control or view status for an RPM:

1. Click the **Devices** tab and select the **RPMs** option. The RPMs page displays.

Figure 11-1 Devices > RPMs

LANTRONIX® EMG850100

Logout Host: emgfcfb5 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

RPMs

Refresh > Add Device > Shutdown Order > Notifications > Raw Data > Logs > Environmental > Manage Device > Outlets >

RPMs: 1 device(s) Beeper: Device:

Id	Name	Managed Via	Type	Outlet #, On	Input (V)	Power (VA)	Power (W)	Battery (%)	Load (%)	Beeper	Status
1	STech16Net23	Net-172.19.100.72:23	PDU	8, N/A	N/A	N/A	N/A	N/A	N/A	N/A	Query failed

- In the RPMs table, select the RPM by clicking on the radio button in the far right column.
The options that are available for that RPM will be displayed as active links above the RPMs table.
- Select one of the following options:

Refresh	Refreshes the information in the RPMs table.
Add Device	Displays the Devices > RPMs - Add Device page to add a new managed PDU or UPS.
Shutdown Order	Displays the order in which all UPS devices are shutdown in the event that a UPS reaches a low battery state. See Figure 11-2 . For more information, see RPM Shutdown Procedure .
Notifications	Displays the notifications configured for each PDU and UPS. See Figure 11-3 .
Raw Data	Displays a window with all of the information returned by the driver when a query for status is requested. This option is available for all RPMs. See Figure 11-4 .
Logs	Displays a window with any logging information that has been accumulated for the selected RPM, if logging is enabled for the RPM. This option is available for all RPMs. See Figure 11-5 .
Environmental	Displays a window with any environmental (humidity and temperature) information that may be available for the selected RPM, if sensors are installed for the RPM. This option is available for all RPMs. See Figure 11-6 .
Managed Device	Displays the RPMs - Manage Device page, with the complete status and configuration for the selected RPM. This option is available for all RPMs.
Outlets	Displays the RPMs - Outlets page for RPMs that support individual outlet control and status.
Beeper: Enable, Mute, Disable	If the RPM has a beeper than can be controlled, these options allow the administrator to Enable , Mute , or Disable the beeper. If you try to use Mute to silence a beeper and the beeper continues to sound, the UPS most likely does not support mute, and the Disable option will be the only way to silence the beeper.

Reboot	Reboots the RPM immediately, which may interrupt the power provided by the RPM while it is rebooting. Some PDUs and UPSes have a default delay that they will wait before initiating a reboot; this setting may be visible in the raw data (see above) as "ups.delay.reboot".
Shutdown	Shuts down the RPM immediately, which will interrupt the power provided by the RPM. Some PDUs and UPSes have a default delay that they will wait before initiating a shutdown; this setting may be visible in the raw data (see above) as "ups.delay.shutdown".
Delete	Deletes the selected RPM, after a confirmation.

Figure 11-2 RPM Shutdown Order




Figure 11-3 RPM Notifications




Figure 11-4 RPM Raw Data Log




Figure 11-5 RPM Logs





Figure 11-6 RPM Environmental Log



RPMs - Add Device

The **Add Device** page assists the administrator with adding a new managed RPM to the EMG configuration. With over 140 different vendors and nearly 1000 different models that are supported, the key to ensuring the EMG can properly manage a PDU or UPS is selecting the right model (with its associated driver) and any required driver options, especially for USB managed devices.

To add a new managed RPM :

1. Click the **Devices** tab and select the **RPMs** option. The RPMs page displays, as shown in [Figure 11-1](#).
2. On the [Devices > RPMs](#) page, click the **Add Device** link. [Figure 11-7](#) shows the RPMs - Add Device page.

Note: The [Devices > RPMs - Add Device](#) page with the same functionality can also be accessed through the [Device Ports > Settings \(1 of 2\)](#) page by selecting RPM in the Connected dropdown menu.

Figure 11-7 Devices > RPMs - Add Device

LANTRONIX[®] EMG850100

Logout Host: emgfc65 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

RPMs - Add Device Help?

Vendor: (U) - USB, (S) - Serial, (N) - Network, (P) - SNMP

Model:

Managed via: ☐ USB ☐ Serial ☐ Network ☐ SNMP

USB Device:

Name:

of Outlets:

IP Address:

Port: Enter "0" for a front USB port.

Driver Opts:

Login:

Password:

Retype Password:

Log Status: ☒ No ☐ Yes, minutes:

Critical SNMP Traps: ☐

Critical Emails:

Low Battery: ☒ Shutdown this UPS ☐ Shutdown all UPSes ☐ Allow battery failure ☐ Shutdown both EMG UPSes

Shutdown Order:

Provides EMG Power: ☐

3. Enter the following:

Vendor	Select the correct vendor from the drop-down menu.
Model	Select the Model in the drop-down menu. The drop-down menu will be populated with models supported for the selected vendor. To the left of each model name is one or two letters in parentheses that indicate the type of control available for the selected model: P - SNMP, S - serial port, U - USB port, N - network. Some of the model names in the list may be truncated because the list of models is very long - in this case, hover over the model name and the complete model name(s) will be displayed.
Managed via	If there is more than one way to manage the selected model, select the appropriate management method.
USB Device	For USB controlled devices, if the RPM is connected to a USB port, the device should be displayed in the USB Device dropdown. Select the correct device. This will automatically fill in the Port with the correct port number and the Driver Opts with the USB vendor and product ID (see below).
Name	Specify the unique name of the RPM (up to 20 characters).
# of Outlets	Specify the number of outlets on the RPM (maximum of 120 outlets).
IP Address	For SNMP and Network (Telnet) managed RPMs, specify the IP address of the RPM.
Port	For network (Telnet) managed RPMs, this is assumed to be port 23 (if left blank), or it can be filled in with an alternate TCP port. For USB managed RPMs, this is the front USB port ("0") or the device port that the RPM is connected to on the EMG (this may be automatically filled in when the USB Device is selected). For serially controlled RPMs, this is the device port that the RPM is connected to on the EMG.
Driver Opts	For the driver associated with the RPM device, these are extra options which may be required to make the driver work. The most frequent use of the driver options is for USB devices (the vendor and product ID may be required so that the EMG can find the correct device on the USB bus), or in the event that the default driver options do not work with the RPM. The vendor and product ID may be automatically filled in if a USB Device is selected. There may also be other driver options that are filled in by the EMG from an internal table - these will be automatically set and can be viewed after the RPM has been added, and can always be overridden by driver options set by the user. For a complete list of RPM models, drivers and driver options, refer to the Network UPS Tools Hardware Compatibility List . The format of the driver options setting is one or more comma-separated parameters-value pairs, e.g. <parameter name>=<value>.
Login	For Network and serially managed RPMs, this is the administrator login.
Password/Retype Password	For Network and serially managed RPMs, this is the administrator password.
Read Community	For SNMP managed RPMs, this is the SNMP read (get) community.
Write Community/Retype Write Comm	For SNMP managed RPMs, this is the SNMP write (set) community.
Log Status	Indicates if the status of the RPM is periodically logged and the interval in minutes. Select Yes and enter a value between 1 and 60 minutes. The logs can be viewed by viewing the Devices > RPMs page and clicking on "Logs".

Critical SNMP Traps	If enabled, under critical conditions (UPS goes onto battery power, UPS battery is low, UPS forced shutdown in progress, UPS on line power, UPS battery needs to be replaced, RPM is unavailable, communications with RPM lost, communications with RPM established), a <code>EMGEventRPMAction</code> trap will be sent to the NMS configured in the SNMP settings. This requires that SNMP traps be enabled.
Critical Emails	If an email address is specified, under critical conditions (see Critical SNMP Traps above), an email notification will be sent to the email address. The Server and Sender configured in the SSH settings will be used to send the email.
Low Battery	For UPS devices only. Indicates the behavior to take when the UPS reaches a low battery state. Options are to Shutdown this UPS - shutdown only the UPS that has reached a low battery state; Shutdown all UPSes - shutdown all UPSes managed by the EMG; Allow battery failure - allow the battery to completely fail, which may result in the unsafe shutdown of the devices it provides power to; Shutdown both EMG UPSes - shutdown both UPSes that provide power to the EMG, including the UPS with that has reached a low battery state (some EMGs have dual power supplies). For more information, see RPM Shutdown Procedure .
Shutdown Order	For UPS devices only. If any of the UPSes managed by the EMG reaches a low battery state AND is configured for Shutdown all UPSes for its Low Battery setting, this indicates the order in which this UPS will be shutdown. All UPSes with a shutdown order of "1" will be shutdown first, followed by all UPSes with a shutdown order of "2", etc. Shutdown orders are in the range of 1 to 49, with 50 being reserved for UPSes that provide power to the EMG - they will always be shutdown last (see Provides EMG Power below).
Provides EMG Power	For UPS devices only. Indicates if this UPS provides power to the EMG.

4. Click **Apply** to Save.

RPMs - Manage Device

The **Manage Device** page allows the administrator to modify the settings for a managed RPM.

To modify a managed RPM:

1. Click the **Devices** tab and select the **RPMs** option. [Figure 11-1 Devices > RPMs](#) shows the page which displays.
2. Select an RPM and click the **Manage Device** link. [Figure 11-8 RPMs - Manage Device](#) shows the page which displays.

Figure 11-8 RPMs - Manage Device

LANTRONIX® EMG850100

Logout Host: emgcb5 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

RPMs - Manage Device [Help?](#)

RPM Id: 1
 Name:
 Status:
 Vendor: **ServerTech**
 Model: **Sentry3, A1-8 (8 outlets)**
 # of Outlets:
 Outlets On: **N/A**
 F/W Version: **[none]**
 Serial Num: **[none]**
 MAC Address: **[none]**
 Apparent Power: **N/A**
 Nominal Apparent Power: **N/A**
 Real Power: **N/A**
 Nominal Real Power: **N/A**

Managed via: **Network**
 IP Address: Port:
 Driver Opts:
 Login:
 Password:
 Retype Password:
 Log Status: ☒ No ☐ Yes, minutes:
 Critical SNMP Traps: ☐
 Critical Emails:
 Low Battery: ☐ Shutdown this UPS
☐ Shutdown all UPSes
☐ Allow battery failure
☐ Shutdown both EMG UPSes
 Shutdown Order:
 Provides EMG Power: ☐

[Outlets >](#)

3. Enter the following:

RPM Id (view only)	The unique number associated with the RPM.
Name	Specify the unique name of the RPM (up to 20 characters).
Status (view only)	The current status of the RPM. Any error status will be shown here.
Vendor (view only)	The manufacturer of the RPM.
Model (view only)	The model of the RPM. The model is read from the device, if it is provided; not all RPMs provide a model string. If the device normally provides the device model and becomes unreachable, or does not provide a model string, the Model is derived from the supported model list strings.
# of Outlets	Specify the number of outlets on the RPM (maximum of 120 outlets).
Outlets On (view only)	The number of outlets that are currently turned on, if this information is provided by the RPM.
F/W Version (view only)	The firmware version of the RPM, if this information is provided by the RPM.
Serial Num (view only)	The serial number of the RPM, if this information is provided by the RPM.
MAC Address (view only)	The MAC address of the RPM, if this information is provided by the RPM.

Current (view only)	The total current value for the RPM in Amperes, if this information is provided by the RPM. If the RPM consists of two separate towers or units, each with its own current value, both current values will be displayed, separated by a slash.
Input Voltage (view only)	The input voltage for the RPM in Volts, if this information is provided by the RPM. If the RPM consists of two separate towers or units, each with its own input voltage value, both voltage values will be displayed, separated by a slash.
Apparent Power (view only)	The apparent power value for the RPM in Volt-Amperes, if this information is provided by the RPM. If the RPM consists of two separate towers or units, each with its own apparent power value, both power values will be displayed, separated by a slash.
Nominal Apparent Power (view only)	The nominal apparent power value for the RPM in Volt-Amperes, if this information is provided by the RPM. If the RPM consists of two separate towers or units, each with its own nominal apparent power value, both power values will be displayed, separated by a slash.
Real Power (view only)	The real power value for the RPM in Watts, if this information is provided by the RPM. If the RPM consists of two separate towers or units, each with its own real power value, both power values will be displayed, separated by a slash.
Battery Charge (view only)	For UPS devices only. Displays the current charge level for the battery, as a percentage.
Battery Runtime (view only)	For UPS devices only. Displays the amount of time remaining in the UPS battery life.
Beeper Status (view only)	For UPS devices only. Displays the current state of the UPS beeper.
Managed via (view only)	Displays the method used to control the RPM device (SNMP, Network, Serial Port, USB port).
IP Address	For SNMP and Network (Telnet) managed RPMs, specify the IP address of the RPM.
Port	For network (Telnet) managed RPMs, this is assumed to be port 23 (if left blank), or it can be filled in with an alternate TCP port. For USB managed RPMs, this is one of the front USB ports ("0") or the device port that the RPM is connected to on the EMG. For serially controlled RPMs, this is the device port that the RPM is connect to on the EMG.
Driver Opts	For the driver associated with the RPM device, these are extra options which may be required to make the driver work. The most frequent use of the driver options is for USB devices (the vendor and product ID may be required so that the EMG can find the correct device on the USB bus), or in the event that the default driver options do not work with the RPM. There may also be other driver options that are filled in by the EMG from an internal table - these will be automatically set and can be viewed after the RPM has been added, and can always be overridden by driver options set by the user. For a complete list of RPM models, drivers and driver options, refer to Network UPS Tools Hardware Compatibility List . The format of the driver options setting is one or more comma-separated parameters-value pairs, e.g. "<parameter name>=<value>".
Login	For Network and serially managed RPMs, this is the administrator login.
Password/Retype Password	For Network and serially managed RPMs, this is the administrator password.
Read Community	For SNMP managed RPMs, this is the SNMP read (get) community.
Write Community/Retype Write Comm	For SNMP managed RPMs, this is the SNMP write (set) community.

Log Status	Indicates if the status of the RPM is periodically logged. Select Yes, minutes to log the status periodically and enter a value between 1 and 60 minutes. The logs can be viewed by viewing the RPMs web page and clicking on "Logs".
Critical SNMP Traps	If enabled, under critical conditions (UPS goes onto battery power, UPS battery is low, UPS forced shutdown in progress, UPS on line power, UPS battery needs to be replaced, RPM is unavailable, communications with RPM lost, communications with RPM established), a slcEventRPMAction trap will be sent to the NMS configured in SNMP settings. This requires that SNMP traps be enabled.
Critical Emails	If an email address is specified, under critical conditions (see Critical SNMP Traps above), an email notification will be sent to the email address. The Server and Sender configured in the SSH settings will be used to send the email.
Low Battery	For UPS devices only. Indicates the behavior to take when the UPS reaches a low battery state. Options are to Shutdown this UPS - shutdown only the UPS that has reached a low battery state; Shutdown all UPSes - shutdown all UPSes managed by the EMG; Allow battery failure - allow the battery to completely fail, which may result in the unsafe shutdown of the devices it provides power to; Shutdown both EMG UPSes - shutdown both UPSes that provide power to the EMG, including the UPS with that has reached a low battery state (some EMGs have dual power supplies). For more information, see RPM Shutdown Procedure
Shutdown Order	For UPS devices only. If any of the UPSes managed by the EMG reaches a low battery state AND is configured for Shutdown all UPSes for its Low Battery setting, this indicates the order in which this UPS will be shutdown. All UPSes with a shutdown order of "1" will be shutdown first, followed by all UPSes with a shutdown order of "2", etc. Shutdown orders are in the range of 1 to 49, with 50 being reserved for UPSes that provide power to the EMG - they will always be shutdown last (see Provides EMG Power in the next field below).
Provides EMG Power	For UPS devices only. Indicates if this UPS provides power to the EMG.

3. To save, click **Apply**.

RPMs - Outlets

The **Outlets** page allows the administrator to view the current status of each individual outlet on an RPM, and change the state of the outlets. Not all RPMs support individual outlet status and control.

To control and view status for RPM outlets:

1. Click the **Devices** tab and select the **RPMs** option. [Figure 11-1 Devices > RPMs](#) shows the page which displays.
2. Select an RPM and click the **Outlets** link. [Figure 11-9 RPMs - Outlets](#) shows the page which displays. This page will, at a minimum, list the outlet numbers and their state - **On** or **Off**. If the RPM provides additional information for the outlets, the custom name and the current reading in Amperes will also be displayed for each outlet.

Figure 11-9 RPMs - Outlets

LANTRONIX® EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

RPMs - Outlets

Help?

Refresh >

RPM #3-STech16SNMP				Outlet:	Cycle Power	Turn On	Turn Off
Id	State	Description	Current (amps)				
1	on	Outlet1	0.00				
2	on	TowerA_Outlet2	0.00				
3	on	TowerA_Outlet3	0.00				
4	on	TowerA_Outlet4	0.00				
5	on	TowerA_Outlet5	0.00				
6	on	TowerA_Outlet6	0.00				

3. To change the state of one or more outlets, select the outlets, and click the **Cycle Power**, **Turn On** or **Turn Off** buttons. The command will be sent to the RPM and the page will refresh. It may take one or two minutes before the new outlet state(s) are reflected on the Outlets page.

RPM Shutdown Procedure

This section applies to UPS-type RPMs only, and does not apply to PDU-type RPMs. This section describes the shutdown process when a UPS managed by the EMG reaches a low battery state. When one UPS reaches a low battery state, the EMG can be configured to allow the UPS to

continue to run until its battery fails completely, to shutdown just the UPS with the low battery, or to shutdown one or more UPSes. UPS-type RPMs can report the following states:

- ◆ **OL** - On line power
- ◆ **OB** - On battery power
- ◆ **LB** - Low battery
- ◆ **HB** - High battery
- ◆ **RB** - The battery needs to be replaced
- ◆ **CHRG** - The battery is charging
- ◆ **DISCHRG** - The battery is discharging (inverter is providing load power)
- ◆ **BYPASS** - UPS bypass circuit is active - no battery protection available
- ◆ **CAL** - UPS is currently performing runtime calibration (on battery)
- ◆ **OFF** - UPS is offline and is not supplying power to the load
- ◆ **OVER** - UPS is overloaded
- ◆ **TRIM** - UPS is trimming incoming voltage
- ◆ **BOOST** - UPS is boosting incoming voltage
- ◆ **FSD** - UPS is in forced shutdown due to a critical condition

Once a UPS is on line power (status is **OL**) and goes off of line power and onto battery power (status is **OB**), it may reach a low battery state (status is **OB**, **LB** or **LB**). Switching from line power to battery power, and reaching a low battery state are critical states that can result in syslog, email and SNMP trap notifications. The exact point at which a UPS reaches a low battery state is device dependent and is related to the **battery.charge**, **battery.charge.low**, **battery.runtime** and **battery.runtime.low** settings which can be viewed in the "Raw Data" report.

Once a UPS reaches a low battery state, the **Shutdown Order**, **Low Battery Action** and **Provides EMG Power** settings determine which UPSes to shutdown, and in what order. The UPS with the low battery will be placed into **FSD** (Forced Shutdown) mode. The following actions will be performed based on the **Low Battery Action** setting for the UPS with the failed battery:

- ◆ **Allow Battery Failure** - The UPS battery will be allowed to run until it fails completely. If the UPS provides power to the EMG and the battery fails, the EMG will not be cleanly shutdown. In this scenario, the **Shutdown Order** setting will be ignored. The **Shutdown Order** setting may be used if another UPS reaches the low battery state (see **Shutdown all UPSes** below).
- ◆ **Shutdown This UPS** - If the UPS provides power to the EMG, the EMG will begin shutdown procedures, shutting down the UPS last. If the UPS does not provide power to the EMG, the UPS will be shutdown, but will continued to be monitored in case it comes back online.
- ◆ **Shutdown all UPSes** - The EMG will begin shutting down all UPSes with a non-zero **Shutdown Order**, shutting down UPSes with a shutdown order of "1" first, UPSes with a shutdown order of "2" second, etc. Any UPS which provides power to the EMG is always forced to have its **Shutdown Order** set to 50, which the highest (and last) Shutdown Order. If the UPS with the failed battery provides power to the EMG (and thus has a Shutdown Order set to 50), the EMG will also begin shutdown procedures, shutting down the failed UPS last. If none of the UPSes provide power to the EMG, after they are all shutdown their drivers will remaining running in case the UPS comes back online. In this case, any queries to an RPM while it is still offline may report "RPM driver data is stale". If the **Low Battery Action** for a UPS is set to **Allow Battery Failure**, but the UPS has a non-zero **Shutdown Order**, the UPS

will still be shutdown if another UPS reaches the low battery state and has its **Low Battery Action** set to **Shutdown all UPSes**.

- ◆ **Shutdown Both EMG UPSes** - This setting should only be used on dual-power EMG units which have each power supply connected to separate (different) UPS devices, and both UPS devices are being managed by the EMG. If a UPS is configured for **Shutdown Both EMG UPSes** but does not have **Provides EMG Power** enabled, this is an ambiguous configuration, and no shutdown action will occur.

For this configuration, when one of the UPSes providing power to the EMG reaches a low battery state, the event will be noted in the system log, and the EMG will continue to run with no further actions until the second UPS providing power to the EMG reaches a low battery state. At this point the EMG will begin shutdown procedures, shutting down both failed UPSes last.

Optimizing and Troubleshooting RPM Behavior

This section gives tips on how to optimize the management of specific PDUs and UPSes, and how to troubleshoot any problems with the EMG connecting to and managing an RPM.

- ◆ **Sentry3 - Network and Serially Managed PDUs** - Some Sentry3 PDUs have a CLI timeout, with a default setting of 5 minutes. This timeout may cause frequent query errors when requesting information from the Sentry3 PDU. It is recommended that the timeout be set as high as possible to reduce the frequency of the query errors.
- ◆ **Serially Managed RPMs with Administrator Logins** - Some serially managed devices will have an administrator login for the console port. It is recommended that any active sessions be logged out before adding the device as an RPM, otherwise the RPM may experience query errors.

If the EMG is unable to communicate with an RPM, or an RPM is displaying the error "driver is not running", the following steps can be used to troubleshoot the driver issues:

- ◆ **Correct Driver** - The CLI command `set rpm driver <RPM Id or Name> action show` can be used to display the current running driver for the RPM. Some serially and network managed RPMs do not have drivers; if this is the case for the RPM, the CLI command will indicate this. Otherwise it will display the driver that is running for the RPM, and it should match the driver listed for the device at [Network UPS Tools Hardware Compatibility List](#). If the wrong driver is shown, the RPM will need to be deleted and re-added, with the correct vendor and model selected. If no driver is shown, the driver may not be able to start for a variety of reasons; see remaining steps.
- ◆ **SNMP Settings** - For SNMP managed devices, verify the **IP Address**, **Read Community** and **Write Community** settings are correct.
- ◆ **Reverse Pinout Setting** - For serially managed devices, verify the **Reverse Pinout** setting (located in the [Device Ports - Settings](#) page) is set correctly.
- ◆ **VendorId and ProductId Driver Options** - For USB managed devices, verify the `vendorid` and `productid` shown in the RPM driver options are correct. These can be set automatically by the EMG from an internal table, set by the user by selecting a specific USB device when adding a USB-managed RPM, or changed by the user at any time. The CLI command `show usb devices` displays all connected USB devices with their port, Product ID and Vendor ID.
- ◆ **Extra Driver Options** - The driver documentation at [Network UPS Tools Hardware Compatibility List](#) may indicate that extra driver options are required for the RPM. Select the driver name link under the Driver column to see any special requirements for the UPS or PDU.

- ◆ **Driver Debug Mode** - The driver can be run in debug mode at the CLI and the output examined to determine why the driver is not starting or is unable to communicate with the RPM. The CLI command `set rpm driver <RPM Id or Name> action debug [level <1|2|3>]` will stop any currently running driver and restart the driver in debug mode with output sent to a local file. Running `set rpm driver <RPM Id or Name> action show` should show a driver running with one or more **-D** flags. The debug output can be examined or emailed with the `set rpm driver <RPM Id or Name> action viewoutput [email <Email Address>] [display <head|tail>] [numlines <Number or Lines>]` command. To return the driver to its normal non-debug state, run `set rpm driver <RPM Id or Name> action restart`. Note that drivers running in debug mode will generate copious output, and for disk space reasons should not be left running in debug mode for long periods of time (e.g. more than an hour).

RPM Commands

Go to [RPM Commands](#) to view CLI commands which correspond to the web page entries described above.

12: Scripts

This chapter describes how to use Scripts to automate tasks performed on the EMG CLI or on device ports. EMG supports the following types of scripts:

- ◆ **Interface Scripts** which use a subset of the Expect/Tcl scripting language to perform pattern detection and action generation on Device Port output.
- ◆ **Batch Scripts** which are a series of CLI commands.
- ◆ **Custom Scripts** are Expect, Tcl or Python scripts which use most of the Expect/Tcl/Python scripting language, can be run against the CLI or a Device Port, and can be [scheduled](#) to run at periodic intervals, with the results from each run saved to a file in a repository. Up to 10 Custom Scripts can be created. Each Custom Script run is an operation, and the [results](#) from each operation can be [viewed](#). Up to 50 script result files will be saved locally in the EMG storage. Once this maximum is reached and new result files are generated, the oldest result files will automatically be deleted to accommodate the new result files.

A user can create scripts at the web, view scripts at the web and the CLI, and utilize (run) scripts at the CLI. For a description of the syntax allowed in the various types of scripts, see [Batch Script Syntax](#), [Interface Script Syntax](#) and [Custom Script Syntax](#).

All scripts have permissions associated with them; a user who runs a script must have the permissions associated with the script in order to run the script.

To add a script:

1. Click the **Devices** tab and select the **Scripts** option. The Scripts page displays.

Figure 12-1 Devices > Scripts

The screenshot shows the LANTRONIX EMG851000 web interface. At the top, there's a header with the LANTRONIX logo and 'EMG851000'. Below it, a navigation bar contains tabs: Network, Services, User Authentication, Devices (selected), Maintenance, and Quick Setup. The Devices tab is active, and the Scripts page is displayed. The page includes a 'Logout' button, host/user information (Host: emgfcf0, User: sysadmin), and a 'Select port for' section with radio buttons for Configuration, WebSSH (DP only), and Connected Device (DP only). The Scripts page has a 'Help?' button and a table with one script named 'getdevicetemp'. The table has columns for Name, Type, Grp, State, Start Time, Freq (H), Stop Time, Device, and Status. The script is in a 'State' of 'Enable' and has a 'Status' of 'N/A'.

LANTRONIX® EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

Scripts Help?

Add Script

Rename Script New Name:

Current Date/Time: 07/31/19 18:25 Refresh Latest Script Results Script Operations

1 Script(s)								
Name	Type	Grp	State	Start Time	Freq (H)	Stop Time	Device	Status
getdevicetemp	Interface	Def	N/A	N/A	N/A	N/A	N/A	N/A

- Click the **Add Script** button. The page for editing script attributes displays.

Figure 12-2 Adding or Editing New Scripts

The screenshot shows the LANTRONIX EMG851000 web interface. At the top, there's a header with the LANTRONIX logo and 'EMG851000'. Below it, a 'Logout' button and user information (Host: emgfcf0, User: sysadmin) are visible. A 'Select port for' section has three radio buttons: Configuration (selected), WebSSH (DP only), and Connected Device (DP only). A navigation bar includes buttons for Network, Services, User Authentication, Devices (selected), Maintenance, and Quick Setup. Below the navigation bar, a list of links includes Device Status, Device Ports, Console Port, USB / SD Card, RPMs, Connections, Xmodem, Host Lists, Scripts, and Sites. The main section is titled 'Scripts' and contains a 'Script Name' input field, a 'Type' section with radio buttons for Interface (selected), Batch, and Custom, and a large text area for script content. Below the 'Scripts' section, there's a 'User Rights' section with a 'Group' dropdown (Default Users selected) and a grid of checkboxes for various permissions: Full Administrative, Networking, Services, Secure Lantronix Network, Date/Time, Reboot & Shutdown, RPMs, Local Users, Remote Authentication, SSH Keys, User Menus, Web Access, Diagnostics & Reports, Firmware & Configuration, Internal Modem, Device Port Operations, Device Port Configuration, USB, and SD Card. At the bottom, there's a 'Back to Scripts' link and an 'Apply' button.

- Enter the following script details:

Script Name	A unique identifier for the script.
Type	◆ Select Interface for a script that utilizes Expect/Tcl to perform pattern detection and action generation on Device Port output. ◆ Select Batch for a script of CLI commands. ◆ Select Custom for an Expect, Tcl or Python script that can be run against a CLI session or a Device Port, either manually or scheduled to run at periodic intervals.

Script Text	In the free-form editing box, enter the contents of the script. Restrictions on the script format are described in Batch Script Syntax , Interface Script Syntax , and Custom Script Syntax .
Group	Select the group to which the script will belong: ◆ Default Users: This group has only the most basic rights. You can specify additional rights for the individual user. ◆ Power Users: This group has the same rights as Default Users plus Networking, Date/Time, Reboot & Shutdown, and Diagnostics & Reports. You can specify additional rights for the individual user. ◆ Administrators: This group has all possible rights. For more information on how the group and rights are used with scripts, see To use a script at the CLI.

4. Assign or unassign User Rights for the specific user by checking or unchecking the following boxes:

Full Administrative	Right to add, update, and delete all editable fields.
Networking	Right to enter Network settings.
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.
Secure Lantronix Network	Right to view and manage secure Lantronix units (e.g., EMG or SLC devices) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the EMG unit.
RPMS	Right to view and enter Remote Power Manager (RPM) settings.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.
Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown.
Internal Modem	Right to configure internal modem settings.
Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port configurations.
USB	Right to enter modem settings for USB modems and to control USB storage devices.
SD Card	Right to view and enter settings for SD card.

5. To save, click the **Apply** button. If the type of script is **Interface** or **Custom**, the script will be validated before it is saved. Once the script is saved, the main [Devices > Scripts](#) page is displayed.

To view or update a script:

1. In the Scripts table, select the script and click the **Edit Script** button. The page for editing script attributes displays (see [Figure 12-2](#)).
2. Update the script attributes (see [To add a script:](#) above).
3. To save, click the **Apply** button.

To rename a script:

1. In the Scripts table, select the script and enter a new script name in the New Name field.
2. Click the **Rename Script** button. The script will be renamed and the [Devices > Scripts](#) page redisplay.

To delete a script:

1. In the Scripts table, select the script to delete.
2. Click the **Delete Script** button. After a confirmation, the script will be deleted and the [Devices > Scripts](#) page redisplay.

To schedule a custom script:

1. In the Scripts table, select the script and click the Schedule button. The Custom Scripts - Schedule page displays.

Figure 12-3 Scripts > Custom Scripts - Scheduler

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

Custom Scripts - Schedule [Help ?](#)

Script Name:

Device Type: ☒ CLI ☐ Device Port:

State: ☐ Enable ☒ Disable ☐ Delete

Command Line Arguments:

Start Time: ☒ Now ☐ At Date/Time: July 10 2019 04 : 30 : 00 pm

Frequency: ☒ Hours ☐ Days

Stop Time: ☒ Forever ☐ At Date/Time: July 10 2019 04 : 30 : 00 pm

[Back to Scripts](#)

2. Enter the following (each Custom Script can be run against one device - CLI or Device Port -

with one schedule):

Device Type	The device - either the CLI or a Device Port - that the script is connected to.
State	The state of the script's schedule. A script must be Enabled in order for the script scheduler to begin running the schedule. Once a script has been scheduled and enabled, it can be Disabled ; in this state the script manager will continue to update the scheduled run time for a script, but the script will not be run or produce any results. At any point a schedule for a script can be Deleted .
Command Line Arguments	Optional command line arguments to pass to the script each time it is run.
Start Time	The date and time when the script should start running, either Now or at a specific date and time.
Frequency	How often the script will run, given in hours or days. The web UI and CLI will always display the frequency in hours.
Stop Time	The date and time when the script should stop running, either at a specified date and time, or Forever if it should never stop running.

3. To save, click the **Apply** button. The schedule will be validated, and the script manager will either immediately start running the script or schedule the next run of the script. The main **Scripts** page is displayed, showing the schedule status of the script (this may take a few seconds to be updated while the script manager processes the script - click **Refresh** to view the latest information).

Notes on scheduling:

- ◆ Scripts that are scheduled to start immediately and run forever will be restarted when the EMG is rebooted.
- ◆ Scripts that are scheduled to start at a specific time will be restarted when the EMG is rebooted if the script is scheduled to run forever or if the stop time has not expired.
- ◆ After the EMG has booted, there will be a short delay after launching each script before starting the next script in order to minimize the impact on system resources. Shortly after boot, if the script status shows that a script is not scheduled when the script is configured with a schedule, refreshing the status will eventually show that all scheduled scripts will be running and/or scheduled.
- ◆ If the date, time or timezone is changed on the EMG while a script is scheduled, the CLI and web UI will still show the same scheduled date and time for the script, until the next time the script is run. It is recommended that the date, time and timezone not be changed while scripts are scheduled to run.

To change the Enable/Disable state of a custom script schedule:

1. In the Scripts table, select the script to enable or disable.
2. Click the **Enable** button (this will resume running of a script at its next scheduled time if it was previously disabled) or the **Disable** button (this will suspend running of a script but continue to update the schedule). The script's state will be updated and the Scripts page redisplay.

To view the list of completed operations (runs) for a custom script:

1. In the Scripts table, select the script to view operations for, and click **Script Operations**.
2. The Custom Scripts - Operations page displays, with a list of any results that have been generated for a script, in reverse date/time order. Any of the results can be viewed by selecting the operation and clicking **Script Results**.

To delete the completed operations (runs) for a custom script:

1. In the Scripts table, select the script to view operations for, and click **Script Operations**.
2. The Custom Scripts - Operations page displays, with a list of any results that have been generated for a script, in reverse date/time order. All the results can be deleted by clicking **Delete Results**.

To view the latest results from a completed operation (run) of a custom script:

1. Click the Devices tab and select the Scripts option. The Scripts page displays.
2. In the Scripts table, select the script to view results for, and click Latest Results Results.

The results are displayed in a popup window.

To use a script at the CLI:

1. To run an Interface Script or a Custom Script on a device port for pattern recognition and action generation, use the `connect script <Script Name> deviceport <Device Port # or Name>` command. This action requires that a EMG user running the connect script command have Device Port Operations (do) rights and port permissions for the selected device port.
2. To run a Batch Script at the CLI with a series of CLI commands, or a Custom Script for pattern recognition and action generation, use the `set script runcli <Script Name>` command. This action requires that an EMG user running the runcli command belong to a group that is the same or greater than the group assigned to the script (e.g., if the script is assigned to the Power group, the user running the runcli command must belong to the Power or Admin group). For Batch Scripts, if this minimum group requirement is met, the EMG user will temporarily be granted all of the individual rights assigned to the script while the Batch Script is running.

Note: *Expect Custom Scripts have a `debug enable` option that supports printing Expect debug information to aid in creating an Expect script. The debug option is not supported for Tcl and Python scripts.*

Script Commands

Go to [Script Commands](#) to view CLI commands which correspond to the web page entries described above.

Batch Script Syntax

The syntax for Batch Scripts is exactly the same as the commands that can be typed at the CLI, with the additions described in this section.

The `sleep` command suspends execution of the script (puts it to 'sleep') for the specified number of seconds.

Syntax:

```
sleep <value>
```

The `while` command allows a loop containing CLI commands to be executed. Syntax:

```
while {<Boolean expression>} {  
    CLI command 1  
    CLI command 2  
    ...  
    CLI command n  
}
```

Note: The closing left brace `}` must be on a line without any other characters. To support a `while` command, the `set` command, variables, and secondary commands are also supported.

Interface Script Syntax

This section describes the abbreviated scripting syntax for Interface Scripts. This limited syntax was created to prevent the creation of scripts containing potentially harmful commands. Script commands are divided into three groups: Primary, Secondary and Control Flow.

Primary commands provide the basic functionality of a script and are generally the first element on a line of a script, as in:

```
send_user "Password:"
```

Secondary commands provide support for the primary commands and are generally not useful by themselves. For example, the `expr` command can be used to generate a value for a set command.

```
set <my_var> [expr 1 + 1]
```

Control Flow commands allow conditional execution of other commands based on the results of the evaluation of a Boolean expression.

Table 12-4 Interface Script Syntax Definitions

Term	Definition
Word	A contiguous group of characters delimited on either side by spaces. Not enclosed by double quotes.
Primary Command	One of the primary commands listed in this section.
Secondary Command	One of the secondary commands defined in this section.
Quoted String	A group of characters enclosed by double quote (") characters. A quoted string may include any characters, including space characters. If a double quote character is to be included in a quoted string it must be preceded (escaped) by a backslash character (\).
Variable Reference	A word (as defined above) preceded by a dollar sign character (\$).
CLI Command	A quoted string containing a valid CLI <code>show</code> command.
Arithmetic Operator	A single character representing a simple arithmetic operation. The character may be one of the following: ◆ A plus sign (+) representing addition ◆ A minus sign (-) representing subtraction ◆ An asterisk sign (*) representing multiplication ◆ A forward slash (/) representing division ◆ A percent sign (%) representing a modulus
Boolean Expression	An expression which evaluates to TRUE or FALSE. A Boolean expression has the following syntax: <pre><value> <Boolean operator> <value></pre> Each can be either a word or a variable reference.
Boolean Operator	A binary operator which expresses a comparison between two operands and evaluates to TRUE or FALSE. The following Boolean operators are valid: ◆ '<' less than ◆ '>' greater than ◆ '<=' less than or equal to ◆ '>=' greater than or equal to ◆ '==' equal to ◆ '!=' not equal to

Primary Commands

These are stand-alone commands which provide the primary functionality in a script. These commands may rely on one or more of the Secondary Commands to provide values for some parameters. The preprocessor will require that these commands appear only as the first element of a command line. The start of a command line is delimited by any of the following:

- ◆ The start of a new line of text in the script
- ◆ A semicolon (';')
- ◆ A left brace ('{')

Table 12-5 Primary Commands

Command	Description
set	The <code>set</code> command assigns a value to a variable. Syntax: <pre>set <variable> <value></pre> where <variable> is a word, and <value> can be defined in one of the following ways: ◆ A quoted string ◆ A word ◆ A variable reference ◆ A value generated via one of the string secondary commands (<code>compare</code>, <code>match</code>, <code>first</code>, etc.) ◆ A value generated via the <code>expr</code> secondary command ◆ A value generated via the <code>format</code> secondary command ◆ A value generated via the <code>expr timestamp</code> command
unset	This command removes the definition of a variable within a script. Syntax: <pre>unset <variable></pre> where <variable> is a word.
scan	The <code>scan</code> command is analogous to the C language <code>scanf()</code>. Syntax: <pre>scan <variable> <format string> <value 1> <value 2> ... <value n></pre> where <variable> a variable reference, and <format string> is a quoted string. Each of the <value x> elements will be a word.
sleep	The <code>sleep</code> command suspends execution of the script (puts it to 'sleep') for the specified number of seconds. Syntax: <pre>sleep <value></pre> where <value> can be a word, a quoted string or a variable reference.
exec	The <code>exec</code> command executes a single CLI command. Currently only CLI 'show' commands may be executed via <code>exec</code>. Syntax: <pre>exec <CLI command></pre>
send, send_user	The <code>send</code> command sends output to a sub-process, The <code>send_user</code> command sends output to the standard output. Both commands have the same syntax: <pre>send <string></pre> <pre>send_user <string></pre> where <string> can be either a quoted string or a variable reference.

Command	Description
expect, expect_user, expect_before, expect_after, expect_background	The <code>expect</code> command waits for input and attempts to match it against one or more patterns. If one of the patterns matches the input the corresponding (optional) command is executed. All <code>expect</code> commands have the same syntax: <pre>expect {<string 1> {command 1} <string 2> {command 2} ... <string n> {command n}}</pre> where <code><string x></code> will either be a quoted string, a variable reference or the reserved word 'timeout.' The command <code>x</code> is optional, but the curly braces ('{' and '}') are required. If present it must be a primary command.
return	The <code>return</code> command terminates execution of the script and returns an optional value to the calling environment. Syntax: <pre>return <value></pre> where <code><value></code> can be a word or a variable reference.

Secondary Commands

These are commands which provide data or other support to the Primary commands. These commands are never used by themselves in a script. The preprocessor will require that these commands always follow a left square bracket '[' character and be followed on a single line by a right bracket (']').

Table 12-6 Secondary Commands

Command	Description
string	The <code>string</code> command provides a series of string manipulation operations. The <code>string</code> command will only be used with the <code>set</code> command to generate a value for a variable. There are nine operations provided by the <code>string</code> command. Syntax (varies by operation): <pre>string compare <str 1> <str 2></pre> Compare two strings <pre>string match <str 1> <str 2></pre> Determine if two strings are equal <pre>string first <str needle> <str haystack></pre> Find and return the index of the first occurrence of 'str_needle' in 'str_haystack' <pre>string last <str needle> <str haystack></pre> Find and return the index of the last occurrence of 'str_needle' in 'str_haystack' <pre>string length <str></pre> Return the length of 'str' <pre>string index <str> <int></pre> Return the character located at position 'int' in 'str' <pre>string range <str> <int start> <int end></pre> Return a string consisting of the characters in 'str' between 'int start' and 'int end' <pre>string tolower <str></pre> Convert <str> to lowercase <pre>string toupper <str></pre> Convert <str> to uppercase <pre>string trim <str 1> <str 2></pre> Trim 'str 2' from 'str 1' <pre>string trimleft <str 1> <str 2></pre> Trim 'str 2' from the beginning of 'str 1' <pre>string trimright <str 1> <str 2></pre> Trim 'str 2' from the end of 'str 1' In each of the above operations, each <str *> element can either be a quoted string or a variable reference. The <int *> elements will be either words or variable references.
expr	This command evaluates an arithmetic expression and returns the result. The <code>expr</code> command will only be used in combination with the <code>set</code> command to generate a value for a variable. Syntax: <pre>expr <value> <operation> <value></pre> Each <value> will be either a word or a variable reference, and <operation> an arithmetic operation.

Command	Description
timestamp	This command returns the current time of day as determined by the EMG. The <code>timestamp</code> command will only be used in combination with the <code>set</code> command to produce the value for a variable. Syntax: <code>timestamp <format></code> where <code><format></code> is a quoted string.
format	The <code>format</code> command is analogous to the C language <code>sprintf()</code> . The <code>format</code> command will only be used in combination with the <code>set</code> command to produce the value for a variable. Syntax: <code>format <format string> <value 1> <value 2> ... <value n></code> where <code><format string></code> will be a quoted string. Each of the <code><value x></code> elements will be a word, a quoted string or a variable reference.

Control Flow Commands

The `control flow` commands allow conditional execution of blocks of other commands. The preprocessor treats these as Primary commands, allowing them to appear anywhere in a script that a Primary command is appropriate.

Table 12-7 Control Flow Commands

Command	Description
while	The <code>while</code> command executes an associated block of commands as long as its Boolean expression evaluates to TRUE. After each iteration the Boolean expression is re-evaluated; when the Boolean expression evaluates to FALSE execution passes to the first command following the associated block. Each command within the block must be a Primary command. Syntax: <code>while {<Boolean expression>} {</code> <code> command 1</code> <code> command 2</code> <code> ...</code> <code> command n</code> <code>}</code>

Command	Description
if, elseif and else	The <code>if</code> command executes an associated block of commands if its Boolean expression evaluates to TRUE. Each command within the block must be a Primary command. Syntax: <pre>if {<Boolean expression>} { command 1 command 2 ... command n }</pre> The <code>elseif</code> command is used in association with an <code>if</code> command - it must immediately follow an <code>if</code> or <code>elseif</code> command. It executes an associated block of commands if its Boolean expression evaluates to TRUE. Each command within the block must be a Primary command. Syntax: <pre>elseif {<Boolean expression>} { command 1 command 2 ... command n }</pre> The <code>else</code> command is used in combination with an <code>if</code> or <code>elseif</code> command to provide a default path of execution. If the Boolean expressions for all preceding <code>if</code> and <code>elseif</code> commands evaluate to FALSE the associated block of commands is executed. Each command within the block must be a Primary Command. Syntax: <pre>else { command 1 command 2 ... command n }</pre>

Custom Script Syntax

This section describes the scripting syntax for Custom Scripts. The syntax is more flexible than Interactive Script syntax, but still has restrictions to prevent the creation of scripts containing potentially harmful commands. In addition, Custom Scripts can be configured to use command line parameters. Custom Scripts have the following guidelines:

1. The size of the script file cannot exceed 6 Kbytes.
2. The size of the results generated by the script cannot exceed 1 Kbyte (any results over 1Kbyte will be truncated).
3. The first line of the script must contain a Linux script style interpreter directive so that the EMG will know which interpreter to use to run the script. The format of the first line is `#! expect`, `#! tcl`, or `#! python`. When a custom script is imported, the interpreter line must match the selected script or file type (Expect, Tcl, or Python), otherwise the script will be invalid.
4. The script should include a spawn command to connect the script to either an EMG CLI session or an EMG Device Port session. Refer to the following spawn command syntax:

Note:

- ◆ *For CLI sessions, a local user name should be given*
- ◆ *For Device Port sessions, the `$devicePort` variable will be used by the EMG to connect the script to the appropriate Device Port. The `-noecho` flag may be passed to spawn command.*
- ◆ **Expect script - CLI session**
`spawn clisession -U <username>`
- ◆ **Expect script - Device Port session**
`spawn portsession -p $devicePort`
- ◆ **Tcl script - CLI session**
`set io [open "| clisession -U <username>" r+]`
- ◆ **Tcl script - Device Port session**
`set io [open "| portsession -p $devicePort" r+]`
- ◆ **Python script - CLI session**

```
subprocess.Popen(['clisession', '-U', '<username>'],
                 stdin=subprocess.PIPE,
                 stdout=subprocess.PIPE,
                 stderr=subprocess.PIPE)
```
- ◆ **Python script - Device Port session**

```
subprocess.Popen(['portsession', '-p', devicePort],
                 stdin=subprocess.PIPE,
                 stdout=subprocess.PIPE,
                 stderr=subprocess.PIPE)
```

It is recommended that scripts that spawn `clisession` only be used with the `set script runcli` command (and not the `connect script` command), and that scripts that spawn `portsession` only be used with the `connect script` command (and not the `set script runcli` command). Scripts that spawn a session should properly wait for the session to end before exiting the script; for example in an Expect script that spawns `clisession`, the script should include a `wait -i $sessionId` after sending the "logout" command to the `clisession`. The `clisession` will not display the Logout Banner as this may interfere with script

termination.

5. The script cannot contain commands which spawn or fork other commands, read or write files on the EMG filesystem, or interrogate the EMG filesystem. The list of commands that are not allowed for Expect scripts includes "fork", "open", "exp_open", "exec", "system", "log_file", "pwd".
6. For scripts that return an exit code, the EMG will interpret an exit code of zero as a successful exit code, and any non-zero exit code as an error. Non-zero exit codes are displayed (at the CLI) or logged (for scripts that are run by the script scheduler).

Example Scripts

- ◆ [Interface Script—Monitor Port on page 298](#)
- ◆ [Batch Script—EMG CLI on page 301](#)
- ◆ [Expect Custom Script - EMG CLI Session on page 303](#)
- ◆ [Expect Custom Script - EMG Device Port Session on page 305](#)
- ◆ [Expect Custom Script - EMG Device Port Session on page 307](#)
- ◆ [Python Custom Script - EMG CLI Session on page 309](#)
- ◆ [Python Custom Script - EMG CLI Session on page 311](#)
- ◆ [Tcl Custom Script - EMG CLI Session on page 315](#)

Interface Script—Monitor Port

The Monitor Port (Monport) script connects directly to a device port by logging into the EMG port, gets the device hostname, loops a couple of times to get port interface statistics, and logs out. The following is the script:

```
set monPort 7
set monTime 5
set sleepTime 2
set prompt ">"
set login "sysadmin"
set pwd "PASS"
#Send CR to echo prompt
send "\r"
sleep $sleepTime
#Log in or check for Command Prompt
expect {
    #Did not capture "login" or Command Prompt
    timeout { send_user "Time out login.....\r\n"; return }
    #Got login prompt
    "login" {
        send_user "Logging in....\r\n"
        send "$login\r"
        expect {
            timeout { send_user "Time out waiting for pwd
                prompt.....\r\n"; return }
            #Got password prompt
            "password" {
                #Send Password
                send "$pwd\r"
                expect {
                    timeout { send_user "Time out waiting for prompt.....\r\n";
                        return }
                    $prompt {}
                }
            }
        }
    }
    #Already Logged in got Command Prompt
    $prompt {
```

```

    send_user "Already Logged....\r\n"
  }
}
#Get hostname info
send "show network port 1 host\r"
expect {
  timeout { send_user "Time out Getting Hostname 1\r\n"; return }
  "Domain" {
    #Get Hostname from EMG
    set hostname "[string range $expect_out(buffer) [string first
      Hostname:
      $expect_out(buffer)] [expr [string first Domain
        $expect_out(buffer)]-2]]"
  }
}
send_user "\r\n\r\n\r\n\r\n\r\n"
send_user "Device [string toupper $hostname]\r\n"
send_user "_____ \r\n"
send_user "Monitored Port: Port $monPort \r\n"
send_user "Monitor Interval Time: $monTime Seconds \r\n"
set loopCtr 0
set loopMax 2
while { $loopCtr < $loopMax } {
  #Get current time

```

The following is the screen output:

```

emg247]> conn script ex4 deviceport 7
login: Logging in.... sysadmin sysadmin
Password: PASS
Welcome to the Lantronix Edge Management Gateway
Model Number: EMG851101
For a list of commands, type 'help'.
[EMG251]> show network port 1
host show network port 1 host
____Current Hostname Settings_____
Hostname: EMG251
Domain: support.int.lantronix.com
[EMG251 Device HOSTNAME: EMG251

Monitored Port: Port 7
Monitor Interval Time: 5 Seconds
[Current Time:21:16:43]
show portcounter deviceport 7
[EMG251]> show portcounter deviceport 7
Device Port: 7 Seconds since zeroed: 1453619
Bytes input: 0 Bytes output: 0
Framing errors: 0 Flow control errors: 0
Overrun errors: 0 Parity errors: 0
[EMG251]>
[Current Time:21:16:58]
show portcounter deviceport 7
show portcounter deviceport 7

```

```
Device Port: 7 Seconds since zeroed: 1453634
Bytes input: 0 Bytes output: 0
Framing errors: 0 Flow control errors: 0
Overrun errors: 0 Parity errors: 0 [
EMG251]>
Port Counter Monitor Script Ending.....
```

```
Login Out.....
logout
Returning to command line
[emg247]>
```


Batch Script—EMG CLI

This script runs the following EMG CLI commands, then runs the Monport Interface script:

- ◆ show network port 1 host
- ◆ show deviceport names
- ◆ show script
- ◆ connect script monport deviceport 7

The following is the screen output of the script:

```
[emg247]> se script runcli cli
[emg247]> show network port 1 host
__Current Hostname Settings__
Hostname: emg247
Domain: <none>
[emg247]>
[emg247]> show deviceport names
__Current Device Port
Names__
01 - SCS_ALIAS_Test 05 - Port-5
02 - Port-2 06 - Port-6
03 - Port-3 07 - EMG251
04 - Port-4 08 - Port-8
[emg247]>
[emg247]> show script
__Interface Scripts__ Group/Permissions
getSLC Adm/ad,nt,sv,dt,lu,ra,um,dp,pc,rp,rs,fc,dr,sn,wb,sk,po,do
Test Adm/ad,nt,sv,dt,lu,ra,um,dp,pc,rp,rs,fc,dr,sn,wb,sk,po,do
monport Adm/<none>
__Batch Scripts__ Group/Permissions
cli Adm/ad,nt,sv,dt,lu,ra,um,dp,pc,rs,fc,dr,sn,wb,sk,po,do,rp
[emg247]>
[emg247]> connect script monport deviceport 7
login: Logging in....
sysadmin
sysadmin
Password: PASS
Welcome to the Lantronix Edge Management Gateway
Model Number: EMG851101
For a list of commands, type 'help'.
[EMG251]> show network port 1 host
show network port 1 host
__Current Hostname Settings__
Hostname: EMG251
Domain: support.int.lantronix.com
Device HOSTNAME: EMG251
Monitored Port: Port 7
Monitor Interval Time: 5 Seconds
[Current Time:21:25:04]
show portcounter deviceport 7
[EMG251]> show portcounter deviceport 7
```

```
Device Port: 7 Seconds  since zeroed: 1454120
Bytes input: 0 Bytes output: 0
Framing errors: 0 Flow  control errors: 0
Overrun errors: 0 Parity errors: 0
[EMG251]>
[Current Time:21:25:20]
show portcounter deviceport 7
show portcounter deviceport 7
Device Port: 7 Seconds  since zeroed: 1454136
Bytes input: 0 Bytes output: 0
Framing errors: 0 Flow  control errors: 0
Overrun errors: 0 Parity errors: 0
[EMG251]>
Port Counter Monitor Script Ending.....
```

```
Login Out.....
logout
Returning to command line
[emg247]>
```

Expect Custom Script - EMG CLI Session

An example of an Expect Custom Script that interacts with an EMG CLI session:

```
#!/ expect
# script to get the current internal temperature of the EMG
# accepts one optional command line parameter for location

set emgPrompt ">"
set emgTemp    "unknown"
set location   ""

proc myprint {str} {
    send_user -- "$str\n"
}

proc abortSession {err} {
    send_user "Error $err. Terminating session.\n"
    exit $err
}

# Are there any command line parameters?
if {$argc > 0} {
    set location [lindex $argv 0]
}

set now [clock seconds]
set date [clock format $now -format {%D %R}]
if {$argc > 0} {
    myprint "Internal temperature of the $location EMG at $date"
} else {
    myprint "Internal temperature of the EMG at $date"
}

# spawn the CLI session
if {[catch {spawn -noecho clisession -U sysadmin} result]} {
    abortSession 1
}
set sessionId $spawn_id

# Handle eof
expect_after {
    -i $sessionId eof {
        myprint "Session unexpectedly terminated."
        abortSession 2
    }
}

set timeout 10
log_user 0

# Wait for the first prompt
set loggedIn false
while {! $loggedIn} {
```

```

    expect {
        timeout {myprint "Timeout waiting to login"; abortSession 3}
        "Need to specify username" {myprint "Need to specify -U ";
    abortSession 4}
        "*> " {set loggedIn true}
    } ;
}

exp_send "\n"
expect {
    timeout {myprint "Timeout waiting for CLI prompt"; abortSession 3}
    -re "\n\r(\\\[^\r]*)>"
}
set emgPrompt $expect_out(1,string)

# Run the temperature command
exp_send "show temperature\n"
expect {
    timeout {myprint "Timeout waiting for temperature"; abortSession 3}
    -re "Current Internal Temperature: (.*)\r\n"
}
set emgTemp $expect_out(1,string)
myprint "Temperature: $emgTemp"

exp_send "logout\n"
wait -i $sessionId
exit 0

```

This script can be run manually at the CLI:

```

[emga508] set script runcli cliExample parameters "East Data Center"
Internal temperature of the East Data Center SLC at 01/27/2019 02:07
Temperature: 48C (118F)

```

Expect Custom Script - EMG Device Port Session

An example of an Expect Custom Script that interacts with a EMG Device Port (in this example a ServerTech PDU is connected to a Device Port):

```
#!/ expect
#
# Script to get the load of a ServerTech PDU outlet
#

set pduPrompt ">"
set pduLoad    "unknown"

proc myprint {str} {
    send_user -- "$str\n"
}

proc abortSession {err} {
    send_user "Error $err. Terminating session.\n"
    exit $err
}

set now [clock seconds]
set date [clock format $now -format {%D %R}]
myprint "Load of ServerTech PDU outlet B1 at $date"

# spawn the port session on a device port
if {[catch {spawn -noecho portsession -p $devicePort} result]} {
    abortSession 1
}
set sessionId $spawn_id

# Handle eof
expect_after {
    -i $sessionId eof {
        myprint "Session unexpectedly terminated."
        abortSession 2
    }
}

set timeout 10
log_user 0

#
# Login to the PDU
# The "Error:*" pattern matches all error messages output by portsession
#
send "\n"
expect {
    "Username:" { send "admn\n" }
    "Error:*\r\n" { send_user $expect_out(0,string); abortSession 2 }
}
expect "Password:"
send "admn\n"
```

```
# Wait for the first prompt
set loggedIn false
while {! $loggedIn} {
    expect {
        timeout {myprint "Timeout waiting to login"; abortSession 3}
        "*CDU: " {set loggedIn true}
    } ;
}

# Detect the prompt
exp_send "\n"
expect "are:\r\n"
expect "LOGIN\r\n"
expect "REMOVE\r\n"
expect "RESTART\r\n"
expect {
    timeout {myprint "Timeout waiting for prompt"; abortSession 3}
    -re "\r\n(\[^r]*:)"
}
set pduPrompt $expect_out(1,string)

# Run the ostat command
exp_send "ostat .b1\n"
expect "Outlet*Power\r\n"
expect "ID*Watts*\r\n"
expect {
    timeout {myprint "Timeout waiting for load"; abortSession 3}
    -re "\.B1\\s+\\S+\\s+\\S+\\s+(\\S+)"
}
set pduLoad $expect_out(1,string)
myprint "Outlet B1 Load: $pduLoad Amps"

expect $pduPrompt
exp_send "logout\n"

wait -i $sessionId
exit 0
```

Expect Custom Script - EMG Device Port Session

An example of an Expect Custom Script that interacts with a EMG Device Port (in this example a Cisco server is connected to a Device Port):

```

#! expect
#
# Save a copy of the running config of a Cisco server to a TFTP server
# The Cisco server is connected to an EMG device port
#

proc myprint {str} {
    send_user -- "$str\n"
}

proc abortSession {err} {
    send_user "Error $err. Terminating session.\n"
    exit $err
}

if {$argc < 2} {
    myprint "Usage: script_md_cisco.exp <TFTP Server> <Backup File Name>"
    abortSession 1
}

set tftp [lindex $argv 0]
set configFile [lindex $argv 1]
set enablePassword "secret"
set timeout 10

set now [clock seconds]
set date [clock format $now -format {%D %R}]
myprint "Backing up Cisco Server to $tftp:$configFile at $date"

# spawn the port session on a device port
if {[catch {spawn -noecho portsession -p $devicePort} result]} {
    abortSession 2
}
set sessionId $spawn_id

# Handle eof
expect_after {
    -i $sessionId eof {
        myprint "Session unexpectedly terminated."
        abortSession 3
    }
}

log_user 0

# Send carriage return, see if we are connected
set loggedIn false
set execMode false

```

```

set passwordPrompt false
set cnt 1
while {! $loggedIn || ! $execMode} {
    if {$cnt == 5} {
        myprint "Timeout waiting for > or # prompt"
        abortSession 4
    }
    if {! $passwordPrompt} {
        send "\r"
    }
    expect {
        "*assword: " { send "$enablePassword\r" }
        ">" { set loggedIn true; set passwordPrompt true; send "enable\r" }
    }

    "#" { set loggedIn true; set execMode true }
    "Error:*\\r\\n" { send_user $expect_out(0,string); abortSession 5 }
    timeout {set cnt [expr {$cnt + 1}] }
}

myprint "Logged in."

send "copy running-config tftp://$tftp/$configFile\r"
expect "$tftp"
send "\r"
expect "$configFile"
send "\r"
myprint "Backup initiated."
expect {
    "!!" { myprint "Successfully backed up." }
    timeout { myprint "Timeout waiting for backup to complete.";
abortSession 6 }
}
send "exit\r"

sleep .5
close
exit 0

```


Python Custom Script - EMG CLI Session

An example of a Python Custom Script that interacts with a CLI session:

```
#!/ python
# Script to set the RADIUS authentication settings of the EMG
# Sets the first RADIUS server and secret, and enables RADIUS
# Note: passing secret as a command line parameter is a security
vulnerability
# Usage:
#   script_cli_radius.py <RADIUS server> <RADIUS secret>
#

import subprocess
import datetime
import sys

num_args = len(sys.argv) - 1
if num_args < 2:
    print("Usage: script_cli_radius.py <RADIUS server> <RADIUS secret>")
    sys.exit(1)

print("Settings RADIUS server on EMG at ", end="")
now = datetime.datetime.now()
print(now.strftime("%Y-%m-%d %H:%M"))

server = sys.argv[1]
secret = sys.argv[2]

proc = subprocess.Popen(['clisession', '-U', 'sysadmin'],
                        stdin=subprocess.PIPE,
                        stdout=subprocess.PIPE,
                        stderr=subprocess.PIPE)

# wait for prompt
while True:
    output_str = proc.stdout.readline()
    if b'list of commands' in output_str:
        proc.stdin.write(b'\n')
        proc.stdin.flush()
    if b']> ' in output_str:
        break
    if b'Invalid local user' in output_str:
        print("Invalid local user passed to clisession.")
        proc.stdin.close()
        proc.terminate()
        proc.wait()
        sys.exit(1)

# Run the RADIUS command
s = "set radius server 1 host " + server + " secret " + secret + "\n"
b = bytearray(s.encode())
proc.stdin.write(b)
proc.stdin.flush()
```

```
while True:
    output_str = proc.stdout.readline()
    if b'RADIUS settings successfully updated' in output_str:
        break
    elif b'set radius' not in output_str:
        # RADIUS command returned an error
        s1 = str(output_str)
        s2 = s1.split("\r")[1]
        print("RADIUS command returned: " + s2.split("\n")[0])
        proc.stdin.close()
        proc.terminate()
        proc.wait()
        sys.exit(1)

proc.stdin.write(b'set radius state enable\n')
proc.stdin.flush()
while True:
    output_str = proc.stdout.readline()
    if b'RADIUS settings successfully updated' in output_str:
        break
    elif b'set radius' not in output_str:
        # RADIUS command returned an error
        s1 = str(output_str)
        s2 = s1.split("\r")[1]
        print("RADIUS command returned: " + s2.split("\n")[0])
        proc.stdin.close()
        proc.terminate()
        proc.wait()
        sys.exit(1)

print("RADIUS settings updated and enabled.")
proc.stdin.close()
proc.terminate()
proc.wait()
sys.exit(0)
```

Python Custom Script - EMG CLI Session

An example of a Python Custom Script that uses the Pexpect module to interact with the CLI session and the device ports to detect the prompt on any devices connected to the EMG, and set the device port name to be the same as the device prompt:

```
#!/ python
# Script to detect the prompt on a device connected to an EMG device
port,
# and set the device port name to the prompt. Punctuation characters are
# removed and the device port number is appended to the name. Prompts
ending
# in '>' are detected. For example, for a Cisco device attached to device
# port 3 and displays this prompt:
#   engcisco_cat3560>
# the name for device port 3 will be set to "engcisco_cat3560-3"

import pexpect
import datetime
import time
import sys
import re

now = datetime.datetime.now()
print("Detecting devices on EMG at ", end="")
print(now.strftime("%Y-%m-%d %H:%M"))

# start the CLI session to get number of device ports
p=pexpect.spawn('clisession -U sysadmin')

emgPrompt = ""
numPorts = 0
loggedIn = False

while not loggedIn:
    i = p.expect([pexpect.TIMEOUT, pexpect.EOF,
                  'Model Number: SLC80(\d*)\r\n', 'Model Number:
SLB882\r\n',
                  '([\.*>)]', timeout=10)
    if i == 0: # Timeout
        print("Timeout waiting to login.")
        p.terminate(True)
        sys.exit(1)
    elif i == 1: # EOF
        print("Session unexpectedly terminated.")
        p.terminate(True)
        sys.exit(1)
    elif i == 2: # SLC8000 model number
        model = p.match.group(1)
        numPorts = int(model)
    elif i == 3: # SLB882 model number
        numPorts = 8
    elif i == 4: # prompt
```

```

        loggedIn = True
        slcPrompt = p.match.group(1).decode('utf-8')

    if numPorts == 0:
        print("Cannot determine number of device ports.")
        p.terminate(True)
        sys.exit(1)

    print("Number of device ports:", numPorts)

    # Terminate the CLI session
    p.sendline("logout")
    time.sleep(.500)
    p.wait()

    skipPorts = False
    devicePort = 1
    pList = []

    if numPorts == 24 or numPorts == 40:
        # Adjust port numbering for SLC8024 and SLC8040
        skipPorts = True
        numPorts = numPorts + 8

    # Loop through device ports, connect and try to detect the prompt
    while devicePort <= numPorts:
        if skipPorts and devicePort >= 9 and devicePort <= 16:
            devicePort = devicePort + 1
            pList.append('')
            continue
        print("Scanning device port", devicePort, "...")
        port = str(devicePort)
        p=pexpect.spawn('portsession', ['-p', port])

        # Login (if required), and wait for the first prompt
        p.sendline("")
        gotPrompt = False
        emgDevice = False
        cnt = 1
        while not gotPrompt:
            i = p.expect([pexpect.TIMEOUT, pexpect.EOF,
                          'login:', 'Error: (.*?)\r\n',
                          '>'], timeout=10)
            if i == 0:      # Timeout
                cnt = cnt + 1
                if cnt == 3:
                    print("Timeout waiting to connect to DP", devicePort, ".")
                    p.terminate(True)
                    p.wait()
                    break
                # may need to send a CR to get prompt
                p.send("\r")
            elif i == 1:    # EOF

```

```

        print("portsession on DP ", devicePort, "unexpectedly
terminated.")
        break
    elif i == 2:    # login prompt
        p.sendline("sysadmin")
        p.expect("Password:")
        p.sendline("PASS")
        emgDevice = True
        gotPrompt = True
    elif i == 3:    # error from portsession
        print(p.match.group(1).decode('utf-8'))
        p.terminate(True)
        p.wait()
        break
    elif i == 4:    # prompt
        gotPrompt = True
    # end if while not gotPrompt:

if not gotPrompt:
    devicePort = devicePort + 1
    pList.append('')
    continue

# Detect the prompt
devPrompt = ""
p.send("\n")
i = p.expect([pexpect.TIMEOUT, pexpect.EOF, '\r\n(.*)>'],
timeout=10)
if i == 0 or i == 1:    # Timeout or EOF
    print("Timeout waiting for the prompt on DP", devicePort, ".")
    p.terminate(True)
    p.wait()
    devicePort = devicePort + 1
    pList.append('')
    continue
if i == 2:              # prompt
    devPrompt = p.match.group(1).decode('utf-8')

if devPrompt == "":
    print("Timeout waiting for the prompt on DP", devicePort, ".")
    devicePort = devicePort + 1
    pList.append('')
    continue

print("Detected prompt", devPrompt, ".")
# Strip characters not allowed in DP names
devPromptStrip = re.sub("[^0-9A-Za-z\._\_-]", "", devPrompt)
devPromptComplete = devPromptStrip + "-" + str(devicePort)
pList.append(devPromptComplete)

p.terminate(True)
p.wait()
devicePort = devicePort + 1
# end of while devicePort <= numPorts:

```

```

# Connect to the EMG CLI and set the device port names
p=pexpect.spawn('clisession -U sysadmin')

loggedIn = False
while not loggedIn:
    i = p.expect([pexpect.TIMEOUT, pexpect.EOF,
                  'Model Number: SLC80(\d*)\r\n', 'Model Number:
SLB882\r\n',
                  '(\[.*>)\'], timeout=10)
    if i == 0: # Timeout
        print("Timeout waiting to login.")
        p.terminate(True)
        sys.exit(1)
    elif i == 1: # EOF
        print("Session unexpectedly terminated.")
        p.terminate(True)
        sys.exit(1)
    elif i == 4: # prompt
        loggedIn = True

devicePort = 1
while devicePort <= numPorts:
    if skipPorts and devicePort >= 9 and devicePort <= 16:
        devicePort = devicePort + 1
        continue
    if len(pList[devicePort - 1]) > 0:
        # Detected a prompt; set it
        print("Setting name on DP", devicePort, "to", pList[devicePort -
1], "...")
        s = "set deviceport port " + str(devicePort) + " name " +
pList[devicePort - 1]
        p.sendline(s)
        i = p.expect([pexpect.TIMEOUT,
                      'Device Port settings successfully updated.\r\n'],
                      timeout=10)
        if i == 0: # Timeout
            print("Timeout waiting for response.")
            devicePort = devicePort + 1

# Terminate the CLI session
p.sendline("logout")
time.sleep(.500)
p.wait()
print("Script completed.")
sys.exit(0)

```

Tcl Custom Script - EMG CLI Session

An example of a Tcl Custom Script that interacts with a CLI session:

```

#! tcl
# Script to get the current internal temperature of the EMG
# Accepts one optional command line parameter for location

set emgTemp "unknown"
set location ""

# Are there any command line parameters?
if {$argc > 0} {
    set location [lindex $argv 0]
}

set now [clock seconds]
set date [clock format $now -format {%D %R}]
if {$argc > 0} {
    puts "Internal temperature of the $location EMG at $date"
} else {
    puts "Internal temperature of the EMG at $date"
}

set io [open "| clisession -U sysadmin" r+]

set loggedIn false
while {! $loggedIn} {
    set len [gets $io line]
    if {[string first "Invalid local user" $line] != -1} {
        puts "Invalid local user passed to clisession"
        break
    }
    if {[string first "For a list of commands" $line] != -1} {
        puts $io "\n"
        flush $io
    }
    if {[string first ">" $line] != -1} {
        set loggedIn true
    }
}

if {! $loggedIn} {
    exit 1
}

puts $io "show temp"
flush $io
set gotTemp false
while {! $gotTemp} {
    set len [gets $io line]
    if {[string first "Current Internal Temperature" $line] != -1} {
        set emgTemp [string range $line [expr {[string first ":" $line] +
1}] end]
    }
}

```

```
        set gotTemp true
    }
}

puts "Temperature: $emgTemp"

puts $io "logout"
flush $io
exit 0
```


13: Connections

[Chapter 10: Device Ports](#) described how to configure and interact with an EMG port connected to an external device. This chapter describes how to use the [Devices > Connections](#) page to connect external devices and outbound network connections (such as Telnet or SSH) in various configurations.

An EMG port attached to an external device can be connected to one of the following endpoints:

- ◆ Another device port attached to an external device
- ◆ Another device port with a modem attached
- ◆ An outgoing Telnet or SSH session
- ◆ An outgoing TCP or UDP network connection

This enables the user to set up connections such as those described in the next section. You can establish a connection at various times:

- ◆ Immediately. These connections are always re-established after reboot.
- ◆ At a specified date and time. These connections connect after the date and time pass.
- ◆ After a specified amount of data or a specified sequence of data passes through the connection. Following reboot, the connection is not reestablished until the specified data passes through the connection.


Typical Setup Scenarios for the EMG unit

Following are typical configurations in which EMG connections can be used, with references to settings on the [Devices > Connections](#) and [Device Ports > Settings \(1 of 2\)](#) web pages.

Terminal Server

In this setup, the EMG acts as a multiplexer of serial data to a single server computer. Terminal devices are connected to the serial ports of the EMG unit and configured as a Device Port to Telnet out type connection on the [Devices > Connections](#) page. The users of the terminals can access the server as if they were connected directly to it by local serial ports or a console.


Figure 13-1 Terminal Server



Remote Access Server

In this setup, the EMG is connected to one or more modems by its device ports. Configure the device ports on the [Device Ports > Settings \(1 of 2\)](#) web page by selecting the Dial-in option in the Modem Settings section. Most customers use the modems in PPP mode to establish an IP connection to the EMG unit and either Telnet or SSH into the EMG. They could also select text mode where, using a terminal emulation program, a user could dial into the EMG unit and connect to the command line interface.


Figure 13-2 Remote Access Server



Reverse Terminal Server

In this scenario, the EMG has one or more device ports connected to one or more serial ports of a mainframe server. Users can access a terminal session by establishing a Telnet or SSH session to the EMG unit. To configure the EMG, select the **Enable Telnet In** or **Enable SSH In** option on the [Device Ports > Settings \(1 of 2\)](#) page.


Figure 13-3 Reverse Terminal Server



Multiport Device Server

A PC can use the device ports on the EMG unit as virtual serial ports, enabling the ports to act as if they are local ports to the PC. To use the EMG in this setup, the PC requires special software, for example, Com Port Redirector (available on www.lantronix.com) or similar software.

Figure 13-4 Multiport Device Server




Console Server

The EMG unit is configured so that the user can manage a number of servers or pieces of network equipment using their console ports. The device ports on the EMG are connected to the console ports of the equipment. To manage a specific piece of equipment, the user can Telnet or SSH to a specific port or IP address on the EMG unit and be connected directly to the console port of the end server or device. To configure this setup, set the **Enable Telnet In** or **Enable SSH In** option on the [Device Ports > Settings \(1 of 2\)](#) page for the device port in question.

The user can implement an extra remote management capability by adding a modem to one of the device ports and setting the **Dial-in** option in the Modem Settings section of the [Device Ports > Settings \(1 of 2\)](#) page. A user could then dial into the EMG using another modem and terminal emulation program at a remote location.

Figure 13-5 Console Server



Connection Configuration

Note: These are advanced connection settings for specific applications. If the EMG is being used as a console or device server it is unlikely that you will need any of the Connection settings described below.

To create a connection:

1. Click the **Devices** tab and select **Connections**. The Connections page displays, as shown in [Figure 13-6](#):

Figure 13-6 Devices > Connections

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication **Devices** Maintenance Quick Setup

Device Status Device Ports Console Port USB / SD Card RPMs Connections Xmodem Host Lists Scripts Sites

Connections Help?

Outgoing Connection Timeout: ☐ No ☒ Yes: 5 seconds

Connect: Device Port Port: [Settings](#)

Data Flow: ☒ ☐ ☐

to: Device Port

Hostname:

Port: [Settings](#)

SSH Out Options

User:

Version: ☒ None ☐ 1 ☐ 2

Command:

Trigger: ☒ Connect now

☐ Connect at date/time: July 11 2019 04 : 47 pm

☐ Auto-connect on characters transferring: ☒ ☐

☐ at least characters

☐ character sequence:

To view details for a connection, hold the mouse over the arrow icon in the Flow column.
If a connection can be modified, the fields above will be filled in; modify the connection and select 'Configure'.
To terminate a connection, select the radio button in the right column below and select 'Terminate'.
Web connections can be viewed [here](#).

Current Connections		Configure	Terminate	Keep Connection: ☐	Restart
Port/Service	Flow	Port/Service	User	Time	
Device Port 2		Command Line	N/A	N/A	☐

2. For a device port, enter the following:

Outgoing Connection Timeout	Select to turn on or turn off the connection timeout: ◆ No for no timeout ◆ Yes for a timeout. Specify the number of seconds in the seconds field.
Port	The number of the device port you are connecting. This device port must be connected to an external serial device and must not have command line interface logins enabled, be connected to a modem, or be running a loopback test. Note: To see the current settings for this device port, click the Settings link.
Data Flow	Select the arrow showing the direction (bidirectional or unidirectional) the data will flow in relationship to the device port you are connecting.
to	From the drop-down list, select a destination for the connection: a device port connected to a serial device, a device port connected to a modem, or an outbound network connection (Telnet out , SSH out , TCP Port , or UDP Port). Note: To see the current settings for a selected device port, click the Settings link.
Hostname	The host name or IP Address of the destination. This entry is required if the to field is set to Telnet out, SSH out, TCP port, or UDP port.

Port	If the to field is set to Device Port or Modem on Device Port, enter the number of the device port. For all other options, this is the TCP/UDP port number, which is optional for Telnet out and SSH out, but required for TCP Port and UDP Port. Note: If you select Device Port, it must not have command line interface logins enabled or be running a loopback test. To view the device port's settings, click the Settings link to the right of the port number.
SSH Out Options	Select one of the following optional flags to use for the SSH connection. ◆ User: Login ID to use for authenticating on the remote host. ◆ Version: Version of SSH. Select 1 or 2. ◆ Command: Enter a specific command on the remote host (for example, reboot).
Trigger	Select the condition that will trigger a connection. Options include: ◆ Connect now: Connects immediately, or if you reboot the EMG, immediately on reboot. ◆ Connect at date/time: Connects at a specified date and time. Use the drop-down lists to complete the date and time. Upon rebooting, the EMG unit reestablishes the connection if the date/time has passed. ◆ Auto-connect on characters transferring: Select the arrow indicating the direction of the data transfer and either the minimum number of characters or a specific character sequence that will trigger the connection. You can select the direction of the data transfer only if Data Flow is bidirectional. Upon rebooting, the EMG does not reestablish the connection until the specified data has passed through one of the endpoints of the connection.

3. To save, click the **Apply** button.

To view, update, or disconnect a current connection:

The bottom of the [Devices > Connections](#) page displays current connections.

Figure 13-7 Current Connections

To view details for a connection, hold the mouse over the arrow icon in the Flow column.
 If a connection can be modified, the fields above will be filled in; modify the connection and select 'Configure'.
 To terminate a connection, select the radio button in the right column below and select 'Terminate'.
 Web connections can be viewed [here](#).

Current Connections		Configure	Terminate	Keep Connection: ☐	Restart
Port/Service	Flow	Port/Service	User	Time	
Device Port 2		Command Line	N/A	N/A	☐

1. To view details about a connection, hold the mouse over the arrow in the **Flow** column.
2. To disconnect (delete) a connection, select the connection in the **Select** column and click the **Terminate** button.
3. To reestablish the connection, create the connection again in the top part of the page.
4. To view information about Web connections, click the **here** link in the text above the table. The [Maintenance > Firmware & Configurations](#) page displays.

Connection Commands

Go to [Connection Commands](#) to view CLI commands which correspond to the web page entries described above.

14: User Authentication

Authentication Methods

Users who attempt to log in to the console manager by means of Telnet, SSH, the console port, or one of the device ports are granted access by one or more authentication methods.

By default, Local user authentication is always enabled and is the first method the console manager uses to authenticate users. The User Authentication page provides a submenu of other methods (NIS, LDAP, RADIUS, Kerberos, TACACS+) you can select to authenticate users attempting to log in. Use this page to assign the order in which the console manager will use the methods.

Note: *even if Local user authentication is disabled or last in the authentication order, the local user sysadmin will always be enabled and granted access first (before any other authentication methods); this ensures that there is always a method to authenticate to the console server in the event that all remote authentication methods are unreachable. See [Limiting Sysadmin User Access](#).*

For security purposes, full administrative access to the console manager via the default sysadmin local user account can be limited to only the front console port of the console manager device. To configure this: (1) enable the Sysadmin access limited to Console Port option on the Local/Remote Users web page; (2) enable a remote authentication method (such as TACACS+ or LDAP) and configure the remote authentication method to be first in the order of methods used; (3) create a remote user account with full administrative rights; and (4) uncheck the Attempt next method on authentication rejection checkbox on the Authentication Methods web page. This will prevent any local users from logging in, restrict the default sysadmin local user to the front console port, and allow a user with administrative rights to login, as long as remote authentication is working.

If you enable multiple authentication methods, and a user has a login ID for more than one of these methods, the login defaults to the highest priority authentication method based on the settings made on this web page.

If you have the same user name defined in multiple authentication methods, the result is unknown.

Example:

There is an LDAP user "joe" and an NIS user "joe" and the order of authentication methods is:

1. Local Users
2. LDAP
3. NIS

User "joe" tries to log in. Because there is an LDAP user "joe," the EMG unit tries to authenticate him against his LDAP password first. If he fails to log in, then the EMG may (or may not) try to authenticate him against his NIS "joe" user password.

To enable, disable, and set the precedence of authentication methods:

1. From the main menu, select **User Authentication**. The following page displays:

Figure 14-1 User Authentication > Auth Methods

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services **User Authentication** Devices Maintenance Quick Setup

Auth Methods Local/Remote Users NIS LDAP RADIUS Kerberos TACACS+ Groups SSH Keys Custom Menus

Authentication Methods Help ?

The EMG can be configured to use one or more authentication methods. Each authentication method is assigned a precedence, indicating the order that the method is used to authenticate a user who logs in to the EMG via SSH, Telnet, the Web or the Console Port.

Enabled methods (in order of precedence):

Local Users

Disabled methods:

NIS
LDAP
RADIUS
Kerberos
TACACS+

Authentication can occur using all methods, in the order of their precedence, using the next method if the previous one rejected the authentication; or using only the first authentication method that responds.

☐ Attempt next method on authentication rejection

Apply

2. To enable a method currently in the **Disabled methods** list, select the method and press the left arrow to the left of the list. The methods include:

NIS (Network Information System)	A network naming and administration system developed by Sun Microsystems for smaller networks. Each host client or server computer in the system has knowledge about the entire system. A user at any host can access files or applications on any host in the network with a single user identification and password. NIS uses the client/server model and the Remote Procedure Call (RPC) interface for communication between hosts. NIS consists of a server, a library of client programs, and some administrative tools. NIS is often used with the Network File System (NFS).
LDAP (Lightweight Directory Access Protocol)	A set of protocols for accessing information directories, specifically X.500-based directory services. LDAP runs over TCP/IP or other connection-oriented transfer services.
RADIUS (Remote Authentication Dial-In User Service)	An authentication and accounting system used by many Internet Service Providers (ISPs). A client/server protocol, it enables remote access servers to authenticate dial-in users and authorize their access to the requested system or service. RADIUS allows a company to maintain user profiles in a central database that all remote servers can share. It increases security, allowing a company to set up a policy that can be applied at a single administered network point.

Kerberos	Kerberos is a network authentication protocol that enables two parties to exchange private information across an unprotected network. It works by assigning a unique electronic credential, called a ticket, to each user who logs on to the network. The ticket is embedded in messages to identify the sender.
TACACS+ (Terminal Access Controller Access Control System)	TACACS+ allows a remote access server to communicate with an authentication server to determine whether the user has access to the network. TACACS+ is a completely new protocol and is not compatible with TACACS or XTACACS. The EMG supports TACACS+ only.
Local Users	Local accounts on the EMG unit used to authenticate users who log in using SSH, Telnet, the web, or the console port.

3. To disable a method currently in the **Enabled methods** list, select the method and click the right  arrow between the lists.
4. To set the order in which the EMG unit will authenticate users, use the up  and down  arrows to the left of the **Enabled methods** list.
5. For **Attempt next method on authentication rejection**, you have the following options:
 - To enable the EMG to use all methods, in order of precedence, until it obtains a successful authentication, select the check box. This is the default.
 - To enable the EMG unit to use only the first authentication method that responds (in case a server is down or unavailable), clear the check box.

Note: When limiting accessibility of the sysadmin login to the physical EMG device, make sure to uncheck **Attempt next method on authentication rejection**.
6. Click **Apply**.

Now that you have enabled one or more authentication methods, you must configure them.

Authentication Commands

Go to [Authentication Commands](#) to view CLI commands which correspond to the web page entries described above.

User Rights

The EMG has three user groups: Administrators, Power Users, and Default Users. Each has a predefined set of rights; users inherit rights from the user group to which they belong. These rights are in addition to the current functions that a user can perform at the command line interface:

- ◆ connect direct/listen
- ◆ set locallog/password/history/cli
- ◆ show datetime/deviceport/locallog/portstatus/portcounters/
- ◆ history/cli/user

The table below shows the mapping of groups and user rights.

Table 14-2 User Types and Rights

User Right	Administrator	Power Users	Default Users
Full Administrative Rights	X		
Networking	X	X	
Services	X		
Date/Time	X	X	
Local Users	X		
Remote Authentication	X		
SSH Keys	X		
User Menus	X		
Device Port Operations	X		
Device Port Configuration	X		
USB	X		
Reboot/Shutdown	X	X	
Ethernet Switch	X		
Firmware/Configuration	X		
Diagnostics and Reports	X	X	
Secure Lantronix Network	X		
Web Access	X	X	
Internal Modem	X		
RPMs	X		
SD Card	X		

You cannot deny a user rights defined for the group, but you can add or remove all other rights at any time.

By default, the system assigns new users to the Default Users group, but you can change their group membership at any time. If you change a user's rights while the user is logged into the web or CLI, the results do not take effect until the next time the user logs in.

Local and Remote User Settings

The system administrator can configure the EMG to use local accounts and remote accounts to authenticate users.

1. Click the **User Authentication** tab and select the **Local/Remote Users** option. The following page displays.

Figure 14-3 User Authentication > Local/Remote Users

LANTRONIX® EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for: ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services **User Authentication** Devices Maintenance Quick Setup

Auth Methods Local/Remote Users NIS LDAP RADIUS Kerberos TACACS+ Groups SSH Keys Custom Menus

Local/Remote Users [Help ?](#)

Enable Local Users: ☒ Local and remote accounts on the EMG are used to authenticate users who login to the EMG via SSH, Telnet, the Web or the Console Port.

Multiple Sysadmin Web Logins: ☒

Sysadmin Access Limited to Console Port: ☐

Authenticate only remote users who are in the remote users list: ☐

Deny access to remote users assigned to groups that do not map to EMG custom group: ☐

Note: remove Escape & Break Sequences for users making raw binary connections to Device Ports.

Local User Passwords

Complex Passwords: ☐ Password Lifetime: 90 days

Allow Reuse: ☒ Note: Password reuse is insecure.

Warning Period: ☐ No ☒ Yes: 7 days

Reuse History: 4

Max Login Attempts: ☒ No ☐ Yes: 0

Lockout Period: ☒ No ☐ Yes: 0 minutes

[Add/Edit User](#) [Delete User](#)

Select the radio button in the right column to edit or delete a user. Shaded users are locked (cannot login).

Local Users (2 users) & Remote Users (0 users)										View Local Users		View Remote Users	
Login	Auth	UID	Group	Permissions	Esc Seq	Brk Seq	Custom Menu	DB	Listen	Data	Clear		
buguser	Local	101	Adm	fa.nt,sv,lu,ra.dt,sk,um,dp,do,ub,rs,fc,dr,sn,wb,sd,md,rp,sw	\x1bA	\x1bB		N	1-4,U1	1-4,U1	1-4,U1	☐	
sysadmin	Local	0	Adm	fa.nt,sv,lu,ra.dt,sk,um,dp,do,ub,rs,fc,dr,sn,wb,sd,md,rp,sw	\x1bA	\x1bB		N	1-4,U1	1-4,U1	1-4,U1	☐	

[Apply](#)

The top of the page has entry fields for enabling local and remote users and for setting password requirements. The bottom of the page displays a table listing and describing all local and remote users.

To enable local and/or remote users:

- 1) Enter the following:

Enable Local Users	Select to enable all local users except sysadmin. The sysadmin user is always available regardless of how you set the check box. Enabled by default.
Multiple Sysadmin Web Logins	Select to allow the sysadmin to have multiple simultaneous logins to the web interface. Disabled by default.
Sysadmin Access Limited to Console Port	Select to limit sysadmin logins to the physical EMG console port only. Disabled by default. Note: For security purposes, full administrative access to the EMG via the default sysadmin local user account can be limited to only the front console port of the EMG device. See Limiting Sysadmin User Access .

Authenticate only remote users who are in the remote users list	Select the check box to authenticate users listed in the Remote Users list in the lower part of the page. Disabled by default.
Deny access to remote users assigned to groups that do not map to EMG custom group	Select the check box to authenticate remote users whose LDAP group or TACACS+ priv_lml map to an EMG custom group, allow EMG access if matched. Disabled by default.

2) Continue to set **Local User Passwords**:

Complex Passwords	Select to enable the EMG unit to enforce rules concerning the password structure (e.g., alphanumeric requirements, number of characters, punctuation marks). Disabled by default. Complexity rules: Passwords must be at least eight characters long. They must contain one upper case letter (A-Z), one lower case letter (a-z), one digit (0-9), and one punctuation character ((),~!@#\$%^&*+=\{}[];":'<>.,?/_).
Allow Reuse	Select to enable users to continue to reuse old passwords. If you disable the check box, they cannot use any of the Reuse History number of passwords. Enabled by default.
Reuse History	The number of passwords the user must use before reusing an old password. The default is 4 . For example, if you set reuse history to 4, the user may reuse an old password after using 4 other passwords.
Password Lifetime (days)	The number of days until the password expires. The default setting is 90 .
Warning Period (days)	The number of days ahead that the system warns that the user's password will expire. The default setting is 7 .
Max Login Attempts	The number of times (up to 8) the user can attempt to log in unsuccessfully before the system locks the user out. The default setting is 0 (disabled).
Lockout Period (minutes)	The number of minutes (up to 90) the locked-out user must wait before trying to log in to the web interface again. The default setting is 0 (disabled).

2. Click the **Apply** button.

Sysadmin Account Default Login Values

On factory default EMG units, the local user sysadmin account has the following default login values.

EMG units manufactured on or after January 1, 2020 and installed with firmware version 8.2.0.1 or later:

username: **sysadmin**

password: the last 8 characters of the Device ID. If the Device ID is not set, the password is the last 8 characters of the serial number.

EMG units manufactured before January 1, 2020 and installed with firmware version 8.2.0.0:

username: **sysadmin**

password: **PASS**

If you don't know when the EMG unit was manufactured, you can do the following to identify whether the device-unique sysadmin password is supported and enabled on the hardware. View the About EMG page or run the CLI admin version command and look for the following in the

result:Admin Password Unique to Device: enabled (or disabled). If that string is absent from the result or the result is set to “disabled”, it indicates that the device doesn’t support the device-unique sysadmin password.

Note: *It is recommended that you change the default password on initial setup. The password should be recorded and stored in a secure place accessible by at least two authorized system administrators. To change the sysadmin password, see the next topic.*

Adding, Editing or Deleting a User

Through this [User Authentication > Local/Remote Users](#) page, you can delete a user listed in the table or open a page for adding or editing a user.

To add a user:

1. On the [User Authentication > Local/Remote Users](#), click the **Add/Edit User** button. The [User Authentication > Local/Remote User Settings](#) page displays.

Figure 14-4 User Authentication > Local/Remote User Settings

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services **User Authentication** Devices Maintenance Quick Setup

Auth Methods Local/Remote Users NIS LDAP RADIUS Kerberos TACACS+ Groups SSH Keys Custom Menus

Local/Remote User Settings Help?

Login: Enable for Dial-back: ☐ Password:

Authentication: ☒ Local ☐ Remote Dial-back Number: Retype Password:

UID: Escape Sequence: Password Expires: ☐

Listen Ports: Break Sequence: Allow Password Change: ☒

Data Ports: Custom Menu: Change Password on Next Login: ☐

Clear Port Buffers: Display Menu at Login: ☒ Lock Account: ☐

Account Status: **Active**

Group: ☒ Default Users ☐ Power Users ☐ Administrators ☐ Custom Group:

Each user is a member of a group which has predefined user rights associated with it. User rights that are associated with a group cannot be modified for individual users.

Full Administrative: ☐ Local Users: ☐ Firmware & Configuration: ☐

Networking: ☐ Remote Authentication: ☐ Internal Modem: ☐

Services: ☐ SSH Keys: ☐ Device Port Operations: ☐

Secure Lantronix Network: ☐ User Menus: ☐ Device Port Configuration: ☐

Date/Time: ☐ Web Access: ☐ USB: ☐

Reboot & Shutdown: ☐ Diagnostics & Reports: ☐ SD Card: ☐

RPMs: ☐ Ethernet Switch: ☐

[Back to Local/Remote Users](#)

2. Enter the following information for the user:

Login	User ID of selected user.
Authentication	Select the type of authenticated user: ◆ Local: User listed in the EMG database. ◆ Remote: User not listed in the EMG database.
UID	A unique numeric identifier the system administrator assigns to each user. Valid UIDs are 101-4294967295. Note: The UID must be unique. If it is not, EMG unit automatically increments it. Starting at 101, the EMG finds the next unused UID.
Listen Ports	The device ports that the user may access to view data using the <code>connect listen</code> command. Enter the port numbers or the range of port numbers (for example, 1, 5, 8, 10-15). U1 denotes the USB port on the EMG unit.
Data Ports	The device ports with which the user may interact using the <code>connect direct</code> command. Enter the port numbers or the range of port numbers.

Clear Port Buffers	The device port buffers the users may clear using the <code>set locallog clear</code> command. Enter the port numbers or the range of port numbers.
Enable for Dial-back	Select to grant a local user dial-back access. Users with dial-back access can dial into the EMG unit and enter their login and password. Once the EMG authenticates them, the modem hangs up and dials them back. Disabled by default.
Dial-back Number	The phone number the modem dials back on depends on this setting for the device port. The user is either dialed back on a fixed number (specified on the Device Port - Settings page), or on a number that is associated with the user's login (specified here).
Escape Sequence	A single character or a two-character sequence that causes the EMG unit to leave direct (interactive) mode. (To leave listen mode, press any key.) A suggested value is Esc+A (escape key, then uppercase "A" performed quickly but not simultaneously). You would specify this value as <code>\x1bA</code>, which is hexadecimal (<code>\x</code>) character 27 (1B) followed by an A. This setting allows the user to terminate the <code>connect direct</code> command on the command line interface when the endpoint of the command is <code>deviceport</code>, <code>tcp</code>, or <code>udp</code>. See Key Sequences for notes on key sequence precedence and behavior.
Break Sequence	A series of 1-10 characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as <code>\x1bB</code>, which is hexadecimal (<code>\x</code>) character 27 (1B) followed by a B. See Key Sequences for notes on key sequence precedence and behavior.
Custom Menu	If custom menus have been created, you can assign a default custom menu to the user. The custom menu will display at login. Note: In the Local Users table, if the menu assigned to a local user no longer exists, it is marked with an asterisk (*).
Display Menu at Login	If custom menus have been created, select to enable the menu to display when the user logs into the CLI.
Password / Retype Password	When a user logs into the EMG, the EMG unit prompts for a password (up to 64 characters). The sysadmin establishes that password here.
Password Expires	If not selected, allows the user to keep a password indefinitely. If selected the user keeps the password for a set period. (See the section, Local and Remote User Settings for information on specifying the length of time before the password expires.)
Allow Password Change	Select to allow the user to change password.
Change Password on Next Login	Indicate whether the user must change the password at the next login.
Lock Account	Select to lock the account indefinitely.
Account Status	Displays the current account status: ◆ Active ◆ Locked ◆ Locked (invalid logins)

3. In the **User Rights** section, select the user group to which local/remote users will belong.

Group	Select the group to which the local or remote user will belong: ◆ Default Users: This group has only the most basic rights. You can specify additional rights for the individual user. ◆ Power Users: This group has the same rights as Default Users plus Web Access, Networking, Date/Time, Reboot & Shutdown, and Diagnostics & Reports. ◆ Administrators: This group has all possible rights. ◆ Custom Group: Select a custom group from the drop-down menu.

4. Select or clear the checkboxes for the following rights:

Full Administrative	Right to add, update, and delete all editable fields.
Networking	Right to enter Network settings.
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.
Secure Lantronix Network	Right to view and manage Secure Lantronix units (e.g., EMG, or SLC units) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the EMG unit.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.
Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Ethernet Switch	Right to view and enter settings for the managed Ethernet Switch.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown .
Internal Modem	Right to update internal modem settings.
Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port settings.
USB	Right to enter modem settings for USB devices and control USB storage devices.
SD Card	Right to enter settings for SD card.
RPM	Right to manage and control remote power managers.

5. Click the **Apply** button.
6. Click the **Back to Local/Remote Users** link to return to the Local/Remote User Settings page.
7. Add another user or click the **Back to Local/Remote Users** link. The Local/Remote Users page displays with the new user(s) listed in the table.

Note: The logged-in user's name displays at the top of the web page. Only the tabs and options for which the user has rights display.

Shortcut

To add a user based on an existing user:

1. Display the existing user on the [User Authentication > Local/Remote Users](#) page. The fields in the top part of the page display the current values for the user.
2. Change the Login to that of the new user. It is best to change the Password too.
3. Click the **Apply** button.

To edit a local user:

1. On the [User Authentication > Local/Remote Users](#) page, select the user and click the **Add/Edit User** button. The Local/Remote User Settings page displays.
2. Update values as desired.
3. Click the **Apply** button.

To delete a local user:

1. On the [User Authentication > Local/Remote Users](#) page, select the user and click the **Add/Edit User** button. The Local/Remote User Settings page displays.
2. Click the **Delete User** button.
3. Click the **Apply** button.

To change the sysadmin password:

1. On the [User Authentication > Local/Remote Users](#) page, select **sysadmin** and click the **Add/Edit User** button. The Local/Remote User Settings page displays.
2. Enter the new password in the Password and Retype Password fields.

Note: You can change Escape Sequence and Break Sequence, if desired. You cannot delete the UID or change the UID, port permissions, or custom menu.

3. Click the **Apply** button.

Local Users Commands

Go to [Local Users Commands](#) to view CLI commands which correspond to the web page entries described above.

Remote User Rights Commands

Go to [Remote User Commands](#) to view CLI commands which correspond to the web page entries described above.

NIS

The system administrator can configure the EMG to use NIS to authenticate users attempting to log in to the EMG unit through the Web, SSH, Telnet, or the console port. If NIS does not provide port permissions, you can use this page to grant device port access to users who are authenticated through NIS.

All NIS users are members of a group that has predefined user rights associated with it. You can assign additional user rights that are not defined by the group.

To configure the EMG unit to use NIS to authenticate users:

1. Click the **User Authentication** tab and select the **NIS** option.

Figure 14-5 User Authentication > NIS

LANTRONIX® EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for: ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services **User Authentication** Devices Maintenance Quick Setup

Auth Methods Local/Remote Users **NIS** LDAP RADIUS Kerberos TACACS+ Groups SSH Keys Custom Menus

NIS Help ?

Enable NIS: ☐

NIS Domain:

Note: The NIS Domain must match the NIS domain name on the NIS Server.

Broadcast for NIS Server: ☐

NIS Master Server:

NIS Slave Server #1: Custom Menu:

NIS Slave Server #2: Escape Sequence:

NIS Slave Server #3: Break Sequence:

NIS Slave Server #4: Enable for Dial-back: ☐

NIS Slave Server #5: Dial-back Number:

Data Ports:

Listen Ports:

Clear Port Buffers:

User Rights

☒ Default Users

Group: ☐ Power Users ☐ Administrators

All NIS users are members of a group which has predefined user rights associated with it. Additional rights which are not defined by the group can be added.

Full Administrative: ☐	Local Users: ☐	Firmware & Configuration: ☐
Networking: ☐	Remote Authentication: ☐	Internal Modem: ☐
Services: ☐	SSH Keys: ☐	Device Port Operations: ☐
Secure Lantronix Network: ☐	User Menus: ☐	Device Port Configuration: ☐
Date/Time: ☐	Web Access: ☐	USB: ☐
Reboot & Shutdown: ☐	Diagnostics & Reports: ☐	SD Card: ☐
RPMs: ☐	Ethernet Switch: ☐	

2. Enter the following:

Enable NIS	Displays selected if you enabled this method on the Authentication Methods page. If you want to set up this authentication method but not enable it immediately, clear the checkbox. <i>Note: You can enable NIS here or on the first User Authentication page. If you enable NIS here, it automatically displays at the end of the order of precedence on the User Authentication page.</i>
NIS Domain	The NIS domain of the EMG must be the same as the NIS domain of the NIS server.
Broadcast for NIS Server	If selected, the EMG unit sends a broadcast datagram to find the NIS Server on the local network.
NIS Master Server	The IP address or host name of the master server.
NIS Slave Servers #1 -5	The IP addresses or host names of up to five slave servers.
Custom Menu	If custom menus have been created you can assign a default custom menu to NIS users.
Escape Sequence	A single character or a two-character sequence that causes the EMG to leave direct (interactive) mode. (To leave listen mode, press any key.) A suggested value is Esc+A (escape key, then uppercase "A" performed quickly but not simultaneously). You would specify this value as \x1bA , which is hexadecimal (\x) character 27 (1B) followed by an A . This setting allows the user to terminate the <code>connect direct</code> command on the command line interface when the endpoint of the command is deviceport, tcp, or udp. See Key Sequences for notes on key sequence precedence and behavior.
Break Sequence	A series of 1-10 characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as \x1bB , which is hexadecimal (\x) character 27 (1B) followed by a B .
Enable for Dial-back	Select to grant a user Dial-back . Users with dial-back access can dial into the EMG and enter their login and password. Once the EMG unit authenticates them, the modem hangs up and dials them back. Disabled by default.
Dial-back Number	The phone number the modem dials back on depends on this setting for the device port. The user is either dialed back on a fixed number, or on a number that is associated with the user's login (specified here).
Data Ports	The ports users are able to monitor and interact with using the <code>connect direct</code> command. Enter the port numbers or the range of port numbers (for example, 1, 5, 8, 10-15). U1 denotes the USB port on the front of the EMG unit.
Listen Ports	The ports users are able to monitor using the <code>connect listen</code> command.
Clear Port Buffers	The ports whose port buffer users may clear using the <code>set locallog clear</code> command.

3. In the **User Rights** section, select the user **Group** to which NIS users will belong:

Group	Select the group to which the NIS users will belong: ◆ Default Users: This group has only the most basic rights. You can specify additional rights for the individual user . ◆ Power Users: This group has the same rights as Default Users plus Web Access, Networking, Date/Time, Reboot & Shutdown, and Diagnostics & Reports. ◆ Administrators: This group has all possible rights.

4. Assign or unassign **User Rights** for the specific user by checking or unchecking the following checkboxes:

Full Administrative	Right to add, update, and delete all editable fields.
Networking	Right to enter Network settings.
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.
Secure Lantronix Network	Right to view and manage secure Lantronix units (e.g., EMG, or SLC units) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the EMG unit.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.
Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Ethernet Switch	Right to view and enter settings for the managed Ethernet Switch.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown.
Internal Modem	Right to update internal modem settings.
Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port settings.
USB	Right to enter modem settings for USB devices and control USB storage devices.
SD Card	Right to enter settings for SD card.
RPM	Right to manage and control remote power managers.

5. Click the **Apply** button.

Note: You must reboot the unit before your changes will take effect.

NIS Commands

Go to [NIS Commands](#) to view CLI commands which correspond to the web page entries described above.

LDAP

The system administrator can configure the EMG to use LDAP to authenticate users attempting to log in using the Web, Telnet, SSH, or the console port.

LDAP allows EMG unit users to authenticate using a wide variety of LDAP servers, such as OpenLDAP and Microsoft Active Directory. The LDAP implementation supports LDAP servers that do not allow anonymous queries.

Users who are authenticated through LDAP are granted device port access through the port permissions on this page.

All LDAP users are members of a group that has predefined user rights associated with it. You can add additional user rights that are not defined by the group.

To configure the EMG unit to use LDAP to authenticate users:

1. Click the **User Authentication** tab and select **LDAP**. The following page displays.

Figure 14-6 User Authentication > LDAP

LANTRONIX® EMG851300

Logout Host: emgcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services **User Authentication** Devices Maintenance Quick Setup

Auth Methods Local/Remote Users NIS LDAP **RADIUS** Kerberos TACACS+ Groups SSH Keys Custom Menus

LDAP Help ?

Enable LDAP: ☐

Server #1:

Server #2:

Port:

Base:
(example: dc=domain,dc=com)

Bind Name: Custom Menu:

Bind Password: Escape Sequence:

Retype Password: Break Sequence:

Bind with Login: ☐ 'login' in the Bind Name will be substituted with the login

User Login Attribute: Enable for Dial-back: ☐

Group Filter Objectclass: Dial-back Number:

Group Member Attribute:

Group Member Value: ☒ DN ☐ Name

Use LDAP Schema: ☐ for User Attributes and Permissions

Active Directory Support: ☐

Encrypt Messages: ☒ Disabled ☐ Start TLS ☐ SSL

Certificate Authority: [Upload File >](#)

Certificate File: [Upload File >](#)

Key File: [Upload File >](#)

The EMG can be configured to use LDAP to authenticate users who login to the EMG via SSH, Telnet, the Web or the Console Port. If port permissions are not provided via LDAP Schema, LDAP users are granted Device Port access through the port permissions below.

User Rights

Group: ☒ Default Users ☐ Power Users ☐ Administrators

All LDAP users are members of a group which has predefined user rights associated with it. Additional rights which are not defined by the group can be added.

Full Administrative: ☐	Local Users: ☐	Firmware & Configuration: ☐
Networking: ☐	Remote Authentication: ☐	Internal Modem: ☐
Services: ☐	SSH Keys: ☐	Device Port Operations: ☐
Secure Lantronix Network: ☐	User Menus: ☐	Device Port Configuration: ☐
Date/Time: ☐	Web Access: ☐	USB: ☐
Reboot & Shutdown: ☐	Diagnostics & Reports: ☐	SD Card: ☐
RPMS: ☐	Ethernet Switch: ☐	

2. Enter the following:

Enable LDAP	Displays selected if you enabled this method on the first User Authentication page. If you want to set up this authentication method but not enable it immediately, clear the checkbox.
Server #1 (or Server #2)	The IPv4 or IPv6 address or host name of the primary and secondary LDAP servers. The secondary LDAP server will be used for authentication in the event that the primary LDAP server cannot be reached.
Port	Number of the TCP port on the LDAP server to which the EMG talks. The default is 389 .
Base	The name of the LDAP search base (e.g., dc=company, dc=com). May have up to 80 characters.
Bind Name	The name for a non-anonymous bind to an LDAP server. This item has the same format as LDAP Base. One example is cn=administrator,cn=Users,dc=domain,dc=com
Bind Password / Retype Password	Password for a non-anonymous bind. This entry is optional. Acceptable characters are a-z , A-Z , and 0-9 . The maximum length is 127 characters.
Bind with Login	Select to bind with the login and password that a user is authenticating with. This requires that the Bind Name contain the \$login token, which will be replaced with the current login. For example, if the Bind Name is uid=\$login,ou=People,dc=lantronix,dc=com, and user roberts logs into the EMG, LDAP will bind with uid=roberts,ou=People,dc=lantronix,dc=com and the password entered by roberts.
User Login Attribute	The attribute used by the LDAP server for user logins. If nothing is specified for the user filter, the EMG unit will use "uid". For AD LDAP servers, the attribute for user logins is typically "sAMAccountName".
Group Filter Objectclass	The objectclass used by the LDAP server for groups. If nothing is specified for the group filter, the EMG will use "posixGroup". For AD LDAP servers, the objectclass for groups is typically "Group".
Group Member Attribute	The attribute used by the LDAP server for group membership. This attribute may be used to search for a name (ie, "msmith") or a Distinguished Name (ie, "uid=msmith,ou=People,dc=lantronix,dc=com"). Select either Name or DN as appropriate for the LDAP server. If nothing is specified for the group membership attribute, the EMG unit will use "memberUID" for name and "uniqueMember" for DN. For AD LDAP servers, the Group Membership Value is typically DN, with the Group Membership Attribute of "member".
Group Member Value	The attribute used by the LDAP server for group membership. This attribute may be used to search for a name (ie, "msmith") or a Distinguished Name (ie, "uid=msmith,ou=People,dc=lantronix,dc=com"). Select either Name or DN as appropriate for the LDAP server. If nothing is specified for the group membership attribute, the EMG will use "memberUID" for name and "uniqueMember" for DN. For AD LDAP servers, the Group Membership Value is typically DN, with the Group Membership Attribute of "member".
Use LDAP Schema	Select the check box to obtain remote user attributes (group/permissions and port access) from an Active Directory server's scheme via the user attribute 'Secure LantronixPerms' (see details below). Disabled by default.
Active Directory Support	Select to enable. Active Directory is a directory service from Microsoft that is a part of Windows 2000 and later versions of Windows. It is LDAP- and Kerberos-compliant. Disabled by default.

Encrypt Messages	Select Start TLS or SSL to encrypt messages between the EMG unit and the LDAP server. If Start TLS is selected, the port will automatically be set to 389 and the StartTLS extension will be used to initiate a secure connection; if SSL is selected, the port will automatically be set to 636 and a SSL tunnel will be used for LDAP communication. The port number can be changed to a non-standard LDAP port; if the port number is set to anything other than 636, Start TLS will be used as the encryption method. Disabled by default.
Certificate Authority	A certificate can be uploaded to the EMG unit for peer authentication. The uploaded certificate may contain a Certificate Authority file, a Certificate file (with an optional Key file), or both. A Key file alone is not a valid certificate. The Certificate Authority and Certificate File are in PEM format, for instance: -----BEGIN CERTIFICATE----- (certificate in base64 encoding) -----END CERTIFICATE----- The Key File is in PEM format, eg: -----BEGIN RSA PRIVATE KEY----- (private key in base64 encoding) -----END RSA PRIVATE KEY-----
Certificate File	
Key File	
Custom Menu	If custom menus have been created, you can assign a default custom menu to LDAP users. (See Custom Menus)
Escape Sequence	A single character or a two-character sequence that causes the EMG to leave direct (interactive) mode. (To leave listen mode, press any key.) A suggested value is Esc+A (escape key, then uppercase "A" performed quickly but not simultaneously). You would specify this value as \x1bA , which is hexadecimal (\x) character 27 (1B) followed by an A . This setting allows the user to terminate the <code>connect direct</code> command on the command line interface when the endpoint of the command is deviceport, tcp, or udp. See Key Sequences for notes on key sequence precedence and behavior.
Break Sequence	A series of 1-10 characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as \x1bB , which is hexadecimal (\x) character 27 (1B) followed by a B .
Enable for Dial-back	Select to grant a user dial-back access. Users with dial-back access can dial into the EMG unit and enter their login and password. Once the EMG authenticates them, the modem hangs up and dials them back. Disabled by default.
Dial-back Number	The phone number the modem dials back on depends on this setting for the device port. The user is either dialed back on a fixed number, or on a number that is associated with the user's login (specified here).
Data Ports	The ports users are able to monitor and interact with using the <code>connect direct</code> command. U1 denotes the USB port on the front of the EMG unit.
Listen Ports	The ports users are able to monitor using the <code>connect listen</code> command.
Clear Port Buffers	The ports whose port buffer users may clear using the <code>set locallog clear</code> command.

3. In the **User Rights** section, select the user group to which LDAP users will belong:

Group	Select the group to which the LDAP users will belong: ◆ Default Users: This group has only the most basic rights. You can specify additional rights for the individual user. ◆ Power Users: This group has the same rights as Default Users plus Web Access, Networking, Date/Time, Reboot & Shutdown, and Diagnostics & Reports. ◆ Administrators: This group has all possible rights.

4. Select or clear the checkboxes for the following rights:

Full Administrative	Right to add, update, and delete all editable fields.
Networking	Right to enter Network settings.
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.
Secure Lantronix Network	Right to view and manage secure Lantronix units (e.g., EMG, or SLC devices) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the EMG unit.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.
Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Ethernet Switch	Right to view and enter settings for the managed Ethernet Switch.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown .
Internal Modem	Right to configure internal modem settings.
Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port configurations.
USB	Right to enter modem settings for USB.
SD Card	Right to view and enter settings for SD card.
RPM	Right to manage and control remote power managers.

5. Click the **Apply** button.

Note: You must reboot the unit before your changes will take effect.

LDAP Commands

Go to [LDAP Commands](#) to view CLI commands which correspond to the web page entries described above.

RADIUS

The system administrator can configure the EMG to use RADIUS to authenticate users attempting to log in using the Web, Telnet, SSH, or the console port.

Users who are authenticated through RADIUS are granted device port access through the port permissions on this page.

All RADIUS users are members of a group that has predefined user rights associated with it. You can add additional user rights that are not defined by the group.

To configure the EMG unit to use RADIUS to authenticate users:

1. Click the **User Authentication** tab and select **RADIUS**. The following page displays.

Figure 14-7 User Authentication > RADIUS

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for: ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services **User Authentication** Devices Maintenance Quick Setup

Auth Methods Local/Remote Users NIS LDAP **RADIUS** Kerberos TACACS+ Groups SSH Keys Custom Menus

RADIUS Help ?

Enable RADIUS: ☐

The EMG can be configured to use RADIUS to authenticate users who login to the EMG via SSH, Telnet, the Web or the Console Port. RADIUS users are granted Device Port access through the port permissions below.

RADIUS Server #1:
 Server #1 Port:
 Server #1 Secret:
 Retype Secret:
 RADIUS Server #2:
 Server #2 Port:
 Server #2 Secret:
 Retype Secret:

Custom Menu:
 Escape Sequence:
 Break Sequence:
 Data Ports:
 Listen Ports:
 Clear Port Buffers:

Timeout: seconds
 Enable for Dial-back: ☐
 Use VSA: ☐ for User Attributes and Permissions
 Dial-back Number:

User Rights

All RADIUS users are members of a group which has predefined user rights associated with it. Additional rights which are not defined by the group can be added.

Group: ☒ Default Users ☐ Power Users ☐ Administrators

Full Administrative: ☐
 Networking: ☐
 Services: ☐
 Secure Lantronix Network: ☐
 Date/Time: ☐
 Reboot & Shutdown: ☐
 RPMs: ☐

Local Users: ☐
 Remote Authentication: ☐
 SSH Keys: ☐
 User Menus: ☐
 Web Access: ☐
 Diagnostics & Reports: ☐
 Ethernet Switch: ☐

Firmware & Configuration: ☐
 Internal Modem: ☐
 Device Port Operations: ☐
 Device Port Configuration: ☐
 USB: ☐
 SD Card: ☐

2. Enter the following:

Enable RADIUS	Displays selected if you enabled this method on the User Authentication page. If you want to set up this authentication method but not enable it immediately, clear the checkbox. <i>Note: You can enable RADIUS here or on the first User Authentication page. If you enable RADIUS here, it automatically displays at the end of the order of precedence on the User Authentication page.</i>
RADIUS Server #1	IPv4 or IPv6 address or hostname of the primary RADIUS server. This RADIUS server may be a proxy for SecurID. SecurID is a two-factor authentication method based on the user's SecurID token and pin number. The SecurID token displays a string of digits called a token code that changes once a minute (some tokens are set to change codes every 30 seconds).
Server #1 Port	Number of the TCP port on the RADIUS server used for the RADIUS service. If you do not specify an optional port, the EMG unit uses the default RADIUS port (1812).
Server #1 Secret	Text that serves as a shared secret between a RADIUS client and the server (EMG unit). The shared secret is used to encrypt a password sent between the client and the server. May have up to 128 characters.
RADIUS Server #2	IPv4 or IPv6 address or host name of the secondary RADIUS server. This server can be used as a SecurID proxy.
Server #2 Port	Number of the TCP port on the RADIUS server used for the RADIUS service. If you do not specify an optional port, the EMG uses the default RADIUS port (1812).
Server #2 Secret	Text that serves as a shared secret between a RADIUS client and the server (EMG unit). The shared secret is used to encrypt a password sent between the client and the server. May have up to 128 characters.
Timeout	The number of seconds (1-30) after which the connection attempt times out. The default is 30 seconds.
Use VSA	Select the check box to obtain remote user attributes (group/permissions and port access) from the RADIUS server via the Vendor-Specific Attribute (VSA). For details on the format of the VSA, see User Attributes & Permissions from LDAP Schema or RADIUS VSA .
Custom Menu	If custom menus have been created, you can assign a default custom menu to RADIUS users.
Escape Sequence	A single character or a two-character sequence that causes the EMG unit to leave direct (interactive) mode. (To leave listen mode, press any key.) A suggested value is Esc+A (escape key, then uppercase "A" performed quickly but not simultaneously). You would specify this value as \x1bA , which is hexadecimal (\x) character 27 (1B) followed by an A . This setting allows the user to terminate the <code>connect direct</code> command on the command line interface when the endpoint of the command is <code>deviceport</code> , <code>tcp</code> , or <code>udp</code> . See Key Sequences for notes on key sequence precedence and behavior.
Break Sequence	A series of 1-10 characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as \x1bB , which is hexadecimal (\x) character 27 (1B) followed by a B .
Enable for Dial-back	Select to grant a user dial-back access. Users with dial-back access can dial into the EMG and enter their login and password. Once the EMG gateway authenticates them, the modem hangs up and dials them back. Disabled by default.

Dial-back Number	The phone number the modem dials back on depends on this setting for the device port. The user is either dialed back on a fixed number, or on a number that is associated with the user's login (specified here).
Data Ports	The ports users are able to monitor and interact with using the <code>connect direct</code> command. U1 denotes the USB port on the front of the EMG unit.
Listen Port	The ports users are able to monitor using the <code>connect listen</code> command.
Clear Port Buffers	The ports whose port buffer users may clear using the <code>set locallog clear</code> command.

Note: Older RADIUS servers may use **1645** as the default port. Check your RADIUS server configuration.

3. In the **User Rights** section, select the user group to which RADIUS users will belong.

Group	Select the group to which the RADIUS users will belong: ◆ Default Users: This group has only the most basic rights. You can specify additional rights for the individual user. ◆ Power Users: This group has the same rights as Default Users plus Web Access, Networking, Date/Time, Reboot & Shutdown, and Diagnostics & Reports. ◆ Administrators: This group has all possible rights.

4. Select or clear the checkboxes for the following rights:

Full Administrative	Right to add, update, and delete all editable fields.
Networking	Right to enter Network settings.
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.
Secure Lantronix Network	Right to view and manage Secure Lantronix units (e.g., EMG, or SLC units) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the EMG unit.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.
Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Ethernet Switch	Right to view and enter settings for the managed Ethernet Switch.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown .
Internal Modem	Right to update internal modem settings.
Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port settings.

USB	Right to enter modem settings for USB devices and control USB storage devices.
SD Card	Right to enter settings for SD card.
RPM	Right to manage and control remote power managers.

5. Click the **Apply** button.

RADIUS Commands

Go to [RADIUS Commands](#) to view CLI commands which correspond to the web page entries described above.

User Attributes & Permissions from LDAP Schema or RADIUS VSA

Remote user attributes (group/permissions and port access) can be obtained from an Active Directory server's schema via the user attribute 'secureLinxSLCPerms', or from a RADIUS server's Vendor-Specific Attribute (see below). This attribute is a set of parameter-value pairs. Each parameter and value is separated by a space, and a space separates each parameter-value pair. Whitespace is not supported in the value strings. The parameters that are supported are:

- ◆ **rights** - User rights. The value string is a comma-separated list of two letter user permissions. Example: "nt,wb,ra".
- ◆ **data** - Data port access. The value string specifies the list of ports the user has 'direct' access to. Example: "2,4-18,U1".
- ◆ **listen** - Listen port access. The value string specifies the list of ports the user has 'listen' access to.
- ◆ **clear** - Clear port access. The value string specifies the list of port buffers the user has the right to clear.
- ◆ **group** - User group. Valid values for the value string are "default", "power", and "admin", and any EMG custom group name. If a custom group name is specified and it matches a current EMG custom group name, any rights attribute will be ignored, and the custom group's rights (permissions) will be used instead. A group name with spaces cannot be specified.
- ◆ **escseq** - Escape sequence. The value string specifies the user's escape sequence. Use "\x" to specify non-printable characters. For example, "\x1bA" specifies the sequence "ESC-A".
- ◆ **brkseq** - Break sequence. The value string specifies the user's break sequence.
- ◆ **menu** - Custom user menu. The value string specifies the user's custom user menu.
- ◆ **display** - Display custom user menu when a user logs into the CLI. Valid values for the value string are "yes" and "no".
- ◆ **dbnumber** - Dial-back number. The value string specifies the user's dial-back number for modem dial-back connections.
- ◆ **allowdb** - Allow a user to have dial-back access. Valid values for the value string are "yes" and "no".

RADIUS servers will need to be configured to support the Lantronix Vendor-Specific Attribute. For example, on a FreeRADIUS server, the dictionary will need be updated with the Lantronix definition by including the contents below in a file named *dictionary.lantronix*, and including it in the RADIUS server dictionary definitions by adding the appropriate `$INCLUDE` directive to the main dictionary file.

```
# dictionary.lantronix
#
# Lantronix Edge Management Gateway
# Provides EMG-specific user attributes
#
VENDOR Lantronix 244

BEGIN-VENDOR Lantronix

ATTRIBUTE Lantronix-User-Attributes 1 string

END-VENDOR Lantronix
```

Once this is complete, the users file can be updated to include the Lantronix VSA for any user:

```
myuser    Auth-Type := Local, User-Password == "myuser_pwd"
          Reply-Message = "Hello, %u",
          Lantronix-User-Attributes = "data 1-4 listen 1-6 clear 1-4
          group power"
```

Kerberos

Kerberos is a network authentication protocol that provides strong authentication for client/server applications by using secret-key cryptography.

The system administrator can configure the EMG to use Kerberos to authenticate users attempting to log in using the Web, Telnet, SSH, or the console port.

Users who are authenticated through Kerberos are granted device port access through the port permissions on this page.

All Kerberos users are members of a group that has predefined user rights associated with it. You can add additional user rights that are not defined by the group.

To configure the EMG to use Kerberos to authenticate users:

1. Click the **User Authentication** tab and select the **Kerberos** option. The following page displays.

Figure 14-8 User Authentication > Kerberos

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services **User Authentication** Devices Maintenance Quick Setup

Auth Methods Local/Remote Users NIS LDAP RADIUS **Kerberos** TACACS+ Groups SSH Keys Custom Menus

Kerberos Help ?

Enable Kerberos: ☐

Realm:

KDC:

KDC IP Address:

KDC Port:

Use LDAP: ☐

Note: If LDAP is used for user lookup, please configure the [LDAP settings](#).

The EMG can be configured to use Kerberos to authenticate users who login to the EMG via SSH, Telnet, the Web or the Console Port. Kerberos users are granted Device Port access through the port permissions below.

Custom Menu:

Escape Sequence:

Break Sequence:

Enable for Dial-back: ☐

Dial-back Number:

Data Ports:

Listen Ports:

Clear Port Buffers:

User Rights

☒ Default Users
Group: ☐ Power Users ☐ Administrators

All Kerberos users are members of a group which has predefined user rights associated with it. Additional rights which are not defined by the group can be added.

Full Administrative: ☐ Local Users: ☐ Firmware & Configuration: ☐

Networking: ☐ Remote Authentication: ☐ Internal Modem: ☐

Services: ☐ SSH Keys: ☐ Device Port Operations: ☐

Secure Lantronix Network: ☐ User Menus: ☐ Device Port Configuration: ☐

Date/Time: ☐ Web Access: ☐ USB: ☐

Reboot & Shutdown: ☐ Diagnostics & Reports: ☐ SD Card: ☐

RPMs: ☐ Ethernet Switch: ☐

2. Enter the following:

Enable Kerberos	Check box displays as checked if this method is enabled on the User Authentication page. If you want to set up this authentication method but not enable it immediately, clear the checkbox. Note: You can enable Kerberos here or on the first User Authentication page. If you enable Kerberos here, it automatically displays at the end of the order of precedence on the User Authentication page.
Realm	Enter the name of the logical network served by a single Kerberos database and a set of Key Distribution Centers. Usually, realm names are all uppercase letters to differentiate the realm from the Internet domain. Realm is similar in concept to an NT domain.
KDC	A key distribution center (KDC) is a server that issues Kerberos tickets. A ticket is a temporary set of electronic credentials that verify the identity of a client for a particular service. Enter the KDC in the fully qualified domain format (FQDN). An example is emg.local.
KDC IP Address	Enter the IPv4 or IPv6 address of the Key Distribution Center (KDC).
KDC Port	Port on the KDC listening for requests. Enter an integer with a maximum value of 65535. The default is 88 .
Use LDAP	Indicate whether Kerberos should rely on LDAP to look up user IDs and Group IDs. This setting is disabled by default. Note: Make sure to configure LDAP if you select this option.
Custom Menu	If custom menus have been created, you can assign a default custom menu to RADIUS users.
Escape Sequence	A single character or a two-character sequence that causes the EMG to leave direct (interactive) mode. (To leave listen mode, press any key.) A suggested value is Esc+A (escape key, then uppercase "A" performed quickly but not simultaneously). You would specify this value as \x1bA, which is hexadecimal (\x) character 27 (1B) followed by an A. This setting allows the user to terminate the <code>connect direct</code> command on the command line interface when the endpoint of the command is <code>deviceport</code>, <code>tcp</code>, or <code>udp</code>. See Key Sequences for notes on key sequence precedence and behavior.
Break Sequence	A series of 1-10 characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as \x1bB , which is hexadecimal (\x) character 27 (1B) followed by a B .
Enable for Dial-back	Select to grant a user dial-back access. Users with dial-back access can dial into the EMG and enter their login and password. Once the EMG unit authenticates them, the modem hangs up and dials them back. Disabled by default.
Dial-back Number	The phone number the modem dials back on depends on this setting for the device port. The user is either dialed back on a fixed number, or on a number that is associated with the user's login (specified here).
Data Ports	The ports users are able to monitor and interact with using the <code>connect direct</code> command. U1 denotes the USB port on the front of the EMG unit.
Listen Port	The ports users are able to monitor using the <code>connect listen</code> command.
Clear Port Buffers	The ports whose port buffer users may clear using the <code>set locallog clear</code> command.

3. In the **User Rights** section, select the user group to which Kerberos users will belong.

Group	Select the group to which the Kerberos users will belong: ◆ Default Users: This group has only the most basic rights. You can specify additional rights for the individual user. ◆ Power Users: This group has the same rights as Default Users plus Web Access, Networking, Date/Time, Reboot & Shutdown, and Diagnostics & Reports. ◆ Administrators: This group has all possible rights.

4. Select or clear the checkboxes for the following rights:

Full Administrative	Right to add, update, and delete all editable fields.
Networking	Right to enter Network settings.
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.
Secure Lantronix Network	Right to view and manage secure Lantronix units (e.g., EMG, or SLC units) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the EMG unit.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.
Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Ethernet Switch	Right to view and enter settings for the managed Ethernet Switch.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown.
Internal Modem	Right to update internal modem settings.
Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port settings.
USB	Right to enter modem settings for USB devices and control USB storage devices.
SD Card	Right to enter settings for SD card.
RPM	Right to manage and control remote power managers.

5. Click the **Apply** button.

Note: You must reboot the unit before your changes will take effect.

Kerberos Commands

Go to [Kerberos Commands](#) to view CLI commands which correspond to the web page entries described above.

TACACS+

Similar to RADIUS, the main function of TACACS+ is to perform authentication for remote access. The EMG supports the TACACS+ protocol (not the older TACACS or XTACACS protocols).

The system administrator can configure the EMG unit to use TACACS+ to authenticate users attempting to log in using the Web, Telnet, SSH, or the console port.

Users who are authenticated through TACACS+ are granted device port access through the port permissions on this page.

All TACACS+ users are members of a group with associated predefined user rights. You may add additional user rights that are not defined by the group.

TACACS+ Groups

This section describes how a `priv_lvl` assigned to a TACACS+ user can be mapped to a EMG custom [Groups](#), which will set the permissions and port rights for a TACACS+ user when they login to the EMG.

TACACS+ users are typically configured to have a privilege level 0-15, with each level representing a privilege level that is a superset of the next lower value. The privilege level can be assigned to individual users, or to groups that the user is a member of. When the EMG authenticates a TACACS+ user, it will first send an authentication request to the TACACS+ server, and wait for an authentication reply. If the user is successfully authenticated, the EMG will next send an authorization request to the TACACS+ server with the **Service** and optional **Protocol**. The EMG will wait for an authorization response that will indicate if the user was successfully authorized for the requested service and protocol, and also contains a set of attribute-value pairs which define the attributes associated with the TACACS+ user.

The **priv_lvl** or **priv-lvl** is the only attribute sent from the TACACS+ server that the EMG will recognize and utilize. The privilege level number will be used to map to a EMG custom user group by finding a group with a name that ends in the same number as the `priv_lvl`. For example, a EMG group called "admin15" will map to any TACACS+ users with `priv_lvl` equal to 15; a EMG group called "manager8" will map to any TACACS+ users with `priv_lvl` equal to 8, and a EMG group called "readonly0" will map to any TACACS+ users with `priv_lvl` equal to 0. If two EMG groups ending with the same number exist, the EMG will select the first matching group it finds while searching the group list; for consistency it is recommended that only one EMG group exist for each `priv_lvl`.

When a TACACS+ user authenticates to the EMG, the Authentication Log will record any `priv_lvl` attribute-value pair returned by the TACACS+ server:

```
Sep 21 15:44:38 2017 slc431d SLC-SLB/x15login[2839]:  
pam_sm_authenticate: server returned attribute `PRIV_LVL=14'
```

Any `priv_lvl` obtained for a TACACS+ user can also be viewed at the CLI with the `show user` command.

To configure the EMG unit to use TACACS+ to authenticate users:

1. Click the **TACACS+** tab and select **TACACS+**. The following page displays.

Figure 14-9 User Authentication > TACACS+

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services **User Authentication** Devices Maintenance Quick Setup

Auth Methods Local/Remote Users NIS LDAP RADIUS Kerberos **TACACS+** Groups SSH Keys Custom Menus

TACACS+ Help ?

Enable TACACS+ ☐

The EMG can be configured to use TACACS+ to authenticate users who login to the EMG via SSH, Telnet, the Web or the Console Port. TACACS+ users are granted Device Port access through the port permissions below.

TACACS+ Server #1:

TACACS+ Server #2:

TACACS+ Server #3:

Port:

Secret:

Retype Secret:

Encrypt Messages: ☒

Authentication Service: ☐ ASCII Login ☒ PPP/PAP ☐ PPP/CHAP

Service:

Protocol:

Timeout: seconds

Source IPv4 Address:

Source IPv6 Address:

Custom Menu:

Escape Sequence:

Break Sequence:

Enable for Dial-back: ☐

Dial-back Number:

Data Ports:

Listen Ports:

Clear Port Buffers:

Access Outlets:

User Rights

☒ Default Users
Group: ☐ Power Users ☐ Administrators

All TACACS+ users are members of a group which has predefined user rights associated with it. Additional rights which are not defined by the group can be added.

Full Administrative: ☐ Local Users: ☐ Firmware & Configuration: ☐

Networking: ☐ Remote Authentication: ☐ Internal Modem: ☐

Services: ☐ SSH Keys: ☐ Device Port Operations: ☐

Secure Lantronix Network: ☐ User Menus: ☐ Device Port Configuration: ☐

Date/Time: ☐ Web Access: ☐ USB: ☐

Reboot & Shutdown: ☐ Diagnostics & Reports: ☐ SD Card: ☐

RPMs: ☐ Ethernet Switch: ☐ Power Outlets: ☐

2. Enter the following:

Enable TACACS+	Displays selected if you enabled this method on the User Authentication page. If you want to set up this authentication method but not enable it immediately, clear the checkbox. You can enable TACACS+ here or on the first User Authentication page. If you enable TACACS+ here, it automatically displays at the end of the order of precedence on the User Authentication page.
TACACS+ Servers 1-3	IPv4 or IPv6 address or host name of up to three TACACS+ servers.
Port	Number of the TCP port on the TACACS+ server to which the EMG talks. The default is 49.
Secret/Retype Secret	Shared secret for message encryption between the EMG and the TACACS+ server. Enter an alphanumeric secret of up to 127 characters.
Encrypt Messages	Select the checkbox to encrypt messages between the EMG unit and the TACACS+ server. Selected by default.
Authentication Service	The type of service used to pass the authentication tokens (e.g., login and password) between the EMG and the TACACS+ server. Options are: ASCII Login (login and password are transmitted in clear, unencrypted text), PPP/PAP (login and password are transmitted in clear, unencrypted text via a PAP protocol packet), and PPP/CHAP (the TACACS+ server sends a challenge that consists of a session ID and an arbitrary challenge string, and the user name and password are encrypted before they are sent back to the server). PPP/PAP is the default.
Service	The service to use when sending a TACACS+ authorization message to the server to obtain an authenticated user's priv_lvl. The priv_lvl is used to assign a EMG custom group to the authenticated user for permissions and port rights (see TACACS+ Groups). Suggested values are "slip", "ppp", "arap", "shell", "tty-daemon", "connection", "system" and "firewall". The default is "shell".
Protocol	The optional protocol associated with the Service, which is included in the TACACS+ authorization message sent to the server to obtain an authenticated user's priv_lvl. The priv_lvl is used to assign a EMG custom group to the authenticated user for permissions and port rights (see TACACS+ Groups). Suggested values are "lcp", "ip", "ipx", "atalk", "vines", "lat", "xremote", "tn3270", "telnet", "rlogin", "pad", "vpdn", "ftp", "http", "deccp", "osicp" and "unknown".
Timeout	The timeout in seconds when attempting to connect to a TACACS+ server. Timeout range is 1 to 10 seconds. 5 seconds is the default.
Source IPv4 Address	The Source IPv4 Address can be used to configure which interface (and source IPv4 address) is used for sending TACACS+ packets. By default, the source IP address for sending TACACS+ traffic is not specified, and the source address of a TACACS+ packet is selected according to the routing table. Source IPv4 Address can be used to select the IPv4 address of Eth1, Eth2, Veth1 or Veth2 as the source IPv4 address for packets sent to all TACACS+ servers defined with an IPv4 address or a name which resolves to an IPv4 address. Before selecting an interface, make sure the interface is enabled and has a valid IPv4 address.
Source IPv6 Address	The Source IPv6 Address can be used to configure which interface (and source IPv6 address) is used for sending TACACS+ packets. By default, the source IP address for sending TACACS+ traffic is not specified, and the source address of a TACACS+ packet is selected according to the routing table. Source IPv6 Address can be used to select the IPv6 address of Eth1, Eth2, Veth1 or Veth2 as the source IPv6 address for packets sent to all TACACS+ servers defined with an IPv6 address or a name which resolves to an IPv6 address. Before selecting an interface, make sure the interface is enabled and has a valid IPv6 address.
Custom Menu	If custom menus have been created (see Custom User Menu Commands), you can assign a default custom menu to TACACS+ users.

Escape Sequence	A single character or a two-character sequence that causes the EMG to leave direct (interactive) mode. (To leave listen mode, press any key.) A suggested value is Esc+A (escape key, then uppercase "A" performed quickly but not simultaneously). You would specify this value as \x1bA, which is hexadecimal (\x) character 27 (1B) followed by an A. This setting allows the user to terminate the <code>connect direct</code> command on the command line interface when the endpoint of the command is <code>deviceport</code>, <code>tcp</code>, or <code>udp</code>.
Break Sequence	A series of 1-10 characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as \x1bB, which is hexadecimal (\x) character 27 (1B) followed by a B. See Key Sequences for notes on key sequence precedence and behavior.
Enable for Dial-back	Select to grant a user Dial-back access. Users with dial-back access can dial into the EMG unit and enter their login and password. Once the EMG authenticates them, the modem hangs up and dials them back. Disabled by default.
Dial-back Number	The phone number the modem dials back on depends on this setting for the device port. The user is either Dial-back on a fixed number, or on a number that is associated with the user's login (specified here).
Data Ports	The ports users are able to monitor and interact with using the <code>connect direct</code> command. U1 denotes the USB port on the front of the EMG unit.
Listen Ports	The ports users are able to monitor using the <code>connect listen</code> command.
Clear Port Buffers	The ports whose port buffer users may clear using the <code>set locallog clear</code> command.

3. In the **User Rights** section, select the user group to which TACACS+ users will belong.

Group	Select the group to which the TACACS+ users will belong: ◆ Default Users: This group has only the most basic rights. You can specify additional rights for the individual user. ◆ Power Users: This group has the same rights as Default Users plus Web Access, Networking, Date/Time, Reboot & Shutdown, and Diagnostics & Reports. ◆ Administrators: This group has all possible rights.

4. Select or clear the checkboxes for the following rights:

Full Administrative	Right to add, update, and delete all editable fields.
Networking	Right to enter Network settings.
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.
Secure Lantronix Network	Right to view and manage secure Lantronix units (e.g., EMG, or SLC units) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the EMG unit.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.

Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Ethernet Switch	Right to view and enter settings for the managed Ethernet Switch.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown .
Internal Modem	Right to update internal modem settings.
Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port settings.
USB	Right to enter modem settings for USB devices and control USB storage devices.
SD Card	Right to enter settings for SD card.
RPM	Right to manage and control remote power managers.

5. Click the **Apply** button.

Note: You must reboot the unit before your changes will take effect.

TACACS+ Commands

Go to [TACACS+ Commands](#) to view CLI commands which correspond to the web page entries described above.

Groups

The EMG has 3 pre-defined groups: Administrators, Power Users, and Default Users. Custom groups can also be created; each custom group is a set of user attributes and permissions. Local Users and Remote Users defined on the EMG unit can be assigned to one of the pre-defined groups or a custom group. When a user authenticates, if they belong to custom group, they will be granted the custom group attributes and permissions, rather than their individual attributes and permissions. The EMG supports querying a LDAP server for groups that a LDAP user is a member of; if any of the LDAP group names match a (Custom Group Name), the LDAP user will be granted the rights of the custom group.

A custom group cannot be given the name of one of the pre-defined groups: "Admin", "Power" or "Default" (or any version of these names where the case of the letters is different) since these names are used for the EMG pre-defined groups. Any LDAP group that matches one of these pre-defined group names will be ignored and not used to assign rights to a user.

To configure Groups in the EMG unit:

1. From the main menu, select **User Authentication - Groups**. The following page displays.

Note: If the fields in the lower part of the page have been populated by viewing another group, the fields can be cleared by selecting the Reset Group button.

Figure 14-10 User Authentication > Groups

LANTRONIX® EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for: ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services **User Authentication** Devices Maintenance Quick Setup

Auth Methods Local/Remote Users NIS LDAP RADIUS Kerberos TACACS+ Groups SSH Keys Custom Menus

Groups Help?

Note: when deleting a group, all users in the group will either be deleted or changed to the default group.

[View Group](#) [Delete Group](#)

Id	Name	Permissions	Esc Seq	Brk Seq	Custom Menu	DB	Listen	Data	Clear
Group Id: 0 Group Name: Listen Ports: 1-4,U1 Data Ports: 1-4,U1 Clear Port Buffers: 1-4,U1 Reset Group Add Group Edit Group Enable for Dial-back: ☐ Dial-back Number: Escape Sequence: \x1bA Break Sequence: \x1bB Custom Menu: <none> Display Menu at Login: ☒ Full Administrative: ☐ Local Users: ☐ Firmware & Configuration: ☐ Networking: ☐ Remote Authentication: ☐ Internal Modem: ☐ Services: ☐ SSH Keys: ☐ Device Port Operations: ☐ Secure Lantronix Network: ☐ User Menus: ☐ Device Port Configuration: ☐ Date/Time: ☐ Web Access: ☐ USB: ☐ Reboot & Shutdown: ☐ Diagnostics & Reports: ☐ SD Card: ☐ RPMs: ☐ Ethernet Switch: ☐									

2. Enter the following:

Group Name	Enter a name for the group.
Listen Ports	The ports users are able to monitor using the <code>connect listen</code> command.
Data Ports	The ports users are able to monitor and interact with using the <code>connect direct</code> command. U1 denotes the USB port on the front of the EMG unit.
Clear Port Buffers	The ports whose port buffer users may clear using the <code>set locallog clear</code> command.
Enable for Dial-back	Select to grant a user. Users with dial-back access can dial into the EMG unit and enter their login and password. Once the EMG authenticates them, the modem hangs up and dials them back. Disabled by default.
Dial-back Number	The phone number the modem dials back on depends on this setting for the device port. The user is either on a fixed number, or on a number that is associated with the user's login (specified here).

Escape Sequence	A single character or a two-character sequence that causes the EMG to leave direct (interactive) mode. (To leave listen mode, press any key.) A suggested value is Esc+A (escape key, then uppercase "A" performed quickly but not simultaneously). You would specify this value as \x1bA, which is hexadecimal (\x) character 27 (1B) followed by an A. This setting allows the user to terminate the <code>connect direct</code> command on the command line interface when the endpoint of the command is <code>deviceport</code>, <code>tcp</code>, or <code>udp</code>.
Break Sequence	A series of one to ten characters users can enter on the command line interface to send a break signal to the external device. A suggested value is Esc+B (escape key, then uppercase "B" performed quickly but not simultaneously). You would specify this value as \x1bB, which is hexadecimal (\x) character 27 (1B) followed by a B.
Custom Menu	If custom menus have been created you can assign a default custom menu to the group. See Custom Menus for more information.
Display Menu at Login	Check the checkbox to display the menu at login.

3. Select or clear the checkboxes for the following rights:

Full Administrative	Right to add, update, and delete all editable fields.
Networking	Right to enter Network settings.
Services	Right to enable and disable system logging, SSH and Telnet logins, SNMP, and SMTP.
Secure Lantronix Network	Right to view and manage Secure Lantronix units (e.g., EMG, or SLC units) on the local subnet.
Date/Time	Right to set the date and time.
Reboot & Shutdown	Right to shut down and reboot the EMG unit.
Local Users	Right to add or delete local users on the system.
Remote Authentication	Right to assign a remote user to a user group and assign a set of rights to the user.
SSH Keys	Right to set SSH keys for authenticating users.
User Menus	Right to create a custom user menu for the CLI.
Web Access	Right to access Web-Manager.
Diagnostics & Reports	Right to obtain diagnostic information and reports about the unit.
Ethernet Switch	Right to view and enter settings for the managed Ethernet Switch.
Firmware & Configuration	Right to upgrade the firmware on the unit and save or restore a configuration (all settings). Selecting this option automatically selects Reboot & Shutdown .
Internal Modem	Right to update internal modem settings.
Device Port Operations	Right to control device ports.
Device Port Configuration	Right to enter device port settings.
USB	Right to enter modem settings for USB devices and control USB storage devices.
SD Card	Right to enter settings for SD card.
RPM	Right to manage and control remote power managers.

4. Click the **Add Group** button.

To view or update a group:

1. In the **Groups** table, select the group and click the **View Group** button. The group attributes and permissions will be displayed in the lower section of the page.
2. Modify the group attributes and permissions and click the **Edit Group** button.

To delete a group:

1. Select the group in the **Groups** table.
2. Click the **Delete Group** button.

Group Commands

Go to [Groups Commands](#) to view CLI commands which correspond to the web page entries described above.

SSH Keys

Overview

The EMG can import and export SSH keys to facilitate shared key authentication for all incoming and outgoing SSH connections. By using a public/private key pair, a user can access multiple hosts with a single passphrase, or, if a passphrase is not used, a user can access multiple hosts without entering a password. In either case, the authentication is protected against security attacks because both the public key and the private key are required to authenticate. For both imported and exported SSH keys, the EMG unit supports RSA keys, and can import and export keys in OpenSSH and SECSH formats. Imported and exported keys are saved with the EMG configuration, and the administrator has the option of retaining the SSH keys during a reset to factory defaults.

The EMG unit can also update the SSH RSA host keys that the SSH server uses with site-specific host keys or reset them to the default values.

Imported Keys

Imported SSH keys can be used for EMG local users, NIS users, and LDAP users. The key can be generated on host "MyHost" for user "MyUser," and when the key is imported into the EMG unit, it must be associated with either "MyUser" (if "MyUser" is an existing EMG local user) or an alternate EMG local user, NIS user, or LDAP user. Once imported, the key can be used to access the console manager from any host, not just the host associated with the key. The public key file can be imported via SCP, SFTP, or FTP; once imported, you can view or delete the public key. Any SSH connection into the EMG unit from the designated host/user combination uses the SSH key for authentication.

Exported Keys

The EMG can generate SSH keys for SSH connections out of the EMG for any EMG user. The EMG retains both the private and public key on the EMG unit, and makes the public key available for export via SCP, SFTP, FTP, or copy and paste. The name of the key is used to generate the name of the public key file that is exported (for example, <keyname>.pub), and the exported keys are organized by user and key name. Once a key is generated and exported, you can delete the

key or view the public portion. Any SSH connection out of the EMG for the designated host/user combination uses the SSH key for authentication.

Create an SSH Key

The EMG can import and export SSH keys to facilitate shared key authentication (or public key authentication) for all incoming and outgoing SSH connections. A public-private key pair is generated on a host that is the SSH client (both keys should be stored secure manner), and the public key is imported into the host that the user wants to SSH to, eg, the SSH server.

An example of how to create a 3072 bit RSA SSH key on a Linux host:

```
% ssh-keygen -t rsa -b 3072
Generating public/private rsa key pair.
Enter file in which to save the key (/home/username/.ssh/id_rsa):
Enter passphrase (empty for no passphrase):
Enter same passphrase again:
Your identification has been saved in /home/username/.ssh/id_rsa.
Your public key has been saved in /home/username/.ssh/id_rsa.pub.
The key fingerprint is:
SHA256:cCWA3ydbTYUAqPtJQ3I8UY7Cyhieri5zNbB56Cc27z0 username@emg0000
The key's randomart image is:
+---[RSA 3072]-----+
|      ..++..o. o.   |
|      .. oo o o     |
|      o+ooo o      |
|      .+o.o.*oo o . |
|      .oo= = .S=    |
|      . + = o .     |
|      o o + o       |
|      + * ..E       |
|      += *o ..      |
+-----[SHA256]-----+
```

It is recommended to use secure bit sizes (-b); for example, at least 2048 bits for RSA keys. The passphrase is optional, and will be used to encrypt the key. Once the key is generated, add the contents of the id_rsa.pub file into the user's .ssh/authorized_keys file on the SSH server.

The EMG can import keys generated by OpenSSH or keys in SECSH format (a format used by other SSH tools); when importing a key in SECSH format it will automatically be converted to OpenSSH format, and require the user to specify the user and host if this is not included with the key file. For example, the public key below from a public-private key pair generated by PuTTY can be imported into the EMG, but will require the user and host associated with the key to be specified:

```
---- BEGIN SSH2 PUBLIC KEY ----
Comment: "rsa-key-20200320"
AAAAB3NzaC1yc2EAAAABJQAAAQEA37tfnOKNcMPLFOA69gPhVk5A1ieKCPywwK
uQsyMG0dCeFabfgtFu5WwnYZG9IzvWR12KTCfOz18EYisUyldoONmsHLf+TNwrho
ktI/Vfq+V4oh9u6Oz/6AI40XqmO3LxEDF1sMqA19+uE30sU0kxvbrEYYsAHk9KLH
QZj/w/2f5Ftg18yL2kxbNEAfqLYjB/FV62SJ5ne+1/1HI2Ave1gsp0P9Lr9TbJq3
r8rnZWylisX0f2OGsLehA3ummcSEevwsE2HiPeo2C+oBM8tTPztJEIBv8dtzidH0
gPh4ZRB0Ur2nnMCCCsJ1NLFZ+cV0i7GwTCcm/+rix8O6H1b16w==
---- END SSH2 PUBLIC KEY ----
```

[SSH/Telnet/Logging on page 166](#) provides information on enabling 'Require SSH Public Key for Authentication'. If enabled, the remote user needs a public key in addition to a password to login to the EMG.

To configure the EMG unit to use SSH keys to authenticate users:

1. From the main menu, select **User Authentication - SSH Keys**. The following page displays.

Figure 14-11 User Authentication > SSH Keys

LANTRONIX® EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services **User Authentication** Devices Maintenance Quick Setup

Auth Methods Local/Remote Users NIS LDAP RADIUS Kerberos TACACS+ Groups SSH Keys Custom Menus

SSH Keys [Help ?](#)

[SSH Server/Host Keys >](#)

Imported Keys (SSH In)
Host & User Associated with Key
(not required if host and EMG Local User login are declared in imported key file, ignored if file contains multiple keys)

Host:
User:

Host & Login for Import
Import via: [Upload File >](#)
Public Key:
Host:
Path:
Login:
Password:
Retype Password:

Imported SSH Keys		
User	Host	Type
View Delete		

Exported Keys (SSH Out)

Export: ☒ New Key for User ☐ All Previously Created Keys
User:
Key Name:
Key Type: ☒ RSA ☐ ECDSA
Number of Bits:
Passphrase:
Retype Passphrase:
SECSH Format: ☐
Public Key Filename:

Host & Login for Export
Export via:
Host:
Path:
Login:
Password:
Retype Password:

Exported SSH Keys		
User	Key Name	Type
View Download Delete		

[Apply](#)

2. Enter the following information:

Imported Keys (SSH In)

Host & User Associated with Key

These entries are required in the following cases:

- ◆ The imported key file does not contain the host that the user will be making an SSH connection from, or
- ◆ The EMG local user login for the connection is different from the user name the key was generated from or is not included in the imported key file, or
- ◆ The imported key file contains multiple keys; in this case, each key must include the user name and host at the end of the line in the standard `<key> <user name>@<host>` format.

If any of these conditions are true, or the imported file is in SECSH format, then you must specify the user and host.

Host & Login for Import

Host	The host name or IP address which will be associated with the SSH Key, typically the host that the key was generated on. Once imported, the key can be used to access the EMG from any host, not just the host associated with the key.
User	The User ID of the user being given secure access to the EMG unit.
Import via	Select SCP , SFTP , FTP , HTTPS , or Copy/Paste as the method for importing the SSH keys. SCP is the default. If SCP, SFTP or FTP are selected, the Filename, Host, Path, Login, and Password fields are filled in. If HTTPS is selected, the Upload File link will become active to upload a file containing a public key to the EMG. If Copy/Paste is selected, the public key will be entered into the Filename/ Public Key field.
Filename Public Key	The name of the file that was uploaded via HTTPS, or to be copied via SCP, SFTP or FTP (may contain multiple keys); or the public key (optionally including "user@host" at the end) if Copy/Paste is used.
Host	IP address of the remote server from which to SCP, SFTP or FTP the public key file.
Path	Optional pathname to the public key file.
Login	User ID to use to SCP, SFTP or FTP the file.
Password / Retype Password	Password to use to SCP, SFTP or FTP the file.

Exported Keys (SSH Out)

Note: Only RSA and ECDSA keys are supported.

Export	Enables you to export created public keys. Select one of the following: ◆ New Key for User: Enables you to create a new key for a user and export the public key in a file. ◆ All Previously Created Keys: Does not create any keys, but exports all previously created public keys in one file.
User	User ID of the person given secure access to the remote server.
Key Name	Name of the key. This will generate the public key filename (e.g., <keyname>.pub).
Key Type	Select either the RSA or the ECDSA encryption standard. RSA is the default.

Number of Bits	Select the number of bits in the key (1024, 2048, 3072 or 4096 for RSA and 256, 384 or 521 for ECDSA). The default for RSA is 2048 ; the default for ECDSA is 384 .
Passphrase / Retype Passphrase	Optionally, enter a passphrase associated with the key. The passphrase may have up to 50 characters. The passphrase is an optional password that can be associated with an SSH key. It is unique to each user and to each key. See Key Sequences for notes on key sequence precedence and behavior.
SECSH Format	Indicate whether the keys will be exported in SECSH format (by default the key is exported in OpenSSH format).
Public Key Filename	Filename of the public host key.

Host and Login for Export

Export via	Select the method (SCP , SFTP , FTP , HTTPS , or Copy/Paste) of exporting the key to the remote server. Copy/Paste , the default, requires no other parameters for export.
Host	IP address of the remote server to which the EMG will SCP, SFTP or FTP the public key file.
Path	Optional path of the file on the host to SCP, SFTP or FTP the public key too.
Login	User ID to use to SCP, SFTP or FTP the public key file.
Password / Retype Password	Password to use to SCP, SFTP or FTP the public key file.

To view or delete a key:

1. Select the key from the appropriate table. The **View** and **Delete** buttons become active.
2. To view the key, click the **View** button. A pop-up page displays the key.

Imported key for sysadmin@DaveSLM:
ssh-rsa AAAAB3NzaC1yc2EAAAABIwAAAIEAxGxPGY9HsG9VqroDo98B89Cf
haqB6jG//0tTMKkb3zrpPu0HHAXaiVXHAvv7lAte3lVTpoXdLAXN0uCvuJLf
aL/LvvGmoEWBUBSu505lQHfL70ijxZWOEVTJGFqUQTSq8Ls3/v3lkUJEX5ln
2AlQx0F40I5wNEC0+m3d5QE+FKc= sysadmin@DaveSLM

3. To delete the key, click the **Delete** button.

SSH Server/Host Keys

To view, reset, or import SSH RSA, ECDSA, and ED25519 host keys:

1. On the **User Authentication - SSH Keys** page, click the **SSH Server/Host Keys** link at the top right. The following page displays the current host keys. In the example below, the current keys are the defaults.

Figure 14-12 Current Host Keys

LANTRONIX® EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services **User Authentication** Devices Maintenance Quick Setup

Auth Methods Local/Remote Users NIS LDAP RADIUS Kerberos TACACS+ Groups SSH Keys Custom Menus

SSH Server/Host Keys [Help?](#)

Current Host RSA Public Key (Default Key)

```
ssh-rsa AAAAB3NzaC1yc2EAAAADAQABAAQAztsGvHdBaAS01NiBQWqqUKLUCab5DmdQritWhP120
NXnEwvVHD8KT2tABotgpB180s/uCvvaQvCCJuh55IuP19wP3N41/e4C0DYIqioLbz2t97EydD22/DhZa
eSp3rszVqrt2GpzEnSb6S3fjHrx/Qe11cr0pofmme01IG+Nmjbg70nJao9pu051z5zA/scW/ko+mDav4
3zEe/ofEz5rmgECni8QhIv71umcRbosA9tggMbHx2ASPVNELhK3Lfvp1lGz203JzK5Ed3p4B47Z4ENZ
KeakOfEwbxkvQjA3Wom11qJ0Hq09AmjuXVtV+KUPtJvfB3aW0ghdsIx3DPoB root@emgfcf0
```

Fingerprint:
2048 SHA256: Zi8/Un5hFKUve7Nz5tYQ/E8NeTcCMJA5L3XtrYxrMNY root@emgfcf0 (RSA)

Current Host ECDSA Public Key (Default Key)

```
ecdsa-sha2-nistp256 AAAAE2VjZHNhLXNoYTItbmlzdHAyNTYAAAAIbmlzdHAyNTYAAABBAIUzB3q
ydLah5AzuBB0LhZIDfAceZX9qy52Bqrpew9FF6kAQDYJFOXs8TaHw12n/x2mAMZwtKy8ujbQXK3nH0o=
root@(none)
```

Fingerprint:
256 SHA256: X575Ik3yVOZISZQxoPNdEPjPoD9AFentc0ko5nyh88Q root@(none) (ECDSA)

Current Host ED25519 Public Key (Default Key)

```
ssh-ed25519 AAAAC3NzaC1lZDI1NTE5AAAAIESNgVkgFjqZCVYvxFPx0Bil8NZVIWXMJFGNQdcnD0vy
root@(none)
```

Fingerprint:
256 SHA256: arnfU4qNvIg4ROMDr0tiqkd2E0kbSyT3dVsFPaJdVkw root@(none) (ED25519)

Reset to Default Host Key: ☐ All Keys ☐ RSA ☐ ECDSA ☐ ED25519

Note: changing a host key requires a reboot for the update to take effect.

Import Host Key: ☐

Type:

Import via:

Public Key Filename: [Upload File](#)

Private Key Filename: [Upload File](#)

Host:

Path:

Login:

Password:

Retype Password:

[Back to SSH Keys](#)

2. View or enter the following:

Reset to Default Host Key	Select the All Keys checkbox to reset all default key(s), or select one or more checkboxes to reset defaults for RSA , ECDSA , or ED25519 keys. All checkboxes are unselected by default.
Import Host Key	To import a site-specific host key, select the checkbox. Unselected by default.

Type	From the drop-down list, select the type of host key to import. The default is RSA .
Import via	From the drop-down list, select the method of importing the host key (SCP or SFTP). The default is SCP .
Public Key Filename	Filename of the public host key.
Private Key Filename	Filename of the private host key.
Host	Host name or IPAddress of the host from which to import the key.
Path	Path of the directory where the host key will be stored.
Login	User ID to use to SCP or SFTP the file.
Password / Retype Password	Password to use to SCP or SFTP the file.

3. Click the **Apply** button.
4. Repeat steps 2-3 for each key you want to import.
5. To return to the SSH Keys page, click the **Back to SSH Keys** link.

SSH Key Commands

Go to [SSH Key Commands](#) to view CLI commands that correspond to the web page entries described above.

Custom Menus

Users can have custom user menus as their command line interface, rather than the standard CLI command set. Each custom user menu can contain up to 50 commands ('logout' is always the last command). Instead of typing each command, the user enters the number associated with the command. Each command can also have a nickname associated with it, which can be displayed in the menu instead of the command. The commands `showmenu <Menu Name>` and `returnmenu` can be entered to display another menu from a menu, or to return to the prior menu. The command `returncli` can be used to break out of a menu and return to the regular CLI.

To add a custom menu:

1. Click the **User Authentication** tab and select the **Custom Menus** option. The Custom Menus page displays:

Figure 14-13 User Authentication > Custom Menus

The screenshot shows the LANTRONIX EMG851300 web interface. At the top, there's a header with the LANTRONIX logo and 'EMG851300'. Below that, a navigation bar includes 'Logout', 'Host: emgfcf0', 'User: sysadmin', and a 'Select port for' section with radio buttons for 'Configuration' (selected), 'WebSSH (DP only)', and 'Connected Device (DP only)'. The main navigation bar has tabs for 'Network', 'Services', 'User Authentication' (selected), 'Devices', 'Maintenance', and 'Quick Setup'. Under 'User Authentication', there are links for 'Auth Methods', 'Local/Remote Users', 'NIS', 'LDAP', 'RADIUS', 'Kerberos', 'TACACS+', 'Groups', 'SSH Keys', and 'Custom Menus' (selected). The 'Custom Menus' page has a 'Help ?' button. It features a table titled 'Custom Menu' with columns 'Name' and a radio button. The table lists 'Menu1' and 'Menu2'. To the right of the table are buttons: 'View Custom Menu', 'Delete Custom Menu', and 'Copy Custom Menu'. Below these is a 'New Menu Name:' input field. Further down, there's a form for creating a new menu with fields for 'Menu Name:', 'Title:', 'Nicknames:' (checked), and 'Redisplay Menu:' (unchecked). To the right of these fields are buttons: 'Clear Custom Menu', 'Add Custom Menu', and 'Edit Custom Menu'. Below the form is a 'Commands/Nicknames List' section. It has input fields for 'Command:' and 'Nickname:', a 'QuickEdit Mode:' checkbox (checked), and buttons for 'Delete Command & Nickname', 'Clear Command & Nickname', and 'Unselect Command & Nickname'. The 'Commands/Nicknames List' itself is a large text area containing 'logout(logout)' with up and down arrow buttons on the right side.

2. In the lower section of the page, enter the following:

Note: To clear fields in the lower part of the page, click the **Clear Custom Menu** button.

Menu Name	Enter a name for the custom menu.
Title	Enter an optional title which will be displayed about the menu at the CLI.
Nicknames	Select to enable nicknames to be displayed in the menu instead of the commands. If the custom menu will have nicknames, this should also be selected prior to entering the commands in the web page, as this will facilitate entry of the nicknames.
Redisplay Menu	Select to redisplay the custom menu each time before the CLI prompt is displayed.

3. You have the following options:

- To save the custom menu without any more commands than the default **logout** command, click the **Add Custom Menu** button.
- To add menu commands, select the **QuickEdit Mode** box. This will move the cursor from **Command** to **Nickname** and back to **Command** (if **Nicknames** is selected), or keep the cursor on **Command** (if **Nicknames** is not selected). Commands (and the optional nicknames) are added to the **Menu Commands/Nicknames** list when carriage return is entered at the **Command** field (if **Nicknames** is not selected) or the **Nickname** field (if **Nicknames** is selected). Most browsers have a "Select All" keystroke (such as Control-A) which allow you to select all of the text in a field; this can be used in conjunction with the Delete key to clear the contents of a field before entering a new command or nickname. The **Clear Command & Nickname** button can also be used to delete the contents of the Command and Nickname fields.

Commands can also be added to the list when **QuickEdit Mode** is not selected. Enter the command and the optional nickname and click the **right**  **arrow**. The command will be added before the logout command (if a command/nickname is not selected in the list) or will replace the currently selected command/nickname in the list. The **Unselect Command & Nickname** button can be used to unselect the currently selected command/nickname in the list.

4. To add more commands to the custom menu, repeat step 3.

5. You also have the following options:

- To edit a command/nickname in the custom menu, select the command in the **Commands/Nicknames List** box and select the **left**  **arrow** button. Change the command and/or the nickname, and with the same command still selected in the list, select the **right**  **arrow** button.
- To remove a command/nickname from the custom menu, select the command in the **Commands/Nicknames List** box and select the **Delete Command & Nickname** button.
- To move a command higher up in the menu (the commands are shown in the order they will be presented in the custom menu, with command #1 listed first), select the command in the **Commands/Nicknames List** box and click the **up**  **arrow**.
- To move a command further down in the menu, select the menu in the **Commands/Nicknames List** and click the **down**  **arrow**.

6. Click the **Add Custom Menu** button.

To view or update a custom menu:

1. In the **Custom Menus** table, select the custom menu and click the **View Custom Menu** button. The custom menu attributes appear in the lower part of the page.
2. Update the menu attributes following the instructions for adding a menu above.
3. Click the **Edit Custom Menu** button.

To delete a custom menu:

1. Select the custom menu in the **Custom Menus** table.
2. Click the **Delete Custom Menu** button.

To create a new custom menu from an existing custom menu:

1. Select the custom menu in the **Custom Menus** table.
2. Enter a name for the new menu in the **New Menu Name** field.
3. Click the **Copy Custom Menu** button.

Custom User Menu Commands

From the current menu, a user can display another menu, thus allowing menus to be nested. The special command `showmenu <Menu Name>` displays a specified menu. The special command `returnmenu` redisplay the parent menu if the current menu was displayed from a `showmenu` command.

The user with appropriate rights creates and manages custom user menus from the command line interface, but can assign a custom user menu to a user from either the command line or the web interface.

When creating a custom user menu, note the following limitations:

- ◆ Maximum of 20 custom user menus
- ◆ Maximum of 50 commands per custom user menu (`logout` is always the last command)
- ◆ Maximum of 15 characters for menu names
- ◆ Maximum of five nested menus can be called.
- ◆ No syntax checking (Enter each command correctly.)

Go to [Custom User Menu Commands](#) to view CLI commands which correspond to the web page entries described above.

15: Maintenance

The system administrator performs maintenance activities and operates the EMG using the options for the Maintenance tab and additional commands on the command line interface.

Firmware & Configurations

The Firmware & Configuration page allows the system administrator to:

- ◆ Configure the FTP, SFTP, or TFTP server that will be used to provide firmware updates and save/restore configurations. (TFTP is only used for firmware updates and configurations restored via the [Zero Touch Provisioning Configuration Restore feature](#).)
- ◆ Set up the location or method that will be used to save or restore configurations (Local Disk, FTP, SFTP, NFS, CIFS, USB, HTTPS or SD card). Update the version of the firmware running on the EMG unit.
- ◆ Save a snapshot of all settings on the EMG device (save a configuration).
- ◆ Restore the configuration, either to a previously saved configuration, or to the factory defaults. Factory defaults can also be initiated by using an external storage device. See [Factory Reset with External Storage Device](#).
- ◆ Configurations can also be pushed to the EMG via the [HTTPS Push Configuration Restore](#) feature.

Zero Touch Provisioning Configuration Restore

The Zero Touch Provisioning feature allows a factory defaulted EMG to acquire a default configuration from a DHCP server when it is booted. If ZTP will be performed in an untrusted network, it is recommended that the Vendor Specific Information option using HTTPS and X.509 certificates be used. At boot-time, before the normal startup process, a unit will attempt to acquire network parameters and a configuration file, first over Eth1, and then over Eth2 if Eth1 does not receive any configuration download information from the local DHCP server.

- ◆ The unit will send DHCP request over Eth1 and then over Eth2, with the following DHCP options:
 - **Vendor Specific Information** (option 43)
 - **TFTP Server IP address list** (option 150, a Cisco proprietary option)
 - **TFTP Server Name or IP address** (option 66)
 - **Boot Filename** (option 67)

For more information on these options see [RFC 2132](#) and [RFC 5859](#). To obtain Vendor Specific Information (VSI), the console manager sends a **Vendor Class Identifier** (option 60) of LantronixSLC8000 (for SLC8000 models) or **LantronixEMG** (for EMG models). The console manager will use VSI suboption 1 (see format below) to determine the location of the ZTP file.

- ◆ If the DHCP Offer received from a DHCP server contains multiple options, they will be utilized in this order:
 - a. Option **VSI/43** with suboption 1 (ZTP file location) will be used, and all other DHCP options will be ignored.

- b. Option **TFTP Server IP/150** and **Boot Filename/67** - if both of these are received, they will be used, and all other DHCP options will be ignored.
- c. Option **TFTP Server IP or Name/66** and **Boot Filename/67** - if both of these are received, they will be used.

Any configuration file specified by VSI/43 or Boot Filename/67 must be a valid console manager configuration filename ending in "-slccfg.tgz" (for SLC8000 console managers) or "-emgcfg.tgz" (for EMG console managers). For TFTP Server IP/150, the first IP address in the IP address list will be used; all other IP addresses will be ignored.

- ◆ **VSI/43 suboption 1 format:** the format of this suboption is a string consisting of tokens separated by spaces. Two tokens are supported: a URL indicating where to download the ZTP configuration file from, and the optional **validatecert** token. The URL can use the HTTPS, HTTP, FTP or TFTP protocol. The **validatecert** token indicates that the HTTPS protocol will be used and that a client side X.509 certificate and certificate authority files will be provided on an external USB drive or SD card; if the certificate files cannot be located, ZTP will terminate and not attempt to location a ZTP file with any other methods. The **preserve_ethname** token indicates that the current Eth1, Eth2, and hostname settings on EMG should be preserved and not over-written with the Eth1, Eth2 and hostname settings from the configuration being restored. Examples of suboption 1 strings are "ftp://ftpuser:ftpuser@myserver.mynetwork.com/ztp2-slccfg.tgz" and "https://10.0.1.131/config/ztp2-emgcfg.tgz validatecert".

For **validatecert**, 3 certificate files are required to be in the top level directory of an external storage device: **cacert.pem** (certificate authority file for validating the HTTPS server), **cert.pem** (client side certificate file), and **key.pem** (client side key file). The console manager will search external storage devices in this order: upper USB port, lower USB port (if present) and SD card. The first external storage device that is found and successfully mounted is expected to be the source for the certificate files; if they are not located in the top level directory, ZTP will terminate and not attempt to locate a ZTP file with any other methods. See [Creating a Certificate](#) for instructions to create a self-signed certificate with OpenSSL.

- ◆ If the console manager is able to download the configuration file, it will restore the configuration onto the console manager, and begin the normal startup process.
- ◆ If any of these steps fail for the Eth1 network port, it will repeat the process of trying to acquire a configuration over the Eth2 network port.
- ◆ After attempting to acquire a configuration over the Eth2 network port, the unit will begin the normal startup process.

Any results of attempting to acquire and restore a configuration file will be output to the console port and the system log. Configurations for firmware versions that are newer than the firmware version running on the unit will not be restored. Spaces are not supported in either the directory or filename portion of the Boot Filename path.

Creating a Certificate

To use OpenSSL to create a self signed root certificate authority, and use it to sign a client certificate that is used on the console manager and a server certificate that is installed in a web server responding to ZTP requests:

1. Setup OpenSSL environment: create a directory to store the OpenSSL configuration and certificate files. This step can be omitted if an existing OpenSSL configuration and directory will be used.
 - a. Create a new directory and copy existing openssl.cnf file (or create openssl.cnf):

```

cd /root
mkdir ztp-cert
cd ztp-cert
mkdir newcerts
cp /etc/ssl/openssl.cnf .
export OPENSSL_CONF=/root/ztp-cert/openssl.cnf

```

- b. Under the **CA_default** section in openssl.cnf, change the directory where everything is kept to ".":

```

[ CA_default ]
dir = . # Where everything is kept

```

- c. The openssl.cnf sections [req] and [req_distinguished_name] can be updated with specific options for certificate requests, or the defaults can be used.
- d. Create the index.txt and serial files, which act as a flat file database to keep track of signed certificates:

```

touch index.txt
echo 1000 > serial
echo 1000 > crlnumber

```

2. Create the root certificate:

- a. Create the root CA's private key (longer bit sizes such as 8192 can be used instead of 4096):

```
openssl genrsa -out ca.key 4096
```

- b. Create the root CA's certificate (the CN, or commonName, overrides the value in openssl.cnf, and can be set to any allowed certificate name):

```
openssl req -new -x509 -days 3650 -key ca.key -out cacert.pem -subj /CN=ztpExampleCA
```

- c. The cacert.pem file output in the previous step can be copied to the top level directory of the external storage device that will be used for ZTP. The certificate can be verified (e.g. view the algorithms, validity date and CN, etc) at anytime with the command:

```
openssl x509 -noout -text -in cacert.pem
```

3. Create the server certificate and sign it with the root certificate:

- a. Create the server certificate's private key (longer bit sizes such as 8192 can be used instead of 4096):

```
openssl genrsa -out server.key 4096
```

- b. Create the server certificate's Certificate Signing Request or CSR (the CN, or commonName, must match the IP address or name used in the URL to access the ZTP configuration file and cannot be the same as the CN of the root CA):

```
openssl req -new -key server.key -out server.csr -subj /CN=example.ztp.com
```

- c. Create the server certificate by signing the CSR with the root CA (**policy_match** can be used in place of **policy_anything** to use a different rule in openssl.cnf for controlling which attributes of a certificate are required to match those given in the CA; by default policy_anything requires that only a CN be specified):

```
openssl ca -days 365 -in server.csr -out server.crt -keyfile
ca.key -policy policy_anything -batch -notext
```

- d. The server.key file and server.crt file output in these steps can be installed in the web server that will provide the ZTP configuration file. The certificate can be verified (e.g. view the root CA, algorithms, validity date and CN, etc) at anytime with the command:

```
openssl x509 -noout -text -in server.crt
```

4. Create the client certificate and sign it with the root certificate:

- a. Create the client certificate's private key (longer bit sizes such as 8192 can be used instead of 4096):

```
openssl genrsa -out client.key 4096
```

- b. Create the client certificate's Certificate Signing Request or CSR (the CN, or commonName, cannot be the same as the CN of the root CA):

```
openssl req -new -key client.key -out client.csr -subj /
CN=ztpExampleClient
```

- c. Create the client certificate by signing the CSR with the root CA (**policy_match** can be used in place of **policy_anything** to use a different rule in openssl.cnf for controlling which attributes of a certificate are required to match those given in the CA; by default policy_anything requires that only a CN be specified):

```
openssl ca -days 365 -in client.csr -out client.crt -keyfile
ca.key -policy policy_anything -batch -notext
```

- d. The client.key file and client.crt file output in these steps can be copied to the top level directory of the external storage device that will be used for ZTP (rename client.key to key.pem and client.crt to cert.pem). The certificate can be verified (e.g. view the root CA, algorithms, validity date and CN, etc) at anytime with the command:

```
openssl x509 -noout -text -in client.crt
```

HTTPS Push Configuration Restore

The HTTPS Push Configuration feature allows a saved configuration to be pushed to a EMG via a command line tool such as "curl" that includes the configuration to upload:

```
% curl --insecure --request POST --form "file=@/home/users/admin/
current-emgcfg.tgz" 'https://myemg.company.com/
cfgupdate.htm?login=sysadmin&password=PASS&config=all&comment=FirmwareUp
date'
```

The configuration file name can have a maximum of 23 characters.

The arguments that are passed with the URL are:

- ◆ **login** - Login token to use for authentication. This must be a local user with firmware/config and reboot/shutdown rights.
- ◆ **password** - Clear text password for the login token.
- ◆ **config** - Indicates the portion of the configuration to restore, either all, or any combination of the following separated by commas: network, datetime, services, localusers, devports, usb, rpms, remoteauth, connections, events, ipfilter, groups, hostlist, nfscifs, maintenance, sites, scripts, slcnetwork, consoleport, menus, sshkeys, or sslcerts.
- ◆ **comment** - optional comment to include in the system log and audit log. If spaces are included in the comment they should be URL encoded as shown in this bash script:

```
#!/bin/bash

url="https://myemg.company.com/
cfgupdate.htm?login=sysadmin&password=PASS&config=all&comment=Update
myemg.company.com with default configuration"

curl --insecure --request POST --form "file=@/home/users/admin/current-
emgcfg.tgz" "$( echo $url | sed 's/ /%20/g' )"
```

If an HTTPS Push Config command is accepted and initiated by the EMG, the EMG will respond with "Configuration restore initiated; EMG will reboot.", the restore will be performed, a message will be logged to the audit log and the system log, and the EMG will reboot. Any errors in the process will result in an error message being displayed.

Factory Reset with External Storage Device

In the event that a reset to factory defaults cannot be performed via the web UI or CLI, a factory reset can be initiated by attaching an external storage device to the console manager with a file in the top level directory of the storage device:

1. Create a file called `FACTORY_DEFAULT` in the top level directory of a USB thumb drive or SD card. The file should contain one line with the MAC address of the Eth1 Ethernet port, with or without colons (case insensitive). If the file is created on a Windows device, the file type should be of type File and not a .txt or Text Document file type. Insert the storage device into the console manager.
2. Boot the console manager. After the message `Starting <model>...` the console manager will attempt to mount an external storage device. The console manager will search external storage devices in this order: upper USB port, lower USB port (if present) and SD card. The first external storage device that is found and successfully mounted is expected to be the source the `FACTORY_DEFAULT` file (any other external storage devices will be ignored). If it successfully mounts a storage device, and finds the appropriate `FACTORY_DEFAULT` file in the top level directory, it will perform a reset to factory defaults. The message `Detected factory reset file on external storage; performing factory reset.` will be displayed on the console.
3. The console manager will complete the boot process. Note that if the external storage device with the `FACTORY_DEFAULT` is left connected to the console manager and the console manager is rebooted, a reset to factory default will be performed again; it is recommended to remove the storage device after a reset to factory defaults.

To configure settings:

1. Click the **Maintenance** tab. The following page displays.

Figure 15-1 Maintenance > Firmware & Configurations

LANTRONIX[®] EMG851300

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices **Maintenance** Quick Setup

Firmware/Config System Log Audit Log Email Log Diagnostics Status/Reports Events Banners System Info

Firmware & Configurations [Help ?](#)

General

Reboot: ☐ Shutdown: ☐

Internal Temperature

Current: 49 °C / 120 °F

Low: °C / 32 °F

High: °C / 149 °F

Calibrate Offset: °C / 0 °F

Note: Temperatures can be entered in either Celsius or Fahrenheit; to indicate a temperature is Fahrenheit, append the degrees with an 'F', eg "75F".

Site Information

Data Center Rack Row:

Data Center Rack Cluster:

Data Center Rack:

Site Tag:

EMG Firmware

Current Version: 9.5.0.0R7

Clear FW Update Log: ☐ [Firmware Update Log](#)

Update Firmware: ☐

Firmware Filename:

Key:

Load Firmware via:

Note: Firmware files stored on NFS, SD Card and USB can be managed by clicking the Manage link below.

Load Firmware Via Options

HTTPS: [Upload File](#)

NFS Mounted Dir:

USB Port: ☒ Port U1

FTP/SFTP/TFTP Server:

Path:

Login:

Password:

Retype Password:

One time Login/Password: ☐

Boot Banks and Bootloader Settings

Bank 1: 9.3.0.0R7

Bank 2: 9.5.0.0R7 (current)

Next Boot Bank:

Switch to Bank 1: ☐

Watchdog Timer: seconds

Copy configuration from Bank 2 to Bank 1 during firmware update: ☒

Boot Count:

Boot Limit:

Boot Delay: seconds

High Resolution Timers: ☐ Requires reboot to take effect.

Panic Reboot: ☒

Configuration Management

☒ No Save/Restore

☐ Save Configuration ☐ Tarball Format (HTTPS only)

☐ Restore Factory Defaults

☐ Restore Saved Configuration

Save with Config or Preserve with Restore:

☐ SSH Keys ☐ SSL Certificate

☐ Scripts

Preserve Configuration after Restore:

☐ Networking ☐ Local Users

☐ Date/Time ☐ Device Ports

☐ Services ☐ USB

☐ Remote Auth

Configuration Name to Save To or Restore From:

Location for Save, Restore or [Manage](#)

☒ Local Disk Saved Configurations:

☐ FTP Server Use: ☒ FTP ☐ SFTP

☐ NFS Mounted Directory: Saved Configurations:

☐ CIFS Share Saved Configurations:

☐ USB Use: ☒ Port U1 Saved Configurations:

☐ HTTPS [Upload File for Restore](#) File will be uploaded to Local Disk.

☐ SD Card Saved Configurations:

☐ Internal SD Card Saved Configurations:

2. Enter the following:

Reboot	Select this option to reboot the EMG immediately. The default is No .
Shutdown	Select this option to shut down the EMG unit. The default is No .

Internal Temperature

Current	Displays current temperature.
Low	Sets the acceptable minimum for the internal temperature of the EMG. If the temperature changes to be outside of this range, the EMG will issue an SNMP trap.
High	Sets the acceptable maximum for the internal temperature of the EMG unit. If the temperature changes to be outside of this range, the EMG unit will issue an SNMP trap.
Calibrate Offset	An offset for calibrating the internal temperature of the EMG unit. The offset will be applied one hour after setting the calibration value. Zeroing the offset will take effect immediately and will cancel any current and/or pending calibration.

Site Information

Data Center Rack Row	Set these fields to define the rack row the EMG unit is located within a large data center. The default for these fields is 1.
Data Center Rack Cluster	Set these fields to define the rack cluster the EMG is located within a large data center. The default for these fields is 1.
Data Center Rack	Set these fields to define the rack the EMG unit is located within a large data center. The default for these fields is 1.
Site Tag	Tag or description used to identify the location or some other attribute of the EMG.

EMG Firmware

Note: The non-active boot bank is updated during the firmware update, without requiring a reboot. The configuration on the current boot bank may optionally be copied to the non-active boot bank during the firmware update.

Current Version	Displays the current firmware version.
Clear FW Update Log (checkbox)	Clears the contents of the Firmware Update log file.
Firmware Update Log (link)	To view a log of all prior firmware updates, click the Firmware Update Log link.
Update Firmware	◆ To update the EMG firmware, select the checkbox. If you select this option, the EMG unit reboots after you apply the update. The first time boot for each bank may take up to 5 minutes. Subsequent boot times will be approximately 2 minutes. The non-active boot bank is updated during the firmware update, without requiring a reboot. The configuration on the current boot bank may optionally be copied to the non-active boot bank during the firmware update. Prior to firmware update, the current configuration is saved to the Local Disk location with the name "before_MMDDYY_HHMM".
Firmware Filename	The name of the firmware update file downloaded from the Lantronix web site.
Key	A key for validating the firmware file. The key is provided with the firmware file (32 hex characters).

Load Firmware Via	From the drop-down list, select the method of loading the firmware. Options are FTP, SFTP, TFTP, HTTPS, NFS, USB, and SD Card. FTP is the default. ◆ If you select HTTPS, the Upload File link becomes active. Select the link to open a popup window that allows you to browse to a firmware update file to upload. ◆ If you select NFS, the mount directory must be specified. ◆ The SD Card option must be selected if an SD card is to be used.

Boot Banks and Bootloader Settings

Bank 1	Displays the version of EMG firmware in bank 1. <i>Note: The word "current" displays next to the bank from which the EMG booted.</i>
Bank 2	Displays the version of EMG firmware in bank 2.
Next Boot Bank	Displays the current setting for bank to boot from at next reboot.
Switch to Bank	If desired, select the alternate bank to boot from at next reboot.
Watchdog Timer	Timer that will reboot the EMG if the boot fails to properly complete. If the timer expires without a successful boot of the EMG, the timer will automatically reboot the EMG. The default is 300 seconds. A value of zero will disable the watchdog timer.
Copy configuration from Bank 1 to Bank 2 during firmware update	If checked, will copy the configuration from the current bank to the bank being updated. The two numbers are automatically generated so that the first number is the current bank.
Boot Count, Boot Delay, Boot Limit	Parameters that control how the EMG boots and when it switches to the alternate boot bank. ◆ Boot Delay - how many seconds the bootloader pauses before booting the EMG. Default is 3 seconds, range is 3 - 1800 seconds. ◆ Boot Limit - how many times the EMG will fail to boot before switching to the alternate boot bank. After the EMG fails to boot 2 times Boot limit (so it has attempted to boot Boot Limit times on each bank), the EMG will go into advanced recovery mode, which may require support from Technical Support to resolve so that the EMG can be booted again. Default is 3 boots, range is 3 - 20. ◆ Boot Count - how many times the EMG has failed to boot. If this value reaches Boot Limit, the EMG will switch to the alternate boot bank. The EMG will switch to the alternate boot bank only once. For example, if it fails to boot Boot Limit times on bank 1, it will automatically switch to bank 2; if it fails to boot Boot Limit times on bank 2, it will enter advanced recovery mode. If Boot Count has reached Boot Limit, setting this value to 0 will enable the EMG to boot again. Default is 0, range is 0 - 1.
High Resolution Timers	Enables or disables timers with a high degree of accuracy. High resolution timers are required for Performance Monitoring , but may affect EMG performance if they are enabled. Off by default. Changing this value requires a reboot for the change to take effect.
Panic Reboot	Enables or disables EMG auto-reboot on a kernel panic.

Load Firmware Via Options

Note: Prior to firmware update, the current configuration is saved to the Local Disk location with the name "before_MMDDYY_HHMM".

HTTPS	Click Upload File to update the EMG firmware.
NFS Mounted Dir	Select the NFS mounted directory from the drop-down menu.
USB Port	Click to select USB port.
FTP/SFTP/TFTP Server	The IP address or host name of the server used for obtaining updates and saving or restoring configurations. May have up to 64 alphanumeric characters; may include hyphens and underscores.
Path	The default path on the server for obtaining firmware update files and getting and putting configuration save files.
Login	The userid for accessing the FTP server. May be blank.
Password / Retype Password	The FTP user password.
One Time Login/ Password	If checked, the FTP Username and Password will not be saved. This is useful in scenarios where an OTP token is used to perform a firmware update or configuration save or restore. This checkbox is only applicable for firmware update and configuration save and restore ; it has no effect for other operations (for example when the FTP/SFTP/TFTP Server, Path, Login and Password are being configured apart from firmware update and configuration save/restore).

Configuration Management

Configuration Management	From the option list, select one of the following: ◆ No Save/Restore: Does not save or restore a configuration. ◆ Save Configuration: Saves all settings to file, which can be backed up to a location that is not on the EMG. If Tarball Format is checked, the configuration will be saved in the old (insecure) compressed tar file format, instead of the password protected zip file format. The Tarball Format is only available for saving a configuration via HTTPS. ◆ Restore Factory Defaults: Restores factory defaults. If you select this option, the EMG unit reboots after you apply the update. ◆ Restore Saved Configuration: Returns the EMG settings to a previously saved configuration. If you select this option, the EMG reboots after you apply the update. ◆ ◆ Save with Config or Preserve with Restore: ➢ Select the SSH Keys checkbox to save any imported or exported SSH keys. ➢ Select the SSL Certificate checkbox to save an imported certificate including LDAP certificates, VPN certificates, and WLAN profile 802.1X certificates (EMG models only).. ➢ Select the Scripts checkbox to save any interface or batch scripts. When restoring a configuration, select these checkboxes to preserve SSH Keys, SSL Certificates or Scripts currently stored on the console manager. Disabled by default.
Preserve Configuration after Restore	Allows the user to keep a subset of the current configuration after restoring a configuration or resetting to factory defaults. Select the checkbox for each part of the current configuration you want to keep, for example, Networking, Services, or Device Ports.

Configuration Name to Save to or Restore From	If you selected to save or restore a configuration, enter a name for the configuration file (up to 12 characters).
Location for Save, Restore, or Manage	If you selected to save or restore a configuration, select one of the following options: ◆ Manage: This link allows you to view and delete all configurations saved to the selected location. This feature is available for the Local Disk, NFS Mounts, CIFS Share, USB, and SD Card locations. See Manage Files. ◆ Local Disk – Saved Configurations: If restoring, select a saved configuration from the drop-down list. ◆ FTP Server: The FTP server specified in the FTP/SFTP/TFTP section. If you select this option, select FTP or SFTP to transfer the configuration file. ◆ NFS Mounted Directory: Local directory of the NFS server for mounting files. ◆ CIFS Share – Saved Configurations: If restoring, select a saved configuration from the drop-down list. ◆ USB: If a USB device is loaded into the USB port of the EMG and properly mounted, the configuration can be saved to or restored from this location. If you select this option, click a saved configuration from the drop-down list. ◆ HTTPS: For saving, the browser will prompt the user to save the configuration. For restoring, the configuration will be uploaded to the Local Disk location. ◆ SD Card: If an SD card is loaded into a card slot of the EMG and properly mounted, the configuration can be saved to or restored from this location. ◆ Internal SD Card: If installed, the internal SD card can be used for saving and restoring configurations. If restoring, select a saved configuration from the drop-down list.

3. To view a log of all prior firmware updates, click the **Firmware Update Log** (blue link near the center of the web page).
4. Click **Apply**.

Note: *If you selected an option that forces a reboot (restore configuration, update firmware, or reset factory defaults), the EMG unit automatically reboots at the end of the process.*

Figure 15-2 Network > Firmware/Config > Manage

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Firmware/Config System Log Audit Log Email Log Diagnostics Status/Reports Events Banners

Firmware & Configurations - Manage Files [Help?](#)

Configurations - Local Disk					
Name	Date/Time Saved	SSH Keys	SSL Certificate	Scripts	
before_070819_1044-slccfg.tgz	07/08/19 10:44:31	Y	Y	Y	☐
before_070319_1414-slccfg.tgz	07/03/19 14:14:02	Y	Y	Y	☐
before_070119_1600-slccfg.tgz	07/01/19 16:00:26	Y	Y	Y	☐

Delete File Download File Rename File New File Name:

Manage Files

The **Manage Files** web page allows you to view the firmware and configuration files saved to the selected location and rename, download or delete any of the files. This feature is available for the Local Disk, NFS Mounts, CIFS Share, USB, and SD card locations.

To manage files:

1. On the [Maintenance > Firmware & Configurations](#) page, click the **Manage** link. The [Network > Firmware/Config > Manage](#) page appears and displays the name and the time and date the file was saved.
2. To rename a file, select a file, enter the **New File Name**, and click the **Rename File** button.
3. To download a file, select a file and click the **Download File** button.
4. To delete files, select one, multiple files, or all files, and click the **Delete File** button. A verification message showing files deleted will appear. Click **Back to Manage Files** to return to the [Network > Firmware/Config > Manage](#) page.

Note: When deleting multiple files with a single command, the list of files that have been deleted will only be shown if 10 or fewer files are deleted.

Administrative Commands

Go to [Administrative Commands](#) to view CLI commands which correspond to the web page entries described above.

System Logs

The [Maintenance > System Logs](#) page allows you to view various system logs. (See [Chapter 8: Services](#) for more information about system logs.) You can also clear logs on this page.

To view system logs:

1. Click the **Maintenance** tab and select the **System Logs** option. The following page displays:

Figure 15-3 Maintenance > System Logs

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin

Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices **Maintenance** Quick Setup

Firmware/Config System Log **Audit Log** Email Log Diagnostics Status/Reports Events Banners

System Logs Help ?

Log: ☒ All ☐ Network ☐ Services ☐ Authentication ☐ Device Ports ☐ Diagnostics ☐ General ☐ Software

Level: ☒ Error ☐ Warning ☐ Info ☐ Debug

Starting at: ☒ Beginning of Log ☐ Date: July 12 2019 02 : 28 : 45 pm

Ending at: ☒ End of Log ☐ Date: July 12 2019 02 : 28 : 45 pm

2. Enter the following to define the parameters of the log you would like to view:

Log	Select the type(s) of log you want to view: ◆ All ◆ Network ◆ Services ◆ Authentication ◆ Device Ports ◆ Diagnostics ◆ General ◆ Software
Level	Select the alert level you want to view for the selected log: ◆ Error ◆ Warning ◆ Info ◆ Debug
Starting at	Select the starting point of the range you want to view: ◆ Beginning of Log: to view the log from the earliest available beginning time and date. ◆ Date: to view the log starting from a specific starting date and time.

Ending at	Select the endpoint of the range you want to view: ◆ End of Log: to view the log from the latest available ending time and date. ◆ Date: to view the log up to the last available log ending date and time.

- Click the **View Log** button. Your specified system log displays. For example, if you select the type **All** and the level **Error**, the EMG unit displays a log similar to this:

Figure 15-4 View System Logs

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Firmware/Config System Log Audit Log Email Log Diagnostics Status/Reports Events Banners

System Logs Help?

Log: All - Error Level Email Output Comment:

Stop Refresh to:

```

Jul 12 14:29:26 2019 slca508 SLC-SLB: last message repeated 30 times
Jul 12 14:28:22 2019 slca508 SLC-SLB: last message repeated 19 times
Jul 12 14:27:19 2019 slca508 SLC-SLB: last message repeated 11 times
Jul 12 14:22:57 2019 slca508 SLC-SLB: last message repeated 7 times
Jul 12 14:11:19 2019 slca508 SLC-SLB: last message repeated 4 times
Jul 12 14:08:05 2019 slca508 SLC-SLB: last message repeated 25 times
Jul 12 14:06:51 2019 slca508 SLC-SLB/xwsd: sw/err-3069580548:error:14094416:SSL
routines:ssl3_read_bytes:ssl3 alert certificate unknown:s3_pkt.c:1498:SSL alert number 46
Jul 12 12:23:39 2019 slca508 SLC-SLB: last message repeated 34 times
Jul 12 12:22:59 2019 slca508 SLC-SLB: last message repeated 14 times
Jul 12 12:21:24 2019 slca508 SLC-SLB: last message repeated 10 times
Jul 12 12:20:06 2019 slca508 SLC-SLB: last message repeated 11 times
Jul 12 12:12:34 2019 slca508 SLC-SLB: last message repeated 6 times
Jul 12 12:11:05 2019 slca508 SLC-SLB: last message repeated 12 times
Jul 12 12:09:58 2019 slca508 SLC-SLB: last message repeated 5 times
Jul 12 12:08:18 2019 slca508 SLC-SLB: last message repeated 17 times
Jul 12 12:06:57 2019 slca508 SLC-SLB: last message repeated 27 times
Jul 12 12:06:21 2019 slca508 SLC-SLB/xwsd: sw/err-3069580548:error:14094416:SSL
routines:ssl3_read_bytes:ssl3 alert certificate unknown:s3_pkt.c:1498:SSL alert number 46
Jul 12 11:47:26 2019 slca508 SLC-SLB: last message repeated 13 times
  
```

From a queried system log (e.g., [Figure 15-4](#)), you may email this information to a specific individual or to Lantronix Technical Support. See [Emailing Logs and Reports](#).

To clear system logs:

- From the [Maintenance > System Logs](#) page, select **Maintenance - System Logs**.
- Click the **Clear Log** button to clear all log information.

System Log Commands

Go to [System Log Commands](#) to view CLI commands which correspond to the web page entries described above.

Audit Log

The [Maintenance > Audit Log](#) page displays a log of all actions that have changed the configuration of the EMG. The audit log is disabled by default. Use the [Services > SSH/Telnet/Logging](#) page ([Chapter 8: Services](#)) to enable the audit log and to configure its maximum size.

Each entry in the log file contains a date/time stamp, user login, and the action performed by the user. The user may clear the log file and sort the log by date/time, user, and command. The audit log is saved through EMG reboots.

1. Click the **Maintenance** tab and select the **Audit Log** option. The following page displays:

Figure 15-5 Maintenance > Audit Log

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Firmware/Config System Log Audit Log Email Log Diagnostics Status/Reports Events Banners

Audit Log Help?

Sorted by: **Date/Time**
 Sort by: Comment:
 to:

Jul 12 14:06:56 2019	sysadmin	Web Authentication Success for user sysadmin
Jul 12 12:23:35 2019	sysadmin	Event Receive Trap deleted
Jul 12 12:23:10 2019	sysadmin	Event Receive Trap/Syslog added/updated
Jul 12 11:32:30 2019	sysadmin	Custom menu 'Menu2' created
Jul 12 11:31:48 2019	sysadmin	Custom menu 'Menu1' created
Jul 12 11:19:00 2019	sysadmin	Group settings updated
Jul 12 11:00:28 2019	sysadmin	Auth order: Local Users=1 NIS=0 LDAP=0 RADIUS=0 Kerberos=0 TACACS=0
Jul 12 10:58:37 2019	sysadmin	Web Authentication Success for user sysadmin
Jul 11 16:36:18 2019	sysadmin	Web Authentication Success for user sysadmin
Jul 11 13:17:21 2019	sysadmin	Web Authentication Success for user sysadmin
Jul 11 11:04:18 2019	sysadmin	Web Authentication Success for user sysadmin
Jul 10 17:11:36 2019	sysadmin	Web Authentication Success for user sysadmin
Jul 10 16:22:41 2019	sysadmin	Host List 'test' updated
Jul 10 16:20:30 2019	sysadmin	Host List 'test' updated
Jul 10 15:20:25 2019	sysadmin	Web Authentication Success for user sysadmin
Jul 10 13:12:29 2019	sysadmin	Web Authentication Success for user sysadmin
Jul 10 11:12:12 2019	sysadmin	Web Authentication Success for user sysadmin
Jul 10 11:01:57 2019	sysadmin	Device inserted at USB port U1
Jul 10 11:00:41 2019	sysadmin	Server settings updated

2. To select a sort option, click the appropriate button:
 - To sort by date and time, click the sort by **Date/Time** button (this is the default.)
 - To sort by user, click the sort by **User** button.
 - To sort by command/action, click the sort by **Command** button.
3. To email this log, follow the instructions in [Emailing Logs and Reports](#).
4. To clear the log, click the **Clear Log** button.
5. To freeze or stop automatic refreshing of the log, click the **Stop Refresh** button.

Audit Log Commands

Go to [Audit Log Commands](#) to view CLI commands which correspond to the web page entries described above.

Email Log

The [Maintenance > Email Log](#) page displays a log of all attempted emails. The log file can be cleared from here. The email log is saved through EMG reboots.

1. Click the **Maintenance** tab and select the Email Log option. The **Email Log** page appears.

Figure 15-6 Maintenance > Email Log

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for: ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices **Maintenance** Quick Setup

Firmware/Config System Log Audit Log **Email Log** Diagnostics Status/Reports Events Banners

Email Log Help ?

Clear Log Email Log Comment:

Stop Refresh to:

Send Failures: 0
Emails Sent: 2
Bytes Sent: 42822

07/31/19 18:59 username@example.com Message Sent (EMG851000 Report (emgfcf0))
07/31/19 18:58 username@example.com Message Sent (EMG851000 Audit Log (emgfcf0))

2. To email this log, follow the instructions in [Emailing Logs and Reports](#).
3. To clear the log, click the **Clear Log** button, and to stop the log refresh, click **Stop Refresh**.
4. To view SMTP log, click **View SMTP Log**. The SMTP log dialog box appears.
5. To clear the log, click the **Clear Log** button, and to stop the log refresh, click **Stop Refresh**.

Logging Commands

Go to [Logging Commands](#), [USB Device Commands](#), [USB Storage Commands](#), and [Internal Modem Commands](#) to view CLI commands which correspond to the web page entries described above.

Diagnostics

The [Maintenance > Diagnostics](#) page provides methods for diagnosing problems such as network connectivity and device port input/output problems. You can use equivalent commands on the command line interface.

1. Click the **Maintenance** tab and select the **Diagnostics** option. The following page displays:

Figure 15-7 Maintenance > Diagnostics

LANTRONIX® EMG851331

Logout Host: Emg_fd1e User: sysadmin Select port for: ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Firmware/Config System Log Audit Log Email Log Diagnostics Status/Reports Events Banners System Info

Diagnostics Help?

Select Diagnostics: ☐ All

- ☐ IPv4 Arp Table
- ☐ IPv6 Neighbor Table
- ☐ Netstat Protocol: ☒ All ☐ TCP ☐ UDP
- ☐ Host Lookup Hostname:
- ☐ Ping Hostname:

Ethernet Port: ☒ All ☐ Ethernet Switch ☐ Eth1 Internal Modem ☐ Eth2 USB Port U1 ☐ Cellular

IPv6: ☐ Count: Packet Size: Timeout: Note: Timeout is for IPv4 ping only, and is not supported for IPv6 ping.

- ☐ Send Packet Protocol: ☒ TCP ☐ UDP Hostname: Port: String: Count:
- ☐ Loopback Device Port: Test: ☒ Internal ☐ External
- ☐ EMG Internals
- ☐ USB Devices Tree Display: ☒ Map Device: ☐
- ☐ iPerf iPerf Mode: ☐ Server ☒ Client iPerf Server: iPerf Options:

2. **Select Diagnostics** from checklist (one or more diagnostic methods you want to run, or select

All to run them all):

IPv4 ARP Table	The IPv4 Address Resolution Protocol (ARP) table used to view the IP address-to-hardware address mapping.
IPv6 Neighbor Table	The IPv6 Neighbor table is used to view a list of neighbor's IPv6 addresses on the same network, and their corresponding MAC addresses.
Netstat	Displays network connections. If selected, select a protocol or select All for both protocols to control the output of the Netstat report.
Host Lookup	Given a hostname, verifies that the console manager can resolve the hostname into an IP address (if DNS is enabled).
Ping	Select to verify that the host is up and running. ◆ Hostname: Specify a host name or IP address of the host to send the packet. ◆ Ethernet Port: Select All (to not bind to any interface) or select a specific interface to bind to when sending the ping packets. ◆ IPv6: Select to use a version of ping that supports IPv6. ◆ Count: Enter the number of ping packets to send. The default is 5. ◆ Packet Size: Specify the size of the packet. ◆ Timeout: Specify the number of seconds/milliseconds to wait for the first response after all count packets are sent. Note: Timeout is for IPv4 ping only, and is not supported for IPv6 ping.
Send Packet	This option sends an Ethernet packet out one of the Ethernet ports, mainly as a network connectivity test. Enter the following: ◆ Protocol: Select the type of packet to send. ◆ Hostname: Specify a host name or IP address of the host to send the packet to. ◆ Port: Specify a TCP or UDP port number of the host to send the packet to. ◆ String: Enter a set of up to 64 characters. The string is encapsulated in the packet (so you could use a network sniffer to track the packet and, by looking at its contents, verify that it was sent). ◆ Count: The count is the number of times the string is sent. For UDP, the number of times the string is sent is equal to the number of packets sent. For TCP, the number of times the string is sent may (or may not) be equal to the number of packets sent, because TCP controls how data is packetized and sent out.
Loopback	Specify loopback information: ◆ Device Port ◆ Select either an Internal or External test ◆ The External test is currently not supported for USB device ports
EMG Internals	Select to display information on the internal memory, storage and processes of the unit.
USB Devices	Select to display information about USB buses and the devices connected to them, including a mapping between a USB device and the EMG ports.

iPerf	Select to start an iPerf3 server or client to measure network throughput. The server will run in “one-off” mode. This means that it will handle one client connection and then terminate. The server will wait indefinitely for the client to connect. The client will time out if a connection is not made to a server within 15 seconds. For more information, visit the iPerf website. ◆ iPerf Mode: Select to run a server or client. Two units can be used to measure network throughput, one running in server mode and one running in client mode. ◆ iPerf Server: Specify the server name or IP address that the client connects to. ◆ iPerf Options: Enter options to configure the packets sent by the server or client. If no options are specified, the server or client will run with a default set of TCP packets. ➤ Set server port to listen on/connect to (default 5201): -p, --port n ➤ Format to report: -f, --format [kmgTKMG] ➤ Pause n seconds between reports: -i, --interval n ➤ Bind to a host, an interface or multicast address: -B, --bind ➤ More detailed output: -V, --verbose ➤ Output in JavaScript Object Notation (JSON) format: -J, --json Note: The options below are supported on the client only: ➤ Set length of buffer to n (default 8 KB): -l, --length n[KMG] ➤ Use UDP rather than TCP: -u, --udp ➤ TCP window size (socket buffer size): -w, --window n[KMG] ➤ Set TCP/SCTP maximum segment size (MTU): -M, --set-mss n ➤ Set TCP/SCTP no delay, disabling Nagle’s Algorithm: -N, --no-delay ➤ Set bandwidth to n bits/sec (default 1Mbit/sec, unlimited for TCP): -b, --bitrate n[KMG] ➤ Number of bytes to transmit (instead of -t): -n, --bytes n[KMG] ➤ Time in seconds to transmit for (default 10 secs): -t, --time n ➤ Set the IPv6 flow label: -L, --flowlabel n ➤ Omit the first n seconds: -O, --omit n ➤ Prefix every output line with this string: -T, --title str ➤ Number of blocks (packets) to transmit (instead of -t/-n): -k, --blockcount ➤ Set the IP type of service, 0-255. The usual prefixes for octal and hex can be used, i.e. 52, 064 and 0x34 all specify the same value: -S, --tos n ➤ Set the IP dscp value, either 0-63 or symbolic: --dscp n Note: The EMG uses iPerf version 3.x, which is incompatible with older iPerf versions (2.x).

3. Click the **Run Diagnostics** button. The [Diagnostics Output](#) page displays.

Figure 15-8 Diagnostics Output

The screenshot shows the LANTRONIX EMG851331 web interface. At the top, there's a header with the logo and a status bar showing MD, CEDIO, U1, E1, 1, 3, 1, 3 and E2, 2, 4, 2, 4. Below the header, there's a navigation bar with tabs: Network, Services, User Authentication, Devices, Maintenance (selected), and Quick Setup. Under Maintenance, there's a sub-navigation bar with links: Firmware/Config, System Log, Audit Log, Email Log, Diagnostics (selected), Status/Reports, Events, Banners, and System Info. The main content area is titled "Diagnostics" and has a "Help ?" button. It shows the "Diagnostic Output: Ping (8.8.8.8)" and an "Email Output" button. There are input fields for "Comment:" and "to:". The output text is as follows:

```
Ping (8.8.8.8)

PING 8.8.8.8 (8.8.8.8): 56 data bytes
64 bytes from 8.8.8.8: seq=0 ttl=115 time=3.394 ms
64 bytes from 8.8.8.8: seq=1 ttl=115 time=4.444 ms
64 bytes from 8.8.8.8: seq=2 ttl=115 time=3.745 ms
64 bytes from 8.8.8.8: seq=3 ttl=115 time=3.711 ms
64 bytes from 8.8.8.8: seq=4 ttl=115 time=3.607 ms

--- 8.8.8.8 ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 3.394/3.780/4.444 ms
```

4. To view a report, click the link for that report.
5. To email this report, follow the instructions in [Emailing Logs and Reports](#).

Diagnostic Commands

Go to [Diagnostic Commands](#) to view CLI commands which correspond to the web page entries described above.

Status/Reports

On this page, you can view the status of the EMG ports and power supplies and generate a selection of reports.

Note: *Status and statistics shown on the web interface represent a snapshot in time. To see the most recent data, you must reload the web page.*

1. Click the **Maintenance** tab and select the **Status/Reports** option. The following page displays:

Figure 15-9 Maintenance > Status/Reports

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Firmware/Config System Log Audit Log Email Log Diagnostics Status/Reports Events Banners

Status/Reports Help?

Eth1: **Up**

Eth2: **Down**

Console Port: **Not Connected**

Internal Temperature: **49 °C (120 °F)**

Device Ports

1: **Ok**

2: **Ok**

3: **Ok**

4: **Ok**

View Report: ☐ All ☐ System Configuration - Complete

☐ Port Status ☐ System Configuration - Basic

☐ Port Counters ☐ System Configuration - Authentication

☐ IP Routes ☐ System Configuration - Devices

☐ Connections

The top half of the page displays the status of each port, power supply, and the internal modem:

- **Green** indicates that the port connection or power supply is active and functioning correctly.
- **Red** indicates an error or failure or that the device is off.

2. Select the desired reports to view under **View Report**:

View Report

All	Displays all reports.
Port Status	Displays the status of each device port: mode, user, any related connections, and serial port settings.
Port Counters	Displays statistics related to the flow of data through each device port.
IP Routes	Displays the routing table.
Connections	Displays all active connections for the EMG unit: Telnet, SSH, TCP, UDP, device port, and modem.
System Configuration – Complete	Displays a complete snapshot of the EMG settings.
System Configuration – Basic	Displays a snapshot of the EMG unit's basic settings (for example, network, date/time, routing, services, console port).
System Configuration – Authentication	Displays a snapshot of authentication settings only (including a list of all localusers).
System Configuration - Devices	Displays a snapshot of settings for each device port, USB Port, Modem, and Host Lists.

3. Click the **Generate Report** button. In the upper left of the [Generated Status/Reports](#) page displays a list of reports generated.

Figure 15-10 Generated Status/Reports

LANTRONIX[®] EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Firmware/Config System Log Audit Log Email Log Diagnostics Status/Reports Events Banners

Status/Reports Help?

Report(s): Comment:

to:

[Port Status](#)
[Port Counters](#)
[IP Routes](#)

Port Status

Device Port:	1	DSR/CD:	No
Name:	Port-1	DTR:	Yes
Mode:	Idle	CTS:	No
		RTS:	Yes
Device Port:	2	DSR/CD:	No
Name:	Port-2	DTR:	Yes
Mode:	Idle	CTS:	No
		RTS:	Yes
Device Port:	3	DSR/CD:	No
Name:	Port-3	DTR:	Yes
Mode:	Idle	CTS:	No
		RTS:	Yes
Device Port:	4	DSR/CD:	No
Name:	Port-4	DTR:	Yes
Mode:	Idle	CTS:	No
		RTS:	Yes

Port Counters

Device Port:	1	Seconds since zeroed:	177554
Bytes input:	0	Bytes output:	0
Framing errors:	0	Flow control errors:	0
Overrun errors:	0	Parity errors:	0
Device Port:	2	Seconds since zeroed:	177554

4. To email these report(s), follow the instructions in [Emailing Logs and Reports](#).

Status Commands

Go to [Status Commands](#) to view CLI commands which correspond to the web page entries described above.

Emailing Logs and Reports


The following logs and reports can be directly emailed to a specific individual or to Lantronix Technical Support directly from the log page:

- ◆ System Log ([Figure 15-4](#))
- ◆ Audit Log ([Figure 15-5](#))
- ◆ Email Log ([Figure 15-6](#))
- ◆ Diagnostic Reports ([Figure 15-8](#))
- ◆ Status/Reports ([Figure 15-10](#))

To email a log to an individual:

1. In the **Comment** field of a particular log or report page, enter a comment (if desired).
2. Select the **to** field beside the empty field where you then enter the person's email address.
3. Press the **Email Output** button. An email is immediately sent and a confirmation appears on the screen.


Figure 15-11 Emailed Log or Report



To view information about the EMG unit and contact information for Lantronix:

1. Click the [?](#) button on the upper right portion of any web page to access the **About EMG** page (see [Figure 15-12](#)).

Figure 15-12 About EMG



LANTRONIX® EMG851300

Host: **emgfcf0**
User: **sysadmin**

Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

About EMG851300

Model: **EMG851300**
Firmware Version: **9.1.0.0R1**
OS Version: **IT Management Gateway OS 7.0**
Bootloader Version: **2.0.0.0R10**
S/N: **0080A38BFCF0**
Device ID: **[REDACTED]**
Memory: **1024 MB**
Flash Size: **1024 MB**
Internal SD Card: **117.4G (117.2G available)**
Power Supply: **external DC**
Number of External USB Ports: **1**
Cellular Modem: **Not Installed**
WiFi: **Not Installed**
Ethernet Switch: **Installed**
Internal Modem: **Not Installed**
Eth1 HW Address: **00:80:a3:8b:fc:f0**
Eth2 HW Address: **00:80:a3:8b:fc:f1**
Ethernet Switch HW Address: **00:80:a3:8b:fc:de**
Main Board Revision: **unknown**
NIC Board Eth1 SFP: **[none]**
NIC Board Eth2 SFP: **[none]**
I/O Module Type(s): **RJ45-04, ETH-04**
I/O Module Revision(s): **04SPB, 04ESB**
Connectivity Module Type(s): **,**
Connectivity Module Revision(s): **,**
Admin Password Unique to Device: **Disabled**
Uptime: **4 days, 4 hours, 35 minutes**

© 2003-2023, Lantronix, All rights reserved.

Lantronix Corporate Headquarters
48 Discovery
Irvine, CA 92618 USA
Tel: +1 (949) 453-3990
Fax: +1 (949) 453-3995

Technical Support
<https://www.lantronix.com/technical-support/>

Software Revisions:
Kernel: **3.6.5**
Web/TLS: **OpenSSL 1.1.1s 1 Nov 2022**
SSH/TLS: **OpenSSH 9.2p1, OpenSSL 1.0.2u-fips 20 Dec 2019**
Telnet: **netkit-telnet-0.17**
NTP: **ntpd 4.2.6p5**
SMB/CIFS: **Version 3.6.14**
RIP: **zebra version 1.2.4**
Web Server: **mini_httpd/1.30**
PAM/NIS: **1.3.1**
LDAP: **153**
RADIUS: **2.0.0**
Kerberos: **2.4.8**
TACACS+: **1.6.0**
ShellInABox: **2.19**
VPN: **Linux strongSwan U5.9.0/K3.6.5**
Expect: **5.45.4**
Tcl: **8.6**
Python: **3.6.7**
Dnsmasq: **2.84**
Syslog: **2.4.4**

Bootloader Configuration:
Number of Ports: **4**
Model Number: **116**
Product Name: **EMG**
Options: **0000000000000000000000000000ffff01**

Events

On this [Maintenance > Events](#) page, you can define what action you want to take for events that may occur in the EMG unit.

1. Click the **Maintenance** tab and select the **Events** option. The following page displays:

Figure 15-13 Maintenance > Events

LANTRONIX® EMG851110

Logout Host: emgfee User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices **Maintenance** Quick Setup

Firmware/Config System Log Audit Log Email Log Diagnostics Status/Reports Events Banners

Events Help?

Trigger: Action:

Host to Ping:

RPM:

Outlet: (optional)

Threshold: Amps or Load %

DIO Port:

Ethernet Port: ☒ Eth1 ☐ Eth2

Modem Connection: ☒ USB Port U1 ☐ Device Port:

NMS/Host to forward trap to:

SNMP Community:

SNMP Trap OID:

Email Address:

To edit or delete an event, select the radio button in the right column below.

Events				
Id	Trigger	Options	Action	Options
Apply				

2. Enter the following:

Event Trigger	From the drop-down list, select the type of incident that triggers an event. Currently, the options are: ◆ Receive Trap ◆ Temperature Over/Under Limit (for Sensorsoft devices) ◆ Humidity Over/Under Limit (for Sensorsoft devices) ◆ Device Port Data Drop ◆ No Internal Modem Dial Tone ◆ Ping Host Fails ◆ RPM Load Over Threshold ◆ DIO Port State Change ◆ DIO Port State Abnormal ◆ Intrusion Detection ◆ Resource Utilization
Host to Ping	When the trigger is set to Ping Host Fails, enter the hostname, IPv4 address or IPv6 address of the host to ping. The host will be pinged every 2 minutes.
RPM	When the trigger is set to RPM Load over Threshold, select the RPM that will be monitored for a current that exceeds a defined threshold. The RPM needs to support providing a current level as part of its status information. The RPM current will be checked every 2 minutes.

Outlet	When the trigger is set to RPM Load over Threshold , select the outlet that will be monitored for a current that exceeds a defined threshold. The RPM needs to support providing a current level for the selected outlet as part of its status information. If an outlet is not specified, the current level for the entire device will be monitored. The RPM current will be checked every 2 minutes.
Threshold	When the trigger is set to RPM Load over Threshold , specify the maximum allowable threshold for the current; any current readings over this threshold will trigger the selected action. The threshold can be specified in Amps (e.g. 8.5) or as a percentage (e.g. 90%).
DIO Port	When the trigger is set to DIO Port State Change or DIO Port State Abnormal , select the DIO port to monitor. For state change, the selected action will be triggered if the state changes from On to Off or from Off to On. For state abnormal, the selected action will be triggered if the state changes from the Normal state to the opposite state (see DIO Port for more information).
Action	From the drop-down list, select the action taken because of the trigger. For example, the action can be writing an entry into the syslog with details of the event or sending the trap(s) to the Ethernet or modem connection. ◆ Syslog ◆ Forward All Traps to Ethernet ◆ Forward Selected Trap to Ethernet ◆ Forward all Traps to a Modem Connection ◆ Forward Selected Trap to a Modem Connection ◆ Email Alert ◆ SNMP Trap ◆ Turn DIO Relay On
Ethernet	For actions that require an Ethernet connection (for example, Forward All Traps to Ethernet), select the Ethernet port to use.
Modem Connection on	For actions that require a modem connection (for example, Forward All Traps to a Modem Connection), select which modem connection to use (Device Port , USB Port U1 , or the Internal Modem).
NMS/Host to forward trap to	For actions that forward a trap, enter the IP address of the computer to forward the trap to. The computer does not have to be an SNMP NMS; it just has to be capable of receiving SNMP traps.
SNMP Community	Forwarded traps are sent with this SNMP community value There is no default.
SNMP Trap OID	Enter a unique identifier for an SNMP object. (An SNMP object is anything that can hold a value and can be read using an SNMP "get" action.) The OID consists of a string of numbers separated by periods (for example, 1.1.3.2.1). Each number is part of a group represented by the number on its left.
Email Addresses	Enter an email address to receive email alerts.

3. You have the following options:

- To add the defined event, click the **Add Event** button. The event displays in the Events table at the bottom of the page.
- To edit an event, select the event from the Events table and click the **Edit Event** button. The [Maintenance > Events](#) page displays the event.
- To delete an event, select the event from the Events table and click the **Delete Event** button. A message asks for confirmation. Click **OK**.

4. To save, click **Apply**.

Events Commands

Go to [Events Commands](#) to view CLI commands which correspond to the web page entries described above.

Banners

The [Maintenance > Banners](#) page allows the system administrator to customize text messages that display to users.

To configure banner settings:

1. Click the **Maintenance** tab and select **Banners** option.

Figure 15-14 Maintenance > Banners

LANTRONIX® EMG851000

Logout Host: emgfcf0 User: sysadmin Select port for ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Firmware/Config System Log Audit Log Email Log Diagnostics Status/Reports Events Banners

Banners

Welcome Banner:

Login Banner:

Logout Banner:

SSH Banner:

Note: Line feeds can be included in the banners with the '\n' character sequence.
The web banner can be configured [here](#).

Apply

2. Enter the following fields.

Welcome Banner	The text to display on the command line interface before the user logs in. May contain up to 1024 characters. Single quote and double quote characters are not supported. Welcome to the EMG is the default. Note: To create more lines use the <code>\n</code> character sequence.
Login Banner	The text to display on the command line interface after the user logs in. May contain up to 1024 characters. Single quote and double quote characters are not supported. Default is blank. Note: To create more lines, use the <code>\n</code> character sequence.
Logout Banner	The text to display on the command line interface after the user logs out. May contain up to 1024 characters. Single quote and double quote characters are not supported. Default is blank. Note: To create more lines use, the <code>\n</code> character sequence.

SSH Banner	The text to display when a user logs into the EMG via SSH, prior to authentication. May contain up to 1024 characters. Single quote and double quote characters are not supported. Blank by default. Note: To create more lines use the <code>\n</code> character sequence.

- Click **Apply** to save.

Administrative Banner Commands

Go to [Administrative Commands](#) to view CLI commands which correspond to the web page entries described above.

System Info

The **System Info** page allows you to generate a ZIP file containing a comprehensive set of data that can be analyzed or sent to Lantronix Tech Support. The ZIP file contains network information, current configuration, logs, port information, and internal diagnostic information.

To generate the System Info file:

- Click **Maintenance** and then click **System Info**. The **System Info** page appears.

Figure 15-15 System Info

LANTRONIX[®] EMG851001

Host: emg8c0
User: sysadmin

Select port for: ☒ Configuration ☐ WebSSH (DP only) ☐ Connected Device (DP only)

Network Services User Authentication Devices Maintenance Quick Setup

Firmware/Config System Log Audit Log Email Log Diagnostics Status/Reports Events Banners System Info

System Info [Help ?](#)

ZIP File Name:

Password to encrypt ZIP file (optional):

Retype Password:

Include System Logs: ☐

Save File via:

NFS Mounted Directory:

USB Port: ☒ Port U1

FTP/SFTP/SCP Server:

Path:

Login:

Password:

Retype Password:

This page allows the user to save a comprehensive set of data that can be analyzed or sent to Lantronix Tech Support. The ZIP file will include the configuration, version, port, networking and internal system information, etc.

- Enter the following information:

ZIP File Name	The name of the System Info ZIP file, without the .zip extension. Up to 40 characters can be entered.


Comment	An optional comment describing the system info file being generated. Up to 80 characters can be entered.
Password to encrypt ZIP file/ Retype Password	An optional password that can be used to encrypt the ZIP file, and will be required to unpack the ZIP file.
Include System Logs	If selected, will include all of the system log files in the ZIP file. This can significantly increase the size of the ZIP file.
Save File via	The method of saving the ZIP file. The available options are FTP , SFTP , SCP , HTTP , NFS , USB , and SD Card . By default, FTP is the default selected. For NFS, a NFS share needs to be configured and mounted on the console manager. For information about NFS, see NFS and SMB/CIFS Commands . For USB and SD Card, external media needs to be present and mounted on the console manager. For information about USB and SD card, see Chapter 9: USB/SD Card Port .
NFS Mounted Dir	The mount directory of NFS. This option is available only when you select the NFS option in Save File via .
USB Port	Select the USB port to save the System Info file.
FTP/SFTP/TFTP Server	The IP address or host name of the server used for saving the System Info file. It may consist of 64 alphanumeric characters, hyphens, and underscores.
Path	The optional directory on the FTP/SFTP/SCP server to use for saving the ZIP file,...
Login/Password/ Retype Password	The user login credentials of the FTP/SFTP/SCP server.

3. Click **Generate System Info File**. The **System Info ZIP** file is saved.

16: Application Examples

Each EMG has multiple serial ports and two network ports. Each serial port can be connected to the console port of an IT device. Using a network port (in-band) or a modem (out-of-band) for dial-up connection, an administrator can remotely access any of the connected IT devices using Telnet or SSH.

Figure 16-1 EMG - Configuration




This chapter includes three typical scenarios for using the EMG unit. The scenarios assume that the EMG is connected to the network and has already been assigned an IP address. In the examples, we use the command line interface. You can do the same things using the web page interface except for directly interacting with the EMG unit (`direct command`).

Telnet/SSH to a Remote Device

The following figure shows a Sun server connected to port 2 of the EMG.

Figure 16-2 Remote User Connected to a SUN Server via the Console Manager



In this example, the sysadmin would:

1. Display the current settings for device port 2:

```
[EMG]> show deviceport port 2
__Current Device Port
Settings_____
Number: 2   Name: Port-2

Modem Settings-----Data Settings-----IP Settings-----
Modem State: disabled      Baud Rate: 9600          Telnet: disabled
Modem Mode: text           Data Bits: 8             Telnet Port: 2002
Timeout Logins: disabled   Stop Bits: 1            SSH: disabled
Local IP: negotiate        Parity: none            SSH Port: 3002
Remote IP: negotiate       Flow Control: xon/xoff   IP: <none>
Authentication: PAP        Logins: disabled
CHAP Host: <none>          Break Sequence: \x1bB
CHAP Secret: <none>       Check DSR: disabled
NAT: disabled             Close DSR: disabled

Dial-out Login: <none>
Dial-out Password: <none>
Dial-out Number: <none>
Dial-back Number: usernumber
Initialization Script: <none>

Logging Settings-----
Local Logging: disabled    USB Logging: disabled
Email Logging: disabled    Log to: upper slot
Byte Threshold: 100        Max number of files: 10
Email Delay: 60 seconds    Max size of files: 2048
Restart Delay: 60 seconds
Email To: <none>
Email Subject: Port %d Logging
Email String: <none>
```

```
NFS File Logging: disabled
Directory to log to: <none>
Max number of files: 10
Max size of files: 2048
```

2. Change the baud to 57600 and disable flow control:

```
[EMG]> set deviceport port 2 baud 57600 flowcontrol none
Device Port settings successfully updated.
```

3. Connect to the device port:

```
[EMG]> connect direct deviceport 2
```

4. View messages from the SUN server console:

```
Mar 15 09:09:44 tssf280r sendmail[292]: [ID 702911 mail.info] starting
daemon (8.12.2+Sun): SMTP+queueing@00:15:00
Mar 15 09:09:44 tssf280r sendmail[293]: [ID 702911 mail.info] starting
daemon (8.12.2+Sun): queueing@00:15:00
Mar 15 14:44:40 tssf280r sendmail[275]: [ID 702911 mail.info] starting
daemon (8.12.2+Sun): SMTP+queueing@00:15:00
Mar 15 14:44:40 tssf280r sendmail[276]: [ID 702911 mail.info] starting
daemon (8.12.2+Sun): queueing@00:15:00
```

5. Reboot the SUN server:


```
Reboot
<shutdown messages from SUN>
```

6. Use the escape sequence to escape from direct mode back to the command line interface.

Dial-in (Text Mode) to a Remote Device

This example shows a phone line connection to the internal modem of the EMG, and a Sun server connected to a device port. You can configure the modem for text mode dial-in, so a remote user can dial into the modem using a terminal emulation program and access the Sun server.

Figure 16-3 Dial-in (Text Mode) to a Remote Device



In this example, the sysadmin would:

1. Configure the device port that the modem is connected to for dial-in:

```
[EMG]> set deviceport port 1 modemmode text
Device Port settings successfully updated.
[EMG]> set deviceport port 1 initscript "AT&F&K3&C1&D2%C0A"
Device Port settings successfully updated.
[EMG]> set deviceport port 1 auth pap
Device Port settings successfully updated.
[EMG]> set deviceport port 1 localsecret "password"
Device Port settings successfully updated.
[EMG]> set deviceport port 1 modemstate dialin
Device Port settings successfully updated.
[EMG]>
```

2. Configure the device port that is connected to the console port of the Sun UNIX server:

```
[EMG]> set deviceport port 2 baud 57600 flowcontrol none
Device Port settings successfully updated.
```

3. Dial into the EMG via the modem using a terminal emulation program on a remote PC. A command line prompt displays.

4. Log into the EMG unit.

```
CONNECT 57600
Welcome to the EMG
login: sysadmin
Password:
Welcome to the EMG Console Manager
Model Number: EMG851000
For a list of commands, type 'help'.
[EMG]>
```

5. Connect to the SUN Unix server using the direct command.


```
[EMG]> connect direct deviceport 2
SunOS 5.7
login: frank
Password:
Last login: Wed Jul 14 16:07:49 from computer
Sun Microsystems Inc.SunOS 5.7Generic October 1998
SunOS computer 5.7 Generic_123485-05 sun4m sparc SUNW,SPARCstation-20
$
```

6. Use the escape sequence to escape from direct mode back to the command line interface.

Local Serial Connection to Network Device via Telnet

This example shows a terminal device connected to an EMG device port, and a Sun server connected over the network to the EMG device. When a connection is established between the device port and an outbound Telnet session, users can access the Sun server as though they were directly connected to it. (See [Chapter 13: Connections](#)).

Figure 16-4 Local Serial Connection to Network Device via Telnet



In this example, the sysadmin would:

1. Display the current settings for device port 2:

```
[EMG]> show deviceport port 2
___Current Device Port
Settings_____
Number: 2  Name: Port-2
Modem Settings-----Data Settings-----IP Settings-----
Modem State: disabled      Baud Rate: 9600      Telnet: disabled
Modem Mode: text           Data Bits: 8         Telnet Port: 2002
Timeout Logins: disabled   Stop Bits: 1         SSH: disabled
Local IP: negotiate        Parity: none         SSH Port: 3002
Remote IP: negotiate       Flow Control: xon/xoff IP: <none>
Authentication: PAP        Logins: disabled
CHAP Host: <none>          Break Sequence: \x1bB
CHAP Secret: <none>       Check DSR: disabled
NAT: disabled             Close DSR: disabled
Dial-out Login: <none>
Dial-out Password: <none>
Dial-out Number: <none>
Dial-back Number: usernumber
Initialization Script: <none>

Logging Settings-----
Local Logging: disabled    USB Logging: disabled
Email Logging: disabled    Log to: upper slot
Byte Threshold: 100        Max number of files: 10
Email Delay: 60 seconds    Max size of files: 2048
Restart Delay: 60 seconds
Email To: <none>
Email Subject: Port %d Logging
Email String: <none>
NFS File Logging: disabled
Directory to log to: <none>
```

Max number of files: 10
Max size of files: 2048

2. Change the serial settings to match the serial settings for the vt100 terminal - changes baud to 57600 and disables flow control:

```
[EMG]> set deviceport port 2 baud 57600 flowcontrol none  
Device Port settings successfully updated.
```

3. Create a connection between the vt100 terminal connected to device port 2 and an outbound telnet session to the server. (The IP address of the server is 192.168.1.1):

```
[EMG]> connect bidirection 2 telnet 192.168.1.1  
Connection settings successfully updated.
```

4. At the VT100 terminal, hit <return> a couple of times. The Telnet prompt from the server displays:

```
Trying 192.168.1.1...  
Connected to 192.168.1.1.  
Escape character is '^['.
```

```
Sun OS 8.0  
login:
```

At this point, a user can log in and interact with the Sun server at the VT100 terminal as if directly connected to the server.

17: Command Reference

After an introduction to using commands, this chapter lists and describes all of the commands available on the EMG command line interface accessed through Telnet, SSH, or a serial connection. The commands are in alphabetical order by category.

Introduction to Commands

Following is some information about command syntax, command line help, and tips for using commands.

Command

Syntax

Commands have the following format:

`<action> <category> <parameter(s)>`

where

`<action>` is `set`, `show`, `connect`, `admin`, `diag`, or `logout`.

`<category>` is a group of related parameters whose settings you want to configure or view. Examples are `ntp`, `deviceport`, and `network`.

`<parameter(s)>` is one or more name-value pairs in one of the following formats:

<code><parameter name> <aa bb></code>	User must specify one of the values (aa or bb) separated by a vertical line (). The values are in all lowercase and must be entered exactly as shown. Bold indicates a default value.
<code><parameter name> <Value></code>	User must specify an appropriate value, for example, an IP address. The parameter values are in mixed case. Square brackets [] indicate optional parameters.

Table 17-1 Actions and Category Options

Action	Category
set	accesslist auth cellular cifs cli command consoleport datetime deviceport dhcp dio groups history hostlist intsd ipfilter kerberos ldap localusers log menu network nfs nis ntp password perfmon power px radius remoteusers routing rpm script sdcard services site slcnetwork snmp sshkey switch tacacs+ temperature usb virtual vpn wlan xmodem
show	accesslist auth auditlog cellular cifs cli connections consoleport datetime deviceport dhcp dio emaillog groups history hostlist intmodem ipfilter kerberos ldap localusers log menu network nfs nis ntp perfmon portcounters portstatus power px radius remoteusers routing rpm script sdcard services site slcnetwork snmp sshkey switch sysconfig syslog sysstatus tacacs+ temperature usb user virtual vpn wlan xmodem

Action	Category
connect	bidirection direct forward global listen restart script terminate unidirection
diag	arp arp6 internals iperf lookup loopback netstat nettrace perfstat ping ping6 sendpacket speedtest top traceroute traceroute6 usb wlan
admin	banner chip clear config eeprom events feature firmware ftp memory quicksetup reboot shutdown site version web
logout	Terminates CLI session.

Command Line Help

For general Help and to display the commands to which you have rights, type:

```
help
```

For general command line Help, type:

```
help command line
```

For release notes for the current firmware release, type:

```
help release
```

For more information about a specific command, type help followed by the command, for example:

```
help set network or help admin firmware
```

Tips

- ◆ Type enough characters to identify the action, category, or parameter name uniquely. For parameter values, type the entire value. For example, you can shorten:

```
set network port 1 state static ipaddr 122.3.10.1 mask 255.255.0.0
```

to

```
se net por 1 st static ip 122.3.10.1 ma 255.255.0.0
```
- ◆ Use the Tab key to automatically complete action, category, or parameter names. Type a partial name and press **Tab** either to complete the name if only one is possible, or to display the possible names if more than one is possible. Following a space after the preceding name, Tab displays all possible names.
- ◆ Should you make a mistake while typing, backspace by pressing the Backspace key and/or the Delete key, depending on how you accessed the interface. Both keys work if you use VT100 emulation in your terminal access program when connecting to the console port. Use the left  and right  arrow keys to move within a command.
- ◆ Use the up  and down  arrows to scroll through previously entered commands. If desired, select one and edit it. You can scroll through up to 100 previous commands entered in the session.
- ◆ To clear an IP address, type 0.0.0.0, or to clear a non-IP address value, type CLEAR.

- ◆ When the number of lines displayed by a command exceeds the size of the window (the default is 25), the command output is halted until the user is ready to continue. To display the next line, press **Enter**, and to display the page, press the space bar. You can override the number of lines (or disable the feature altogether) with the `set cli` command.
- ◆ Keyboard Shortcuts:
 - Control-a:** move to the start of the line
 - Control-e:** move to the end of the line
 - Control-b:** move back to the start of the current word
 - Control-f:** move forward to the end of the next word
 - Control-u:** erase from cursor to the beginning of the line
 - Control-k:** erase from cursor to end of the line
- ◆ Show Commands Output Filtering (grep, with Posix Extended Regex functionality, see <https://www.man7.org/linux/man-pages/man7/regex.7.html>):


```
show <category> <parameters> grepi|grepic|grepe|grepec <Token|RE:Regex Token>
```

 - `grepi` - show output containing token (case sensitive)
 - `grepic` - show output containing token (case insensitive)
 - `grepe` - show output not containing token (case sensitive)
 - `grepec` - show output not containing token (case insensitive)

For example:

 - `'show network all grepi Bytes'` displays lines containing the string 'Bytes'
 - `'show network all grepi RE:[0-9]'` displays lines containing digits 0-9
 - `'show network all grepi "RE:^Gateway "'` displays lines starting with 'Gateway '

Administrative Commands

admin banner login

Syntax

```
admin banner login <Banner Text>
```

Description

Configures the banner displayed after the user logs in.

Note: To go to the next line, type `\n` and press **Enter**.

admin banner logout

Syntax

```
admin banner logout <Banner Text>
```

Description

Configures the banner displayed after the user logs out.

Note: To go to the next line, type `\n` and press **Enter**.

admin banner show

Syntax

```
admin banner show
```

Description

Displays the welcome, SSH, login, and logout banners.

admin banner ssh

Syntax

```
admin banner ssh <Banner Text>
```

Description

Configures the banner that displays prior to SSH authorization.

admin banner welcome

Syntax

```
admin banner welcome <Banner Text>
```

Description

Configures the banner displayed before the user logs in.

Note: To go to the next line, type `\n` and press **Enter**.

admin clear

Syntax

```
admin clear <resource_name>
```

Description

Resets various system resources. For example,

To clear the directory holding temporary files:

```
admin clear tmpdir
```

To remove the SSH Known Hosts Keys:

```
admin clear sshknownhosts
```

To clear the dmesg kernel log buffer:

```
admin clear dmesg
```

admin config checksum

Syntax

```
admin config checksum
```

Description

Displays a checksum for the current configuration. Can be used to determine if the configuration has changed.

admin config copy

Syntax

```
admin config copy <current|Config Name>  
[location <local|nfs|cifs|usb|sdcard>  
[nfssdir <NFS Mounted Directory>] [usbport <U1>] ]
```

Description

Copies the current configuration (or optionally, a configuration from another location) to the other bank (for dual-boot EMGs).

admin config rename|delete

Syntax

```
admin config rename|delete <Config Name>  
location <local|nfs|cifs|usb|sdcard|intsd>  
[nfssdir <NFS Mounted Directory>] [usbport <U1>]
```

Description

Deletes or renames a configuration.

admin config factorydefaults

Syntax

```
admin config factorydefaults [savesshkeys <enable|disable>]  
[savesslcert <enable|disable>][savescripts <enable|disable>]  
[preserveconfig <Config Params to Preserve>]
```

<Config Params to Preserve> is a comma-separated list of current configuration parameters to retain after the `config restore` or `config factorydefaults`:

nt	Networking
sv	Services
dt	Date/Time
lu	Local Users
dp	Device Ports
ra	Remote Authentication
ub	USB Port/SD Card
po	Power Outlets

Description

Restores the EMG unit to factory default settings.

admin config restore

Syntax

```
admin config restore <Config Name>
    location <local|ftp|sftp|nfs|cifs|usb|sdcard|intsd>
    [nfsdir <NFS Mounted Directory>] [usbport <U1>]
    [savesshkeys <enable|disable>][savesslcert <enable|disable>]
    [savescripts <enable|disable>]
    [onetimepassword <enable|disable>] [preserveconfig
<Config Params to Preserve>]
```

<Config Params to Preserve> is a comma-separated list of current configuration parameters to retain after the `config restore` or `factorydefaults`:

nt	Networking
sv	Services
dt	Date/Time
lu	Local Users
ra	Remote Authentication
dp	Device Ports
ub	USB Port/SD Card
po	Power Outlet

Description

Restores a saved configuration to the EMG.

admin config save**Syntax**

```
admin config save <Config Name>
      location <local|ftp|sftp|nfs|cifs|usb|sdcard|intsd>
      [nfssdir <NFS Mounted Dir>] [usbport <U1>]
      [savesshkeys <enable|disable>][savesslcert <enable|disable>]
      [savescripts <enable|disable>]
      [onetimepassword <enable|disable>]
```

Description

Saves the current EMG configuration to a selected location.

admin config show**Syntax**

```
admin config show <local|ftp|sftp|nfs|cifs|usb|sdcard>
      [nfssdir <NFS Mounted Dir>] [usbport <U1>]
      [sort <filename|date>]
```

Description

Lists the configurations saved to a location.

admin config commands**Syntax**

```
admin config commands <sftp|scp|usb|coppypaste>
      [escapechar <enable|disable>] [host <IP Address or Name>]
      [login <User Login>] [path <Directory>]
      [file <CLI Commands Filename>] [usbport <U1>]
```

Note: Note: the 'admin config commands' will output passwords in cleartext.

Note: The 'escapechar' option will prepend every "\" in the output with a "\".

Description

Exports the current configuration as a text file containing CLI commands. The file can be saved as a backup, optionally modified, and restored to the EMG.

admin config batch**Syntax**

```
admin config batch <sftp|scp|usb|coppypaste>
      [escapechar <enable|disable>] [host <IP Address or Name>]
      [login <User Login>] [path <Directory>]
      [file <CLI Commands Filename>] [usbport <U1>]
```

Note: The 'escapechar' option will remove the prepended '\ ' in the input, before running the CLI command.

Description

Imports a previously saved configuration text file containing CLI commands and applies it to the EMG.

admin eeprom

Syntax

```
admin eeprom slot <integer> [id <string>]
slot:
    0 for first slot
    1 for second slot
    2 for third slot
    3 for fourth slot
id:
    "04UBA" for 4 Port USB FRU, part number 330-0374-00 Rev A
    "04UBB" for 4 Port USB FRU, part number 330-0374-01 Rev A
    "04SPB" for 4 Port RJ45 FRU, part number 330-0373-00 Rev A
    "04SPC" for 4 Port RJ45 FRU, part number 330-0373-01 Rev A
    "01LTA" for LTE modem FRU
    "01WFA" for WiFi FRU
    "01DMA" for DialUp Modem FRU
```

Description

Commands for EEPROM IDs. These commands should only be used under the direction of Lantronix Technical Support.

Show/Update EEPROM ID of the attached FRU.

Not all EMG models will have all slots.

admin firmware update

Syntax

```
admin firmware update <ftp|tftp|sftp|nfs|usb|sdcard>
    file <Firmware File>
    key <Checksum Key> [nfssdir <NFS Mounted Dir>]
    [usbport <U1>][onetimepassword <enable|disable>]
    [verbose <enable|disable>]
```

Description

Updates the EMG firmware to a new revision (the firmware file should be accessible via the settings displayed by 'admin ftp show').

Note: the verbose flag will enable debug output for sftp and ftp.

admin firmware bootbank**Syntax**

```
admin firmware bootbank <1|2>
```

Description

Sets the boot bank to be used at the next EMG reboot.

admin firmware show**Syntax**

```
admin firmware show [viewlog <enable|disable>]
```

Description

Lists the current firmware revision, the boot bank status, and optionally displays the log containing details about firmware updates.

admin firmware clearlog**Syntax**

```
admin firmware clearlog
```

Description

Clears the firmware update log.

admin firmware bootcount**Syntax**

```
admin firmware bootcount <0|1>
```

Description

Configures bootcount parameter that control how many times the EMG has failed to boot. If this value reaches Boot Limit, the EMG will switch to the alternate boot bank. The EMG will switch to the alternate boot bank only once. For example, if it fails to boot Boot Limit times on bank 1, it will automatically switch to bank 2; if it fails to boot Boot Limit times on bank 2, it will enter advanced recovery mode. If Boot Count has reached Boot Limit, setting this value to 0 will enable the EMG to boot again. Default is 0, range is 0 - 1.

admin firmware bootlimit**Syntax**

```
admin firmware bootlimit <3-20>
```

Description

Configures bootlimit parameters that control how many times the EMG will fail to boot before switching to the alternate boot bank. After the EMG fails to boot 2 times Boot limit (so it has attempted to boot Boot Limit times on each bank), the EMG will go into advanced recovery mode, which may require support from Technical Support to resolve so that the EMG can be booted again. Default is 3 boots, range is 3 - 20.

admin firmware bootdelay**Syntax**

```
admin firmware bootdelay <3-1800>
```

Description

Configures bootcount parameters that control how seconds the bootloader pauses before booting the EMG. The default is 3 seconds and the range is between 3 and 1800 seconds.

admin firmware highrestimers**Syntax**

```
admin firmware highrestimers <enable|disable>
```

Description

Enables high resolution timers required for Performance Monitoring or disables high resolution timers (the default). Changing this setting requires a reboot in order for the change to take effect.

admin firmware uniquepassword**Syntax**

```
admin firmware uniquepassword <enable|disable>
```

Description

Enables or disables default sysadmin password that is unique to each device.

admin firmware watchdog**Syntax**

```
admin firmware watchdog <disable|180-1800 seconds>
```

Description

Configures how long the EMG waits for boot completion before forcing a reboot.

admin firmware panicreboot**Syntax**

```
admin firmware panicreboot <enable|disable>
```

Description

Enables EMG auto-reboot on a kernel panic.

admin firmware hwwatchdog**Syntax**

```
admin firmware hwwatchdog <enable|disable>
```

Description

Enables EMG Hardware Watchdog.

admin ftp password**Syntax**

```
admin ftp password
```

Description

Sets the FTP server password and prevent it from being echoed.

admin ftp server**Syntax**

```
admin ftp server <IP Address or Hostname> [login <User Login>] [path  
<Directory>]
```

Description

Sets the FTP/TFTP/SFTP server used for firmware updates and configuration save/restore.

admin ftp show**Syntax**

```
admin ftp show
```

Description

Displays FTP settings.

admin memory show**Syntax**

```
admin memory show
```

Description

Displays information about EMG memory usage.

admin memory swap add**Syntax**

```
admin memory swap add <Size of Swap in MB> usbport <U1>
```

Description

Creates a swap space from an external storage device.

admin memory swap delete**Syntax**

```
admin memory swap delete
```

Description

Deletes the swap space from an external storage device.

admin quicksetup**Syntax**

```
admin quicksetup
```

Description

Runs the quick setup script.

admin reboot**Syntax**

```
admin reboot
```

Description

Immediately terminates all connections and reboots the EMG.

admin shutdown**Syntax**

```
admin shutdown
```

Description

Prepares the EMG to be powered off.

admin site**Syntax**

```
admin site row <Data Center Rack Row Number>
admin site cluster <Data Center Rack Group Number>
admin site rack <Data Center Rack Number>
admin site tag <Site Description>
admin site show
```

Description

Configures information about the site where the EMG is located.

admin sysinfo

```
admin sysinfo save <ZIP File Name> location
<ftp|sftp|scp|nfs|usb|sdcard>
[nfsdir <NFS Mounted Directory>] [usbport <U1>]
[host <IP Address or Name>] [login <User Login>]
[path <Path to Save File>]
[comment <Comment Included in the System Info File>]
[auto <enable|disable>]
```

Description

Saves the current EMG system info to a selected location in ZIP format.

Note: the 'auto' option includes the logs, does not prompt for an encryption password for the sysinfo file, and appends a date-time stamp to the filename; this supports automating sysinfo generation from a CLI batch script.

For example, a script that saves a sysinfo file every 60 seconds:

```
[emg]> show script type batch name auto_sysinfo
____Batch Script 'auto_sysinfo'_____
Group/Perms: Adm/ad,nt,sv,dt,lu,ra,um,dp,ub,rs,fc,dr,sn,wb,sk,do,sd,
             md,rp,di
set cnt 5
while { $cnt >= 1 } {
    admin sysinfo save EMGsysinfo location usb auto enable
    sleep 60
    set cnt [expr $cnt - 1]
}
```

admin version**Syntax**

```
admin version
```

Description

Displays current hardware and firmware information.

admin web timeout**Syntax**

```
admin web timeout <disable|5-120>
```

Description

Configures the timeout for web sessions.

admin web tlsv10**Syntax**

```
admin web tlsv10 <enable|disable>
```

Description

Enables or disables TLS v1.0.

admin web tlsv11**Syntax**

```
admin web tlsv11 <enable|disable>
```

Description

Enables or disables TLS v1.1.

admin web tlsv12**Syntax**

```
admin web tlsv12 <enable|disable>
```

Description

Enables or disables TLS v1.2.

admin web group**Syntax**

```
admin web group <Local or Remote Group Name>
```

Description

Configures the group that can access the web.

admin web server**Syntax**

```
admin web server <enable|disable>
```

Description

Enables or disables running the web server (TCP ports 80 and 443).

admin web banner**Syntax**

```
admin web banner <banner text>
```

Description

Configures the banner displayed on the web home page.

admin web iface**Syntax**

```
admin web iface <none,eth1,eth2,veth1,veth2,cell,wlan,ap,ppp>
```

Description

Defines a list of network interfaces the web is available on.

admin web ciphers**Syntax**

```
admin web ciphers <prompt|Comma Separated List of Disabled Ciphers>
```

Description

Defines the set of TLS ciphers that are enabled, either by prompting for each cipher or by specifying a complete list of disabled ciphers.

admin web terminate**Syntax**

```
admin web terminate <Session ID>
```

Description

Terminates a web session. Use 'admin web show' to view the current sessions and their ID.

admin web certificate import**Syntax**

```
admin web certificate import via <sftp|scp> [rootfile  
    <Cert Authority File>]  
    certfile <Certificate File> privfile <Private Key File>  
    host <IP Address or Name> login <User Login> [path <Path to Files>]
```

Description

Imports an SSL certificate.

admin web certificate reset**Syntax**

```
admin web certificate reset
```

Description

Resets the web server to the default SSL certificate.

admin web certificate show**Syntax**

```
admin web certificate show
```

Description

Displays the web server SSL certificate.

admin web certificate custom**Syntax**

```
admin web certificate custom
```

Description

Generates a custom self-signed SSL certificate. The SHA256 hashing algorithm will be used to generate the certificate.

admin web restart**Syntax**

```
admin web restart
```

Description

Restarts the web server.

admin web show**Syntax**

```
admin web show [viewcipherlist <enable|disable>]
```

Description

Display current settings, with optional extra sessions or current ciphers.

Warning: *The following admin chip commands should only be used under the direction of Lantronix Technical Support.*

admin chip resetmodem**Description**

Resets the internal modem chip in key system chips.

Syntax

```
admin chip resetmodem  
admin chip reseti2cmux
```

Description

Resets the I2C Mux chip in key system chips.

Syntax

```
admin chip reseti2cmux  
admin chip resetsfp ethport <1|2>
```

Description

Resets the SFP chip in key system chips.

Syntax

```
admin chip resetsfp ethport <1|2>
```

Audit Log Commands

show auditlog

Syntax

```
show auditlog <parameters>
```

Parameters

```
sort <date|command|user>
display <head|tail> [numlines <Number of Lines>]
starttime <MMDDYYhhmm[ss]>
endtime <MMDDYYhhmm[ss]>
email <Email Address>
Defaults:    sort=date, numlines=40
```

Note: Note: display and time parameters cannot be used simultaneously.

Description

Display the audit log, sorted by date/time. The audit log may also be sorted by command or user, and the contents of the log may be cleared.

show auditlog clear

Syntax

```
show auditlog clear
```

Description

Clears the auditlogs

Authentication Commands

set auth

Syntax

```
set auth <one or more parameters>
```

Parameters

```
authusenextmethod <enable|disable>
kerberos <1-6>
ldap <1-6>
localusers <1-6>
nis <1-6>
radius <1-6>
tacacs+ <1-6>
```


Description

Sets ordering of authentication methods.

Local Users authentication is always the first method used. Any methods omitted from the command are disabled.

show auth

Syntax

```
show auth
```

Description

Displays authentication methods and their order of precedence.

show user

Syntax

```
show user
```

Description

Displays attributes of the currently logged in user.

Kerberos Commands

set kerberos

Syntax

```
set kerberos <one or more parameters>
```

Parameters

```
allowdialback <enable|disable>
clearports <Port List>
custommenu <Menu Name>
dataports <Port List>
dialbacknumber <Phone Number>
breakseq <1-10 Chars>
escapeseq <1-10 Chars>
group <default|power|admin>
ipaddr <Key Distribution Center IP Address>
kdc <Key Distribution Center>
listenports <Port List>
permissions <Permission List>
```

Note: See 'help user permissions' for information on groups and user rights.

```
port <Key Distribution Center TCP Port>
realm <Kerberos Realm>
state <enable|disable>
useldapforlookup <enable|disable>
```

Description

Configures the EMG to use Kerberos to authenticate users who log in via the Web, SSH, Telnet, or the console port.

show kerberos

Syntax

```
show kerberos
```

Description

Displays Kerberos settings.

LDAP Commands

set ldap

Syntax

```
set ldap <one or more parameters>
```

Parameters

```
state <enable|disable>
server1 <IP Address or Name>
server2 <IP Address or Name>
port <TCP Port>
base <LDAP Base>
bindname <Bind Name>
bindwithlogin <enable|disable>
useldapschema <enable|disable>
adsupport <enable|disable>
filteruser <User Login Attribute>
filtergroup <Group Objectclass>
grmemberattr <Group Membership Attribute>
grmembervalue <dn|name>
encrypt <starttls|ssl|disable>
dataports <Port List>
listenports <Port List>
clearports <Port List>
escapeseq <1-10 Chars>
breakseq <1-10 Chars>
custommenu <Menu Name>
allowdialback <enable|disable>
```

```
dialbacknumber <Phone Number>  
group <default|power|admin>  
permissions <Permission List>
```

Note: See 'help user permissions' for information on groups and user rights.

Description

Configures the EMG to use LDAP to authenticate users who log in via the Web, SSH, Telnet, or the console port.

set ldap bindpassword

Description

Set the LDAP bind password.

Syntax

```
set ldap bindpassword
```

set ldap certificate import

Description

To upload X.509/PEM certificate for Start TLS encrypted connections:

Syntax

```
set ldap certificate import via <sftp|scp> rootfile <Cert Auth File>  
    certfile <Certificate File> keyfile <Key File>  
    host <IP Address or Name> login <User Login> [path <Path to Files>]
```

set ldap certificate delete

Description

To delete an LDAP certificate.

Syntax

```
set ldap certificate delete
```

show ldap

Syntax

```
show ldap
```

Description

Displays LDAP settings.

Local Users Commands

set localusers state

Syntax

```
set localusers state <enable|disable>
```

Description

Enables or disables authentication of local users.

set localusers add|edit

Syntax

```
set localusers add|edit <User Login> [<parameters>]
```

Parameters

```
allowdialback <enable|disable>
breakseq <1-10 Chars>
changenextlogin <enable|disable>
changepassword <enable|disable>
clearports <Port List>
dataports <Port List>
dialbacknumber <Phone Number>
displaymenu <enable|disable>
escapeseq <1-10 Chars>
listenports <Port List>
custommenu <Menu Name>
uid <User Identifier>
group <default|power|admin|Custom Group Name>
passwordexpires <enable|disable>
permissions <Permission List>
```

Note: See 'help user permissions' for information on groups and user rights. Password reuse is insecure. Remove Escape & Break Sequences for users making raw binary connections to Device Ports.

Description

Configures local accounts (including sysadmin) who log in to the EMG by means of the Web, SSH, Telnet, or the console port.

set localusers allowreuse

Syntax

```
set localusers allowreuse <enable|disable>
```

Description

Sets whether a login password can be reused.

set local users complexpasswords

Syntax

```
set localusers complexpasswords <enable|disable>
```

Description

Sets whether a complex login password is required. Complex passwords require at least one uppercase character, one lowercase character, one digit, and one non-alphanumeric character.

set localusers delete

Syntax

```
set localusers delete <User Login>
```

Description

Deletes a local user.

set localusers lifetime

Syntax

```
set localusers lifetime <Number of Days>
```

Description

Sets the number of days the login password may be used. The default is 90 days.

set localusers maxloginattempts

Syntax

```
set localusers maxloginattempts <Number of Logins>
```

Description

Sets the maximum number of login attempts before the account is locked. Disabled by default.

set localusers password

Syntax

```
set localusers password <User Login>
```

Description

Sets a login password for the local user.

set localusers periodlockout**Syntax**

```
set localusers periodlockout <Number of Minutes>
```

Description

Sets the number of minutes after a lockout before the user can try to log in again. Disabled by default.

set localusers periodwarning**Syntax**

```
set localusers periodwarning <Number of Days>
```

Description

Sets the number of days the system warns the user that the password will be expiring. The default is 7 days.

set localusers reusehistory**Syntax**

```
set localusers reusehistory <Number of Passwords>
```

Description

Sets the number of passwords the user must use before reusing an old password. The default is 4.

set localusers multipleadminlogins**Syntax**

```
set localusers multipleadminlogins <enable|disable>
```

Description

Allows multiple admin logins among local users to the web server.

set localusers consoleonlyadmin**Syntax**

```
set localusers consoleonlyadmin <enable|disable>
```

Description

Sets local users. to console only admin setting. If enabled, the admin user can only log into the EMG via the console, and will be prevented from logging in via the web, SSH or Telnet.

set localusers lock|unlock

Syntax

```
set localusers lock|unlock <User Login>
```

Description

Blocks (lock) or allows (unlock) a user's ability to login.

show localusers

Syntax

```
show localusers [display <brief|extended>] [user <User Login>]
```

Description

Displays local users.

NIS Commands

set nis

Syntax

```
set nis <one or more parameters>
```

Parameters

```
allowdialback <enable|disable>
broadcast <enable|disable>
clearports <Port List>
custommenu <Menu Name>
dialbacknumber <Phone Number>
dataports <Port List>
domain <NIS Domain Name>
breakseq <1-10 Chars>
escapeseq <1-10 Chars>
group <default|power|admin>
listenports <Port List>
master <IP Address or Hostname>
permissions <Permission List>
```

Note: See 'help user permissions' for information on groups and user rights.

```
slave1 <IP Address or Hostname>  
slave2 <IP Address or Hostname>  
slave3 <IP Address or Hostname>  
slave4 <IP Address or Hostname>  
slave5 <IP Address or Hostname>  
state <enable|disable>
```

Description

Configures the EMG to use NIS to authenticate users who log in via the Web, SSH, Telnet, or the console port.

show nis

Syntax

```
show nis
```

Description

Displays NIS settings.

RADIUS Commands

set radius

Syntax

```
set radius <one or more parameters>
```

Parameters

```
state <enable|disable>  
allowdialback <enable|disable>  
clearports <Port List>  
custommenu <Menu Name>  
dataports <Port List>  
dialbacknumber <Phone Number>  
breakseq <1-10 Chars>  
escapeseq <1-10 Chars>  
group <default|power|admin>  
listenports <Port List>  
permissions <Permission List>
```

Note: See 'help user permissions' for information on groups and user rights.

```
timeout <enable|1-30>
```

Note: Sets the number of seconds after which the connection attempt times out. It may be 1-30 seconds.

Description

Configures the EMG to use RADIUS to authenticate users who log in via the Web, SSH, Telnet, or the console port.

set radius server

Syntax

```
set radius server <1|2> host <IP Address or Hostname> secret <Secret>
[port <TCP Port>]
```

Description

Identifies the RADIUS server(s), the text secret, and the number of the TCP port on the RADIUS server.

Note: The default port is 1812.

show radius

Syntax

```
show radius
```

Description

Displays RADIUS settings.

TACACS+ Commands

set tacacs+

Syntax

```
set tacacs+ <one or more parameters>
```

Parameters

```
state <enable|disable>
server1 <IP Address or Name>
server2 <IP Address or Name>
server3 <IP Address or Name>
port <TCP Port>
encrypt <enable|disable>
authservice <login|pap|chap>
service <Service to Authorize>
protocol <Protocol for Service>
timeout <1-10 seconds>
srcipaddr <none|eth1|eth2|veth1|veth2>
srcipv6addr <none|eth1|eth2|veth1|veth2>
```

```
dataports <Port List>
listenports <Port List>
clearports <Port List>
escapeseq <1-10 Chars>
breakseq <1-10 Chars>
custommenu <Menu Name>
allowdialback <enable|disable>
dialbacknumber <Phone Number>
group <default|power|admin>
permissions <Permission List>
```

Note: See 'help user permissions' for information on groups and user rights.

Description

Configures the EMG to use TACACS+ to authenticate users who log in via the Web, SSH, Telnet, or the console port.

set tacacs+ secret

Syntax

```
set tacacs+ secret
```

Description

Set the TACACS+ secret (any extra parameters will be ignored).

show tacacs+

Syntax

```
show tacacs+
```

Description

Displays TACACS+ settings.

User Permissions Commands

Syntax

help user permissions

Synopsis

User Permissions

Each user is a member of a group (Default Users, Power Users, Administrators), and has a set of user rights associated with the group. Additional user rights which are not defined by their group may also be granted to them using the 'permissions' parameter. A <Permission List> is a comma-separated list of user rights to be added to or removed from the user's current permissions. Precede the two-letter acronym with a '-' to remove a user right. For example, 'nt,dt,-wb' adds Networking and Date/Time rights and removes Web Access rights.

User Rights:

nt - configure Networking	dp - configure Device Ports
sv - configure Services	do - Device Port operations
dt - configure Date/Time	ub - configure USB Devices
lu - configure Local Users	um - configure User Menus
ra - configure Remote Authentication methods	dr - view Diagnostics & Reports
rs - Reboot or Shutdown the EMG	wb - Web Access
fc - manage Firmware and Configurations	sn - configure Secure Ltx Network
sd - manage SD Card	md - configure Internal Modem
rp - manage Remote Power Managers	sk - configure SSH Keys
ad - full Administrative rights	di - configure DIO Ports
sw - configure Switch Ports	

Note: Note: for remote authentication methods, there is one group and set of user rights defined for all users who login via a remote authentication method.

set localusers group

Syntax

```
set localusers add|edit <user> group <default|power|admin|custom group name>
```

Description

Adds a local user to a user group or changes the group the user belongs to.

set localusers lock**Syntax**

```
set localusers lock <User Login>
```

Description

Blocks (locks) a user's ability to login.

set localusers unlock**Syntax**

```
set local users unlock <User Login>
```

Description

Allows (unlocks) a user's ability to login.

set localusers permissions**Syntax**

```
set localusers add|edit <user> permissions <Permission List>
```

Note: See 'help user permissions' for information on groups and user rights.

To remove a permission, type a minus sign before the two-letter abbreviation for a user permission.

Description

Sets a local user's permissions (not defined by the user group).

set <nis|ldap|radius|kerberos|tacacs+> permissions**Syntax**

```
set <nis|ldap|radius|kerberos|tacacs+> permissions <Permission List>
```

Note: See 'help user permissions' for information on groups and user rights.

Description

Sets permissions not already defined by the assigned permissions group.

show user**Syntax**

```
show user
```

Description

Displays the rights of the currently logged-in user.

Remote User Commands

set remoteusers add|edit

Syntax

```
set remoteusers add|edit <User Login> [<parameters>]
```

Parameters

```
dataports <Port List>
breakseq <1-10 Chars>
escapeseq <1-10 Chars>
listenports <Port List>
clearports <Port List>
custommenu <Menu Name>
displaymenu <enable|disable>
allowdialback <enable|disable>
dialbacknumber <Phone Number>
group <default|power|admin|Custom Group Name>
permissions <Permissions List>
```

Note: See 'help user permissions' for information on groups and user rights.

To remove a permission, type a minus sign before the two-letter abbreviation for a user right.

Description

Sets attributes for users who log in by a remote authentication method.

set remoteusers listonlyauth

Syntax

```
set remoteusers listonlyauth <enable|disable>
```

Description

Configure whether remote users who are not part of the remote user list will be authenticated.

set remoteusers denyaccessnocustomgroup

Syntax

set remoteusers denyaccessnocustomgroup <enable|disable>

Description

Access to authenticated remote users whose LDAP group or TACACS+ priv_lvl map to a EMG custom group.

set remoteusers lock|unlock

Syntax

set remoteusers lock|unlock <User Login>

Description

Allow (unlock) or block (lock) a user's ability to login.

set remoteusers delete

Syntax

set remoteusers delete <User Login>

Description

Removes a remote user.

show remoteusers

Syntax

show remoteusers [display <brief|extended>] [user <User Login>]

Description

Displays settings for all remote users.

set <nis|ldap|radius|kerberos|tacacs+> group

Syntax

set <nis|ldap|radius|kerberos|tacacs+> group <default|power|admin>

Description

Sets a permission group for remotely authorized users.

Access List Commands

set accesslist add/edit

Syntax

```
set accesslist add|edit <Access List Name> [<parameters>]
```

Parameters

name <New Access List Name>

response <hangup|ignore>

Description

Configure an access list of phone numbers to be granted access for modem dial-in connections. Create or edit an access list (when creating a list, the user will be prompted for the list entries).

set accesslist add/edit

Syntax

```
set accesslist add|edit <Access List Name>  
    entry <Entry Number> phonenumber <Phone Number>
```

Description

Add a phone number entry to a list or edit an existing entry.

set accesslist delete

Syntax

```
set accesslist add|edit <Access List Name>  
    entry <Entry Number> phonenumber <Phone Number>
```

Description

Delete an access list, or a single phone number entry from an access list.

show accesslist

Syntax

```
show accesslist <all|names|Access List Name>
```

Description

Displays access list.

Cellular Modem Commands

set cellular

Syntax

```
set cellular <parameters>
set cellular simpin
set cellular factoryreset
set cellular reboot
set cellular cellpass
set cellular atcmd <AT Command>
```

Parameters

```
state <dhcp|disable>
apn <APN of Mobile Carrier>
apnauto <enable|disable>
preferrednet <AUTO|4G|3G>
roam <enable|disable>
carrier <carrier name>
cellauth <none|pap|chap>
celluser <Cellular Carrier Username>
simlock <enable|disable>
ipv6 <enable|disable>
mtu <Maximum Transmission Unit>
```

Description

Configure cellular modem.

Note: If *apnauto* is enabled, any predefined APN will be cleared and any APN set with the 'apn' parameter will be overridden; the EMG will try to perform the initial LTE connection without an APN.

set cellular update

Syntax

```
set cellular update <ftp|sftp|scp|usb|sdcard>
                    fwfile <Firmware File> prifile <carrier PRI File>
                    [host <IP Address or Name>] [login <User Login>] [path <File
Path>]
```

Description

Transfer files to initiate a firmware update on the cellular modem.

set cellular fota

Syntax

```
set cellular fota <enable|disable>
```

Description

Enable FOTA (Firmware Over The Air) mode on the EMG. It is recommended to limit other activity on the EMG while the firmware update is performed. To enable FOTA mode on the EMG, run the 'set cellular fota enable' command. This will place the cellular modem in a mode where it can communicate with AirVantage cloud. Once the firmware update is complete, the FOTA mode should be disabled by running the 'set cellular fota disable' command. See online help for more information.

show cellular

Syntax

```
show cellular [basic|config|status]
```

Description

Displays cellular modem configuration and status.

show cellular fota

Syntax

```
show cellular fota
```

Description

Displays cellular modem FOTA configuration and status.

PercepXion Commands

set px client

Syntax

```
set px client <enable|disable>
```

Description

Configure interaction with PercepXion management server. The communication with the server is enabled by default, and can be disabled.

set px statusinterval**Syntax**

```
set px statusinterval <1-60 minutes> fwconfiginterval <1-72 hours>
```

Description

Set interval between status updates, and firmware and configuration checks.

set px fwupdate**Syntax**

```
set px fwupdate <enable|disable> configupdate <enable|disable>
```

Description

Enable or disable firmware and configuration updates via PercepXion.

set px rebootafterupdate**Syntax**

```
set px rebootafterupdate <enable|disable>
```

Description

Enable or disable reboots after firmware or configuration updates.

set px allowremoteconnection**Syntax**

```
set px allowremoteconnection <enable|disable>
```

Description

Enable or disable remote connections.

set px auditlogmessages**Syntax**

```
set px auditlogmessages <enable|disable>
```

Description

Enable or disable sending audit log messages.

set px connection**Syntax**

```
set px connection <cloud|onpremise> [<one or more parameters>]
```

Parameters

```
host <IP Address or Name>  
port <TCP Port>  
secureport <enable|disable>  
validatecerts <enable|disable>  
mqtstate <enable|disable>
```

Description

Configure PercepXion Cloud or On-Premise settings.

set px devicename**Syntax**

```
set px devicename <Device Name> description <Device Description>
```

Description

Configure the device name and description used for registration.

set px timeoutcli**Syntax**

```
set px timeoutcli <1-1800 seconds>  
set px timeoutdp <1-1800 seconds>
```

Description

Configure the timeout for the PercepXion Web Terminal sessions.

set px digitalprobe**Syntax**

```
set px digitalprobe <Device Port # or List or Name>  
frequency <disable|15-3600 seconds>
```

Description

Configures the device port digital probe for determining managed device connection status.

set px id**Syntax**

```
set px id
```

Description

Set the device ID.

set px key**Syntax**

```
set px key
```

Description

Set the PercepXion key

set px useproxy**Syntax**

```
set px useproxy <enable|disable> [<one or more parameters>]
```

Parameters

```
proxytype <socks5|http>  
proxyhost <FQDN or IP Address>  
proxyport <Port Number>  
proxylogin <User Name>
```

Description

Enables or disables the use of a proxy server to act as a gateway between the PercepXion client and the PercepXion server.

set px proxypassword**Syntax**

```
set px proxypassword
```

Description

Set the Proxy Server password.

set px clear updatelog**Syntax**

```
set px clear updatelog
```

Description

Clear the Firmware/Config update log.

show px

Syntax

```
show px
show px status
show px perfmon
show px scripts
show px probes
```

Description

Show PercepXion settings

show px connecttest

Syntax

```
show px connecttest
```

Description

Test connection to PercepXion server (with proxy settings if configured).

CLI Commands

set cli scscommands

Syntax

```
set cli scscommands <enable|disable>
Commands: info          direct <Device Port # or Name>
           version       listen <Device Port # or Name>
           reboot        clear <Device Port # or Name>
           poweroff       telnet <IP Address or Name>
           listdev        ssh <IP Address or Name>
```

Description

Configures the current command line session. Allows you to use SCS-compatible commands as shortcuts for executing commands. It is disabled by default.

Note: Settings are retained between CLI sessions for local users and users listed in the remote users list.

set cli terminallines**Syntax**

```
set cli terminallines <enable|disable>
```

Description

Sets the number of lines in the terminal emulation (screen) for paging through text one screenful at a time, if the EMG cannot detect the size of the terminal automatically.

set cli allusers**Syntax**

```
set cli allusers <enable|disable>
```

Description

Globally enable or disable the terminallines feature for all users. Only sysadmin users or users with full administrative rights can modify the allusers parameter.

set cli menu**Syntax**

```
set cli menu <start|Menu Name>
```

Description

If a menu is associated with the current user and the menu was not displayed at login, 'start' will run the menu. Users with full administrative or menu user rights can also specify the name of any menu to run.

Note: Settings are retained between CLI sessions for local users and users listed in the remote users list.

show cli**Syntax**

```
show cli
```

Description

Displays current CLI settings.

show user**Syntax**

```
show user
```

Description

Displays attributes of the currently logged in user.

set history**Syntax**

```
set history clear
```

Description

Clears the commands that have been entered during the command line interface session.

show history**Syntax**

```
show history
```

Description

Displays the last 100 commands entered during the session.

Connection Commands

connect bidirection**Syntax**

```
connect bidirection <Port # or Name> <endpoint> <one or more Parameters>
```

Parameters

Endpoint is one of:

charcount <# of Chars>

charseq <Char Sequence>

charxfer <toendpoint|fromendpoint>

date <MMDDYYhhmm[ss]>

deviceport <Device Port # or Name>

exclusive <enable|**disable**>

ssh <IP Address or Name> [port <TCP Port>] [<SSH flags>]

where <SSH flags> is one or more of:

user <Login Name>

version <1|2>

command <Command to Execute>

tcp <IP Address> [port <TCP Port>]

telnet <IP Address or Name> [port <TCP Port>]

trigger <**now**|datetime|chars>

If the trigger is `datetime` (establish connection at a specified date/time), enter the `date` parameter. If the trigger is `chars` (establish connection on receipt of a specified number or characters or a character sequence), enter the `charxfer` parameter and either the `charcount` or the `charseq` parameter.

```
udp <IP Address> [port <UDP Port>]
```

Description

Connects a device port to another device port or an outbound network connection (data flows in both directions).

connect direct

Syntax

```
connect direct <endpoint>
```

Parameters

Endpoint is one of:

```
deviceport <Device Port # or Name|U1|U2>
telnet <IP Address or Name> [port <TCP Port>]
ssh <IPv4/IPv6 Address or Name> [port <TCP Port>] [<SSH flags>]
tcp <IP Address> [port <TCP Port>]
udp <IP Address> [port <UDP Port>]
hostlist <Host List>
```

where <SSH flags> is one or more of:

```
user <Login Name>
iface <eth1|eth2|veth1|veth2|eth1v6|eth2v6|veth1v6|veth2v6>
command <Command to Execute>
```

Description

Connects to a device port to monitor and/or interact with it, or establishes an outbound network connection.

connect forward

Syntax

```
connect forward iface <eth1|eth2> inport <TCP port> ipaddr <IP Address> outport <TCP Port>
```

Description

Configure a port on Eth1 or Eth2 to listen for incoming connections and redirect traffic to an IP address:Port on the Ethernet switch or local subnet.

Note: This requires that SSH logins to the CLI be enabled.

connect global outgoingtimeout**Syntax**

```
connect global outgoingtimeout <disable|1-9999 seconds>
```

Description

Sets the amount of time the EMG will wait for a response (sign of life) from an SSH/Telnet server that it is trying to connect to.

Note: *This is not a TCP timeout.*

connect listen deviceport**Syntax**

```
connect listen deviceport <Device Port # or Name>
```

Description

Monitors a device port.

connect restart**Syntax**

```
connect restart <Connection ID>
```

Description

Restarts a forwarding, bidirectional or unidirectional connection that was previously terminated with 'keep' enabled.

Use 'show connections' to view the current connections and their ID.

connect script

See [Script Commands on page 486](#).

connect terminate**Syntax**

```
connect terminate <Connection ID>
```

Description

Terminates a connection.

connect unidirection**Syntax**

```
connect unidirection <Device Port # or Name>
    dataflow <toendpoint|fromendpoint> <endpoint> <one or more
parameters>
<endpoint> is one of:
deviceport <Port # or Name>
telnet <IP Address or Name> [port <TCP Port>]
ssh <IP Address or Name> [port <TCP Port>][<SSH flags>]
tcp <IP Address> [port <TCP Port>]
udp <IP Address> [port <UDP Port>]
```

Parameters

```
exclusive <enable|disable>
trigger <now|datetime|chars>
date <MMDDYYhhmm[ss]>
charcount <# of Chars>
charseq <Char Sequence>
Defaults: exclusive=disable, trigger=now
```

```
<SSH flags> is one or more of:
user <Login Name>
version <1|2>
command <Command to Execute>
```

If the trigger is `datetime` (establish connection at a specified date/time), enter the date parameter. If the trigger is `chars` (establish connection on receipt of a specified number or characters or a character sequence), enter either the `charcount` or the `charseq` parameter. An existing connection can be modified by giving this command with the endpoints and dataflow of the connection along with the updated parameters.

Description

Connects a device port to another device port or an outbound network connection (data flows in one direction).

show connections**Syntax**

```
show connections [deviceport <Device Port # or Name>]
                 [email <Email Address>]
```

Description

Displays a list of all current connections. You can optionally email the displayed information.

The connection IDs are in the left column of the resulting table. The connection ID associated with a particular connection may change if the connection times out and is restarted.

show connections connid**Syntax**

```
show connections connid <Connection ID> [email <Email Address>]
```

Description

Displays details for a single connection. You can optionally email the displayed information.

Console Port Commands

set consoleport**Syntax**

```
set consoleport <one or more parameters>
```

Parameters

```
access <enable|disable>
baud <300-115200>
databits <7|8>
flowcontrol <none|xon/xoff|rts/cts>
group <Local or Remote Group Name>
parity <none|odd|even>
showlines <disable|1-50 lines>
stopbits <1|2>
timeout <disable|1-30>
```

Description

Configures console port settings.

show consoleport**Syntax**

```
show consoleport
```

Description

Displays console port settings.

Custom User Menu Commands

When creating a custom user menu, note the following limitations:

- ◆ Maximum of 20 custom user menus.

- ◆ Maximum of 50 commands per custom user menu (logout is always the last command).
- ◆ Maximum of 15 characters for menu names.
- ◆ Maximum of five nested menus can be called.
- ◆ No syntax checking. (Enter each command correctly.)

set localusers

Syntax

```
set localusers add|edit <User Login> custom menu <Menu Name>
```

Description

Assigns a custom user menu to a local user.

set menu add

Syntax

```
set menu add <Menu Name> [command <Command Number>]
```

Description

Creates a new custom user menu or adds a command to an existing custom user menu.

```
set menu edit
```

Syntax

```
set menu edit <Menu Name> <parameter>
```

Parameters

```
command <Command Number>  
nickname <Command Number>  
redisplaymenu <enable|disable>  
shownicknames <enable|disable>  
title <Menu Title>
```

Description

Changes a command within an existing custom user menu. Changes a nickname within an existing custom user menu. Enables or disables the redisplay of the menu before each prompt. Enables or disables the display of command nicknames instead of commands. Sets the optional title for a menu.

set menu delete

Syntax

```
set menu delete <Menu Name> [command <Command Number>]
```

Description

Deletes a custom user menu or one command within a custom user menu.

set <nis|ldap|radius|kerberos|tacacs+> custommenu

Syntax

```
set <nis|ldap|radius|kerberos|tacacs> custommenu <Menu Name>
```

Description

Assigns a custom menu to users who authenticate via NIS, LDAP, Radius, Kerberos, or TACACS+.

set remoteusers add|edit

Syntax

```
set remoteusers add|edit <User Login> custommenu <Menu Name>
```

Description

Sets a default custom menu for remotely authorized users.

show menu

Syntax

```
show menu <all|Menu Name>
```

Description

Displays a list of all menu names or all commands for a specific menu.

Email Commands

show emaillog

Syntax

```
show emaillog [email <Email Address>]
```

Description

Displays the email log.

show emaillog clear**Syntax**

```
show emaillog clear
```

Description

Clears the email log.

show emaillog smtplog**Syntax**

```
show emaillog smtplog
```

Description

Displays the SMTP log along with SMTP protocol details.

show emaillog smtplog clear**Syntax**

```
show emaillog smtplog clear
```

Description

Clears the SMTP log.

Date and Time Commands

set datetime**Syntax**

```
set datetime <one parameter>
```

Parameters

```
date <MMDDYYhhmm[ss]>  
timezone <Time Zone>
```

Note: If you do not know a valid <Time Zone>, enter 'timezone <invalid time zone>' and you will be guided through selecting one from the available time zones.

Description

Sets the local date, time, and local time zone (one parameter at a time).

show datetime**Syntax**

```
show datetime
```

Description

Displays the local date, time, and time zone.

set ntp**Syntax**

```
set ntp <one or more parameters>
```

Parameters

```
state <enable|disable>
sync <broadcast|poll>
poll <local|public>
localserver1 <IP Address or Hostname>
localserver2 <IP Address or Hostname>
localserver3 <IP Address or Hostname>
localserver4 <IP Address or Hostname>
localserver5 <IP Address or Hostname>
localserver6 <IP Address or Hostname>
publicserver <IP Address or Hostname>
srcipaddr <none|eth1|eth2|veth1|veth2>
srcipv6addr <none|eth1|eth2|veth1|veth2>
```

Description

Synchronizes the EMG clock with a remote time server using NTP.

set ntp localserverid**Syntax**

```
set ntp localserverid <1-6> [keyindex <1-65535>]
                             [hash <disable|aes128cmac|ripemd160|sha1|md5>]
```

Description

Configure NTP authentication for local servers 1-6; for each server, configure a key index and the message digest algorithm.

set ntp localserverkey**Syntax**

```
set ntp localserverkey <1-6> format <hex|ascii>
```

Description

Configure HEX or ASCII key for NTP authentication for local servers 1-6.

show ntp

Syntax

show ntp

Description

Displays NTP settings.

Device Commands

set command

Syntax

set command <Device Port # or Name or List> <one or more parameters>

Parameters

sensorsoft lowtemp <Low Temperature>

Sets the lowest temperature permitted for the port.

sensorsoft hightemp <High Temperature>

Sets the highest temperature permitted for the port.

sensorsoft lowhumidity <Low Humidity %>

Sets the lowest humidity permitted for the port.

sensorsoft highhumidity <High Humidity %>

Sets the lowest humidity permitted for the port.

sensorsoft degrees <celsius|fahrenheit>

Enables or disables temperature settings as celcius or fahrenheit.

sensorsoft traps <enable|disable>

Enables or disables traps when specified conditions are met.

sensorsoft status

Displays the status of the port.

sensorsoft showall

Displays the status for all connected Sensorsoft devices and ignores the device port\nlist.

Note: The Sensorsoft lowtemp and hightemp settings are given in the scale specified by the degrees setting.

Description

Sends commands to (or control) a device connected to an EMG device port over the serial port.

Note: Currently the only devices supported for this type of interaction are Sensorsoft devices.

Device Port Commands

set deviceport global

Syntax

```
set deviceport global <one or more parameters>
```

Parameters

```
sshport <TCP Port>
telnetport <TCP Port>
tcpport <TCP Port>
autorefreshcounters <enable|disable>
```

Description

Configures settings for all or a group of device ports.

set deviceport port

Description

Sets the dialout password.

Syntax

```
set deviceport port <Device Port # or List or Name> <one or more device
port parameters>
```

Example: set deviceport port 2-5,6,12,15-16 baud 2400

Parameters

```
actiondelay <Action Delay>
actionrestart <Restart Delay>
assertdtr <enable|disable>
auth <pap|chap>
banner <Banner Text>
baud <300-921600>
breakseq <1-10 Chars>
bytethreshold <# of Characters>
```

```

calleridcmd <Modem Command String>
calleridlogging <enable| disable>
cbctype <admin|user>
cbcpnocalback <enable|disable>
chapauth <chaphost|localusers>
chaphost <CHAP Host or User Name>
checkdsr <enable|disable>
closedsr <enable|disable>
connectedmsg <enable|disable>
databits <7|8>
device <none|sensorsoft|rpm>
detectname <enable|disable>
detecttokens <Name Detection Tokens>
dialbackdelay <PPP Dial-back Delay>
dialbacknumber <username|Phone Number>
dialbackretries <1-10>
dialinlist <Host List for Dial-in>
dialoutlogin <Remote User Login>
dialoutnumber <Phone Number>
dodauth <pap|chap>
dodchaphost <CHAP Host or User Name>
dtrcontrol <none|toggledtr|autodtr>
emailsubj <Email Subject>
emailto <Email Address>
flowcontrol <none|xon/xoff|rts/cts>
group <Local or Remote Group Name>
idletimeoutmsg <enable|disable>
initscript <Modem Initialization Script>
ipaddr <IP Address[/Mask Bits]>
locallogging <enable|disable>
maxdirect <1-15>

```

Note: We recommend preceding the *initscript* with **AT** and include **E1 V1 x4 Q0** so that the EMG may properly control the modem.

```

localipaddr <negotiate|IP Address>
logins <enable|disable>
minimizelatency <enable|disable>
modemmode <text|ppp>
modemstate <disable|dialin|dialout|dialback|dialinhostlist|dialondemand|
    dialin+ondemand|dialback+ondemand|cbcpclient|cbcpserver>
modemtimeout <disable|1-9999 seconds>
name <Device Port Name>
nat <enable|disable>
newusermsg <enable|disable>
nfsdir <Logging Directory>
nfslogging <enable|disable>
nfsmaxfiles <Max # of Files>
nfsmaxsize <Size in Bytes>
numsessionsmsg <enable|disable>
parity <none|odd|even>
portlogseq <1-10 Chars>
poweraction <on|off|cycle>
powermgmtseq <1-10 Chars>

```

```

powersupply <Managed Power Supply Name>
remoteipaddr <negotiate|IP Address>
restartdelay <PPP Restart Delay>
reversepinout <enable|disable>
sendstring <String to Send|QUOTEDSTRING>
sendtermstr <enable|disable>
showlines <disable|1-50 lines>
slmlogging <enable|disable>
slmnms <NMS IP Address>
slmthreshold <Threshold>
slmtime <Time Frame>
sshauth <enable|disable>
sshdatabdir <netin|netout|both>
sshin <enable|disable>
sshport <TCP Port>
sstimeout <disable|1-3600 seconds>
stopbits <1|2>
sysloglogging <enable|disable>
tcpauth <enable|disable>
tcpdatabdir <netin|netout|both>
tcpin <enable|disable>
tcpport <TCP Port>
tcptimeout <disable|1-3600 seconds>
telnetauth <enable|disable>
telnetdatabdir <netin|netout|both>
telnetin <enable|disable>
telnetport <TCP Port>
telnetsoftiac <enable|disable>
telnettimeout <disable|1-3600 sec>
termstr <Termination String>
timeoutlogins <disable or 1-30 minutes>
tokenaction <List of none,log,trap,email,string,power>
tokendatabdetect <enable|disable>
tokenstring <Regex String>
tokentrigger <bytecnt|charstr>
usbchannel <1-2>
usblogging <enable|disable>
usbmaxfiles <Max # of Files>
usbmaxsize <Size in Bytes>
usbport <U1|SD|INTSD>
usbvbus <enable|disable>
usesites <enable|disable>
viewportlog <enable|disable>

```

Description

Configures a single port or a group of ports.

Set the modem password and CHAP secrets (any extra parameters will be ignored):

```

set deviceport port <Device Port # or List or Name> dialoutpassword
set deviceport port <Device Port # or List or Name> chapsecret
set deviceport port <Device Port # or List or Name> dodchapsecret

```

Reset a device port, terminating and restarting all relevant connections:

```
set deviceport port <Device Port # or List or Name> reset
```

Configure up to 4 managed power supplies for device connected to a device port:

```
set deviceport port <Device Port # or Name> managepower
```

Reset a device port, terminating and restarting all relevant connections:

```
set deviceport port <Device Port # or List or Name> reset
```

Note: A group of device ports can be configured by specifying a comma-separated list of ports (i.e., '1-4,8,10-12') or 'ALL'. Remove breakseq for Device Ports connected to raw binary connections. The logging level for the Device Ports log must be set to 'Info' to view Syslog entries for Device Port logging. It is recommended that the 'initscript' be prepended with 'AT' and include 'E1 V1 x4 Q0' so that the EMG may properly control the modem.

show deviceport global

Syntax

```
show deviceport global
```

Description

Displays global settings for device ports.

show deviceport names

Syntax

```
show deviceport names
```

Description

Displays a list of all device port names.

show deviceport port

Syntax

```
show deviceport port <Device Port List or Name>  
[display <ip|data|modem|logging|device>]
```

Description

Displays the settings for one or more device ports.

show deviceport types

Syntax

```
show deviceport types
```

Description

Displays the list of port types (RJ45 or USB) for all device ports.

show portcounters**Syntax**

```
show portcounters [deviceport <Device Port List or Name>]  
                  [email <Email Address>]
```

Description

Displays device port statistics and errors for all ports, or for a single port, or a list of ports.

Note: The output can optionally be emailed. A comma-separated Device Port lists (or 'All') can be used to specify a group of Device Ports (i.e., '1-4,8').

show portcounters zerocounters**Syntax**

```
show portcounters zerocounters <Device Port List or Name>
```

Description

Zeros the port counters for one or more device ports.

show portstatus**Syntax**

```
show portstatus [deviceport <Device Port List or Name>] [email <Email  
Address>]
```

Description

Displays the modes and states of one or more device port(s). You can optionally email the displayed information.

DHCP Commands

set dhcp**Syntax**

```
set dhcp <switch> <one or more parameters>
```

Parameters

```
mode <disable|server|relay>
```

```
ip <Eth Switch Port IP Address>
mask <Eth Switch Port Subnet Mask>
DHCP Server Mode Parameters:
serverstartip <Server Start IP Address>
serverendip <Server End IP Address>
serverprimarydns <Server Primary DNS>
serversecondarydns <Server Secondary DNS>
servergw <Server Gateway>
domain <Domain Name>
leasetime <1-336 hours>
DHCP Relay Mode Parameters:
relayserverip1 <DHCP Server IP Address>
relayserverip2 <DHCP Server IP Address>
```

Description

Configure the DHCP settings for the Ethernet Switch.

show dhcp

Syntax

```
show dhcp
```

Description

Displays DHCP settings for the Ethernet switch

show dhcp display clients

Syntax

```
show dhcp display clients
```

Description

Displays DHCP active client list

DIO Commands

Digital Input/Output Port Command Synopsis

set dio port

Syntax

```
set dio port <inf1|inf2> <parameters>
```

Parameters

```
name <DIO Port Name>
normalstate <on|off>
```

Description

Configure the DIO input ports #1 or #2 on the front of the EMG:

set dio port relayf

Syntax

```
set dio port relayf <parameters>
```

Parameters

```
name <DIO Port Name>
wakeup <on|off>
state <on|off>
normalstate <on|off>
latch <enable|disable>
```

Description

Configure the DIO relay/output port on the front of the EMG:

```
show dio
```

Diagnostic Commands

diag arp

Syntax

```
diag arp|arp6 [email <Email Address>]
```

Description

Displays the Address Resolution Protocol table (for IPv4) or the Neighbor table (for IPv6) for mapping IP Addresses to hardware addresses.

diag internals

Syntax

```
diag internals [email <Email Address>]
```

Enable debug printing on the next EMG reboot:

```
diag internals [printapplication <enable|disable>
  printconnection <enable|disable>
  printmanagement <enable|disable>
```

Description

Displays information on the internal memory, storage and processes of the EMG. You can optionally email the displayed information.

diag iperf**Syntax**

```
diag iperf mode <server|client> [host <iPerf Server IP Address or Name>]
      [options <iPerf options>] [email <Email Address>]
```

Options

iPerf Options (enclose all options in quotes):

Set server port to listen on/connect to (default 5201):	-p, --port n
Format to report:	-f, --format [kmgTKMG]
Pause n seconds between reports:	-i, --interval n
Bind to a host, an interface or multicast address	-B, --bind <host>
More detailed output:	-V, --verbose
Output in JSON format:	-J, --json
Options below are supported on client only:	
Set length of buffer to n (default 8 KB):	-l, --length n[KMG]
Use UDP rather than TCP:	-u, --udp
TCP window size (socket buffer size):	-w, --window n[KMG]
Set TCP/SCTP maximum segment size (MTU):	-M, --set-mss n
Set TCP/SCTP no delay, disabling Nagle's Algorithm:	-N, --no-delay
Set bandwidth to n bits/sec (default 1Mbit/sec, unlimited for TCP):	-b, --bitrate n[KMG]
Number of bytes to transmit (instead of -t):	-n, --bytes n[KMG]
Time in seconds to transmit for (default 10 secs):	-t, --time n
Set the IPv6 flow label:	-L, --flowlabel n
Use a 'zero copy' method of sending data:	-Z, --zerocopy
Omit the first n seconds:	-O, --omit n
Prefix every output line with this string:	-T, --title str
# of blocks (packets) to transmit (instead of -t/-n):	-k, --blockcount
Set the IP type of service, 0-255.	
The usual prefixes for octal and hex can be used, i.e. 52, 064 and 0x34 all specify the same value:	-S, --tos n
Set the IP dscp value, either 0-63 or symbolic:	--dscp n

Description

Runs an iPerf server or client to measure network throughput. You can optionally email the output. The EMG uses iPerf version 3.X, which is incompatible with older versions (2.x).

diag lookup

Syntax

```
diag lookup <Name> [email <Email Address>]
```

Description

Resolves a host name into an IP address. You can optionally email the displayed information.

diag loopback

Syntax

```
diag loopback <Device Port #or Name>[<parameters>]
```

Parameters

```
test <internal|external>  
xferdatasize <Size In Kbytes to Transfer>  
Defaults: test=external, xferdatasize=1K
```

Description

Tests a device port by transmitting data out the port and verifying that it is received correctly. A special loopback cable comes with the EMG to test a device port.. Plug the cable into the device port and run this command. The command sends the specified Kbytes to the device port and reports success or failure. The test is performed at 9600 baud. Only an external test requires a loopback cable. The External test is currently not supported for USB device ports.

diag netstat

Syntax

```
diag netstat [protocol <all|tcp|udp>] [email <Email Address>]  
Defaults: protocol=all
```

Description

Displays a report of network connections. You can optionally email the displayed information.

diag nettrace

Syntax

```
diag nettrace <one or more parameters>
```

Parameters

```
ethport <1|2|cell|switch|intmodem>  
protocol <tcp|udp|icmp|esp>  
host <IP Address or Name>  
numpackets <Number of Packets>
```

```
verbose <low|medium|high|disable>
pcapfile <File Name> location <usb|sdcard> [usbport <U1>]
```

Description

Displays all network traffic, applying optional filters (the output can be saved to a Wireshark pcap file on external storage). This command is available in the CLI but not the web.

diag perfstat

Syntax

```
diag perfstat [ethport <1|2|cell|switch>]
```

Description

Display performance statistics for an Ethernet Port or Device Port, averaged over the last 5 seconds. Must specify an Ethernet Port or Device Port.

diag ping|ping6

Syntax

```
diag ping|ping6 <IP Address or Name> [<parameters>]
```

Parameters

```
count <Number Of Times To Ping>
packetsize <Size In Bytes>
ethport <eth1|eth2|veth1|veth2|cell|switch|intmodem|U1>
timeout <Seconds or Milliseconds (append 'm', eg: 100m) to wait
        for the first response after all count packets are sent>
```

Defaults: count=5, packetsize=64, timeout=10
(count and timeout must be specified together; if only one is given the default value will be used for the omitted parameter)

Note: Timeout is for IPv4 ping only, and is not supported for IPv6 ping. The ethport parameter specifies the source IP address of the ping.

Description

Verifies if the EMG can reach a host over the network.

diag sendpacket host

Syntax

```
diag sendpacket host <IP Address or Name> port <TCP or UDP Port Number>
                    [string <Packet String>] [protocol <tcp|udp>]
                    [count <Number of Packets>]
```

Description

Generate and send Ethernet packets.

diag speedtest**Syntax**

```
diag speedtest [email <Email Address>]
```

Description

Runs a network performance test over the default gateway to speedtest.net and outputs the results (speedtest.net must be reachable in order to perform the test). This tool is useful for testing performance of various network configurations, including performance of a cellular connection.

diag top**Syntax**

```
diag top [parameters]
```

Description

Displays CPU usage, memory usage and tasks.

Parameters

```
continuous <enable|disable>  
count <Number of Iterations to Display>  
delay <Delay in Seconds>  
numlines <Number of Lines to Display>
```

Defaults:

```
count=1, delay = 5 seconds
```

diag traceroute**Syntax**

```
diag traceroute <IP Address or Hostname>
```

Description

Displays the route that packets take to get to a network host.

diag traceroute6**Syntax**

```
diag traceroute6 <IP Address or Name>
```

Description

Displays the route that packets take to get to a network host.

diag usb**Syntax**

```
diag usb [<parameters>]
```

Parameters

```
treedisplay <enable|disable>  
mapdevice <enable|disable>  
email <Email Address>  
Defaults: treedisplay=enable
```

Description

To display information about USB buses and the devices connected to them, including the mapping between a USB device and the EMG port. For "mapdevice enable", the port numbers will be displayed at the end of the line in square brackets.

diag wlan**Synopsis**

Display boot log messages related to wireless devices:

```
diag wlan bootlog
```

Display device capabilities:

```
diag wlan capabilities
```

Display available channels:

```
diag wlan channels
```

Display country / regional information:

```
diag wlan region
```

Display driver information:

```
diag wlan driver
```

Display wireless interface log:

```
diag wlan interfacelog [timestamps <epoch|local>]  
                        [display <head|tail>] [numlines <Number of Lines>]
```

Clear the wireless interface log:

```
diag wlan interfacelog clear
```

Display access point status, including connected clients:

```
diag wlan apstatus
```

Display access point log:

```
diag wlan aplog [timestamps <epoch|local>]
                  [display <head|tail>] [numlines <Number of Lines>]
```

Clear the access point log:

```
diag wlan aplog clear
```

Reset the wireless interface (this will terminate any WiFi connections):

```
diag wlan reset
```

Events Commands

admin events add

Syntax

```
admin events add <trigger> <response>
```

<trigger> is one of:

dpdatadrop, humidlimit, nomodemdial, pingfails, receivetraps, dioportchange, dioportabnormal, rpmload, or templimit.

<response> is one of:

action syslog

action emailalert emailaddress <destination email address>

action snmptrap nms <SNMP NMS> community <SNMP Community>

action diorelayon

action <fwdalltraps|fwdseltrap> nms <SNMP NMS>
community <SNMP Community> [oid <SNMP OID>]

Description

Manages the response to events that occur in the EMG.

admin events delete

Syntax

```
admin events delete <Event ID>
```

Description

Deletes an event definition.

admin events edit**Syntax**

```
admin events edit <Event ID> <parameters>
```

Parameters

```
community <SNMP Community>
emailaddress <destination email address>
host <IP Address or Name>
nms <SNMP NMS>
oid <SNMP Trap OID>
outlet <Outlet #>
rpm <RPM Id or Name>
threshold <Load Percentage|Current in Amps>
dioport <inf1|inf2|relayf>
```

Description

Edits event definitions.

admin events show**Syntax**

```
admin events show
```

Description

Displays event definitions.

Groups Commands

```
set groups add|edit <Group Name> [<parameters>]
```

Syntax

```
set groups add|edit <Group Name> [<parameters>]
```

Parameters

```
dataports <Port List>
listenports <Port List>
clearports <Port List>
escapeseq <1-10 Chars>
breakseq <1-10 Chars>
custommenu <Menu Name>
displaymenu <enable|disable>
allowdialback <enable|disable>
dialbacknumber <Phone Number>
```

```
permissions <Permission List>
```

Note: See 'help user permissions' for information on user rights.

Rename a group:

```
set groups rename <Group Name> newname <New Group Name>
```

Delete a group:

```
set groups delete <Group Name>
```

Show one or more groups:

```
show groups [name <Group Name>] members <enable|disable>
```

Description

Configure custom group attributes.

Host List Commands

```
set hostlist add|edit <Host List Name>
```

Syntax

```
set hostlist add|edit <Host List Name> [<parameters>]
```

Parameters

```
name <Host List Name> (edit only)
retrycount <1-10>
Default: retrycount=3, auth=enable.
auth <enable|disable>
```

Description

Configures a prioritized list of hosts to be used for modem dial-in connections.

```
set hostlist add|edit <Host List Name> entry
```

Syntax

```
set hostlist add|edit <Host List Name> entry <Host Number>
[<parameters>]
```

Parameters

```
host <IP Address or Name>
protocol <ssh|telnet|tcp>
port <TCP Port>
```

```
escapeseq <1-10 Chars>
```

Description

Adds a new host entry to a list or edit an existing entry.

```
set hostlist edit <Host List Name> move
```

Syntax

```
set hostlist edit <Host List Name> move <Host Number> position <Host Number>
```

Description

Moves a host entry to a new position in the host list.

```
set hostlist delete
```

Syntax

```
set hostlist delete <Host List> [entry <Host Number>]
```

Description

Deletes a host list, or a single host entry from a host list.

```
show hostlist
```

Syntax

```
show hostlist <all|names|Host List Name>
```

Description

Displays the members of a host list.

Internal Modem Commands

Configure the internal modem:

```
set intmodem <parameters>
```

Parameters

modemstate <disable dialin dialout dialback dialondemand> usesites <enable disable>	
modemmode <text ppp>	group <Local or Remote Group Name>
timeoutlogins <disable 1-30 minutes>	modemtimeout <disable 1-9999 sec>
localipaddr <negotiate IP Address>	restartdelay <PPP Restart Delay>
remoteipaddr <negotiate IP Address>	calleridlogging <enable disable>

auth <pap chap>	calleridcmd <Modem Command String>
chaphost <CHAP Host or User Name>	initscript <Modem Init Script>
chapauth <chaphost localusers>	nat <enable disable>
dialbacknumber <username Phone Number>	checkdialtone <disable 5-600 min>
dialbackdelay <PPP Dialback Delay>	dialoutnumber <Phone Number>
dialbackretries <1-10>	dialoutlogin <Remote User Login>

Set the modem password and CHAP secret (any extra parameters will be ignored):

```
set intmodem dialoutpassword
set intmodem chapsecret
```

Note: It is recommended that the *initscript* be prepended with 'AT' and include 'E1 V1 x4 Q0' so that the EMG may properly control the modem.

Display settings for the internal modem:

```
show intmodem
```

IP Filter Commands

set ipfilter state

Syntax

```
set ipfilter state <enable|disable> [testtimer <disable|1-120 minutes>]
```

Description

Enables or disables IP filtering for incoming network traffic.

set ipfilter mapping

Syntax

```
set ipfilter mapping <parameters>
```

Parameters

```
ethernet <1|2|cell|wlan|ap|bond0> state <disable>
ethernet <1|2|cell|wlan|ap|bond0> state <enable> ruleset <Ruleset Name>
deviceport <1..48> state <disable>
deviceport <1..48> state <enable> ruleset <Ruleset Name>
usbport <U1> state <disable>
usbport <U1> state <enable> ruleset <Ruleset Name>
internal modem state <disable>
internal modem state <enable> ruleset <Ruleset Name>
```

Description

Maps an IP filter to an interface.

set ipfilter rules**Syntax**

```
set ipfilter rules <parameters>
```

Parameters

```
add <Ruleset Name>
delete <Ruleset Name>
edit <Ruleset Name> <Edit Parameters>
```

Edit Parameters

```
append
insert <Rule Number>
replace <Rule Number>
delete <Rule Number>
```

Description

Sets IP filter rules. A maximum of 256 rules can be created for each ruleset.

set ipfilter delete**Syntax**

```
set ipfilter delete all
```

Description

Deletes all rulesets and mappings.

show ipfilter**Syntax**

```
show ipfilter
show ipfilter ruleset <all|Ruleset Name>
show ipfilter mapping
show ipfilter status <all|Ruleset Name>
```

Description

Show IP filter.

Logging Commands

set deviceport port

Syntax

```
set deviceport port <Device Port List or Name> <one or more deviceport parameters>
```

Parameters

```
actiondelay <Action Delay>
actionrestart <Restart Delay>
bytethreshold <# of Characters>
emailsubj <Email Subject>
emailto <Email Address>
locallogging <enable|disable>
nfsdir <Logging Directory>
nfslogging <enable|disable>
nfsmaxfiles <Max # of Files>
nfsmaxsize <Size in Bytes>
poweraction <on|off|cycle>
powersupply <Managed Power Supply Name>
sendstring <String to Send|QUOTEDSTRING>
tokenaction <List of none,log,trap,email,string,power>
tokendatadetect <enable|disable>
tokenstring <Regex String>
tokentrigger <bytecnt|charstr>
usblogging <enable|disable>
usbmaxfiles <Max # of Files>
usbmaxsize <Size in Bytes>
usbport <U1|SD|INTSD>
sysloglogging <enable|disable>
```

Description

Configures logging settings for one or more device ports.

Local logging must be enabled for a device port for the `locallog` commands to be executed. To use the `set locallog clear` command, the user must have permission to clear port buffers (see [Chapter 14: User Authentication](#).)

Example

```
set deviceport port 2-5,6,12,15-16 locallogging enable
```

show locallog

Syntax

```
show locallog <Device Port # or Name> [<parameters>]
```

Parameters

[bytes <Bytes To Display>]
[startbyte <Byte Index>]
Defaults: bytes=1000, startbyte=1

Description

Displays a specific number of bytes of data for a device port. 1K is the default.

set locallog clear

Syntax

set locallog clear <Device Port # or Name>

Description

Clears the local log for a device port.

The locallog commands can only be executed for a device port if local logging is enabled for the port. The set locallog clear command can only be executed if the user has permission to clear port buffers (see [Chapter 14: User Authentication](#)).

set log clear

Syntax

set log clear <Device Port # or Name>

Description

Clear the modem log (the modem log is automatically pruned when it reaches 50K):

set log modem ppplog

Syntax

set log modem ppplog <enable|disable>

Description

Enables PPP activity messages in the modem log.

set log modem ppplog <enable|disable>

Syntax

set log modem pppdebug

Description

Enables PPP debugging messages in the modem log.

set log modem pppdebug <enable|disable>

Syntax

```
show log modem[display <head|tail>] [numlines <Number of Lines>]
```

Description

View the modem activity log for external modems and USB modems.

show log local

Syntax

```
show log local|nfs|usb|sdcard|intsd <Device Port # or Name>
[<parameters>]
```

Parameters

```
display <head|tail>
numlines <Number of Lines>
bytes <Bytes to Display>
startbyte <Byte Index>
logfile <NFS, USB or SD card Log File>
Defaults: bytes=1000, startbyte=1, numlines=40
```

Description

View the log for local, NFS, USB, or SD Card logging (NFS and USB/SD Card use the current logging settings for the Device Port). Default is to show the log tail.

Syntax

```
show log files nfs|usb|sdcard|intsd [localdir <NFS Mount Local
Directory>]
[usbport <U1>]
[deviceport <Device Port # or Name>]
```

Description

Lists the NFS, USB or SD Card log files, either for a specific Device Port, or all log files in a USB, NFS or SD Card location.

Network Commands

set network port

Syntax

```
set network port <1|2> <parameters>
```

```
set network ipv6 <enable|disable>
```

Parameters

```
state <dhcp|bootp|static|disable> [ipaddr <IP Address> mask <Mask>]  
ipv6addr <IPv6 Address/Prefix>  
mode <auto|10mbit-half|100mbit-half|10mbit-full|100mbit-full|  
    1000mbit-full>  
mtu <Maximum Transmission Unit>  
activeport <rj45|sfp>
```

Description

Configure Ethernet Port 1 or 2.

set network bonding

Syntax

```
set network bonding <disabled|active-backup|802.3ad|load-balancing>
```

Description

Configure Ethernet bonding.

set network dns

Syntax

```
set network dns <1-10> ipaddr <IP Address>
```

Description

Configures up to 10 DNS servers.

set network dnsipv4prec

Syntax

```
set network dnsipv4prec <enable|disable>  
set network dnssrcipaddr <none|veth1|veth2>
```

Description

Configures IPv4/IPv6 lookup precedence.

set network dnssrcipaddr

Syntax

```
set network dnssrcipaddr <none|eth1|eth2|veth1|veth2>
```

Description

Configures the interface and source IPv4 address used for sending DNS packets.

set network dnssrcipv6addr

Syntax

```
set network dnssrcipv6addr <none|eth1|eth2|veth1|veth2>
```

Description

Configures the interface and source IPv6 address used for sending DNS packets.

set network gateway

Syntax

```
set network gateway <parameters>
```

Parameters

```
default <IP Address>
ipv6default <IPv6 Address>
precedence <dhcp|default|wlan>
failover <IP Address>
pingip <IP Address>
ethport <1|2|bond0>
failoverport <eth2|cell|cell|wlan|intmodem>
pingdelay <1-250 seconds>
failedpings <1-250>
faildevice <none|hspa|sierra|g52x>
faildevapn <Fail-over Device: APN of Mobile Carrier>
faildevlockpin <enable|disable>
faildevlogin <Fail-over Device: Admin Login (Default HSPA+:admin,
Sierra:user, Lantronix G52x:admin)>
faildevcelluser <Fail-over Device: SIM Login>
faildevcelldialstr <Fail-over Device: Dialup Str>
faildevcellroam <enable|disable>
faildevpassthru <enable|disable>
faildevethip <IP Address>
faildevdhcp <enable|disable>
```

Description

Sets default and fail-over gateway configuration parameters. The fail-over gateway is a backup default gateway, used when it is determined through a fail-over trigger, that the primary default gateway is no longer a viable route. A fail-over event happens when a ping device reachable via an ethernet interface and the default gateway, becomes unreachable. Fail-back is when the ping device becomes reachable again, causing the primary default route to be restored.

set network gateway faildevupdate**Syntax**

```
set network gateway faildevupdate <ftp|sftp|scp|usb|sdcard>  
    gwfile <Firmware File> radiofile <Radio File> [usbport <U1>]  
    [host <IP Address or Name>] [login <User Login>] [path <File Path>]
```

Description

Transfers firmware update files to the EMG to initiate a firmware update on the fail-over device.

set network gateway (other operations)**Syntax**

```
set network gateway reboot  
set network gateway faildevpin  
set network gateway faildevpuk  
set network gateway faildevcellpwd  
set network gateway faildevpassword  
    (Default faildevpassword HSPA+:PASS, Sierra:12345, Lantronix  
    G52x:admin)
```

Description

Reboot the fail-over device, or set the fail-over device SIM Card PIN #, SIM Personal Unblocking Key or Admin Password (any extra parameters are ignored).

set network host**Syntax**

```
set network host <Hostname> [domain <Domain Name>]
```

Description

Sets the EMG host name and domain name.

set network fqdnlist**Syntax**

```
set network fqdnlist <1-15> ipaddr <IP Address> fqdn <hostname>
```

Description

Updates the local hosts table for DNS lookup of FQDNs.

set network

Syntax

```
set network <parameters>
```

Parameters

```
startprobes <1-99999 Seconds>  
probes <Number of Probes>  
interval <1-99999 Seconds>  
ipforwarding <enable|disable>  
ip6forwarding <enable|disable>  
reversepathfilter <enable|disable>
```

Description

Sets TCP Keepalive, IP Forward and reverse path filter network parameters.

show network

Syntax

```
show network port <1|2>  
show network bonding  
show network dns  
show network gateway  
show network host  
show network fqdnlist  
show network ipv6  
show network sfp  
show network all
```

Description

Displays network settings.

NFS and SMB/CIFS Commands

set nfs mount

Syntax

```
set nfs mount <one or more parameters>
```

Parameters

```
locdir <Directory>  
mount <enable|disable>  
remdir <Remote NFS Directory>
```

```
rw <enable|disable>
```

Enables or disables read/write access to remote directory.

Description

Mounts a remote NFS share.

The `remdir` and `locdir` parameters are required, but if they have been specified previously, you do not need to provide them again.

```
set nfs unmount
```

Syntax

```
set nfs unmount <1|2|3>
```

Description

Unmounts a remote NFS share.

```
set cifs
```

Syntax

```
set cifs <one or more parameters>
```

Parameters

```
eth1 <enable|disable>
```

```
eth2 <enable|disable>
```

```
state <enable|disable>
```

```
workgroup <Windows workgroup>
```

Description

Configures the SMB/CIFS share, which contains the system and device port logs.

The `admin config` command saves EMG configurations on the SMB/CIFS share.

```
set cifs password
```

Syntax

```
set cifs password
```

Description

Changes the password for the SMB/CIFS share login (default is **cifsuser**).

```
show cifs
```

Syntax

```
show cifs
```

Description

Displays SMB/CIFS settings.

show nfs

Syntax

```
show nfs
```

Description

Displays NFS share settings.

Performance Monitoring Commands

show perfmon

Syntax

```
show perfmon [probe <all|Probe Id or Name>]
```

Description

Display global settings and all probes, or a selected probe.

show perfmon status

Syntax

```
show perfmon status [probe <Probe Id or Name>]
```

Description

Display the running status of all probes or a selected probe.

show perfmon operations

Syntax

```
show perfmon operations <Probe Id or Name>
```

Description

Display list of completed operation sets for a probe.

set perfmon results

Syntax

```
show perfmon results <Probe Id or Name> [set <Operation Set Number>]
```

```
[display <head|tail>] [numlines <Number of Lines>]  
[email <Email Address>]
```

Description

Display round trip times (RTT) for last completed operation set or selected set, and optionally email the complete results.

show perfmon accumulated**Syntax**

```
show perfmon accumulated <Probe Id or Name> [set <Operation Set Number>]  
[email <Email Address>]
```

Description

Display accumulated statistics for last completed operation set or selected set, and optionally email the statistics.

set perfmon repo**Syntax**

```
set perfmon repo <local|usb|sdcard> [usbport <U1>]
```

Description

Set repository where probe operations are stored.

set perfmon keep**Syntax**

```
set perfmon keep <Number of Operations to Keep>
```

Description

Set number of operations stored for each probe.

set perfmon udpjitterresp**Syntax**

```
set perfmon udpjitterresp <enable|disable>
```

Description

Enable responders for UDP jitter.

set perfmon udpechoresp**Syntax**

```
set perfmon udpechoresp <UDP Port Number|disable>
```

Description

Enable responders for UDP echo.

set perfmon tcpconnectresp**Syntax**

```
set perfmon tcpconnectresp <TCP Port Number|disable>
```

Description

Enable responders for TCP connect.

set perfmon add**Syntax**

```
set perfmon add <Probe Name>
type <dns|http|icmp|tcpconnect|udpecho|udpjitter|udpjittervoip>
```

Parameters

```
name <Probe Name>
    starttime <now|HH:MM[:SS][MMDD]|afterHH:MM:SS>
    operations <Number of Operations to Perform>
    frequency <Seconds between Operations>
    packets <Number of Packets to Send>
    interval <Milliseconds between Packets>
    timeout <Milliseconds to Wait for Response>
    host <Destination IP Address or Name>
    port <Destination Port>
    precision <milli|micro>
    datasize <Payload Data Size in Bytes>
    verifydata <enable|disable>
    codec <g729a|g711alaw|g711mulaw>
    tos <none|Type of Service>
    interface <all|eth1|eth2|cell|wlan|ap>
    nameserver <IPv4 Address>
```

Description

Add a new probe.

set perfmon edit**Syntax**

```
set perfmon edit <Probe Id or Name> [<parameters>]
```

Parameters

```
name <Probe Name>
    starttime <now|HH:MM[:SS][MMDD]|afterHH:MM:SS>
    operations <Number of Operations to Perform>
    frequency <Seconds between Operations>
    packets <Number of Packets to Send>
    interval <Milliseconds between Packets>
    timeout <Milliseconds to Wait for Response>
    host <Destination IP Address or Name>
    port <Destination Port>
    precision <milli|micro>
    datasize <Payload Data Size in Bytes>
    verifydata <enable|disable>
    codec <g729a|g711alaw|g711mulaw>
    tos <none|Type of Service>
    interface <none|eth1|eth2>
    nameserver <IPv4 Address>
```

Description

Edit an existing probe.

set perfmon delete**Syntax**

```
set perfmon delete <Probe Id or Name> [data <all|# of Sets to Keep>]
```

Description

Delete a probe, or delete all operation data for a probe, or delete all but the most recent operation sets for a probe.

set perfmon state**Syntax**

```
set perfmon state <all|Probe Id or Name> action <restart>
```

Description

Set the running state of all probes or a single a probe.

Power Commands

set power

Syntax

```
set power model <none|sp1004a|sp1004b>
set power port <U1|U2|Device Port # or Name>
set power pdulogin <PDU Username>
set power pdupassword
set power outlet <Outlet # or List or Name> <one or more parameters>
Parameters:  name <Outlet Name>
              description <Outlet Description>
              state <on|off>
              wakeup <on|off|laststate>
              reboot
```

Description

Configure and control power outlets on an integrated PDU.

show power

Syntax

```
show power [outlet <Outlet # or Name>]
           [pduinfo <devicestatus|networkstatus|inletstatus|
           userlogs|eventlogs>]
```

Description

Show power settings

Routing Commands

set routing

Syntax

```
set routing [parameters]
```

Parameters

```
rip <enable|disable>
version <1|2|both>
static <enable|disable>
route <1-64> ipaddr <IP Address> mask <Netmask> gateway <IP Address>
ipv6route <1-64> ipv6addr <IPv6 Address/Prefix> ipv6gateway <IPv6
Address>
```

Description

Configures static or dynamic routing.

To delete a static route, set the IP address, mask, and gateway parameters to **0.0.0.0**.

show routing

Syntax

```
show routing [resolveip <enable|disable>] [email <Email Address>]
```

Description

Sets the routing table to display IP addresses (disable) or the corresponding host names (enable). You can optionally email the displayed information.

RPM Commands

set rpm add

Syntax

```
set rpm add <RPM Name>
```

Description

Adds an RPM to be managed (prompts will guide selection of RPM vendor and model).

set RPM command

Syntax

```
set rpm command <RPM Id or Name>  
    outlet <all|Outlet # or List> state <on|off|cyclepower>
```

Description

Sends a command to control one or more outlets on an RPM.

Syntax

```
set rpm command <RPM Id or Name> device <reboot|shutdown>
```

Description

Sends a command to control an RPM device.

Syntax

```
set rpm command <RPM Id or Name> beeper <mute|enable|disable>
```


Description

Sends a command to control an RPM beeper.

set rpm delete

Syntax

```
set rpm delete <RPM Id or Name>
```

Description

Deletes an RPM.

set rpm driver

Syntax

```
set rpm driver <RPM Id or Name> action restart
set rpm driver <RPM Id or Name> action debug [level <1|2|3>]
set rpm driver <RPM Id or Name> action show
set rpm driver <RPM Id or Name> action viewoutput [email <Email Address>]
[display <head|tail>] [numlines <Number of Lines>]
```

Description

Control and debug the RPM driver if the driver is not properly communicating with the PDU or UPS: restart the driver; restart the driver with debug output to a file; show the running driver; view and email the driver debug output.

Note: *Drivers running in debug mode will generate copious output and for disk space reasons should not be left running in debug mode for long periods of time.*

set rpm edit

Syntax

```
set rpm edit <RPM Id or Name> <one or more parameters>
```

Parameters

```
name <New RPM Name>
outlets <# of Outlets>
ipaddr <IP Address>
port <TCP or Device Port>
login <RPM Admin Login>
rocommunity <SNMP Read-Only Community>
rwcommunity <SNMP Read-Write Community>
logstatus <disable|1-60 minutes>
snmptraps <enable|disable>
emailaddress <Email Address>
upslowbattery <shutdown|shutdownall|shutdownboth|allowfailure>
sdorder <disable|1-49>
```

```
powertoslc <enable|disable>
driveropts <Driver Options Override>
```

Description

Configure and control Remote Power Managers (RPMs), including PDUs and UPSes.

set rpm password

Syntax

```
set rpm password <RPM Id or Name>
```

Description

Set RPM administrative password.

show RPM

Syntax

```
show rpm [type <ups|pdu>]
         [config <sdorder|notify>]
         [device <RPM Name or Id> [data <raw|logs|envmon>]]
```

Note: The `show rpm envmon` command for RPM-configured ServerTech Serial/Network Mode is not supported by NUT/Powerman.

Description

Display a list of all RPMs, RPMs of a specific type, UPS shutdown and notification configuration, or details and outlets for a single RPM device.

Script Commands

set script import

Syntax

```
set script import <interface|batch|custom> via <ftp|scp|coppypaste>
               [file <Script File>] [name <Script Name>] [host <IP Address
               or Name>]
               [login <User Login>] [path <Path to Script File>]
               [filetype <expect|tcl|python>]
```

Note: Interface scripts will be given default/do user rights; Batch and Custom scripts will be given admin/ad user rights. The name of the script will be the same as the file name (if it is a valid script name), otherwise a script name must be specified for import.

Description

Import a script.

set script update**Syntax**

```
set script update <interface|batch|custom> name <Script Name>
                  [group <default|power|admin>] [permissions <Permission List>]
```

Note: See 'help user permissions' for information on groups and user rights.

Description

Update a script.

set script rename**Syntax**

```
set script rename <interface|batch|custom> name <Script Name>
                  newname <New Script Name>
```

Description

Rename a script.

set script delete**Syntax**

```
set script delete <interface|batch|custom> name <Script Name> [data
<all|# of Sets to Keep>]
```

Description

Delete a script, or delete all operation data for a custom script, or delete all but the most recent operation sets for a custom script.

set script runcli**Syntax**

```
set script runcli <Script Name> [parameters <Command Line Parameters>]
```

Parameters

```
[prompt <Prompt String>]
[debug <enable|disable>]
```

Description

Run a CLI batch or custom script one time (script output will be displayed in the current terminal; custom script output will be saved in the repository).

connect script**Syntax**

```
connect script <Script Name> deviceport <Device Port # or Name>
    [parameters <Command Line Parameters>]
    [debug <enable|disable>]
```

Description

Connect an interface or custom script to a Device Port and run it one time (script output will be displayed in the current terminal; custom script output will be saved in the repository).

set script schedule**Syntax**

```
set script schedule <Script Name> [device <cli|Device Port # or Name>]
[state <enable|disable|delete>] [parameters <Cmd Line Parameters>]
[starttime <now|HH:MM[MMDD]|afterHH:MM>]
[frequency <Hours/Days between each operation>]
[stoptime <forever|HH:MM[MMDD]|afterHH:MM>]
```

Description

Schedule a custom script to be run at a certain time, either once or recurring; frequency is specified as hours (4H for 4 hours) or days (2D for 2 days).

show script**Syntax**

```
show script [type <interface|batch|custom> [name <Script Name>]]
```

Description

Display list of scripts, or view the details and contents of a script.

show script status**Syntax**

```
show script status [script <Script Name>]
```

Description

Display the running status of all custom scripts or a single custom script.

show script operations**Syntax**

```
show script operations <Script Name>
```

Description

Display list of completed results for a custom script.

show script results

```
show script results <Script Name> [set <all|Operation Set Number>]  
[display <head|tail>] [numlines <Number of Lines>]  
[email <Email Address>]
```

Description

Display the results for the last completed custom script operation or a selected operation, and optionally email the results.

SD Card Commands

Enables or disables access to SD Card devices:

```
set sdcard access <enable|disable>
```

Mounts a SD Card for use as a storage device. The SD Card can be used for saving configurations, firmware updates and device logging.

```
set sdcard mount
```

Unmounts a SD Card:

```
set sdcard unmount
```

Formats a SD Card:

```
set sdcard format [filesystem <ext2|fat16|fat32|ntfs>]
```

Defaults: filesystem=ext2

Runs a filesystem check on a SD Card (recommended if it does not mount):

```
set sdcard fsck
```

Displays a directory listing of an internal or external SD Card:

```
set sdcard|intsd dir [subdir <Directory Path>]
```

Renames a file on a SD Card:

```
set sdcard rename <Filename> newfile <New Filename>
```

Copies a file on a SD Card:

```
set sdcard copy <Filename> newfile <New Filename>
```

Removes a file on a SD Card:

```
set sdcard delete <Current Filename>
```

Displays information about the SD Card device:

```
show sdcard
```

Services Commands

set services

Syntax

```
set services <one or more services parameters>
```

Parameters

auditlog <enable disable>	ssh <enable disable>
auditsize <1-500 Kbytes>	webssh <enable disable>
clicommands <enable disable>	timeoutssh <disable 1-30 minutes>
includesyslog <enable disable>	sshdatabdir <netin netout both>
netlog <off error warning info debug>	portssh <TCP Port>
servlog <off error warning info debug>	requiresshpublickey <enable disable>
authlog <off error warning info debug>	telnet <enable disable>
devlog <off error warning info debug>	webtelnet <enable disable>
diaglog <off error warning info debug>	timeouttelnet <disable 1-30 minutes>
genlog <off error warning info debug>	telnetdatabdir <netin netout both>
syslogserver1 <IP Address or Name>	escapeseqtelnet <1-10 Chars>
syslogserver2 <IP Address or Name>	outgoingtelnet <enable disable>
syslogsrcipaddr <none eth1 eth2 veth1 veth2>	
syslogsrcip6addr <none eth1 eth2 veth1 veth2>	
rpmlogsize <5-40 Kbytes>	discoveryserver <enable disable>
otherlogsize <5-400 Kbytes>	
termbufsize <Number of Lines>	
smtpserver <IP Address or Name>	smtpsender <Email Address>
smtplogin <Username or Email Address>	smtpport <SMTP TCP Port>
smtpauth <none auto plain cram-md5 login>	smtpsecurity <none starttls tls>

Description

Configures services (system logging, SSH and Telnet access, SSH and Telnet timeout, SNMP agent, email [SMTP] server, and audit log.)

set services sshalgorithms**Syntax**

```
set services sshalgorithms <prompt|List of Disabled SSH Algorithms>
```

Description

Defines the set of SSH algorithms that are enabled, either by prompting for each algorithm or by specifying a complete list of disabled algorithms. For example "MACs:hmac-sha2-256,hmac-sha1;Ciphers:aes128-gcm@openssh.com;" disables 2 MACs and one cipher and leaves all other algorithms enabled. Available algorithm types are 'MACs', 'Ciphers', 'KEX' and 'HostKey'.

set services smtppassword**Syntax**

```
set services smtppassword
```

Description

Sets SMTP password.

set services testemail**Syntax**

```
set services testemail <Email Address> [comment <Comment>]
```

Description

Allows you to validate the SMTP server configuration by proving a test email.

show services**Syntax**

```
show services
```

Description

Displays current service settings.

Syntax

```
show services [viewalgorithms <enable|disable>]
```

Description

Displays the list of ciphers used in SMTP.

Syntax

```
show services smtplog
```

Description

Displays the SMTP logs.

Syntax

```
show services smtplog clear
```

Description

Clears the SMTP logs

Site Commands

Configure a set of site-oriented modem parameters that can be activated by various modem-related events (authentication, outbound network traffic for DOD connections, etc.). The site parameters will override any parameters configured for the modem. To use sites with a modem, enable 'usesites'. Sites can be used with the following modem states: dialin, dialback, cbcpserver, dialondemand, dialin+ondemand, and dialback+ondemand.

set site add|edit**Syntax**

```
set site add|edit <Site Name> [<parameters>]
```

Parameters

name <Site Name> (edit only)	
deviceport <Device Port # or Name or none>	dialoutnumber <Phone Number>
usbport <U1>	dialoutlogin <User Login>
internal modem	allowdialback <enable disable>
auth <pap chap>	dialbacknumber <Phone Number>
loginhost <User Login/CHAP Host>	dialbackdelay <Dial-back Delay>
localipaddr <negotiate IP Address>	dialbackretries <1-10>
remoteipaddr <negotiate IP Address>	timeoutlogins <disable 1-30 minutes>
routeipaddr <IP Address>	modemtimeout <disable 1-9999 secs>
routemask <Mask>	restartdelay <PPP Restart Delay>
routegateway <Gateway>	cbcpnocalback <enable disable>
nat <enable disable>	

Set the site password and CHAP secret (any extra parameters will be ignored):

```
set site dialoutpassword <Site Name>
set site chapsecret <Site Name>
```

Deletes a site:

```
set site delete <Site Name>
show site <all|names|Site Name>
```


SLC Network Commands

Displays all SLC, SLB, EMG, and Spider units on the local network.

set slcnetwork

Syntax

```
set slcnetwork <one or more parameters>
```

Parameters

```
add <IP Address>  
delete <IP Address>  
search <localsubnet|ipaddrlist|both>
```

Description

Detects and displays all EMG or user-defined IP addresses on the local network.

show slcnetwork

Syntax

```
show slcnetwork [ipaddrlist <all|IP Address Mask>][format <csv|nopad>]
```

Description

Detects and displays all EMG or user defined IP addresses on the local network.

Without the `ipaddrlist` parameter, the command searches the local network. With the `ipaddrlist` parameter, the command displays a sorted list of all IP addresses or displays the IP addresses that match the mask (for example, 172.19.255.255 would display all IP addresses that start with 172.19).

SNMP Commands

set SNMP

Syntax

```
set snmp <one or more parameters>
```

Parameters

agent <enable disable>	location <Physical Location>
v1 <enable disable>	contact <Admin Contact Info>
v2c <enable disable>	rocommunity <Read-Only Community>
v3 <enable disable>	rwcommunity <Read-Write Community>
v3tls <enable disable>	trapcommunity <Trap Community>
tlspport <TLS Port>	v3security <noauth auth authncrypt>
nms1 <IP Address or Name>	v3encrypt <des aes aes192 aes256>
nms2 <IP Address or Name>	v3auth <md5 sha sha2_224
alarmdelay <1-6000 Seconds>	sha2_256 sha2_384 sha2_512
traps <enable disable>	v3user <v3 RO User>
trapversion <1 2 3>	v3rwuser <v3 RW User>
trapsovertls <enable disable>	v3trapuser <v3 Trap User>
trapsrcipaddr <none eth1 eth2 veth1 veth2>	
trapsrcipv6addr <none eth1 eth2 veth1 veth2>	

Note: v1 and v2c are insecure.

Description

Configure SNMP agent

set snmp v3password**Syntax**

```
set snmp v3password|v3phrase|v3rwpasswrd|v3rwphrase|v3trappasswrd|
v3trapphrase
```

Description

Set SNMP v3 read-only, read-write and trap password/passphrase:

set snmp trapenable**Syntax**

```
set snmp trapenable <prompt|Comma Separated List of Trap Numbers>
```

Description

Defines the set of SNMP traps that are sent by the EMG (see online help or SNMP web page for supported traps). When specifying a list of trap numbers, specify the last 2 digits of the trap OID, e.g "5.3.0.2,0.24".

set snmp certificate import**Syntax**

```
set snmp certificate import via <sftp|scp> rootfile <Cert Auth File>
    certfile <Agent Certificate File> keyfile <Agent Private Key
    File>
    clientcert <Client Certificate File> host <IP Address or Name>
    login <User Login> [path <Path to Files>]
```

Description

Manage SNMP agent & outbound trap client X.509 certificates for TLS connections.

set snmp certificate delete**Syntax**

```
set snmp certificate delete
```

Description

Deletes SNMP certificate.

set snmp certificate attributes**Syntax**

```
set snmp certificate attributes
    fingerprint <Client Certificate SHA1 or SHA256 Fingerprint>
    mapfield <username|email|fqdn|ipaddr|commonname|any>
    token <Field String>
```

Description

Sets SNMP certificate attributes.

set snmp certificate show**Syntax**

```
set snmp certificate show
```

Description

Displays SNMP certificate.

show snmp**Syntax**

```
show snmp
```

Description

Displays current SNMP settings.

SSH Key Commands

set sshkey import**Syntax**

```
set sshkey import
```

Description

```
set sshkey import <ftp|sftp|scp|coppypaste> [file <Public Key File>]
[host <IP Address or Name>] [login <User Login>]
[path <Path to Public Key File>] [keyuser <SSH Key User>]
[keyhost <SSH Key IP Address or Name>]
```

Description

Imports an SSH key.

Note: the key file may contain multiple keys; in this case the keyuser and keyhost will be ignored.

set sshkey export**Syntax**

```
set sshkey export <ftp|sftp|scp|coppypaste> keyuser <SSH Key User>
keyname <SSH Key Name> type <rsa|ecdsa>
[bits <1024|2048|3072|4096|256|384|521>]
[host <IP Address or Name>] [login <User Login>]
[path <Path to Copy Key>] [format <openssh|secsh>]
```

Description

Create and export an sshkey.

set sshkey all export**Syntax**

```
set sshkey allelexport <ftp|sftp|scp|coppypaste> [pubfile <Public Key
File>]
```

```
[host <IP Address or Name>] [login <User Login>]  
[path <Path to Copy Keys>]
```

Description

Exports the public keys all of the previously created SSH keys.

set sshkey delete

Syntax

```
set sshkey delete <one or more parameters>
```

Parameters

```
keyhost <SSH Key Host>  
keyname <SSH Key Name>  
keyuser <SSH Key User>
```

Description

Deletes an ssh key.

Specify the `keyuser` and `keyhost` to delete an imported key; specify the `keyuser` and `keyname` to delete exported key.

show sshkey import

Syntax

```
show sshkey import <one or more parameters>]
```

Parameters

```
[keyhost <SSH Key IP Address or Name>]  
[keyuser <SSH Key User>]  
[viewkey <enable|disable>]
```

Description

Displays all keys that have been imported or keys for a specific user, IP address, or name.

show sshkey export

Syntax

```
show sshkey export <one or more parameters>
```

Parameters

```
[keyname <SSH Key Name>]  
[keyuser <SSH Key User>]  
[viewkey <enable|disable>]
```

Description

Displays all exported keys or keys for a specific user, IP address, or name.

set sshkey server import type**Syntax**

```
set sshkey server import type <rsa|ecdsa|ed25519> via <sftp|scp>  
    pubfile <Public Key File> privfile <Private Key File>  
    host <IP Address or Name> login <User Login> [path <Path to Key File>]
```

Description

Imports an EMG host key.

set sshkey server reset**Syntax**

```
set sshkey server reset [type <all|rsa|ecdsa|ed25519>]
```

Description

Resets defaults for all or selected host keys.

set sshkey server remove**Syntax**

```
set sshkey server remove
```

Description

Remove all host keys; they will be regenerated after EMG reboot.

show sshkey server**Syntax**

```
show sshkey server [type <all|rsa|ecdsa|ed25519>]
```

Description

Displays host keys (public key only).

Status Commands

show connections

Syntax

```
show connections [deviceport <Device Port # or Name>]
                  [email <Email Address>]
```

Description

Displays a list of current connections. Optionally emails the displayed information. The connection IDs are in the left column of the resulting table. The connection ID associated with a particular connection may change if the connection times out and is restarted.

show connections connid

Syntax

```
show connections connid <Connection ID> [email <Email Address>]
```

Description

Display details for a single connection. Connection IDs are displayed in the left column of the 'show connections' command. The Connection ID associated with a particular connection may change if the connection times out and is restarted. Optionally emails the displayed information.

Note: Use the basic *show connections* command to obtain the Connection ID.

show portcounters

Syntax

```
show portcounters [deviceport <Device Port List or Name>]
                  [email <Email Address>]
```

Description

Generates a device port statistics report for one or more ports. Optionally emails the displayed information.

show portstatus

Syntax

```
show portstatus [deviceport <Device Port List or Name>] [email <Email
Address>]
```

Description

Displays device port modes and states for one or more ports. Optionally emails the displayed information.

show sysconfig**Syntax**

```
show sysconfig [display <basic|auth|devices>] [email <Email Address>]
```

Description

Displays a snapshot of all configurable parameters. Optionally emails the displayed information.

show sysstatus**Syntax**

```
show sysstatus [email <Email Address>]
```

Description

To display the overall status of all EMG units. Optionally emails the displayed information.

Switch Commands

set switch port**Syntax**

```
set switch port <Port # or Name> <one or more parameters>
```

Parameters

```
name <Switch or Port name>
state <enable|disable>
mode <auto|10mbit-half|100mbit-half|10mbit-full|
    100mbit-full|1000mbit-full>
mdix <auto|manualmdi|manualmdix>
```

Description

Configure ports on the Ethernet switch.

set switch internal**Syntax**

```
set switch internal <enable|disable>
```

Description

Enable or disable the internal Ethernet port.

Note: To set the switch IP address and netmask, see the 'set dhcp' command.

set switch vlan

Syntax

```
set switch vlan <VLAN ID> <one or more parameters>
```

Parameters

name <VLAN Name>

fid <Forwarding Information Database 0-255>

membership <Switch Port List>

Note: To remove a VLAN, set VLAN name to "". For example, 'set switch vlan <VLAN ID> name ""'. The default VLAN for all Ports is #1. VLAN ID #1 cannot be removed.

Note: The FID maps learned MAC Addresses to Ingress Port VLAN IDs.

Description

Configure VLANs on the Ethernet switch (a 'Default' VLAN initially contains all switch ports):

show switch vlan

Syntax

```
show switch vlan <vid|name|all> [vid <VLAN ID>] [name <VLAN Name>]
```

vid: shows the VLAN information for a specific VLAN ID

name: shows the VLAN information for a specific VLAN name

all: shows all VLAN entries in switch

Description

Display status of the Ethernet switch VLANs

show switch

Syntax

```
show switch [port <Port # or Name>] [display <status|statistics|all>]
```

Description

Display status of the Ethernet switch or individual ports

show switch ipaddr

Syntax

```
show switch ipaddr
```

Description

Display (scan for) IP addresses accessible via the Ethernet switch

show switch macaddr**Syntax**

```
show switch macaddr
```

Description

Display the MAC address table

show switch internal**Syntax**

```
show switch internal
```

Description

Display status for the internal Ethernet port

System Log Commands

show syslog**Syntax**

```
show syslog [<parameters>]
```

Parameters

```
log <all|netlog|servlog|authlog|devlog|diaglog|genlog>  
level <error|warning|info|debug>  
display <head|tail> [numlines <Number of Lines>]  
starttime <MMDDYYhhmm[ss]>  
endtime <MMDDYYhhmm[ss]>  
email <Email Address>  
Defaults:    log=all, level=error, numlines=40
```

Description

Displays the system logs containing information and error messages.

Note: The level, display, and time parameters cannot be used simultaneously.

show syslog clear**Syntax**

```
show syslog clear <all|netlog|servlog|authlog|devlog|diaglog|genlog>
```

Description

Clears one or all of the system logs.

USB Access Commands

set usb access

Syntax

```
set usb access <enable|disable>
```

Description

Enables or disables access to USB devices.

USB Device Commands

show usb devices

Syntax

```
show usb devices
```

Description

Displays all usb devices with the port each device is connected to.

diag usb

Syntax

```
diag usb [<parameters>]
```

Parameters

```
treedisplay <enable|disable>  
mapdevice <enable|disable>  
email <Email Address>
```

Defaults: treedisplay=enable

Description

Displays information about USB buses and the devices connected to them, including the mapping between a USB device and the EMG port.

Note: For "mapdevice enable", the port names will displayed at the end of the line in square brackets. To see a list of USB devices with vendor id and product id, use 'treedisplay disable'.

USB Serial Commands

set usb serial

Syntax

```
set usb serial <U1|U2> <parameters>
```

Parameters

```

baud <300-230400>                                databits <7|8>
parity <none|odd|even>                             stopbits <1|2>
flowcontrol <none|xon/xoff|rts/cts>
service <none|telnet|ssh|tcp>
telnetport <TCP Port>                             telnetauth <enable|disable>
sshport <TCP Port>                                sshauth <enable|disable>
tcpport <TCP Port>                                tcpauth <enable|disable>
Note: the maximum number of simultaneous connections to a USB device is
3.
```

Description

Configures a serial device connected to a USB port.

show usb serial

Syntax

```
show usb serial
```

Description

Display product information and settings for any USB serial device.

USB Storage Commands

set usb storage dir

Syntax

```
set usb storage dir <U1> [subdir <Directory Path>]
```

Description

Views a directory listing of a USB flash drive.

set usb storage fsck**Syntax**

```
set usb storage fsck <U1>
```

Description

Runs a file system check on a thumb drive (recommended if it does not mount).

set usb storage format**Syntax**

```
set usb storage format <U1> [filesystem <ext2|fat16|fat32>]
```

Description

Formats a USB flash drive.

set usb storage mount**Syntax**

```
set usb storage mount <U1>
```

Description

Mounts a USB flash drive in the EMG for use as a storage device.

The USB flash drive must be formatted with an ext2 or FAT file system before you mount it.

set usb storage unmount**Syntax**

```
set usb storage unmount <U1>
```

Description

Unmounts a USB flash drive. Enter this command before removing the USB device.

set usb storage rename**Description**

Renames a file on a thumb drive.

Syntax

```
set usb storage rename <U1> file <Filename> newfile <New Filename>
```

set usb storage copy**Description**

Copies a file on a thumb drive.

Syntax

```
set usb storage copy <U1> file <Filename> newfile <New Filename>
```

set usb storage delete**Description**

Removes a file on a thumb drive.

Syntax

```
set usb storage delete <U1> file <Current Filename>
```

show usb storage**Description**

Display product information and settings for any USB thumb drive.

Syntax

```
show usb storage
```

show usb**Description**

Display currently attached USB devices with product information and settings.

Syntax

```
show usb  
show usb modem
```

Description

Display product information and settings for any USB modem:

Syntax

```
set usb storage download <U1> file <File Name> via <scp|sftp>  
host <IP address or Name> login <User Login>  
path <Directory for Download>  
[subdir <Directory Name>]
```

Description

Downloads a file on a thumb drive.

USB Modem Commands**set usb modem****Syntax**

```
set usb modem <ul> <parameters>
```

Parameters

```
auth <pap|chap>
baud <300-115200>9600 is the default.
calleridcmd <Modem Command String>
calleridlogging <enable|disable>
cbcpnocalback <enable|disable>
cbctype <admin|user>
chapauth <chaphost|localusers>
chaphost <CHAP Host or User Name>
checkdialtone <disable|5-600 minutes>
databits <7|8>
dialbackdelay <PPP Dialback Delay>
dialbacknumber <username|Phone Number>
dialbackretries <1-10>
dialinlist <Host List for Dial-in>
dialoutlogin <Remote User Login>
dialoutnumber <Phone Number>
dodauth <pap|chap>
dodchaphost <CHAP Host or User Name>
flowcontrol <none|xon/xoff|rts/cts>
group <Local or Remote Group Name>
initscript <Modem Init Script>
localipaddr <negotiate|IP Address>
modemmode <text|ppp>
modemstate
<disable|dialin|dialout|dialback|cbcpserver|cbcpclient|dialondemand|
    dialin+ondemand|dialback+ondemand|dialinhostlist>
modemtimeout <disable|1-9999 sec>
nat <enable|disable>
parity <none|odd|even>
remoteipaddr <negotiate|IP Address>
restartdelay <PPP Restart Delay>
service <none|telnet|ssh|tcp>
sshauth <enable|disable>
sshport <TCP Port>
stopbits <1|2>
tcpauth <enable|disable>
```

```
tcpport <TCP Port>
telnetauth <enable|disable>
telnetport <TCP Port>
timeoutlogins <disable|1-30 minutes>
usesites <enable|disable>
```

Description

Configures a currently loaded USB Modem. **Syntax:**

```
set usb modem <U1> dialoutpassword
set usb modem <U1> chapsecret
set usb modem <U1> dodchapsecret
```

Description

Set the dialout password and CHAP secrets.

Note: *It is recommended that the `initscript` be prepended with 'AT' and include 'E1 V1 x4 Q0' so that the EMG may properly control the modem.*

show usb modem

Syntax

```
show usb modem
```

Description

Display product information and settings for any USB modem.

Virtual Interface Commands

set virtual

Syntax

```
set virtual port <1|2> <parameters>
```

Parameters

```
state <enable|disable>
ipaddr <IP Address> mask <Mask>
ipv6addr <IPv6 Address/Prefix>
```

Note: *It is highly recommended that an IP address/subnet for VEth1 and VEth2 be different than the IP address/subnet for Eth1 and Eth2. Configuring VEth1 or VEth2 with the same IP address/subnet as Eth1 or Eth2 may cause the console manager to become unreachable.*

Description

Configure Virtual Interface Port 1 or 2

show virtual [port <1|2>]

Syntax

show virtual [port <1|2>]

Description

Display virtual interface Port 1 or 2

VPN Commands

set vpn

Syntax

```
set vpn <parameters>
```

Description

Configures setting for an IPsec VPN tunnel.

Parameters

```
tunnel <enable|disable>
name <VPN Tunnel Name>
auth <rsa|psk|x509>
remotehost <Remote Host IP Address or Name>
remoteid <Authentication Name>
remotehop <IP Address>
remotesubnet <one or more subnets in CIDR notation>
remotesourceip <config|CIDR|IP Address Range|poolname>
localip <IP Address>
localid <Authentication name>
localhop <IP Address>
localsubnet <one or more subnets in CIDR notation>
localsourceip <config4|config6|IP Address>
ikenegotiation <main|aggressive>
ikeenc <any|3des|aes|aes192|aes256>
ikeauth <any|sha1|md5|sha2_256|sha2_384|sha2_512>
ikedhgroup <any|dh2|dh5|dh14|dh15|dh16|dh17|dh18|dh19>
ikever <any|ikev1|ikev2>
espcnc <any|3des|aes|aes192|aes256>
espauth <any|sha1|md5|sha2_256|sha2_512|sha2_256_96>
espdhgroup <any|dh2|dh5|dh14|dh15|dh16|dh17|dh18|dh19>
lifetime <SA Lifetime in Seconds (3600) or Bytes with 'b' suffix (3600b)>
xauthclient <enable|disable>
xauthlogin <User Login>
ciscounity <enable|disable>
modeconfig <push|pull>
forceencaps <enable|disable>
deadpeerdelay <disable|1-300 seconds>
deadpeertimeout <5-1200 seconds>
deadpeeraction <restart|hold|clear>
tunnelrestart <enable|disable>
email <Email Address>
startvpnfailoveronly <enable|disable>
```

Enter Pre-Shared Key of remote host:

```
set vpn key
```

Enter XAUTH password (any extra parameters will be ignored):

```
set vpn xauthpassword
```

Configure X.509 certificate for remote peer or local peer.

```
set vpn certificate local via <sftp|scp> rootfile <Cert Authority File>
    certfile <Certificate File> keyfile <Private Key File>
    host <IP Address or Name> login <User Login> [path <Path to Files>]
set vpn certificate remote via <sftp|scp> [rootfile
    <Cert Authority File>]
    certfile <Certificate File> host <IP Address or Name>
    login <User Login> [path <Path to Files>]
```

Delete X.509 certificate for local and/or remote peer.

```
set vpn certificate delete
```

Generate RSA Key for the EMG (any extra parameters will be ignored):

```
set vpn genrsakey
set vpn peerrsaaction upload via <sftp|scp> host <IP address or Name>
    login <User Login> rsafile <rsa key file>
    [path <Path to key file>]
set vpn peerrsaaction delete
```

Display all VPN settings and current status:

```
show vpn [email <Email Address>]
```

Display detailed VPN status:

```
show vpn status [email <Email Address>]
```

Display VPN logs:

```
show vpn viewlog [numlines <Number of Lines>] [email <Email Address>]
```

Display RSA public key of the EMG:

```
show vpn rsakey
```

Display X.509 certificate for local peer (EMG) and remote peer:

```
show vpn certificate
```

Download IPSec conf file (VPN tunnel must be enabled to generate ipsec.conf for download; can be customized and uploaded to access more strongSwan options):

```
set vpn confaction download via <sftp|scp> host <IP address or Name>
    login <User Login> [path <Directory for download>]
```

Upload IPSec conf file to the EMG:

```
set vpn confaction upload via <sftp|scp> host <IP address or Name>
    login <User Login> conffile <Conf File> [path <Path to conf file>]
```

Delete the uploaded conf file:

```
set vpn confaction delete
```

Display all VPN settings and current status:

```
show vpn [email <Email Address>]
```

Display detailed VPN status:

```
show vpn status [email <Email Address>]
```

Display VPN logs:

```
show vpn viewlog [numlines <Number of Lines>] [email <Email Address>]
```

Display X.509 certificate for local peer (EMG) and remote peer:

```
show vpn certificate
```

Display RSA public key of the local peer (EMG) and remote peer:

```
show vpn rsakey
```

Display the uploaded or auto-generated IPSec conf file:

```
show vpn vpnconf
```

WLAN Commands

The EMG can be configured as a wireless client (WLAN) or an access point (AP).

Configure the wireless mode:

```
set wlan mode <client|accesspoint|disable>
```

Configure the wireless access point:

```
set wlan accesspoint <parameters>
```

Parameters

```
ssid <SSID/Network Name>
ssidbroadcast <enable|disable>
channel <auto|Channel Id>
suite <none|wpa|wpa2>
encryption <any|ccmp|tkip>
ipaddr <IP Address> mask <Mask>
dhcpstartaddr <Starting IP Address> dhcpendaddr <Ending IP Address>
```

Set the access point WPA/WPA2 pre-shared key (any extra parameters are ignored):

```
set wlan accesspoint wpa-psk
```

Create, edit, rename or delete a custom WLAN profile:

```
set wlan profile <add|edit> <Profile Name> <parameters>
```

Parameters

```
networkname <Network Name>
state <enable|disable>
priority <Profile Priority 1-4, lower number is lower priority>
auth <none|wep|wpa-wpa2>
[wepauth <open|shared>] [wepkeytype <passphrase|hex>]
[wepkeylength <40|104>] [weptxkeyindex <1|2|3|4>]
[wpaauth <psk|802.1x>] [wpakeytype <passphrase|hex>]
[wpaencryption <any|ccmp|tkip>]
[wpa802eap <eap-tls|eap-ttls|peap|fast|leap>]
[wpa802username <User Name>]
```

```
[wpa802ttlsauth <eap-mschapv2|mschapv2|mschap|chap|pap|eap-md5>]
[wpa802peapauth <eap-mschapv2|eap-md5|eap-tls>]
[wpa802fastauth <mschapv2|md5|gtc>]
[wpa802fastprovision <unauth|auth|both>]
[wpa802validatecert <enable|disable>]
```

Configure certificate files for a WPA-WPA2 802.1X profile:

```
set wlan profile edit <Profile Name> certificate import via <sftp|scp>
    host <IP Address or Name> login <User Login> [path <Path to
Files>]
    [certfile <Certificate File> keyfile <Private Key File>]
    [rootfile <CA Certificate>]
set wlan profile edit <Profile Name> certificate delete

set wlan profile rename <Profile Name> newname <New Profile Name>

set wlan profile delete <Profile Name>
```

Configure the WEP PSK, WEP keys, WPA/WPA2 PSK or key, and 802.1x password:

```
set wlan profile weppsk <Profile Name>
set wlan profile wepkey1 <Profile Name>
set wlan profile wepkey2 <Profile Name>
set wlan profile wepkey3 <Profile Name>
set wlan profile wepkey4 <Profile Name>
set wlan profile wpapsk <Profile Name>
set wlan profile wpa802password <Profile Name>
```

Enable a default profile that allows network scanning without a custom profile:

```
set wlan profile defaultprofile <enable|disable>
```

Configure the wireless client interface:

```
set wlan interface <parameters>
```

Parameters

```
state <dhcp|static> [ipaddr <IP Address> mask <Mask>]
ipv6addr <IPv6 Address/Prefix>
mtu <Maximum Transmission Unit>
```

Set the WiFi radio's regulatory domain. The supported regions are FCC (United States), IC (Industry Canada), CN (China), JP (Japan), KCC (Korea), ETSI (Europe without EN 300 440 support), EN440 (Europe with EN 300 440 support), AU (Australia) and WW (World Mode):

```
set wlan radio region <ww|fcc|ic|etsi|en440|kcc|jp|cn|au>
```

Warning: Each time the region is changed it is programmed into the radio, which can be done a maximum of ~10 times; use care when changing the region. Update the wireless firmware:

```
set wlan update <scp|sftp|ftp|usb|sdcard> fwfile <Firmware File>
                  dbfile <.db File> [host <IP Address or Name>]
                  [login <User Login>] [path <File Path>]

set wlan update reset

show wlan [email <Email Address>]
show wlan accesspoint [display <clients|detailed|all>]
                     [email <Email Address>]
show wlan interface [email <Email Address>]
show wlan networks [display <list|detailed>] [email <Email Address>]
show wlan profiles [display <list|detailed>] [email <Email Address>]
                  [profile <Profile Name>] [viewkeys <enable|disable>]
show wlan radio [email <Email Address>]
```

Note: see 'diag wlan' for diagnostic tools.

Temperature Commands

set temperature

Syntax

```
set temperature
```

Description

Sets the acceptable range for the internal temperature sensor (an SNMP trap is sent if the temperature is outside of this range). Temperatures can be entered in either Celsius or Fahrenheit; to indicate a temperature is Fahrenheit, append the degrees with an 'F', i.e., "75F".

Parameter

```
set temperature <one or more parameters>
Parameters: low <Low Temperature in C. or F.>
high <High Temperature in C. or F.>
calibrate <Temperature Calibration in C. or F.|cancel>
```

Note: The calibration offset will be applied one hour after setting the value.

Description

Displays the acceptable range and the current reading from the internal temperature sensor.

show temperature

Syntax

```
show temperature
```

Description

Shows the temperature.

Xmodem Commands

set xmodem repo

Syntax

```
set xmodem repo import <Xmodem File> via <ftp|sftp|scp>
                        host <IP Address or Name> login <User Login>
                        [path <Path to Xmodem File>]
set xmodem repo rename <Xmodem File> newfile <New Filename>
set xmodem repo delete <Xmodem File>
```

Description

Manages a repository of files that can be sent to or received from a device port with Xmodem, Ymodem, or Zmodem. The maximum file size is 20 MB, and the maximum total repository size is 25 MB.

set xmodem send/receive

Syntax

```
set xmodem send <Device Port # or Name> file <Xmodem File>
                protocol <xmodem|ymodem|zmodem> xfer <binary|ascii>
set xmodem receive <Device Port # or Name> [file <Xmodem File>]
                protocol <xmodem|ymodem|zmodem> xfer <binary|ascii>
                [overwrite <enable|disable>]
```

Description

Send or receive files with Xmodem, Ymodem or Zmodem (by default receive will not overwrite a file in the repository with the same name).

show xmodem

Syntax

```
show xmodem
```

Description

Shows the Xmodem repository files.

Appendix A: Security Considerations

The EMG provides data path security by means of SSH or Web/SSL. Even with the use of SSH/SSL, however, do not assume you have complete security. Securing the data path is only one measure needed to ensure security. This appendix briefly discusses some important security considerations.

Security Practice

Develop and document a Security Practice. The Security Practice should state:

- ◆ The dos and don'ts of maintaining security. For example, the power of SSH and SSL is compromised if users leave sessions open or advertise their password.
- ◆ The assumptions that users can make about the facility and network infrastructure, for example, how vulnerable the CAT 5 wiring is to tapping.

Factors Affecting Security

External factors affect the security provided by the EMG unit, for example:

- ◆ Telnet sends the login exchange as clear text across Ethernet. A person snooping on a subnet may read your password.
- ◆ A terminal to the EMG may be secure, but the path from the EMG to the end device may not be secure.
- ◆ With the right tools, a person with physical access to open the EMG unit may be able to read the encryption keys.
- ◆ There is no true test for a denial-of-service attack. There is always a legitimate scenario for a request storm. A denial-of-service filter locks out some high-performance automated/scripted requests. The EMG will attempt to service all requests and will not filter out potential denial-of-service attacks.

Security Best Practices

The following practices are suggested for configuring the EMG with the most secure configuration for encryption protocols (both incoming and outgoing network traffic), as well as access to external components. By default, the console manager is configured with the web UI enabled via HTTPS port 443, SSH enabled via port 22, and the Discovery Server enabled (supports the Lantronix Discovery Protocol for discovering other Lantronix devices on the local subnet on UDP port 30718).

- ◆ **SSH** - use the following SSH settings: enable SHA2 and Higher ciphers, disable NIST Algorithms, disable RSA Host Key Algorithms, configure a SSH Timeout, and require SSH users logging into the EMG to use MFA via SSH public key plus a password. See [SSH/Telnet/Logging](#).

-
- ◆ **TLS/SSL** - use only TLSv1.3 and the Highest ciphers and a trusted certificate, or disable the web server if only CLI access is needed. See [Web Server](#).
 - ◆ **VPN** - use the following VPN settings: use IKEv2 (avoid IKEv1 with Aggressive Mode), configure both the IKE Encryption and ESP Encryption algorithms (use AES256, SHA2_256 or higher, Diffie-Hellman group 18 or higher), and a trusted certificate for Authentication. See [VPN Settings](#).
 - ◆ **WiFi (EMG models)** - disable Access Point mode, and in Wireless Client mode only use WPA2 authentication with the EAP-TLS protocol and a trusted certificate. See [VPN Settings](#).
 - ◆ **SNMP** - disable SNMP v1, SNMP v2 and use only SNMP v3 over TLS with a trusted certificate. See [SNMP](#).
 - ◆ **SMTP** - use TLS with SMTP authentication. See [SSH/Telnet/Logging](#).
 - ◆ **LDAP** - encrypt traffic with SSL and a trusted certificate. See [LDAP](#).
 - ◆ **Device Ports** - if direct network access to a Device Port is enabled, it should be only via SSH with Authentication; in addition, SSH Timeouts, Group Access, New User Message, and Max Direct Connects can be configured for each device port to control which users have access to a port, how many users can simultaneously access a port, and notifications when another user connects to a port. See [Device Ports - Settings](#).
 - ◆ **External USB Port(s)** - if the external USB ports are not used for firmware updates, saving configurations, serial connections, external analog modems or port logging, the ports can be disabled. See [USB/SD Card Storage](#).
 - ◆ **External SD Card** - if the external SD Card is not used for firmware updates, saving configurations, or port logging, the SD Card can be disabled. See [USB/SD Card Storage](#).
 - ◆ **External Modems** - in addition to disabling the external USB ports (see above), Access Lists can be used to control phone numbers that will be granted dial-in access. See [Access Lists](#).
 - ◆ **LDP (Lantronix Discovery Protocol)** - this protocol (and open UDP port 30718) can be disabled with the Discovery Server setting. See [SSH/Telnet/Logging](#).
 - ◆ **Saving Device Configurations** - configurations saved via the Maintenance web page (tarball format) are not encrypted, and if used, should be securely stored as configurations contain credentials that should be protected. See [Firmware & Configurations](#).

Appendix B: Safety Information

Safety Precautions

Please follow the safety precautions described below when installing and operating the EMG.

Caution: *EQUIPMENT IS FOR INDOOR USE ONLY!*

Cover

- ◆ Do not remove the cover of the chassis. There are no user-serviceable parts inside. Opening or removing the cover may expose you to dangerous voltage that could cause fire or electric shock.
- ◆ Refer all servicing to Lantronix.

Power Plug

- ◆ Connect the power plug in the following order: 1) Connect the DC plug to the EMG first. 2) Connect the AC cable to the external power supply. 3) Connect the AC cable to the power source. When removing power, the AC cable to the power source should be unplugged first.
- ◆ Always connect the power cord to a properly wired and grounded power source. Do not use adapter plugs or remove the grounding prong from the cord.
- ◆ When disconnecting the power cable from the socket, pull on the plug, not the cord.
- ◆ Only use a power cord with a voltage and current rating greater than the voltage and current rating marked on the EMG unit.
- ◆ The EMG unit must be connected to a branch circuit provided with 15A or 20A, single pole circuit breaker.
- ◆ Install the EMG near an AC outlet that is easily accessible.
- ◆ Always connect any equipment used with the product to properly wired and grounded power sources.
- ◆ To help protect the product from sudden, transient increases and decreases in electrical power, use a surge suppressor, line conditioner, or uninterruptible power supply (UPS).
- ◆ Do not connect or disconnect this product during an electrical storm.

Input Supply

Warning: *Disconnect all power supply sources before servicing to avoid electric shock.*

- ◆ Check nameplate ratings to assure there is no overloading of supply circuits that could affect over current protection and supply wiring.

Grounding

1. Maintain reliable grounding of this product.
2. Pay particular attention to supply connections when connecting to power strips, rather than directly to the branch circuit.

Rack Mounting

If rack mounted EMGs are installed in a closed or multi-unit rack assembly, they may require further evaluation by Certification Agencies. The following items must be considered:

- ◆ Do not install the EMG unit in a rack in such a way that a hazardous stability condition results because of uneven loading. A drop or fall could cause injury.
- ◆ The ambient temperature (Tma) inside the rack may be greater than the room ambient temperature. Make sure to install the EMG in an environment with an ambient temperature less than the maximum operating temperature of the EMG unit. See [Hardware Specifications on page 42](#).
- ◆ Install the equipment in a rack in such a way that the amount of airflow required for safe operation of the equipment is not compromised.
- ◆ Mount the equipment in the rack so that a hazardous condition is not achieved due to uneven mechanical loading.
- ◆ Maintain reliable earthing of rack-mounted equipment. Give particular attention to supply connections other than direct connections to the branch circuit (e.g. use of power strips).
- ◆ Before operating the EMG, make sure the EMG unit is secured to the rack.

Wall Mounting

If wall-mounted units are installed, the following items must be considered:

- ◆ Do not install the unit in such a way that a hazardous stability condition results because of uneven loading. A drop or fall could cause injury.
- ◆ Make sure to install the EMG unit in an environment with an ambient temperature less than the maximum operating temperature of the EMG unit. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (Tma) specified by the manufacturer.
- ◆ Maintain reliable earthing of wall-mounted equipment. Give particular attention to supply connections other than direct connections to the branch circuit (e.g. use of power strips) because of the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.
- ◆ Before operating the EMG, make sure the device mounting is secured.

Port Connections

-
- ◆ Only connect the network port to an Ethernet network that supports 10/100/1000 BASE-T.
 - ◆ Only connect device ports to equipment with serial ports that support EIA-232 (formerly RS-232C).
 - ◆ Only connect the console port to equipment with serial ports that support EIA-232 (formerly RS-232C).
 - ◆ Only connect a telephone line to the MODEM port.

Caution: *To reduce the risk of fire, use only number 26 AWG or larger (e.g., 24 AWG) UL-listed or CSA-certified telecommunication line cord.*

Appendix C: Adapters and Pinouts

The serial device ports of the EMG products match the RJ45 pinouts of the console ports of many popular devices found in a network environment. The EMG uses conventional straight-through Category 5 fully pinned network cables for all connections when used with Lantronix adapters. The cables are available in various lengths.


In most cases, you will need an adapter for your serial devices. Lantronix offers a variety of RJ45-to-serial connector adapters for many devices. These adapters convert the RJ45 connection on the EMG unit to a 9-pin or 25-pin serial connector found on other manufacturers' serial devices or re-route the serial signals for connections to other devices that use RJ45 serial connectors.

The console port is wired the same way as the device ports and has the same signal options.

Note: You can view or change the console port settings using the [Device Ports](#) page or the command line interface `show console port` and `set consoleport` commands.

The adapters illustrated below are compatible with the Lantronix EMG models.

Figure C-1 RJ45 Receptacle to DB25M DCE Adapter for the EMG Unit (PN 200.2066A)



Use PN 200.2066A adapter with a dumb terminal or with many SUN applications.





Figure C-2 RJ45 Receptacle to DB25F DCE Adapter for the EMG Unit (PN 200.2067A)**Figure C-3 RJ45 Receptacle to DB9M DCE Adapter for the EMG Unit (PN 200.2069A)**

Figure C-4 RJ45 Receptacle to DB9F DCE Adapter for the EMG Unit (PN 200.2070A)

Use PN 200.2070A adapter with a PC's serial port.

Figure C-5 RJ45 Receptacle to DB25M DTE Adapter (PN 200.2073)

Appendix D: Protocol Glossary

BOOTP (Bootstrap Protocol)

Similar to DHCP, but for smaller networks. Automatically assigns the IP address for a specific duration of time.

CHAP (Challenge Handshake Authentication Protocol)

A secure protocol for connecting to a system; it is more secure than the PAP.

DHCP (Dynamic Host Configuration Protocol)

Internet protocol for automating the configuration of computers that use TCP/IP.

DNS (Domain Name Servers)

A system that allows a network nameserver to translate text host names into numeric IP addresses.

EAP (Extensible Authentication Protocol)

An authentication framework used to pass the authentication information between the supplicant (the console manager) and the authentication server. See also EAP-TLS, EAP-TTLS, FAST, LEAP, and PEAP.

EAP-TLS (EAP Transport Layer Security)

An authentication protocol that uses TLS and Public key infrastructure (PKI) to set up authentication with a RADIUS server. This method requires the use of a client-side certificate for communicating with the server.

EAP-TTLS (EAP Tunneled Transport Layer Security)

An authentication protocol that uses TTLS and server-side certificates to set up authentication between the console manager and a RADIUS server. The actual authentication is, however, performed using passwords.

FAST (Flexible Authentication via Secure Tunneling)

An authentication protocol that uses Protected Access Credential (PAC) for verifying clients on the network. Instead of using a certificate to achieve mutual authentication, FAST authenticates by means of a PAC stored on the console manager, which can be managed dynamically by the authentication server.

FTP (File Transfer Protocol)

A protocol for transferring files between computers on a network that is insecure by design and susceptible to interception. See also SCP, SFTP, and TFTP.

IKEv1 and IKEv2 (Internet Key Exchange)

A protocol used to set up a security association in the IPsec protocol suite that allows two parties to send data securely.

IPsec

A protocol suite for securing Internet Protocol (IP) communications by authenticating and encrypting each IP packet of a communication session.

Kerberos

A network authentication protocol that provides strong authentication for client/server applications by using secret-key cryptography.

LAN (Local Area Network)

Any collection of independent computers that exchange information with each other over a shared communication medium.

LEAP (Lightweight Extensible Authentication Protocol)

Authentication protocol that uses dynamic WEP keys and mutual authentication with a modified version of MS-CHAP between the console manager and a RADIUS server.

LDAP (Lightweight Directory Access Protocol)

A protocol for accessing directory information.

MIB (Management Information Base)

MIB is part of the Simple Network Management Protocol (SNMP) and describes the set of manageable objects within a network device.

NAT (Network Address Translation)

An Internet standard that enables a LAN to use one set of IP addresses for internal traffic and a second set of addresses for external traffic. This enables a company to shield internal addresses from the public Internet.

NFS (Network File System)

A protocol that allows file sharing across a network. Users can view, store, and update files on a remote computer. You can use NFS to mount all or a portion of a file system. Users can access the portion mounted with the same privileges as the user's access to each file.

NIS (Network Information System)

System developed by Sun Microsystems for distributing system data such as user and host names among computers on a network.

NMS (Network Management System)

NMS acts as a central server, requesting and receiving SNMP-type information from any computer using SNMP.

NTP (Network Time Protocol)

A protocol used to synchronize time on networked computers and equipment.

PAP (Password Authentication Protocol)

A method of user authentication in which the username and password are transmitted over a network and compared to a table of name-password pairs.

PEAP (Protected EAP)

An authentication protocol that uses server-side public key certificates to authenticate the console manager with a RADIUS server. This type of authentication creates an encrypted TLS tunnel between the console manager and the server. The exchange of information is encrypted and stored in the tunnel ensuring the user credentials are kept secure.

PPP (Point-to-Point Protocol)

A protocol for creating and running IP and other network protocols over a serial link.

RADIUS (Remote Authentication Dial-In User Service)

An authentication and accounting protocol. Enables remote access servers to communicate with a central server to authenticate dial-in users and their access permissions. A company stores user profiles in a central database that all remote servers can share.

SCP (Secure Copy Protocol)

A file transfer protocol that is similar to SFTP in that it uses SSH encryption and authentication, but is slightly faster.

SFP (Small form-factor pluggable)

A type of hot-swappable network interface module used for both telecommunications and data communications applications.

SFTP (SSH File Transfer Protocol)

Secure file transfer protocol over SSH Commands and data in transit are encrypted.

SMB/CIFS (Server Message Block/Common Internet File System)

Microsoft's protocol for allowing all applications as well as Web browsers to share files across the Internet. CIFS runs on TCP/IP and uses the SMB protocol in Microsoft Windows for accessing files. With CIFS, users with different platforms and computers can share files without having to install new software.

SNMP (Simple Network Management Protocol)

A protocol that system administrators use to monitor networks and connected devices and to respond to queries from other network hosts.

SMTP (Simple Mail Transfer Protocol)

TCP/IP protocol for sending email between servers.

SSL (Secure Sockets Layer)

A protocol that provides authentication and encryption services between a web server and a web browser.

SSH (Secure Shell)

A secure transport protocol based on public-key cryptography.

TACACS+ (Terminal Access Controller Access Control System)

A method of authentication used in UNIX networks. It allows a remote access server to communicate with an authentication server to determine whether the user has access to the network.

Telnet

A terminal protocol that provides an easy-to-use method of creating terminal connections to a network host.

TLS (Transport Layer Security)

A security protocol that facilitates authentication and encryption services for communication over the Internet.

TFTP (Trivial File Transfer Protocol)

Simpler version of FTP that doesn't require any type of authentication.

WAN (Wide Area Network)

A large network of information that combines multiple LANs that are geographically separate.

Xmodem

A file transfer protocol that allows file transfer between two computers across the serial port. Subsequent modified versions of the protocol are called Ymodem and Zmodem.

Appendix E: Compliance Information

Manufacturer's Name & Address

Lantronix Inc., 48 Discovery, Suite 250, Irvine, CA 92618 USA

Declares that the following product:

Product Name(s): EMG 8500 and EMG 7500

Conforms to the following standards or other normative documents:

Table E-1 Regional Certifications

Country	Specification
USA	FCC 47 CFR part 15 Subpart B FCC 47 CFR part 15 Subpart 22H, 22E, 27 & 90S FCC 47 CFR Part 15 Subpart E
Canada	ISED RSS-130 Issue 2 RSS-132 Issue 3 RSS-133 Issue 6 RSS 139 Issue 3 RSS195 Issue 2 RSS-199 RSS-247 Issue 2 RSS-GEN Issue 5
EU	EU Declaration of Conformity ♦ EMG 8500, see Figure E-4 and Figure E-5 ♦ EMG 7500, see Figure E-6
Australia, New Zealand	AS/NZS CISPR 32:2015
Safety	UL/EN 60950-1 UL/EN 62368-1 CAN/CSA C22.2 62368-1-14 CAN/CSA C22.2 60950-1-07
Cellular Certification	PTCRB, AT&T

Table E-2 Country Transmitter IDs

Country	Specification
USA FCC ID	Cellular Module: N7NEM7455 Wi-Fi Module (pending): SQG-60SIPT
Canada IC ID	Cellular Module: 2417C-EM7455 Wi-Fi Module (pending): 3147A-602230C

Table E-3 Cellular Bands for US and EU

Cellular/Bands	US	EU
3G	2/4/5	1/3/8
4G	2/4/5/7/12/13/25/26/41	1/3/7/8/20

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- ◆ Reorient or relocate the receiving antenna.
- ◆ Increase the separation between the equipment and receiver.
- ◆ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ◆ Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Operations are restricted to indoor usage only.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Antenna Installation

- 1) The antenna must be installed such that 20 cm is maintained between the antenna and users, and
- 2) The transmitter module may not be co-located with any other transmitter or antenna.

Statement:

This device complies with RSS-247 of the Industry Canada Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Ce dispositif est conforme à la norme CNR-247 d'Industrie Canada applicable aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

This device is intended only for use under the following conditions:

- 1) The antenna must be installed such that 20 cm is maintained between the antenna and users, and
- 2) The transmitter module may not be co-located with any other transmitter or antenna.

Cet appareil est conçu uniquement pour les intégrateurs OEM dans les conditions suivantes: (Pour utilisation de dispositif module)

- 1) L'antenne doit être installée de telle sorte qu'une distance de 20 cm est respectée entre l'antenne et les utilisateurs, et
- 2) Le module émetteur peut ne pas être coïmplanté avec un autre émetteur ou antenne.

Figure E-4 EMG 8500, EU Declaration of Conformity



We,
Company Name: LANTRONIX, INC.
Postal address: 7535 Irvine Center Dr. Suite 100
Postcode: 92618
City: Irvine
Telephone number: 949 453-3990
Web address: www.lantronix.com

Declare that the DoC is issued under our sole responsibility and belongs to the following product:

Apparatus model/Product: EMG 8500
Type: Edge Management Gateway

Object of the declaration

Edge Management Gateway, EMG 8500,

Item	
Cellular Radio Firmware	SW19X20C_02.32.11.00

The object of the declaration described above is in conformity with the relevant Union harmonization legislation:

- Radio Equipment Directive (RED), 2014/53/EU
- Restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS) Directive, 2011/65/EU

The following harmonized standards and technical specifications have been applied

Radio Equipment Directive Article 3.1(a) Safety Standards:

- EN 60950-1: 2006 + A11:2009 + A1:2010 + A12:2011 + A2:2013 - Information technology equipment - Safety -- Part 1: General requirements
- EN 62368-1:2014 + AC:2015 - Audio/video, information and communication technology equipment - Part 1: Safety requirements (IEC 62368-1:2014, modified)
- EN 62311: 2008 - Assessment of electronic and electrical equipment related to human exposure restrictions for electromagnetic fields (0 Hz - 300 GHz)

Figure E-5 EMG 8500 EU Declaration of Conformity, continued

- EN 301 489-52 V1.1.0 Electromagnetic Compatibility (EMC) standard for radio equipment and services; Part 52: Specific conditions for Cellular Communication Mobile and portable (UE) radio and ancillary equipment

Radio Equipment Directive Article 3.2 Radio Standards:

- EN 300 328 V2.1.1 - Wideband transmission systems; Data transmission equipment operating in the 2,4 GHz ISM band and using wide band modulation techniques; Harmonized Standard covering the essential requirements of article 3.2 of Directive 2014/53/EU
- EN 301 893 v2.1.1 5 GHz RLAN; Harmonized Standard covering the essential requirements of article 3.2 of Directive 2014/53/EU
- ETSI TS 151 010-1 V13.2.0 Digital cellular telecommunications system (Phase 2+) (GSM); Mobile Station (MS) conformance specification; Part 1: Conformance specification (3GPP TS 51.010-1 version 13.2.0 Release 13)
- ETSI TS 301 511 V12.5.1 Global System for Mobile communications (GSM); Mobile Stations (MS) equipment; Harmonized Standard covering the essential requirements of article 3.2 of Directive 2014/53/EU
- ETSI TS 301 908 v11.1.2 IMT cellular networks; Harmonized Standard covering the essential requirements of article 3.2 of Directive 2014/53/EU; Part 13: Evolved Universal Terrestrial Radio Access (E-UTRA) User Equipment (UE)


ROHS Directive

- EN 50581:2012 - Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

Signed for and on behalf of:

Place of Issue: Lantronix Inc., Irvine CA.

Date of issue: 12-30-2019



Fathi Hakam, VP of Engineering

Figure E-6 EMG 7500 EU Declaration of Conformity




EU DECLARATION OF CONFORMITY

Manufacturer's Name: LANTRONIX INC.
Manufacturer's Address: 7535 Irvine Center Drive, Suite 100
Irvine, CA. 92618. USA

Product Type: Edge Management Gateway
Product Family: EMG 7500
Rated: 9-30VDC
Intended use: Commercial installations, indoor use

Manufacturer's Quality System:


ISO 9001:2015 Certificate No. 74 300 4282 TUV Rheinland

Applicable EU Directives:

Low Voltage Directive (2014/35/EU)

- EN 62368-1:2014 + A11:2017

EMC Directive (2014/30/EU)

- Draft EN 301 489-52 V1.1.2 (2020-12)
- EN 301 489-1 V2.2.3 (2019-11)
- EN 55032:2015+A11: 2020, Class B
- EN 61000-3-2:2014, Class A
- EN 61000-3-3:2013
- EN 55035:2017
- EN 61000-4-2:2009
- EN 61000-4-3:2006 +A1:2008 +A2:2010
- EN 61000-4-4:2012
- EN 61000-4-5:2014 +A1:2017
- EN 61000-4-6:2014
- EN 61000-4-8:2010
- EN 61000-4-11:2004 +A1:2017

RF Radio Directive (2014 / 53 / EU)

- EN 301 908-1 V13.1.1 (2019-11)
- EN 301 908-2 V11.1.1 (2017-06)
- EN 301 908-13 V6.2.1 (2015-10)
- EN 50385(2017)

EU Directive 2011/65/EU for Restriction of Hazardous Substance (RoHS2) with exemption 7(c)-I

Statement of Conformity: The product specified above complies with applicable EU directive referenced, including the application of sound engineering practice.

Signature:  Date: May 21, 2021

Name: Fathi Hakam Title: VP of Engineering

CERT-00206 rev B

Table E-7 EU Statements

Code	Language	Statement
	Bulgarian	Lantronix, Inc., декларира, че този EMG 8500, EMG 7500 отговаря на основните изисквания и други приложими разпоредби на Директива 2014/53 / EC. Пълният текст на декларацията на ЕС за съответствие е достъпен на следния интернет адрес: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads Известие на ЕС за ограничения при употреба: Това устройство е ограничено само за вътрешна употреба. Може да не се работи на открито.
cs	Česky [Czech]	Lantronix, Inc. tímto prohlašuje, že tento EMG 8500, EMG 7500 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 2014/53/EU. Úplné znění ES prohlášení o shodě je k dispozici na této internetové adrese: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads Oznámení EU o omezení používání: Toto zařízení je omezeno pouze na použití uvnitř. Nesmí být provozován venku.
da	Dansk [Danish]	Undertegnede Lantronix, Inc. erklærer herved, at følgende udstyr EMG 8500, EMG 7500 overholder de væsentlige krav og øvrige relevante krav i direktiv 2014/53/EU. Den fulde tekst til EU-overensstemmelseserklæringen er tilgængelig på følgende internetadresse: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads EU-meddelelse om begrænsninger i brug: Denne enhed er kun begrænset til indendørs brug. Det betjenes måske ikke udendørs.
de	Deutsch [German]	Hiermit erklärt Lantronix, Inc., dass sich das Gerät EMG 8500, EMG 7500 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 2014/53/EU befindet. Der vollständige Text der EU-Konformitätserklärung ist unter folgender Internetadresse abrufbar: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads EU-Hinweis zu Nutzungsbeschränkungen: Dieses Gerät darf nur in Innenräumen verwendet werden. Es darf nicht im Freien betrieben werden.

Code	Language	Statement
et	Eesti [Estonian]	Käesolevaga kinnitab Lantronix, Inc. seadme EMG 8500, EMG 7500 vastavust direktiivi 2014/53/EU põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele. EL-i vastavusdeklaratsiooni täielik tekst on saadaval järgmisel Interneti-aadressil: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads EL-i teade kasutuspiirangute kohta: seda seadet saab kasutada ainult siseruumides. Seda ei tohi õues kasutada.
en	English	Hereby, Lantronix, Inc., declares that this EMG 8500, EMG 7500 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads EU Notice of Restrictions on Use: This device is limited to indoor use only. It may not be operated outdoors.
es	Español [Spanish]	Por medio de la presente Lantronix, Inc. declara que el EMG 8500, EMG 7500 module cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 2014/53/EU. El texto completo de la declaración de conformidad de la UE está disponible en la siguiente dirección de Internet: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads Aviso de restricciones de uso de la UE: este dispositivo está limitado solo para uso en interiores. No puede ser operado al aire libre.
el	Ελληνική [Greek]	ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Lantronix, Inc. ΔΗΛΩΝΕΙ ΟΤΙ EMG 8500, EMG 7500 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 2014/53/EU. Το πλήρες κείμενο της δήλωσης συμμόρφωσης της ΕΕ διατίθεται στην ακόλουθη διεύθυνση διαδικτύου: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads Ειδοποίηση της ΕΕ για περιορισμούς χρήσης: Η συσκευή αυτή περιορίζεται μόνο σε εσωτερικούς χώρους χρήσης. Μπορεί να μην λειτουργεί σε εξωτερικούς χώρους.

Code	Language	Statement
fr	Français [French]	Par la présente Lantronix, Inc. déclare que l'appareil EMG 8500, EMG 7500 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 2014/53/EU. Le texte complet de la déclaration de conformité UE est disponible à l'adresse Internet suivante : https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads Avis de restrictions d'utilisation de l'UE: Cet appareil est limité à une utilisation en intérieur uniquement. Il ne doit pas être utilisé à l'extérieur.
	Icelandic	Hér með lýsir Lantronix, Inc. því yfir að EMG 8500, EMG 7500 sé í samræmi við grunnkröfur og önnur viðeigandi ákvæði tilskipunar 2014/53 / ESB. Í heildartexta ESB-samræmisýfirlýsingarinnar er að finna á eftirfarandi internetfangi: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads Tilkynning ESB um takmarkanir á notkun: Þetta tæki er eingöngu takmarkað við notkun innanhúss. Það má ekki nota það úti.
it	Italiano [Italian]	Con la presente Lantronix, Inc. dichiara che questo EMG 8500, EMG 7500 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 2014/53/EU. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads Avviso di restrizioni d'uso dell'UE: questo dispositivo è limitato esclusivamente all'uso in interni. Potrebbe non essere utilizzato all'aperto.
	Latviski [Latvian]	Ar šo Lantronix, Inc. deklarē, ka EMG 8500, EMG 7500 atbilst Direktīvas 2014/53/EU būtiskajām prasībām un citiem ar to saistītajiem noteikumiem. Pilns ES atbilstības deklarācijas teksts ir pieejams šādā tīmekļa vietnē: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads ES paziņojums par lietošanas ierobežojumiem: šo ierīci var izmantot tikai iekštelpās. To nedrīkst darbināt ārpus telpām.

Code	Language	Statement
	Lietuvių [Lithuanian]	Šiuo Lantronix, Inc. deklaruoja, kad šis EMG 8500, EMG 7500 atitinka esminius reikalavimus ir kitas 2014/53/EU Direktyvos nuostatas. Visą ES atitikties deklaracijos tekstą galite rasti šiuo interneto adresu: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads ES pranešimas apie naudojimo apribojimus: Šis prietaisas skirtas naudoti tik patalpose. Jo negalima naudoti lauke.
nl	Nederlands [Dutch]	Hierbij verklaart Lantronix, Inc. dat het toestel EMG 8500, EMG 7500 overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 2014/53/EU. De volledige tekst van de EU-conformiteitsverklaring is beschikbaar op het volgende internetadres: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads EU kennisgeving van gebruiksbepalingen: dit apparaat is beperkt tot gebruik binnenshuis. Het mag niet buitenshuis worden gebruikt.
mt	Malti [Maltese]	Hawnhekk, Lantronix, Inc., jiddikjara li dan EMG 8500, EMG 7500 jikkonforma mal'htigijiet essenzjali u ma provvedimenti oħrajn rilevanti li hemm fid-Dirrettiva 2014/53/EU. It-test s'hih tad-dikjarazzjoni ta 'konformità tal-UE huwa disponibbli fl-indirizz tal-internet li ġej: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads Avviż tal-UE dwar Restrizzjonijiet fuq l-Użu: Dan l-apparat huwa limitat għal użu ġewwa biss. Ma jistax jiġihaddem barra.
hu	Magyar [Hungarian]	Alulírott, Lantronix, Inc. nyilatkozom, hogy a EMG 8500, EMG 7500 megfelel a vonatkozó alapvető követelményeknek és az 2014/53/EU irányelv egyéb előírásainak. Az EU-megfelelőségi nyilatkozat teljes szövege a következő internetes címen érhető el: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads EU értesítés a korlátozásokról: Ez az eszköz csak beltéri használatra korlátozódik. Lehet, hogy szabadban nem üzemeltethető.

Code	Language	Statement
	Norwegian	Lantronix, Inc. erklærer herved at denne EMG 8500, EMG 7500 er i samsvar med de grunnleggende kravene og andre relevante bestemmelser i direktiv 2014/53 / EU. Den fullstendige teksten til EU-samsvarserklæringen er tilgjengelig på følgende internettsadresse: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads EUs merknad om bruksbegrensninger: Denne enheten er bare begrenset til innendørs bruk. Det kan hende at den ikke brukes utendørs.
pl	Polski [Polish]	Niniejszym Lantronix, Inc. oświadcza, że EMG 8500, EMG 7500 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 2014/53/EU. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads Zawiadomienie UE o ograniczeniach użytkowania: To urządzenie jest przeznaczone wyłącznie do użytku w pomieszczeniach. Nie można go obsługiwać na zewnątrz.
pt	Português [Portuguese]	Lantronix, Inc. declara que este EMG 8500, EMG 7500 está conforme com os requisitos essenciais e outras disposições da Directiva 2014/53/EU. O texto completo da declaração UE de conformidade está disponível no seguinte endereço na Internet: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads Aviso da UE de restrições de uso: Este dispositivo está limitado apenas ao uso interno. Não pode ser operado ao ar livre.
	Romanian	Prin prezenta, Lantronix, Inc., declară că acest EMG 8500, EMG 7500 respectă cerințele esențiale și alte dispoziții relevante din Directiva 2014/53 / UE. Textul complet al declarației de conformitate a UE este disponibil la următoarea adresă de internet: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads Notificarea UE privind restricțiile de utilizare: Acest dispozitiv este limitat numai la uz interior. Este posibil să nu funcționeze în aer liber.

Code	Language	Statement
	Serbian	Овиме, Лантроник, Инц., изјављује да је овај ЕМГ 8500, ЕМГ 7500 у складу са суштинским захтевима и осталим релевантним одредбама Директиве 2014/53 / ЕУ. Комплетан текст ЕУ изјаве о усаглашености доступан је на следећој Интернет адреси: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads Обавештење ЕУ о ограничењима употребе: Овај уређај је ограничен само на унутрашњу употребу. Можда се не користи на отвореном.
sl	Slovensko [Slovenian]	Lantronix, Inc. izjavlja, da je ta EMG 8500, EMG 7500 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 2014/53/ EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads Obvestilo EU o omejitvah uporabe: Ta naprava je omejena samo na notranjo uporabo. Morda ga ne uporabljate na prostem.
	Slovensky [Slovak]	Lantronix, Inc. týmto vyhlasuje, že EMG 8500, EMG 7500 enterprise Wi-Fi IoT module spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 2014/53/EU. Úplné znenie EÚ vyhlásenia o zhode je k dispozícii na tejto internetovej adrese: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads Oznámenie EÚ o obmedzeniach pri používaní: Toto zariadenie je obmedzené iba na použitie v interiéri. Nesmie sa používať vonku.
fi	Suomi [Finnish]	Lantronix, Inc. vakuuttaa täten että EMG 8500, EMG 7500 tyyppinen laite on direktiivin 2014/53/EU oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen. EU-vaatimustenmukaisuusvakuutuksen koko teksti on saatavana seuraavassa Internet-osoitteessa: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads EU: n ilmoitus käyttörajoituksista: Tämä laite on rajoitettu vain sisäkäyttöön. Sitä ei saa käyttää ulkona.

Code	Language	Statement
sv	Svenska [Swedish]	Härmed intygar Lantronix, Inc. att denna EMG 8500, EMG 7500 står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 2014/53/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande internetadress: https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads EU-meddelande om begränsningar för användning: Den här enheten är endast begränsad till inomhusbruk. Det får inte användas utomhus.

Safety and Hazards

Do not operate your EMG 8500 or EMG 7500 / EMG 7500W device:

- ◆ In areas where blasting is in progress
- ◆ Where explosive atmospheres may be present including refueling points, fuel depots, and chemical plants
- ◆ Near medical equipment, life support equipment, or any equipment which may be susceptible to any form of radio interference. In such areas, the EMG 8500 and EMG 7500 / EMG 7500W MUST BE POWERED OFF. Otherwise, the EMG 8500 and EMG 7500 / EMG 7500W can transmit signals that could interfere with this equipment.

In an aircraft, the EMG 8500 and EMG 7500 / EMG 7500W MUST BE POWERED OFF.

Otherwise, the EMG 8500 and EMG 7500 / EMG 7500W module can transmit signals that could interfere with various onboard systems and may be dangerous to the operation of the aircraft or disrupt the cellular network. Use of a cellular phone in an aircraft is illegal in some jurisdictions. Failure to observe this instruction may lead to suspension or denial of cellular telephone services to the offender, or legal action or both.

This device is limited to indoor use only. It may not be operated outdoors.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Table E-8 Conducted Transmit Power Specifications.

Technology	Band	TX Frequency range	Conducted TX power
LTE	1	1920 – 1980 Mhz	+23 dBm +/- 1 dB
LTE	2	1850 – 1920 Mhz	+23 dBm +/- 1 dB
LTE	3	1710 – 1785 Mhz	+23 dBm +/- 1 dB
LTE	4	1710 – 1755 Mhz	+23 dBm +/- 1 dB
LTE	5	824 – 849 Mhz	+23 dBm +/- 1 dB
LTE	8	880 – 915 Mhz	+23 dBm +/- 1 dB
LTE	12	699 – 716 Mhz	+23 dBm +/- 1 dB
LTE	13	777 – 787 Mhz	+23 dBm +/- 1 dB
LTE	20	832 – 862 Mhz	+23 dBm +/- 1 dB

Technology	Band	TX Frequency range	Conducted TX power
LTE	25	1850 – 1915 Mhz	+23 dBm +/- 1 dB
LTE	26	814 – 849 Mhz	+23 dBm +/- 1 dB
LTE	7	2500 – 2570 Mhz	+22 dBm +/- 1 dB
LTE	41	2496 - 2690 Mhz	+22 dBm +/- 1 dB
UMTS	1	1920 – 1980 Mhz	+23 dBm +/- 1 dB
UMTS	2	1850 – 1920 Mhz	+23 dBm +/- 1 dB
UMTS	3	1710 – 1785 Mhz	+23 dBm +/- 1 dB
UMTS	4	1710 – 1755 Mhz	+23 dBm +/- 1 dB
UMTS	5	824 – 849 Mhz	+23 dBm +/- 1 dB
UMTS	8	880 – 915 Mhz	+23 dBm +/- 1 dB

Table E-9 EMG 7500W Conducted Transmit Power Specifications.

Technology	Band	TX Frequency Range	Conducted TX power
LTE	1	1920-1980 MHz	+23 dBm +/- 1 dB
LTE	2	1850-1910 MHz	+23 dBm +/- 1 dB
LTE	3	1710-1785 MHz	+23 dBm +/- 1 dB
LTE	4	1710-1755 MHz	+23 dBm +/- 1 dB
LTE	5	824-849 MHz	+23 dBm +/- 1 dB
LTE	7	2500-2570 MHz	+22 dBm +/- 1 dB
LTE	8	880-915 MHz	+23 dBm +/- 1 dB
LTE	12	699-716 MHz	+23 dBm +/- 1 dB
LTE	13	777-787 MHz	+23 dBm +/- 1 dB
LTE	20	832-862 MHz	+23 dBm +/- 1 dB
LTE	25	1850-1915 MHz	+23 dBm +/- 1 dB
LTE	26	814-849 MHz	+23 dBm +/- 1 dB
LTE	29	n/a	+23 dBm +/- 1 dB
LTE	30	2305-2315 MHz	+22 dBm +/- 1 dB
LTE	41	2496-2690 MHz (TDD)	+22 dBm +/- 1 dB
WCDMA	1	1920-1980 MHz	+23 dBm +/- 1 dB
WCDMA	2	1850-1910 MHz	+23 dBm +/- 1 dB
WCDMA	3	1710-1785 MHz	+23 dBm +/- 1 dB
WCDMA	4	1710-1755 MHz	+23 dBm +/- 1 dB
WCDMA	5	824-849 MHz	+23 dBm +/- 1 dB
WCDMA	8	880-915 MHz	+23 dBm +/- 1 dB

Table E-10 EMG 7500W Wi-Fi Specifications

Feature	Description	
2.4 GHz Frequency Bands	ETSI: 2.4 GHz to 2.483 GHz FCC: 2.4 GHz to 2.473 GHz	
5 GHz Frequency Bands	ETSI: 5.15 GHz to 5.35 GHz (Ch 36/40/44/48/52/56/60/64) 5.47 GHz to 5.725 GHz (Ch 100/104/108/112/116/120/124/128/132/136/140/144) FCC: 5.15 GHz to 5.35 GHz (Ch 36/40/44/48/52/56/60/64) 5.47 GHz to 5.725 GHz (Ch 100/104/108/112/116/120/124/128/132/136/140/144) 5.725 GHz to 5.85 GHz (Ch 149/153/157/161/165)	
Transmit Power <i>Note: Transmit power on each channel varies per individual country regulations. All values are nominal with +/-2 dBm tolerance at room temperature. Tolerance could be up to +/-2.5 dBm across operating temperature.</i> <i>Note: HT20 - 20 MHz-wide channels HT40 - 40 MHz-wide channels HT80- 80 MHz-wide channels</i>	802.11a 6 Mbps 54 Mbps 802.11b 1 Mbps 11 Mbps 802.11g 6 Mbps 54 Mbps 802.11n (2.4/5 GHz) 6.5 Mbps (MCS0-5/MCS8-13; HT20) 65 Mbps (MCS6-7/MCS14-15; HT20) 13.5 Mbps (MCS0-5/MCS8-13; HT40) 135 Mbps (MCS6-7/MCS14-15; HT40) 802.11ac (5 GHz) 6.5/13 Mbps (MCS0-6; Ntst=1,2; HT20) 78/156 Mbps (MCS7-8; Ntst=1,2; HT20) 13.5/27 Mbps (MCS0-5; Ntst=1,2; HT40) 180/360 Mbps (MCS6-8; Ntst=1,2; HT40) 200/400 Mbps (MCS9; Ntst=1,2; HT40) 29.5/58.5 Mbps (MCS0-5; Ntst=1,2; HT80) 263.3/526.5 Mbps (MCS6-8; Ntst=1,2; HT80) 390/780 Mbps (MCS9; Ntst=1,2; HT80) Bluetooth 1 Mbps (1DH5) 2 Mbps 3 Mbps BLE (1 Mbps)	18 dBm (63 mW) 16 dBm (40 mW) 18 dBm (63 mW) 18 dBm (63 mW) 18 dBm (63 mW) 16 dBm (40 mW) 18 dBm (63 mW) 16 dBm (40 mW) 16 dBm (40 mW) 14 dBm (25 mW) 18 dBm (63 mW) 16 dBm (40 mW) 16 dBm (40 mW) 14 dBm (25 mW) 12 dBm (15.8 mW) 14 dBm (25 mW) 12 dBm (15.8 mW) 10 dBm (10 mW) 10 dBm (12.5 mW) 7 dBm (6.3 mW) 7 dBm (6.3 mW) 7 dBm (6.3 mW)

Figure E-11 UL Declaration of Conformity



Lantronix, Inc.
7535 Irvine Center Dr., Suite 100
Irvine, CA 92618
USA

November 10, 2020

To Whom It May Concern,

UL Verification Services Inc. (UL) provided conformance testing services to Lantronix, Inc. for the Edge Management Gateway (EMG) version 8.4.0.0 and the Advanced Console Manager (ACM) version 8.4.0.0 hardware applications.

The application uses the following FIPS 140-2 validated cryptographic module (Historical List) and corresponding cryptographic functionality:

Cryptographic Module	Algorithms Used by Application
OpenSSL FIPS Object Module SE, v2.0.16 (FIPS 140-2 Cert. #2398 Historical List)	AES-CBC, CCM, CFB, CTR, GCM, OFB, XTS (Certs. #3090, #3264, #3451, #3751, #3990, #4141, #4391, and #4469) AES-CMAC (Certs. #3090, #3264, #3451, #3751, #3990, #4141, #4391, and #4469) DRBG (Certs. #607, #723, #845, #1027, #1182, #1256, #1414, and #1451) ECDH (Certs. #372, #472, #534, #699, #814, #947, #1094, and #1181) ECDSA (Certs. #558, #620, #698, #801, #886, #952, #1050, and #1091) HMAC (Certs. #1937, #2063, #2197, #2452, #2605, #2714, #2918, and #2966) RSA (Certs. #1581, #1664, #1766, #1928, #2048, #2258, #2374, and #2444) SHS (Certs. #2553, #2702, #2847, #3121, #3294, #3411, #3620, and #3681) Triple-DES CBC, CFB, ECB, OFB (Certs. #1780, #1853, #1942, #2086, #2190, #2263, #2366, and #2399) Triple-DES CMAC (Certs. #1780, #1853, #1942, #2086, #2190, #2263, #2366, and #2399)

The EMG and ACM hardware operate with the following operating environment:

- Operating System: Linux 3.6.5
- Processor: ARM Cortex-A9 (ARMv7 Architecture) without NEON
- Compiler: GCC compiler 4.9.4

The OpenSSL FIPS Object Module SE was tested on many different operational environments, which include versions of Linux. The tested operating environments that include Linux are in the following list:

- Linux 3.10 32-bit running on Intel Atom E3845 (x86) with PAA (gcc Compiler Version 4.8.1)
- Linux 3.10 32-bit running on Intel Atom E3845 (x86) without PAA (gcc Compiler Version 4.8.1)
- Linux 3.12 running on NXP T2080 (PPC) (gcc Compiler Version 4.9.2)

Although the EMG and ACM hardware applications are running on an operational environment that is not included as part of the OpenSSL FIPS Object Module SE's validation, FIPS Implementation Guidance G.5 includes provisions for the use of a validated module on a different operational environment.

UL Verification Services Inc.
709 Fiero Ln., Suite 25, San Luis Obispo, CA 93401 US

20-5031-C-0097 V1.0

Figure E-12 UL Declaration of Conformity, continued

UL reviewed the EMG and ACM hardware applications to confirm that the following functions are performed using the embedded FIPS 140-2 validated cryptographic module (Historical List):

- Web / Lightweight Directory Access Protocol (LDAP) / ConsoleFlow (libwebsockets, libcurl): AES, ECDH, RSA, and SHA
- Transport Layer Security (TLS) v1.2: AES, ECDH, RSA, and SHA
- Secure Shell (SSH)v2: AES, ECDH, ECDSA, and SHA
- Simple Network Management Protocol (SNMP)v3: AES, SHA
- Virtual Private Network (VPN) Internet Protocol Security (IPSec) protocols Internet Key Exchange (IKE) IKEv1 and IKEv2: AES, SHA, and Triple-DES
- WiFi using WPA-WPA2: AES

Since the embedded module is used to perform this cryptography, it is not necessary for the EMG and ACM hardware applications to be separately validated.

Source code review was performed to verify that the EMG and ACM hardware uses the FIPS validated module in conformance with the module's Security Policy.

Important Notes:

- The OpenSSL FIPS Object Module SE Certificate #2398 has been moved to the CMVP Historical List due to the FIPS 186-2 transition.
- "No assurance of the minimum strength of generated keys", due to entropy being provided from an outside source that has not been validated.

UL may be contacted to verify the contents of this letter at (805) 783-0810.

Sincerely,



Gus Burgess
FIPS Program Manager

RoHS, REACH, and WEEE Compliance Statement

Please visit <http://www.lantronix.com/legal/rohs/> for Lantronix's statements about RoHS, REACH, and WEEE compliance.

Appendix F: Ansible Interoperability

[Ansible](#) is a tool that can be used to automate IT tasks. This page shows an example of an Ansible playbook that queries and configures an EMG console manager. For more information on Ansible see the Ansible [documentation](#) suite.

Ansible Installation

The Ansible control node (the host that runs Ansible) can be nearly any Unix/Linux host or Windows host running Windows Subsystem for Linux (WSL) with Python installed. The sample playbook shown here was run on Ubuntu 20.04.03 with Python3 3.10.4 and Ansible 2.17.7 with pyenv (Python version management, example setup [here](#)). The Ansible documentation link above contains detailed instructions for installing Ansible.

In addition to Python3 and Ansible, the following modules or packages are required:

- ◆ `ansible.netcommon.network_cli` plugin
- ◆ `ansible-pylibssh` Python bindings
- ◆ Python3 `paramiko` SSHv2 module

Sample ansible version after installation:

```
(ansible_test) sh-5.0$ ansible --version
ansible [core 2.17.7]
  config file = /home/ansy/ansible_test/ansible.cfg
  configured module search path = ['/home/ansy/.ansible/plugins/
modules', '/usr/share/ansible/plugins/modules']
  ansible python module location = /home/ansy/.local/share/virtualenvs/
ansible_test-5QOcfLIY/lib/python3.10/site-packages/ansible
  ansible collection location = /home/ansy/.ansible/collections:/usr/
share/ansible/collections
  executable location = /home/ansy/.local/share/virtualenvs/
ansible_test-5QOcfLIY/bin/ansible
  python version = 3.10.4 (main, Dec  5 2024, 15:01:48) [GCC 9.4.0] (/
home/ansy/.local/share/virtualenvs/ansible_test-5QOcfLIY/bin/python)
  jinja version = 3.1.4
  libyaml = True
```

```
(ansible_test) sh-5.0$ pip freeze
ansible==10.7.0
ansible-core==2.17.7
ansible-pylibssh==1.2.2
cffi==1.17.1
cryptography==44.0.0
Jinja2==3.1.4
MarkupSafe==3.0.2
packaging==24.2
pyparser==2.22
PyYAML==6.0.2
resolvelib==1.0.1
```


Ansible Setup

Create a subdirectory to hold the Ansible config and playbook files: a configuration file, a public/private SSH key, an inventory (target hosts) file, and a sample YAML playbook:

```
(ansible_test) sh-5.0$ ls -l
total 60
-rw-rw-r-- 1 ansy ansy    89 Dec  5 15:34 ansible.cfg
-rw----- 1 ansy ansy  1675 Dec  5 15:33 id_rsa
-rw-r--r-- 1 ansy ansy   396 Dec  5 15:33 id_rsa.pub
-rw-rw-r-- 1 ansy ansy   217 Dec  5 15:38 inventory.ini
-rw-rw-r-- 1 ansy ansy   956 Dec  5 17:42 slc_example.yml

(ansible_test) sh-5.0$ cat ansible.cfg
[defaults]
inventory = inventory.ini
host_key_checking = false
host_key_auto_add = false
private_key_file = id_rsa

(ansible_test) sh-5.0$ cat inventory.ini
[all:vars]
ansible_connection=ansible.netcommon.network_cli
ansible_user=christi
ansible_become=no
ansible_network_os=cisco.ios.ios

[allhosts]
10.0.1.91
10.0.1.156

(ansible_test) sh-5.0$ cat slc_example.yml
---
- name: Query version info, run set and show commands, print to terminal
  window
    hosts: allhosts
    gather_facts: false

  tasks:
    - name: Ping all hosts
      ansible.builtin.ping:

    - name: Run 'admin version' command
      ansible.netcommon.cli_command:
        command: admin version
        register: command_output
    - debug: var=command_output.stdout_lines

    - name: Run 'show network dns' command
      ansible.netcommon.cli_command:
        command: show network dns
        register: command_output
```

-
- debug: var=command_output.stdout_lines
 - name: Run 'set network dns' command
 - ansible.netcommon.cli_command:
 - command: set network dns 1 ipadd 192.168.10.254
 - register: command_output
 - debug: var=command_output.stdout_lines
 - name: Run 'show network dns' command
 - ansible.netcommon.cli_command:
 - command: show network dns
 - register: command_output
 - debug: var=command_output.stdout_lines

This setup contains the IP addresses of 2 hosts - a SLC and EMG, each running different firmware versions. Ansible authenticates to the SLC and EMG using a local user named **christi** with a SSH public key that has been imported into the SLC and EMG. The local user that Ansible is configured with should have the appropriate console manager permissions and rights to run the CLI commands in the playbook.

```
[emg0c80]> show localu
__Current Local Users
Settings_____
State: enabled
Order: 1
Complex Passwords: disabled
Allow Reuse of Passwords: enabled
Reuse History: 4
Password Lifetime: 90 days
Warning Period: 7 days
Max Failed Login Attempts before Account is Locked: disabled
Lockout Period: disabled
Multiple Sysadmin Web Logins: disabled
Sysadmin Access Limited to Console Port: disabled

Login      Lock Grp Data      Listen  Clear    Esc    Break Menu
Dialback
=====
sysadmin   no   Adm 1-8,U1   1-8,U1   1-8,U1   \x1bA \x1bB  N/
christi    no   Adm 1-8,U1   1-8,U1   1-8,U1   \x1bA \x1bB  N/
2 user(s).  For complete information, use 'show localusers user '.

[emg0c80]> show sshkey import keyuser christi
Imported SSH Keys:
User-----Host-----Type-----
christi          thurmond          RSA, 2048 bits
```

Pinging Hosts and Running Playbooks

The hosts can be checked for reachability using either SSH (the default) or paramiko:

```
(ansible_test) sh-5.0$ ansible allhosts -m ping -i inventory.ini -c ssh
10.0.1.156 | SUCCESS => {
    "changed": false,
    "ping": "pong"
}
10.0.1.91 | SUCCESS => {
    "changed": false,
    "ping": "pong"
}
(ansible_test) sh-5.0$ ansible allhosts -m ping -i inventory.ini -c
paramiko
10.0.1.91 | SUCCESS => {
    "changed": false,
    "ping": "pong"
}
10.0.1.156 | SUCCESS => {
    "changed": false,
    "ping": "pong"
}
```

The **slc_example.yml** playbook queries version information (**admin version**), queries the current DNS servers, sets a static DNS server, then queries the DNS servers again.

```
$ ansible-playbook -i inventory.ini slc_example.yml

PLAY [Run some set and show commands, and print to terminal window] **

TASK [Ping all hosts] *****
ok: [10.0.1.156]
ok: [10.0.1.91]

TASK [Run 'admin version' command] *****
ok: [10.0.1.156]
ok: [10.0.1.91]

TASK [debug] *****
ok: [10.0.1.91] => {
    "command_output.stdout_lines": [
        "___Current
Version_____",
        "Model: SLC8016",
        "Firmware Version: 9.5.0.0R15",
        "Firmware Updated: Tue Oct 29 19:37:57 2024",
        "OS Version: IT Management Gateway OS 7.0",
        "Bootloader Version: 2.0.0.0R10",
        "S/N: 0080A38BFC31",
        "Device ID: 00204AVBN213EQJOXUEA1S73KTVQM9YU",
        "Memory: 512 MB",
```

```

"Flash Size: 512 MB",
"Power Supply: AC, 2 power supplies",
"Number of External USB Ports: 2",
"Ethernet Switch: Installed",
"Internal Modem: Installed",
"Eth1 HW Address: 00:80:a3:8b:fc:31",
"Eth2 HW Address: 00:80:a3:8b:fc:32",
"Ethernet Switch HW Address: 00:80:a3:8b:fe:f3",
"Main Board Revision: unknown",
"NIC Board Type: SFP",
"NIC Board Revision: 02FPA",
"NIC Board Eth1 SFP: 1000BASE-T (Vendor: FiberStore PN: SFP-GB-
GE-T Rev: B)",
"NIC Board Eth2 SFP: [none]",
"I/O Module Type(s): RJ45-16, ETH-16, ",
"I/O Module Revision(s): 16SPB, 16ESA, ",
"Admin Password Unique to Device: Disabled",
"Uptime: 9 days, 6 hours, 40 minutes",
"Software Revisions:",
"  Kernel: 3.6.5",
"  Web/TLS: OpenSSL 1.1.1w  11 Sep 2023",
"  SSH/TLS: OpenSSH_9.8p1, OpenSSL 1.1.1w  11 Sep 2023",
"  Telnet: netkit-telnet-0.17",
"  NTP: ntpd 4.2.6p5",
"  SMB/CIFS: Version 3.6.14",
"  RIP: 1.2.4",
"  Web Server: mini_httpd/1.30",
"  PAM/NIS: 1.3.1",
"  LDAP: 153",
"  RADIUS: 2.0.0",
"  Kerberos: 2.4.8",
"  TACACS+: 1.6.0",
"  ShellInABox: 2.19",
"  VPN: Linux strongSwan U5.9.0/K3.6.5",
"  Expect: 5.45.4",
"  Tcl: 8.6",
"  Python: 3.6.7",
"  Dnsmasq: 2.84",
"  Syslog: 2.4.4",
"",
"Bootloader Configuration:",
"  Number of Ports: 16",
"  Model Number: 103",
"  Product Name: SLC",
"  Options: 00000000000000000000000000ffff02",
"  Features: 0xffff"
]
}
ok: [10.0.1.156] => {
  "command_output.stdout_lines": [
    "___Current
Version_____",
    "Model: EMG851121",
    "Firmware Version: 9.4.0.0R5",

```

```
"Firmware Updated: Thu Apr 18 19:55:34 2024",
"OS Version: IT Management Gateway OS 7.0",
"Bootloader Version: 2.0.0.0R10",
"S/N: 0080A3FA0C80",
"Device ID: 00204ACSKMXENQH72KVF4VYK5X5E426F",
"Memory: 1024 MB",
"Flash Size: 1024 MB",
"Power Supply: external DC",
"Number of External USB Ports: 1",
"Cellular Modem: Installed",
"Cellular Firmware Version: 02.24.05.06",
"Cellular Carrier: VERIZON",
"Cellular USBNet Driver Version: 2020-08-17/SWI_2.64",
"Cellular Serial Driver Version: 2020-08-17/SWI_2.42",
"WiFi: Installed",
"WiFi Radio FW Version: 5.4.46.5",
"WiFi Driver Version: 10.4.0.10",
"Ethernet Switch: Not Installed",
"Internal Modem: Not Installed",
"Eth1 HW Address: 00:80:a3:fa:0c:80",
"Eth2 HW Address: 00:80:a3:fa:0c:81",
"Cellular Modem HW Address: fa:42:6e:a3:4e:08",
"Main Board Revision: 080-0696-00 (G)/330-0372-01 (Rev 1)",
"NIC Board Eth1 SFP: [none]",
"NIC Board Eth2 SFP: [none]",
"I/O Module Type(s): RJ45-04, RJ45-04",
"I/O Module Revision(s): 04SPC, 04SPB ",
"Connectivity Module Type(s): WIFI-01, LTE-01",
"Connectivity Module Revision(s): 01WFA, 01LTA",
"Admin Password Unique to Device: Enabled",
"Uptime: 10 days, 6 hours, 31 minutes",
"Software Revisions:",
"  Kernel: 3.6.5",
"  Web/TLS: OpenSSL 1.1.1w  11 Sep 2023",
"  SSH/TLS: OpenSSH_9.6p1, OpenSSL 1.1.1w  11 Sep 2023",
"  Telnet: netkit-telnet-0.17",
"  NTP: ntpd 4.2.6p5",
"  SMB/CIFS: Version 3.6.14",
"  RIP: 1.2.4",
"  Web Server: mini_httpd/1.30",
"  PAM/NIS: 1.3.1",
"  LDAP: 153",
"  RADIUS: 2.0.0",
"  Kerberos: 2.4.8",
"  TACACS+: 1.6.0",
"  ShellInABox: 2.19",
"  VPN: Linux strongSwan U5.9.0/K3.6.5",
"  Expect: 5.45.4",
"  Tcl: 8.6",
"  Python: 3.6.7",
"  Dnsmasq: 2.84",
"  Syslog: 2.4.4",
"",
"Bootloader Configuration:",
```

```

        " Number of Ports: 8",
        " Model Number: 120",
        " Product Name: EMG",
        " Options: 00000000000000000000000000ffff01",
        " Features: 0xffff"
    ]
}

TASK [Run 'show network dns' command] *****
ok: [10.0.1.156]
ok: [10.0.1.91]

TASK [debug] *****
ok: [10.0.1.91] => {
    "command_output.stdout_lines": [
        "___Current DNS
Settings_____",
        "10 of the listed DNS servers are used.",
        "Static DNS Server #1: 11.80.103.7",
        "          #2: <none>",
        "          #3: <none>",
        "          #4: <none>",
        "          #5: <none>",
        "          #6: <none>",
        "          #7: <none>",
        "          #8: <none>",
        "          #9: <none>",
        "         #10: <none>",
        "Eth1 DHCP-Acquired DNS Server #1: 10.0.1.12",
        "Prefer IPv4 DNS Records: enabled",
        "Source IPv4 Address: None",
        "Source IPv6 Address: None"
    ]
}
ok: [10.0.1.156] => {
    "command_output.stdout_lines": [
        "___Current DNS
Settings_____",
        "3 of the listed DNS servers are used (active).",
        "Static DNS Server #1: 11.80.103.7 (Active)",
        "Static DNS Server #2: <none>",
        "Static DNS Server #3: <none>",
        "Eth1 DHCP-Acquired DNS Server #1: 10.0.1.12 (Active)",
        "Prefer IPv4 DNS Records: enabled",
        "Source IPv4 Address: None",
        "Source IPv6 Address: None"
    ]
}

TASK [Run 'set network dns' command] *****
ok: [10.0.1.156]
ok: [10.0.1.91]

TASK [debug] *****

```

```

ok: [10.0.1.91] => {
  "command_output.stdout_lines": [
    "DNS settings successfully updated."
  ]
}
ok: [10.0.1.156] => {
  "command_output.stdout_lines": [
    "DNS settings successfully updated."
  ]
}

TASK [Run 'show network dns' command] *****
ok: [10.0.1.156]
ok: [10.0.1.91]

TASK [debug] *****
ok: [10.0.1.91] => {
  "command_output.stdout_lines": [
    "___Current DNS
Settings_____",
    "10 of the listed DNS servers are used.",
    "Static DNS Server #1: 192.168.10.254",
    "          #2: <none>",
    "          #3: <none>",
    "          #4: <none>",
    "          #5: <none>",
    "          #6: <none>",
    "          #7: <none>",
    "          #8: <none>",
    "          #9: <none>",
    "          #10: <none>",
    "Eth1 DHCP-Acquired DNS Server #1: 10.0.1.12",
    "Prefer IPv4 DNS Records: enabled",
    "Source IPv4 Address: None",
    "Source IPv6 Address: None"
  ]
}
ok: [10.0.1.156] => {
  "command_output.stdout_lines": [
    "___Current DNS
Settings_____",
    "3 of the listed DNS servers are used (active).",
    "Static DNS Server #1: 192.168.10.254 (Active)",
    "Static DNS Server #2: <none>",
    "Static DNS Server #3: <none>",
    "Eth1 DHCP-Acquired DNS Server #1: 10.0.1.12 (Active)",
    "Prefer IPv4 DNS Records: enabled",
    "Source IPv4 Address: None",
    "Source IPv6 Address: None"
  ]
}

PLAY RECAP *****

```

```
10.0.1.156      : ok=9    changed=0    unreachable=0    failed=0
skipped=0      rescued=0    ignored=0
10.0.1.91       : ok=9    changed=0    unreachable=0    failed=0
skipped=0      rescued=0    ignored=0
```