


# LANTRONIX®



## M110 Series Cellular Modem User Guide

Part Number PMD-00036  
Revision C December 2023

---

## Intellectual Property

© 2023 Lantronix, Inc. All rights reserved. No part of the contents of this publication may be transmitted or reproduced in any form or by any means without the written permission of Lantronix.

*Lantronix* is a registered trademark of Lantronix, Inc. in the United States and other countries.

Patented: [www.lantronix.com/legal/patents/](http://www.lantronix.com/legal/patents/). Additional patents pending.

*Windows* and *Internet Explorer* are registered trademarks of Microsoft Corporation. *Firefox* is a registered trademark of the Mozilla Foundation. *Chrome* is a trademark of Google Inc. All other trademarks and trade names are the property of their respective holders.

## Warranty

For details on the Lantronix warranty policy, please go to our web site at [www.lantronix.com/support/warranty/](http://www.lantronix.com/support/warranty/)

## Contacts

### Lantronix, Inc.

48 Discovery, Suite 250  
Irvine, CA 92618, USA  
Toll Free: 800-526-8766  
Phone: 949-453-3990  
Fax: 949-453-3995

### Technical Support

Online: [www.lantronix.com/support](http://www.lantronix.com/support)

### Sales Offices

For a current list of our domestic and international sales offices, go to the Lantronix web site at [www.lantronix.com/about-us/contact/](http://www.lantronix.com/about-us/contact/)

## Disclaimer

All information contained herein is provided “AS IS.” Lantronix undertakes no obligation to update the information in this publication. Lantronix does not make, and specifically disclaims, all warranties of any kind (express, implied, or otherwise) regarding title, non-infringement, fitness, quality, accuracy, completeness, usefulness, suitability, or performance of the information provided herein. Lantronix shall have no liability whatsoever to any user for any damages, losses and causes of action (whether in contract or in tort or otherwise) in connection with the user’s access or usage of any of the information or content contained herein. The information and specifications contained in this document are subject to change without notice.

## Open Source Software

Some applications are Open Source software licensed under the Berkeley Software

---

Distribution (BSD) license, the GNU General Public License (GPL) as published by the Free Software Foundation (FSF), or the Python Software Foundation (PSF) License Agreement for Python 2.7.3 (Python License). Lantronix grants you no right to receive source code to the Open Source software; however, in some cases, rights and access to source code for certain Open Source software may be available directly from Lantronix' licensors. Your use of each Open Source component or software is subject to the terms of the applicable license. The BSD license is available at <http://opensource.org/licenses>. The GNU General Public License is available at <http://www.gnu.org/licenses/>. The Python License is available at <http://cmpt165.csil.sfu.ca/Python-Docs/license.html>. Your use of each Open Source component or software is subject to the terms of the applicable license.

OPEN SOURCE SOFTWARE IS DISTRIBUTED WITHOUT ANY WARRANTY, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. SEE THE APPLICABLE LICENSE AGREEMENT FOR ADDITIONAL INFORMATION.

You may request a list of the open source components and the licenses that apply to them. Contact your regional Lantronix sales associate. [www.lantronix.com/about-us/contact/](http://www.lantronix.com/about-us/contact/)

## Revision History

Date	Rev.	Comments
Sep., 2017	1.0	1.0 First release
Oct., 2017	1.1	1.1 RAM size and model list
Nov., 2017	1.2	1.2 Compatible models
Jun., 2018	1.3	1.3 Compatible models
Mar., 2019	1.4	1.4 Compatible models, Power, Accessories and Basic AT Command summary
October 2019	A	Initial Lantronix document. Added Lantronix document part number, Lantronix logo, branding, contact information, and links.
September 2022	B	Updates to Part Numbers and Accessories
December 2023	C	Added model M114 CAT-1 BIS and its corresponding features.

For the latest revision of this product document, please check our online documentation at [www.lantronix.com/support/documentation](http://www.lantronix.com/support/documentation).

---

## Table of Contents

<b>1. Safety Precautions</b> .....	<b>5</b>
1.1 General precautions.....	5
1.2 Using the modem in vehicles.....	5
1.3 Protecting your modem.....	5
<b>2. M110 Series Compatible Modems</b> .....	<b>7</b>
<b>3. Product Features</b> .....	<b>8</b>
3.1 Hardware .....	8
3.2 Power .....	8
3.3 Interfaces .....	9
3.4 Lantronix application software (mPACK).....	9
3.5 Lantronix Software Services.....	10
<b>4. Accessories</b> .....	<b>11</b>
<b>5. LED Status Indicator</b> .....	<b>12</b>
<b>6. Hardware Installation</b> .....	<b>13</b>
6.1 Inserting SIM card:.....	13
6.2 Connecting cellular antenna:.....	13
6.3 Connecting USB Type-C cable .....	14
6.4 Connecting RS-232 DB-9 serial cable .....	14
6.5 Powering the modem .....	14
<b>7. Communication with the Modem</b> .....	<b>15</b>
7.1 Communications test.....	15
7.2 Echo Function.....	15
7.3 Received Signal Strength.....	16
7.4 Network Registration .....	17
7.5 PIN Code.....	17
7.6 Basic AT command summary.....	18
<b>8. Technical Support</b> .....	<b>19</b>

## 1. Safety Precautions

### 1.1 General precautions

The modem generates radio frequency (RF) power. When using the modem, precaution must be taken to ensure safety as well as compliance with all regulations that surround the use of RF equipment.

Do not use the modem in aircraft, hospitals, and petrol stations or in places where using mobile cellular products or other RF equipment is prohibited, and make sure that the modem will not be interfering with nearby equipment such as pacemakers or medical equipment.

The antenna of the modem should be directed away from computers, office equipment, home appliance, etc., and always keep the modem at a minimally safe distance of 26.6cm or more from a human body.

Do not put the antenna inside metallic boxes or other containers.

### 1.2 Using the modem in vehicles

Check for any regulations or laws authorising the use of GSM, W-CDMA, and LTE equipment in vehicles in the country before installing the modem.

Installation of the modem should be done by qualified personnel. Consult your vehicle dealer for any possible interference concerns related to the use of the modem.

Power consumption of the modem and related circuit should be taken into consideration when the modem is powered by the battery of the vehicle as the battery may deplete after an extended period.

### 1.3 Protecting your modem

To ensure error-free usage, please install and operate the modem with care and comply with the following.

Do not expose the modem in extreme conditions such as high humidity/rain, high temperatures, direct sunlight, caustic/harsh chemicals, dust, or water.

Do not try to disassemble or modify the modem as there is no user serviceable parts inside and warranty will void in case of tampering.

Do not drop, hit, shake the modem or place in extreme vibration.

Do not pull the power supply cable. Attach or detach it by holding the connector after switching off the supply.

Install and connect the modem in accordance with this user manual. Failure to do so will void the warranty.

## 2. M110 Series Compatible Modems

MODEL NAME	TERRITORIES OR OPERATOR(S)	CELLULAR TYPE <sup>1</sup>	BANDS <sup>2</sup>	FALLBACK MODE <sup>1</sup>	BAND(S) <sup>2</sup>	PLANNED / OBTAINED CERTIFICATIONS <sup>3</sup>	PLANNED / MADE FCS <sup>4</sup>	ORDER CODE
M111	World excl. Japan, Korea	2G <sup>A1</sup>	5/8/3/2	*	N/A	CE <sup>6</sup>	Aug. '18	M111F00FS
M113	World	Dual mode LTE-M1 / NB-IoT	LTE CAT M1 / NB1 MODULE, LTE BANDS 2, 3, 4, 5, 8, 12, 13, 20, 25, 28			ISED; FCC <sup>7</sup> , PTCRB, Verizon Wireless, AT&T Wireless; IFT; RCM, Telstra; JRF, JPA, NTT docomo; KC, SK telecom; CCC, SRRC, CTA	Sep. '18	M113F00FS
							Jan. '19	M113F002S
M114	EMEA	LTE cat. 1	20/3/7	2G <sup>A3</sup>	5/8/3/2 8/3	CE <sup>6</sup>	Jan. '19	M114F002S
	Verizon Wireless		13/4	*	N/A	FCC <sup>7</sup> , Verizon Wireless	Jun. '18	MM114F002S
	AT&T Wireless, T-Mobile USA, Sprint		12 <sup>a</sup> /5/4/2	3G	5/2	ISED; FCC <sup>7</sup> , PTCRB, AT&T Wireless	TBD	M114F001S
	Asia Pacific		28/8/3		1	RCM; NCC	Oct. '18	M114F000S
	NTT docomo		19/1	*	N/A	JRF, JPA	TBD	M114F003S
M114 CAT-1 BIS	World	LTE cat.1 Bis	ELS62-W GSM/GPRS/EDGE: V, VIII, III, II LTE: 1, 2, 3, 4, 5, 7, 8, 20, 28, 38, 40, 41 <sup>2</sup> , 66	2G	V/ VIII/ III/ II	CE/UKCA, RCM, CB	Aug. '23	M114B00FS
M115	World					TBD		F00FS

Please consult us regarding the models or features shown in grey, which are subject to MOQ and other considerations.

### <sup>1</sup> Uplink / Downlink maximum data rates

- 2G: <sup>A1</sup> 42.8 / 85.6; or 236.8 / <sup>A2</sup> 236.8; or <sup>A3</sup> 296 kbps
- NB-IoT: 62.5 / 27.2 kbps
- LTE-M1: 375 / 375 kbps
- LTE cat. 1: 5<sup>2</sup> / 10<sup>3</sup> Mbps
- 3G: 5<sup>76</sup> / 7.2 Mbps
- LTE cat. 1 Bis: 5 / 10 Mbps

### <sup>2</sup> Ranked by increasing frequencies

- <sup>a</sup> incl. North America's ("NorAm's") B17
- <sup>b</sup> incl. KDDI's B18 as well as NorAm's B5, the latter incl. NTT docomo's B19, itself incl. Japan's B6 (3G)
- <sup>c</sup> incl. Japan's B9
- <sup>d</sup> incl. NorAm's B2

### <sup>3</sup> Besides MIL-STD-810G

- <sup>4</sup> First customer shipment [date of]
- <sup>5</sup> Concurrent GPS, Galileo and either GLONASS or Beidou
- <sup>6</sup> Based on compliance with RED; EN 60950-1; etc.
- <sup>7</sup> Also, Class I Division 2 for use in explosive atmospheres as a factory option subject to MOQ and other considerations

16 December 2023

### 3. Product Features

The M110 series cellular modem is designed for M2M applications operating in tough environmental condition, with the Lantronix mPACK application software (refer to the M110 Commands Guide), which makes the modem suitable for industrial equipment such as electricity meters, PLC, lifts, vending machines, etc.

#### 3.1 Hardware

Specification	Description	Model
Casing	Extruded aluminium	M112, M113, M114 & M114CAT-1 BIS
Dimensions	60 x 60 x 21.7 (mm)	
Weight	89 g (approximately)	
Temperature	Operating: -30°C ~ +70°C Storage: -40°C ~ +85°C	M112, M113 & M114
	Operating: -15°C ~ +75°C Storage: -40°C ~ +85°C	M114CAT-1 BIS
MCU Memory	Flash: 256 kB RAM: 128 kB	M112, M113 & M114
	Flash: 1024 KB RAM: 786 KB	M114CAT-1 BIS

#### 3.2 Power

Specification	Description	Model
Power supply	5 – 32 Vdc with Slow Start in 4-pin Micro-Fit	M112, M113, M114 & M114 CAT-1 BIS
Last Gasp (optional):	Last for approximately 5 SMS messages, backed up by two industrial grade super caps.	M112, M113 & M114


#### Power consumption table (mA)

Model/Device State	DC Input		
	8V	12V	32V
<b>M111</b>			
GSM900 Call (PCL 5, RS-232)	220	138	52
GSM1800 Call (PCL 0, RS-232)	155	108	41
GPRS900 2Tx@gamma 3 (RS-232)	405	258	100
GPRS1800 2Tx@gamma 3 (RS-232)	288	182	72
Stand-by (RS-232 & USB connected)	54	37	15
Stand-by (RS-232 connected)	54	37	15
<b>M113</b>	<b>8V</b>	<b>12V</b>	<b>32V</b>
LTE in communication mode (Tx Max, RS-232)	125	100	45
Stand-by (RS-232 & USB connected)	54	37	15
Stand-by (RS-232 connected)	54	37	15
<b>M114</b>	<b>8V</b>	<b>12V</b>	<b>32V</b>
GSM900 (PCL 5, RS-232)	225	140	54
GSM1800 (PCL 0, RS-232)	160	110	43
GPRS900 4Tx@gamma 3 (RS-232)	412	262	103



GPRS1800 4Tx@gamma 3 (RS-232)	294	187	74
W-CDMA in communication mode (band 1, Tx max, RS232)	426	235	107
HSDPA in communication mode (band 1, Tx max, RS-232)	460	292	115
LTE in communication mode (Tx Max, RS-232)	376	220	95
Stand-by (RS-232 & USB connected)	54	37	15
Stand-by (RS-232 connected)	54	37	15
<b>M114 CAT-1 BIS</b>	<b>8V</b>	<b>12V</b>	<b>32V</b>
Idle state (Cellular off, RS232 & USB disconnected)	18	11	6
RS232 and USB connected (Cellular off)	24	16	9
RS232 and USB connected (Cellular standby)	42	32	11
RS232 and USB connected (Cellular standby & Dial-up connection established)	65	47	21
RS232 and USB connected (Dial-up connection established & LTE communication)	78	53	22

### 3.3 Interfaces

Interface	Type	Note
RS-232	DB-9 socket 1. DCD 2. Rx 3. Tx 4. DTR 5. Ground 6. DSR 7. RTS 8. CTS 9. RI	
USB	Type-C connector	n/a
I/Os	Analog input (x2) or Digital output (x2)	0V – 48 Vdc, 12 bit resolution Open collector; 200 mA; 50 Vdc max.
Cellular antenna	SMA connector	1 connector – M111, M113 & M114 CAT-1 BIS 2 connectors – M114
SIM interface	2FF SIM 1.8 V/3.0 V	n/a
LED indicators	Two (2) – amber, green	n/a

### 3.4 Lantronix application software (mPACK)

- Dial-up connection
- TCP/UDP permanent client/server or on-demand
- Network connectivity watchdog
- Configurable text and recipients upon the Last Gasp (*Not supported by M114 CAT-1 BIS.*)
- DOTA via user's HTTP server
- Configure via: Terminal program, SMS, and Telnet

For information about working with the mPACK software, refer to *M110 Series mPACK Software Command Reference*. This is available for download from the M110 series product page at: <https://www.lantronix.com/products/m110-series-modems/>.

### **3.5 Lantronix Software Services**

Lantronix provides PercepXion, a centralized device management and monitoring platform. It allows you to access your devices and push new configurations and firmware upgrades.

## 4. Accessories

Part number	Description
<b>Power supply/Power cable</b>	
P22E0	12V1.25A switching power adapter, with 2pin Molex connector. Euro plug AC cable.
P22E2	12V1.25A switching power adapter, with 2pin Molex connector. USA plug AC cable.
P22E3	12V1.25A switching power adapter, with 2pin Molex connector. Australia & NZ plug AC cable.
P22E4	12V1.25A switching power adapter, with 2pin Molex connector. UK/HK plug AC cable.
KDC42	ACC-CA10 SPARE CABLE (4-PIN) WITH POWER FUSE HS CODE: 8544 4211
<b>Serial and USB cable</b>	
KS990	RS232 CABLE DB9P/M TO DB9P/F L=1000MM
KUCA1	USB 2.0 A/M to USB Type C/M black cable, L=800mm
<b>Antennae</b>	
A31M0	JCG017L, Single LTE Antenna, Adhesive remote antenna with 3000mm RG174 cable, SMA male
A31H0	Single LTE Antenna, ultrawideband I-Bar antenna, 3000mm Cable with SMA male, Adhesive mount.
A32M0	Two in one LTE, 2*LTE antenna, 2*3000mm RG174 cable, SMA male
A32H0	Two in one LTE, 2*LTE antenna, 2*3000mm cable, SMA male, adhesive mount
<b>Miscellaneous</b>	
BR350	ACC-DIN DIN CLIP HS CODE: 8517 7091
SC485	RS232 to RS485 converter

## 5. LED Status Indicator


The modem operation status is indicated by two LEDs, which are located on the front side described in the below table.

LED State	Amber LED	Green LED
ON	<b>Solid</b> Cellular connection established	<b>Solid</b> Good CSQ > 10
	<b>Blinking</b> Cellular connection established & data transfer in process	<b>Slow blinking</b> No signal, or CSQ < 4 or = 99
		<b>Fast blinking</b> Marginal, CSQ is 4 – 9
OFF	No cellular connection	No power

For further description on CSQ, refer to section [7.3 Received Signal Strength](#).

## 6. Hardware Installation

### 6.1 Inserting SIM card:




(1) Eject the SIM tray by pushing the eject button inwards.

(2) Pull the SIM tray out.


Place the mini-SIM card on the tray with SIM chip facing up, then push the tray back in place carefully.

### 6.2 Connecting cellular antenna:




Screw (clockwise) the SMA antenna onto the SMA connector.

### 6.3 Connecting USB Type-C cable



### 6.4 Connecting RS-232 DB-9 serial cable



Connect the RS-232 DB-9 serial cable and secure the connection by tightening both thumb knobs on the connector.

### 6.5 Powering the modem



Connect the 4-pin Micro-Fit connector power supply to the modem as shown above.

## 7. Communication with the Modem

After all the above setup, communications between the terminal equipment and the modem can now be tested, AT commands can be sent to the modem using a terminal program (i.e., Tera Term) installed on computer for configuring the modem.

### 7.1 Communications test

- Connection between the terminal equipment and the modem can be made using two types of cables:

RS-232 DB-9 Serial cable  
or  
USB Type-C cable

- Configuration of the RS-232 port on the terminal equipment/program should initially be:

Baud-rate: 115,200 bps  
Data bits: 8  
Parity: None  
Stop Bits: 1  
Flow control: None

- To see if the communications between the terminal program and the modem is established, enter:

**AT**

and modem will respond with:

**OK**

### 7.2 Echo Function

The default echo setting is off/disabled (**ATE0**), to enable the echo function, either:

- Enable "Local echo" in terminal program  
or
- Enable the modem echo function (enter **ATE1**)

In M2M application, it is highly recommended to disable the modem echo function (enter **ATE0**) to avoid unnecessary traffic between DTE and DCE.

In terminal program, if response is not displayed after an AT command is entered, recheck the above setting.

If communications cannot be established with the modem, check:

- The RS-232 physical connection
- The RS-232 configuration

After communication is established, refer to below AT commands to start using the modem.

AT Command	Description
AT+CGMI	To check the module manufacturer identification
AT+CPIN=XXXX	To enter a PIN code (if required) (XXXX is actual PIN)
AT+CSQ	To verify the received signal strength
AT+CREG?	To verify the network registration status
ATD<phone number>;	To initiate a voice call
ATH	To end the above voice call

### 7.3 Received Signal Strength

The modem can only establish a call or data session when the received signal strength is sufficient. In terminal window, enter AT+CSQ to see the received signal strength, then the modem will respond in the following format:

```
+CSQ: <RSSI>,<BER>
or
<RSSI>,<BEP>
or
<RSSI>,<ECN0>
or
<RSSI>,<RSRQ>
```

Where:

- <RSSI> : Received Signal Strength Indication
- <BER> : channel Bit Error Rate (GPRS)
- <BEP> : channel Bit Error Pattern (EGPRS)
- <ECN0> : Energy per Chip Noise ratio (UMTS)
- <RSRQ> : Reference Signal Received Quality (LTE)

For SMS, voice, and data operation, please refer to the below table for sufficient RSSI levels.

RSSI Level	Description
6 to 8	SMS/Voice



10 to 12	SMS/Voice/Data
13 to 31	All above, to maximum RSSI level
99	Not measurable

## 7.4 Network Registration

To verify network registration, first ensure the SIM card has been provisioned.

If the model has embedded SIM, first ensure the modem has been activated by the network provider.

To see the network registration status, in terminal program, enter:

**AT+CREG?**

and refer to the below responses of network registration status.

Response	Description
+CREG: 0,0	Not registered
+CREG: 0,1	Registered on home network
+CREG: 0,2	Not registered and attempting
+CREG:0,3	Registration denied
+CREG: 0,5	Registered on network when roaming

If it is not registered on the network, check the following.

- If the antenna was attached properly
- The received signal strength (refer to section 8.2)
- If the SIM card was provisioned

## 7.5 PIN Code

To verify, in terminal program, enter:

**AT+CPIN?**

and refer to the below responses of PIN code status:

Response	Description
+CPIN: READY	PIN code has been entered correctly or not required
+CPIN: SIM PIN	PIN code has not been entered or entered incorrectly

## 7.6 Basic AT command summary

Below table is a summary of basic AT commands, for the full set of commands, refer to M110 Command Reference.

Feature	AT Command	Response	Description
Check network registration	AT+CREG?	+CREG: 0,0	Not registered
		+CREG: 0,1	Registered on home network
		+CREG: 0,2	Not registered and attempting
		+CREG: 0,5	Registered on network and roaming
Enter PIN code & status	AT+CPIN=XXXX	OK	PIN code accepted
		*+CME ERROR: 16	Incorrect PIN code
	AT+CPIN?	Ready	SIM is ready to use
Receive a voice call	ATA	OK	Answer the call
Initiate a voice call	ATD<phone number>;	OK	Communication established
		*+CME ERROR: 11	PIN code not entered (with +CMEE=1 mode)
Hang up	ATH	OK	End the call
Store settings in EEPROM	AT&W	OK	Configuration settings are stored in non-volatile memory

\*AT+CMEE=1 to enable +CME error result code, otherwise only 'error' will be displayed instead.

XXXX is the actual PIN code, if required.

## 8. Technical Support

Lantronix offers many resources to support our customers and products at <http://www.lantronix.com/technical-support>.

For example, you can browse the knowledge base, open a support issue, find firmware downloads, view tutorials, and more. At this site you can also find FAQs, product bulletins, warranty information, extended support services, and product documentation.

To submit a support request, please use the Lantronix Technical Support portal at <https://ltxdev.atlassian.net/wiki/spaces/LTRXTS/overview> (registration required).

To contact Lantronix Sales, look up your local office at <https://www.lantronix.com/about-us/contact/>.