



# NTC-550 Series User Guide

NTC-551  
NTC-552

Part Number PMD-00305  
Revision B June 2026

---

## Intellectual Property

© 2026 Lantronix, Inc. All rights reserved. No part of the contents of this publication may be transmitted or reproduced in any form or by any means without the written permission of Lantronix.

*Lantronix* is a registered trademark of Lantronix, Inc. in the United States and other countries.

Patented: <https://www.lantronix.com/legal/patents/>. Additional patents pending.

## Trademark Notice

This product may reference NetComm. On December 26, 2024, Lantronix, Inc. acquired the Industrial Internet of Things (IIoT) product portfolio from NetComm Wireless Pty Ltd and is authorized to use the NetComm trademark in association with this product.

## Warranty

For details on the Lantronix warranty policy, please go to our web site at <https://www.lantronix.com/support/warranty/>.

## Contacts

Lantronix, Inc.  
48 Discovery, Suite 250  
Irvine, CA 92618, USA  
Toll Free: 800-526-8766  
Phone: 949-453-3990  
Fax: 949-453-3995

## Technical Support

Online: [www.lantronix.com/technical-support/](http://www.lantronix.com/technical-support/)

## Sales Offices

For a current list of our domestic and international sales offices, go to the Lantronix website at <https://www.lantronix.com/about-us/contact/>.

## Disclaimer

All information contained herein is provided “AS IS.” Lantronix undertakes no obligation to update the information in this publication. Lantronix does not make, and specifically disclaims, all warranties of any kind (express, implied or otherwise) regarding title, non-infringement, fitness, quality, accuracy, completeness, usefulness, suitability or performance of the information provided herein. Lantronix shall have no liability whatsoever to any user for any damages, losses and causes of action (whether in contract or in tort or otherwise) in connection with the user’s access or usage of any of the information or content contained herein. The information and specifications contained in this document are subject to change without notice.

## Important Notice

This device, like any wireless device, operates using radio signals which cannot guarantee the transmission and reception of data in all conditions. While the delay or loss of signal is rare, you should not rely solely on any wireless device for emergency communications or otherwise use the device in situations where the interruption of data connectivity could lead to death, personal injury, property damage, data loss, or other loss. Lantronix accepts no responsibility for any loss or damage resulting from errors or delays in transmission or reception, or the failure of the Lantronix NTC-550 Series to transmit or receive such data.

---

## Safety and Hazards



**Warning:** Do not connect or disconnect cables or devices to or from the USB port, SIM card tray, Ethernet port or the terminals of the power connector in hazardous locations such as those in which flammable gases or vapours may be present, but normally are confined within closed systems; are prevented from accumulating by adequate ventilation; or the location is adjacent to a location from which ignitable concentrations might occasionally be communicated.

---

## Revision History

Date	Rev.	Comments
July 2025	A	Initial document
June 2026	B	Updated for Firmware Release 2.3.1 (3.3.1) which includes the following: <ul style="list-style-type: none"><li>• Added Unlock timer setting to Cell Lock List</li><li>• Added External SIM APN and e-SIM APN parameters to WAN profiles and updated description for APN parameter</li><li>• Added Auto Enable feature and Active SIM parameter to WAN profile settings</li><li>• Added PercepXion</li><li>• Added TR-369</li><li>• Updated OpenVPN P2P configuration settings</li><li>• Added 5G NR extended information details to Field Test</li></ul> Updated Package contents Updated Compliance details

For the latest revision of this product document, please check our online documentation at <https://www.lantronix.com/support/documentation/>.

---

# Contents

<b>1. Overview</b>	<b>10</b>
Introduction	10
Target audience	10
Prerequisites	10
Notation	10
<b>2. Product introduction</b>	<b>11</b>
Product overview	11
Product features	11
Package contents	11
Ordering Information	11
Product Label	12
<b>3. Physical dimensions and indicators</b>	<b>13</b>
Physical dimension	13
Interfaces	14
LED indicators	16
Signal strength LEDs	17
LED update interval	17
Ethernet port LED indicators	18
<b>4. Placement of the router</b>	<b>19</b>
Antenna Installation	19
Mounting Options	20
Wall Mount	20
Ceiling Mount	20
Desk Mount	21
Mounting Using DIN Rail Mounting Kit	21
<b>5. Installation and configuration of the NTC-550 Series router</b>	<b>23</b>
Powering the router	23
DC power via separately purchased DC power supply	23
DC power via field terminated power source	23
Installing the router	24
<b>6. Advanced configuration</b>	<b>25</b>
Initialization	25
Configure as a new device (create new passwords)	26

---

Logging In.....	28
<b>7. Status.....</b>	<b>29</b>
System Information .....	31
Cellular Connection Status .....	31
WWAN Connection Status.....	32
Ethernet WAN Connection Status .....	33
Wi-Fi Status.....	33
Advanced Status .....	34
4G LTE Neighboring Cell Information .....	36
5G NR Neighboring Cell Information .....	36
2.5GE LAN/WAN .....	37
1GE LAN .....	37
WAN.....	37
<b>8. Networking .....</b>	<b>38</b>
Cellular settings .....	39
SIM security .....	39
SIM switching .....	43
Network bands .....	44
Operator selection.....	45
Cell lock list.....	46
WAN profiles .....	47
5G network slicing .....	52
Service assurance .....	56
LAN Settings.....	57
LAN .....	57
DHCP.....	59
VLAN .....	62
Wi-Fi Settings.....	64
Wi-Fi mode .....	64
Access Point configuration .....	65
Wi-Fi client.....	67
WAN Settings.....	69
Interface assignment.....	69
WAN configuration.....	70
Failover .....	71

---

Routing settings.....	74
Static routes .....	74
Firewall .....	76
DMZ .....	77
Port forwarding .....	78
Filtering.....	79
Redundancy (VRRP).....	82
RIP.....	85
VPN settings.....	86
IPSec .....	86
OpenVPN .....	89
GRE Tunnelling .....	101
Server Certificate.....	103
<b>9. Services.....</b>	<b>105</b>
Network time (NTP).....	106
SMS messaging .....	107
Setup.....	107
Diagnostics .....	109
Inbox.....	122
Compose message.....	123
Outbox.....	124
Dynamic DNS .....	124
DNS server .....	125
GPS.....	126
GPS Configuration .....	126
Assisted GPS .....	127
GPS odometer .....	128
GPS geofence.....	129
Internet of Things .....	132
MQTT client.....	132
Cumulocity agent.....	136
Remote management.....	138
OMA-LWM2M .....	138
SNMP .....	142
Configuring SNMP .....	142

---

Configuring SNMP traps .....	143
TR-069 .....	143
TR-369 .....	145
Serial data status .....	148
Data stream manager .....	148
Endpoints.....	148
Data stream .....	164
Event Configuration.....	166
Notification configuration .....	166
Destination configuration.....	167
Event notification log .....	168
Email settings.....	169
Low power mode.....	171
IO configuration.....	173
PercepXion .....	176
Configuration.....	176
Connection 1 .....	178
Connection 2 .....	179
<b>10. System .....</b>	<b>180</b>
Log .....	180
System log .....	180
System log settings.....	180
Diagnostic log .....	182
IPSec log.....	184
Watchdog .....	185
Periodic ping.....	185
Periodic reboot.....	187
System configuration.....	188
LDAP Settings.....	188
Restore factory defaults .....	189
Web server setting .....	190
Administration settings .....	191
Settings backup/restore .....	193
Site and location settings .....	194
Runtime configuration .....	194

---

SSH key management.....	195
LED operation mode.....	196
A/B system.....	198
Firmware upgrade .....	199
Updating the router firmware.....	199
SD Card .....	200
Access control.....	201
Reboot .....	202
Field test .....	203
Encrypted debuginfo .....	205
USB-OTG .....	206
Storage.....	207
Voltage Monitor .....	208
<b>11. Help .....</b>	<b>209</b>
<b>Appendix A.    Configuring Radio Access Technologies .....</b>	<b>210</b>
<b>Appendix B.    Inputs / Outputs .....</b>	<b>211</b>
Hardware Interface .....	211
Wiring examples .....	212
Open Collector Output driving a relay.....	212
Logic level output .....	212
LED output .....	212
Digital inputs.....	213
NAMUR sensor .....	214
Analogue Sensor with Voltage output.....	214
Analogue Sensor with 4 to 20mA output .....	215
Analogue Sensor with Thermistor .....	215
System Example – Solar powered router with battery backup.....	216
Power detection (ignition) input .....	217
<b>Appendix C.    Compliance Information .....</b>	<b>218</b>
EU Declaration of Conformity .....	219
EU Statements .....	220
UK Declaration of Conformity .....	225

# 1. Overview

## Introduction

This document provides you all the information you need to set up, configure and use the Lantronix NTC-550 Series router.

## Target audience

This document is intended for system integrators or experienced hardware installers who understand telecommunications terminology and concepts.

## Prerequisites

Before continuing with the installation of your NTC-550 Series router, please confirm that you have the following:

- An electronic computing device with a working Ethernet network adapter
- A web browser such as Mozilla Firefox® or Google Chrome™

## Notation

The following symbols may be used in this document:



**Note:** *This note contains useful information.*



**Important:** *This is important information that may require your attention.*



**Warning:** *This is a warning that may require immediate action to avoid damage or injury.*

## 2. Product introduction

### Product overview

The NTC-550 Series routers are high-end, high-speed industrial-grade 5G routers. Designed with critical and complex applications in mind, they provide ultra-reliable, high bandwidth throughput even in extremely demanding environments.

The NTC-550 Series features support the latest wireless technologies including Release 16 5G and Wi-Fi 6 to ensure access to the latest innovations and the best possible throughput at a world-leading price point.

Ideal for use in emergency vehicles, trucks, and buses, or as the core of complex systems to monitor and control critical infrastructure in remote, unmanned locations.

### Product features

- 5G with failover to 4G
- Wi-Fi 6 and Bluetooth support (Bluetooth support not available in current firmware.)
- Multiple gigabits per second ports
- Built-in GPS
- Serial port, I/Os and Ignition sensing
- Robust, ruggedized industrial-grade metal housing and a wide operating temperature range
- Designed, assembled, and tested for unmanned locations in extreme environments

### Package contents

The Lantronix NTC-550 Series router package contains:

- 1 x NTC-550 Series router
- 1 x Six-way terminal block connector
- 1 x 1 m Ethernet cable
- 1 x DIN rail mounting kit
- 1 x Box Insert

If any of these items are missing or damaged, please contact your sales representative or the support team.

### Ordering Information

Model	Lantronix Part Number	Description
NTC-551	NTC-551-01-01	5G Release 16 Sub 6 Industrial Grade 5 Port Router with Wi-Fi for North America
NTC-552	NTC-552-01-01	5G Release 16 Sub 6 Industrial Grade 5 Port Router with Wi-Fi, Global

## Product Label



Figure 2-1 NTC-552 Product Label

### 3. Physical dimensions and indicators

#### Physical dimension




Figure 3-1 NTC-550 Series top and side views

Table 3-1 NTC-550 Series Router Dimensions

NTC-550 Series Router Dimensions	
Length	175 mm
Depth	193.3 mm
Height	51.7 mm
Weight	1.050 kg

## Interfaces

The following interfaces are available on the NTC-550 Series router:



Figure 3-2 Interfaces

Table 3-2 Interfaces

No.	ITEM	DESCRIPTION
1	2.5Gbps WAN Ethernet Port	Connect a wired WAN connection here.
2	Gigabit LAN Ethernet ports	Connect local Ethernet compatible devices here.
3	Serial Port	Configurable RS232 DE-9 serial port used to connect serial devices to the router.
4	Factory reset button	<p>Press and hold for less than 5 seconds to reboot to normal mode. The LEDs are green and extinguish in sequence to indicate that the router will reboot normally if the button is released during this period.</p> <p>Press and hold for 5 to 10 seconds to reboot to another partition for recovery purpose. The LEDs are amber and extinguish in sequence to indicate that the router will load the recovery image.</p> <p>Press and hold for 10 to 15 seconds to reset the router to factory default settings. The LEDs are red and extinguish in sequence to indicate that the router will reset to factory default settings if the button is released during this period.</p>
5	Bluetooth pairing button	Press for one second then release to initiate Bluetooth pairing.
6	Six-way terminal block connector	Connect power source, ignition and I/O wires here. Power from a DC power supply, ignition, and I/O wires may be terminated on the supplied terminal block connector and the connector inserted into the terminal block socket on the router. Refer to <a href="#">Powering the Router</a> section for further information.
7	Cellular antenna connectors (claret violet)	FAKRA connectors for cellular antennas.
8	GNSS antenna connector (signal blue)	FAKRA connector for GNSS antenna.
9	Wi-Fi antenna connectors (beige)	FAKRA connectors for Wi-Fi antennas.
10	SIM card tray	Insert SIM card (2FF size) here.
11	SIM eject button	Press to eject the SIM card tray.
12	microSD card slot	Insert microSD card here. Remove the cover using a Phillips head screwdriver to access the slot.
13	USB-C port	Provides USB connectivity for debugging. Remove the cover using a Phillips head screwdriver to access the slot.






















## LED indicators













The NTC-550 Series router uses LEDs to display the current system and connection status.




Figure 3-3 LED Indicators

Table 3-3 LED Indicators

LED	NAME	COLOUR	STATE	DESCRIPTION
	Power		Off	Power off
			Blinking	Router starting up
			On	Power on
	SIM		Off	No SIM detected
			Blinking	SIM error
			On	SIM installed and working
	4G Network		Off	No 4G connection
			Blinking	Connecting to 4G network
			On	4G connected
	5G Network		Off	No 5G connection
			Blinking	Connecting to 5G network
			On	5G connected
<b>SIGNAL</b>	Signal Strength		Off	No signal
			One Lit	Poor signal
			Two Lit	Fair signal
			Three Lit	Good signal
	Wireless		Off	Wireless off

LED	NAME	COLOUR	STATE	DESCRIPTION
			Blinking	Client mode enabled
			On (Amber)	Connected to Wi-Fi network as client device
			On	Wireless Access Point enabled
	Bluetooth		Off	Bluetooth off
			Blinking	Bluetooth pairing mode
			On	Bluetooth on
	GPS		Off	GPS off
			Blinking	Acquiring GPS location
			On	GPS on
<b>CUSTOM</b>	Custom 1	Customizable		Programmable LED for custom use
<b>CUSTOM</b>	Custom 2	Customizable		Programmable LED for custom use

 **Note:** The custom LEDs would be available for configuration with future feature enhancements.

### Signal strength LEDs

The following table lists the signal strength range corresponding to the number of lit signal strength LEDs.

*Table 3-4 Signal strength LED indicators*

NUMBER OF LIT LEDs	SIGNAL STRENGTH
All LEDs unlit	No signal
1	> -120 dBm
2	> -105 dBm
3	> -90 dBm

### LED update interval

The signal strength LEDs update within a few seconds with a rolling average signal strength reading. When selecting a location for the router or connecting and positioning an external antenna, please allow up to 20 seconds for the signal strength LEDs to update before repositioning.

## Ethernet port LED indicators




Figure 3-4 NTC-550 Series Ethernet port LED indicators

The table below describes the status of each light and their meanings.

Table 3-5 Ethernet port LED indicators

LED	STATUS	DESCRIPTION
Green	On	Valid network link.
	Blinking	Activity on the network link.
	Off	No valid network detected.
Amber	On	Ethernet port is operating at a speed of 100 Mbps or 1000 Mbps or 2500 Mbps.
	Off	Ethernet port is operating at a speed of 10 Mbps or no ethernet cable is connected

## 4. Placement of the router

### Antenna Installation

The NTC-550 Series router is fitted with multiple FAKRA antenna connectors to connect cellular, Wi-Fi, and GNSS antennas. Attach antennas fitted with FAKRA connectors to the corresponding antenna connectors on your router. Refer to the [Interfaces](#) section for the antenna connector layout.



Figure 4-1 Connecting Antenna

**Note:** The antennas are not shipped with the device and have to be ordered separately.


If you find the signal strength is weak, try adjusting the orientation of the antennas. If you are unable to get an acceptable signal, try moving the router to a different place or mounting it differently.

**Note:** When selecting a location for the router, allow at least 20 seconds for the signal strength LEDs to update before trying a different location.

## Mounting Options


You have multiple options to mount the NTC-550 Series router.

### Wall Mount



*Figure 4-2 NTC-550 Series Router Wall Mount*

### Ceiling Mount



*Figure 4-3 NTC-550 Series Router Ceiling Mount*

## Desk Mount




Figure 4-4 NTC-550 Series Router Desk Mount

## Mounting Using DIN Rail Mounting Kit

The DIN rail mounting kit allows you to install the device in two orientations. Install the DIN rail mounting kit by screwing the DIN rail mounts into the locations as shown below.



Figure 4-5 Installing DIN Rail Mounts





Figure 4-6 Mounting Using DIN Rail Kit

## 5. Installation and configuration of the NTC-550 Series router

### Powering the router

The NTC-550 Series router can be powered in one of two ways:

- DC power input via separately purchased DC power supply (8-40 V DC)
- DC power input via field terminated power source (8-40 V DC)

The green power LED on the router lights up when a power source is connected. Nominal power input is (12 V DC/1.5 A).

#### DC power via separately purchased DC power supply

The positive and ground terminals on the 6-pin connector can accept power from a separately sold DC power supply. Both a standard temperature range DC power supply and an extended temperature range DC power supply are available to purchase as accessories.

If you have purchased an optional DC power supply, first remove the terminal block connector from the socket. The terminal block connector uses rising cage clamps to secure the wires and ships with the cages lowered and ready for wire insertion. Inspect the cage clamps and use a flathead screwdriver to lower the cage clamps if they have moved during transportation. Insert the wires into the terminal block connector as shown below noting the polarity of the wires and then use a flathead screwdriver to raise the cage clamp to secure the wires. Insert the wired terminal block connector into the terminal block socket of the router and then connect the adapter to a wall socket.




Figure 5-1 Terminal block wiring diagram




Figure 5-2 Locking Power Terminal block pinout

#### DC power via field terminated power source

If an existing 8-40V DC power supply is available, you can insert the wires into the supplied terminal block connector to power your router. Use a flathead screwdriver to tighten the terminal block connector screws and secure the power wires, making sure the polarity of the wires is correctly matched as shown above. You should avoid using DC cables greater than 2 metres in length.

Table 5-1 Locking Power Terminal Block Pinout Description

Terminal	Description
+	Positive wire for power
-	Ground wire
i	Dedicated terminal for ignition detection
I/O	Used for general purpose input/output (refer to IO configuration section for more information)

## Installing the router

After you have mounted the router and connected a power source, follow the below steps to complete the installation process:

1. Connect equipment that requires network access to the Ethernet port of your router. This may be your computer for advanced configuration purposes, or your end equipment which requires data access via the NTC-550 Series router. You can connect one device directly, or several devices using a network switch.
2. Connect the antennas, if required.
3. If your router does not come with a pre-installed SIM, insert a SIM card into the SIM card slot. Press the SIM Eject button to eject the SIM card tray, place the SIM card in the tray and then insert the loaded tray into the SIM slot with the gold side facing up.
4. Ensure the external power source is switched on and wait 2 minutes for your NTC-550 Series router to start up and connect to the mobile network. Your router arrives with preconfigured settings that should suit most customers. Your router is now connected. To check the status of your router, compare the LED indicators on the device with those listed in the LED indicators table.

## 6. Advanced configuration

To access the web-based user interface, open a web browser (e.g., Mozilla Firefox or Google Chrome), type `https://192.168.1.1` into the address bar and press Enter.

The router's web user interface is displayed.



**Important:** The HTTP protocol is disabled by default, secure HTTP (HTTPS) is the default protocol. HTTP access is available but must be manually enabled.

### Initialization

The first time the device is booted (or booted after a factory reset), the device enters configuration mode. The below prompt displays.

Welcome to your new router. The router is now in configuration mode and must be either configured with secure passwords or restored to a previous configuration before it is operational.

[Next](#)

In configuration mode, the router runs a setup wizard which must be completed before the device boots into live mode. This is a security feature which enables you to configure the router as new device and set strong passwords for the web UI users (root, admin, and user) and passwords for SSH and Wi-Fi access access or restore a previous configuration from a backup file.

To complete the setup:

1. Click **Next** on the first prompt. The below prompt displays.

To begin using your device, please enter the factory default password. The factory default password is printed on the device label.

[Next](#)

2. Enter the factory default password which is printed on the device label, then click **Next**, the below dialogue box displays.

Select one of the following options:

I want to configure this as a new device.

I want to restore my configuration from a previous backup.

[OK](#)


3. Select whether to configure the router as a new device or restore a previous configuration backup.

### Configure as a new device (create new passwords)

Select **I want to configure this as a new device**, then click **OK**.

In the **NEW PASSWORDS** section, enter a strong password for in the **New (username) password** field and re-enter the password in the **Confirm (username) password** field. Click the **Same as above** checkbox for the password fields of a user to use the same passwords set for the above user. You may configure the same password for all accounts, but it must meet the following security requirements:

- The password must be a minimum of eight characters and no more than 128 characters in length.
- The password must contain at least one upper case, one lower case character, and one number.
- The password must contain at least one special character, such as: ` ~ ! @ # \$ % ^ & \* ( ) - \_ = + [ { ] \ | ; : ' " , < > / ?
- Additionally, the password must satisfy an algorithm which analyses the characters as you type them, searching for commonly used patterns, passwords, names, and surnames according to US census data, popular English words from Wikipedia, US television, movies, and other common patterns such as dates, repeated characters (aaa), sequences (abcd), keyboard patterns (qwertyuiop), and substitution of numbers for letters.

Click the  icon for each password field to display the password criteria.

## NEW DEVICE CONFIGURATION

### NEW PASSWORDS

Please enter a root, admin, user and SSH password in the respective fields below. For details on password complexity criteria, select the information link next to each field.

**New root password** [i](#)

**Confirm root password**

**New admin password** [i](#)   Same as the above

**Confirm admin password**

**New user password** [i](#)   Same as the above

**Confirm user password**

**New SSH password** [i](#)   Same as the above

**Confirm SSH password**

**New Wi-Fi password** [i](#)   Same as the above

**Confirm Wi-Fi password**

*Figure 6-1 New device configuration dialog page*

Once you have entered values for all password fields, Click **Save** button. If the passwords meet the security requirements, they are saved and the router reboots to Live mode automatically and the login page displays.

LANTRONIX | [Status](#) | [Networking](#) | [Services](#) | [System](#) | [Help](#) 👤

### Login


Username

Password

*Figure 6-2 Login page for web-based user interface*

## Logging In

To log into the router, enter the login username (root, admin or user) and the password that you configured for that user during the initialisation process.



*Figure 6-3 Login page for web-based user interface*

**Note:** If logging in as user, the account allows you to manage all settings of the router except functions such as firmware upgrade, device configuration backup and restore and reset to factory default settings, which are privileged only to the root account.





---

## 7. Status

The Status page displays once you login into the NTC-550 Series router web interface. The Status page displays the following details:

- System Information
- Cellular Connection Status
- WWAN Connection Status
- Ethernet WAN Connection Status
- Wi-Fi Status
- Advanced Status
- 4G LTE Neighboring Cell Information
- 5G NR Neighboring Cell Information
- 2.5GE LAN/WAN
- 1GE LAN
- WAN

Click  or  buttons in each section tab to hide or show the details in that section. Extra sections will appear as additional software features are enabled.

LANTRONIX | 
 [Status](#) | 
 [Networking](#) | 
 [Services](#) | 
 [System](#) | 
 [Help](#)

 root

^ SYSTEM INFORMATION

<div style="text-align: center; color: #0070c0; font-weight: bold; margin-bottom: 10px;">Device information</div> <table border="0" style="width: 100%;"> <tr> <td style="width: 50%;"><b>Device name</b> 5G Industrial IoT Router</td> <td style="width: 50%;"><b>Serial number</b> 219743243300074</td> </tr> <tr> <td><b>Model</b> NTC-552-01</td> <td><b>Hardware version</b> 01.01</td> </tr> <tr> <td><b>Uptime</b> 00:46:16</td> <td><b>Device firmware</b> 2.3.1.0R3</td> </tr> <tr> <td><b>Site name</b> Not configured</td> <td></td> </tr> <tr> <td><b>Location</b> Not configured</td> <td></td> </tr> </table>	<b>Device name</b> 5G Industrial IoT Router	<b>Serial number</b> 219743243300074	<b>Model</b> NTC-552-01	<b>Hardware version</b> 01.01	<b>Uptime</b> 00:46:16	<b>Device firmware</b> 2.3.1.0R3	<b>Site name</b> Not configured		<b>Location</b> Not configured		<div style="text-align: center; color: #0070c0; font-weight: bold; margin-bottom: 10px;">Cellular module</div> <table border="0" style="width: 100%;"> <tr> <td><b>Model</b> RG520N-EU</td> </tr> <tr> <td><b>Module firmware</b> RG520NEUDAR03A04M8GA</td> </tr> <tr> <td><b>IMEI</b> 353736500000742</td> </tr> <tr> <td><b>IMEISV</b> 12</td> </tr> </table>	<b>Model</b> RG520N-EU	<b>Module firmware</b> RG520NEUDAR03A04M8GA	<b>IMEI</b> 353736500000742	<b>IMEISV</b> 12
<b>Device name</b> 5G Industrial IoT Router	<b>Serial number</b> 219743243300074														
<b>Model</b> NTC-552-01	<b>Hardware version</b> 01.01														
<b>Uptime</b> 00:46:16	<b>Device firmware</b> 2.3.1.0R3														
<b>Site name</b> Not configured															
<b>Location</b> Not configured															
<b>Model</b> RG520N-EU															
<b>Module firmware</b> RG520NEUDAR03A04M8GA															
<b>IMEI</b> 353736500000742															
<b>IMEISV</b> 12															

v 2.5GE LAN/WAN

v 1GE LAN

v WAN

v CELLULAR CONNECTION STATUS

v WWAN CONNECTION STATUS

v ETHERNET WAN CONNECTION STATUS

v WI-FI STATUS

v ADVANCED STATUS

v 4G LTE NEIGHBOURING CELL INFORMATION

v 5G NR NEIGHBOURING CELL INFORMATION

Figure 7-1 NTC-550 Series router status page

## System Information

The table below lists the System Information details:

*Table 7-1 System Information details*

Item	Description
<b>Device Information</b>	
Device name	The device name of the NTC-550 Series router
Model	The commercial product name which helps to identify the available features of the router.
Uptime	The current up time (the time since the router was last turned on) of the router.
Site name	The configured site name.
Location	The configured location.
Serial number	The serial number of the router.
Hardware version	The hardware version of the router.
Device Firmware	The firmware version of the router
<b>Cellular Module</b>	
Model	The type of cellular module
Module firmware	The firmware revision of the cellular module.
IMEI	The International Mobile Station Equipment Identity number used to uniquely identify a mobile device.
IMEISV	International Mobile Equipment Identity and Software Version. It is a 16-digit code that uniquely identifies a mobile device and its software version.

## Cellular Connection Status

The table below lists the Cellular Connection Status details.

*Table 7-2 Cellular Connection Status Items*

Item	Description
SIM status	Displays the SIM status of the router. This includes information about whether there is a SIM inserted or if the SIM card has an error.
Signal strength	The current signal strength measured in dBm.
Network registration status	The status of the router registration for the current network.
Operator selection	The mode used to select an operator network.

Item	Description
Provider	The current operator network in use.
Roaming status	The roaming status of the Series router.
Enabled bands	The bands to which the router may connect.
Current band	The current band being used by the router.
Connection (RAT)	The radio access technology in use.
Coverage	The type of mobile coverage being received by the router.
Service options	The network options provided by the current service in use.

## WWAN Connection Status

The table below lists the WWAN Connection Status details.

*Table 7-3 WWAN Connection Status Items*

Item	Description
Profile	The name of the active profile.
APN	The Access Point name currently in use, If the APN has been manually entered by you. Auto-assigned is displayed if the APN is assigned by the network.
Connection uptime	The duration of the current mobile connection session.
Default profile	Indicates whether the current profile in use is the default profile.
IPv4 status	The IPv4 connection status of the active profile.
IPv4 WWAN	The IPv4 address assigned by the mobile broadband carrier network.
IPv4 DNS server	The primary and secondary IPv4 DNS servers for the WWAN connection.
IPv4 MTU	The current IPv4 Maximum Transmission Unit (MTU) of the WWAN connection.
IPv6 status	The IPv6 connection status of the active profile.
IPv6 WWAN	The IPv6 address assigned by the mobile broadband carrier network.
IPv6 DNS server	The primary and secondary IPv4 DNS servers for the WWAN connection.
IPv6 MTU	The current IPv6 Maximum Transmission Unit of the WWAN connection.

## Ethernet WAN Connection Status

The table below lists the Ethernet WAN Connection Status details.

*Table 7-4 Ethernet WAN Connection Status Items*

Item	Description
#	Index number of the WAN interface.
Name	The interface name as it is shown on the system.
Status	Displays whether interface is up or down.
IP address	IP address assigned to the ethernet interface.
Gateway	Gateway address for the ethernet interface.

## Wi-Fi Status

The table below lists Wi-Fi Status details.

*Table 7-5 Wi-Fi Status Items*

Item	Description
<b>Wi-Fi client</b>	
Network name (SSID)	Network name (SSID) of the Wi-Fi access point.
Channel	The frequency band used for the Wi-Fi communication.
State	Status of the Wi-Fi network.
IP	IP address assigned to the Wi-Fi interface by the access point to which it is connected.
<b>5GHz AP</b>	
Network name (SSID)	Network name (SSID) of the router that is broadcasted in the network.
Channel	The frequency band used for the Wi-Fi communication.
State	Status of the Wi-Fi network.
Broadcast SSID	Status the SSID broadcast.
<b>2.4GHz AP</b>	
Network name (SSID)	Network name (SSID) of the router that is broadcasted in the network.
Channel	The frequency band used for the Wi-Fi communication.
State	Status of the Wi-Fi network.
Broadcast SSID	Status the SSID broadcast.

## Advanced Status

The table below lists the Advanced Status details.

*Table 7-6 Advanced Status Items*

Item	Description
Mobile country code	The Mobile Country Code (MCC) of the router.
Mobile network code	The Mobile Network Code (MNC) of the router.
SIM ICCID	The Integrated Circuit Card Identifier of the SIM card used with the router, a unique number up to 19 digits in length.
IMSI	The International Mobile Subscriber Identity is a unique identifier of the user of a cellular network.
Packet service status	Displays whether the packet service is attached or detached. When APN or username/password is changed, the device detaches and reattaches to the network.
<b>4G LTE</b>	
ECGI	E-UTRAN Cell Global Identifier. The globally unique identity of a cell in E-UTRA. The ECGI concatenates the PLMN-Id and the ECI (E-UTRAN Cell Identifier).  The ECI concatenates the eNodeB ID and the Cell ID
eNodeB	Also known as the Evolved Node B, 5G this is the hardware element in the LTE network that communicates directly with mobile devices.
Cell ID	A unique code that identifies the base station from within the location area of the current mobile LTE network signal.
PCI	Physical Cell ID of the LTE Cell.
Channel number (EARFCN)	The channel number of the current cellular connection.
Reference Signal Received Power (RSRP)	Average power received from a single reference signal within a specific bandwidth.
Reference Signal Received Quality (RSRQ)	RSRQ calculates signal quality taking into consideration the RSSI. It is calculated by $N \times \text{RSRP} / \text{RSSI}$ where N is the number of Physical Resources Blocks (PRBs) over which the RSSI is measured.
Signal to Interference plus Noise Ratio (SINR)	The power of a certain signal of interest divided by the sum of the interference power (from all the other interfering signals) and the power of some background noise.
CQI	Channel Quality Indicator. This is a value between 1 and 15 with 15 being the highest rating.

Item	Description
<b>5G NR</b>	
NCGI	NR Cell Global Identifier. This concatenates the PLMN-Id (PLMN Identifier) and the 36bit NCI (NR Cell Identity). This information is not available when the device is operating in LTE or 5G non-standalone mode.
gNodeB	The gNodeB (gNB) is the term given to network equipment that transmits and receives wireless communications between UE and a mobile network
gNB Cell ID	A unique code that identifies the base station from within the location area of the current mobile 5G network signal. This is not available when the device is operating in LTE or 5G non-standalone mode.
gNB PCI	Physical Cell ID of the 5G NR Cell.
Channel number (NR ARFCN)	The channel number of the current 5G cellular connection.
SSB Channel number (SSB ARFCN)	The Synchronization Signal Block (SSB) channel number of the current 5G cellular connection.
SCS	The size of the current Subcarrier Spacing (SCS) expressed in KHz.
Reference Signal Received Power (SS-RSRP)	Synchronization Signal Reference Signal Received Power (SS-RSRP). The linear average over the power contributions (in Watts) of the resource elements that carry Secondary Synchronization Signal (SSS).
Reference Signal Received Quality (SS-RSRQ)	Secondary Synchronization Signal Reference Signal Received Quality (SS-RSRQ). It calculates signal quality taking into consideration the RSSI. It is calculated by $N \times SS-RSRP / NR \text{ carrier RSSI}$ where N is the number of Physical Resources Blocks (PRBs) over which the NR RSSI is measured.
Signal to Interference plus Noise Ratio (SS-SINR)	Synchronization Signal – Signal to interference plus noise ratio. The power of a certain signal of interest divided by the sum of the interference power (from all the other interfering signals) and the power of some background noise.
NR CQI	The 5G NR Channel Quality Indicator (CQI).
Synchronisation Signal Block (SSB) Index	This is a key part of beam management. It is a value comprised of Primary Synchronization Signal (PSS), Secondary Synchronization Signal (SSS) and the Physical Broadcast Channel (PBCH).

## 4G LTE Neighboring Cell Information

The table below lists the 4G LTE Neighboring Cell Information details.

*Table 7-7 4G LTE Neighboring Cell Information Items*

Item	Description
PCI	The Physical Cell ID.
EARFCN	E-UTRA Absolute Radio Frequency Channel Number. Uniquely identifies the LTE Band and carrier frequency.
RSRP	Reference Signal Received Power.
RSRQ	Reference Signal Received Quality.
RAT	The radio signal being served e.g., 5G NR, LTE.

## 5G NR Neighboring Cell Information

The table below lists the 5G NR Neighboring Cell Information details.

*Table 7-8 5G NR Neighboring Cell Information Items*

Item	Description
PCI	The Physical Cell ID.
NR ARFCN	Absolute radio-frequency channel number
SS-RSRP	Synchronization Signal Reference Signal Received Power.
SS-RSRQ	Secondary Synchronization Signal Reference Signal Received Quality.
Type	Serving or neighbor
Role	Defines the function of the neighbor cell, such as whether it is considered for handover, idle-mode reselection, measurement only, or to be avoided. It helps control how the device evaluates and interacts with neighboring cells during network operation.
SSB ARFCN	The Synchronization Signal Block (SSB) channel number of the current 5G cellular connection.
RAT	The radio signal being served e.g., 5G NR, LTE.

## 2.5GE LAN/WAN

The table below lists the 2.5GE LAN/WAN details.

*Table 7-9 2.5GE LAN/WAN Items*

Item	Description
Interface assignment	Displays the current interface assignment, whether LAN or WAN.
IP	The IP address and subnet mask assigned to the interface.
MAC address	The MAC address of the interface.
Ethernet port status	The status of the port and its current operating speed.

## 1GE LAN

The table below lists the 1GE LAN details.

*Table 7-10 1GE LAN Items*

Item	Description
IP	The IP address and subnet mask assigned to the interface.
MAC address	The MAC address of the interface.
Ethernet port status #1	The status of the port and its current operating speed.
Ethernet port status #2	The status of the port and its current operating speed.
Ethernet port status #3	The status of the port and its current operating speed.
Ethernet port status #4	The status of the port and its current operating speed.

## WAN

WAN section displays the priority and status of the available WAN connections.

## 8. Networking

The Networking page allows you to configure the following features:

- Cellular settings
- LAN settings
- Wi-Fi settings
- WAN settings
- Routing settings
- VPN settings

To access the Networking page, click **Networking** tab on the top menu bar.

The screenshot shows the LANTRONIX Networking page. The top navigation bar includes the LANTRONIX logo, Status, **Networking**, Services, System, Help, and a user profile for 'admin'. A left sidebar contains expandable menu items for Cellular settings, LAN settings, Wi-Fi settings, WAN settings, Routing settings, and VPN settings. The main content area is titled 'WAN PROFILES' and contains a table with the following columns: Profile no., Profile name, Status, APN, External SIM APN, e-SIM APN, IP passthrough, Map to LAN/VLAN, and Default route. There are six rows of profile configurations, each with 'On' and 'Off' toggle buttons for status and IP passthrough, and a dropdown menu for 'Map to LAN/VLAN'. A 'Save' button is located at the bottom of the table.

Profile no.	Profile name	Status	APN	External SIM APN	e-SIM APN	IP passthrough	Map to LAN/VLAN	Default route
1		On Off	blank	blank	blank	On Off	bridge0	<input checked="" type="radio"/>
2		On Off	ims	blank	blank	On Off	None	<input type="radio"/>
3		On Off	sos	blank	blank	On Off	None	<input type="radio"/>
4		On Off	blank	blank	blank	On Off	None	<input type="radio"/>
5		On Off	blank	blank	blank	On Off	None	<input type="radio"/>
6		On Off	blank	blank	blank	On Off	None	<input type="radio"/>

Save

Figure 8-1 Networking page

## Cellular settings

### SIM security

The SIM security page allows you to manage the PIN settings of the of the SIM, if the SIM is PIN enabled. To access the SIM security page, navigate to **Networking > Wireless WAN > SIM security**.

The screenshot shows the 'SIM SECURITY' page with the following elements:

- SIM SECURITY MANAGEMENT** header
- Status: SIM OK
- PIN retries remaining: 3
- PIN protection: A toggle switch set to 'Off'.
- Current PIN: An empty text input field with an eye icon to its right.
- Confirm current PIN: An empty text input field with an eye icon to its right.
- Remember PIN: An unchecked checkbox.
- Save: A button at the bottom.

*Figure 8-2 SIM security page*

To enable PIN protection set **PIN protection** to **ON**, enter the PIN number in the **Current PIN** and **Confirm current PIN** fields and click **Save**. Once SIM protection is enabled the PIN settings page displays with **Change PIN** button.

The screenshot shows the 'SIM SECURITY' page after enabling PIN protection, with the following elements:

- SIM SECURITY MANAGEMENT** header
- Status: SIM OK
- PIN retries remaining: 3
- PIN protection: A toggle switch set to 'On'.
- Change PIN: A blue button that has appeared below the toggle.
- Current PIN: An empty text input field with an eye icon to its right.
- Confirm current PIN: An empty text input field with an eye icon to its right.
- Remember PIN: An unchecked checkbox.
- Save: A button at the bottom.

*Figure 8-3 SIM security page after enabling PIN protection*

When SIM protection is enabled, each time you log into the router after a reboot you will be prompted to unlock the SIM.

You must enter your PIN code to unlock and use the SIM.

OK

Click **OK**, you are directed to SIM security page.

The screenshot shows the 'SIM SECURITY' management interface. At the top, the status is 'PIN locked'. Below this, it indicates 'PIN retries remaining' as 3. There are two input fields: 'Current PIN' and 'Confirm current PIN', each with a toggle icon to the right. A 'Remember PIN' checkbox is present and unchecked. A 'Save' button is located at the bottom of the form.

*Figure 8-4 SIM security page when SIM is PIN locked*


Enter the PIN in **Current PIN** and **Confirm Current PIN** fields and click **Save**, to unlock the SIM. Once the SIM is unlocked you are redirected to the Login page. Log into the device, the SIM security page displays.

The screenshot shows the 'SIM SECURITY' management interface after the SIM is unlocked. The status is now 'SIM OK'. The 'PIN retries remaining' is still 3. A 'PIN protection' toggle switch is shown, currently set to 'On'. A blue 'Change PIN' button is visible above the 'Current PIN' and 'Confirm current PIN' input fields. The 'Remember PIN' checkbox remains unchecked. A 'Save' button is at the bottom.

*Figure 8-5 SIM security page after SIM is unlocked*


Once unlocked, you can disable PIN protection, if you do not wish to have access locked by a PIN. To disable PIN protection set **PIN protection** to **OFF**, enter the PIN number in the **Current PIN** and **Confirm current PIN** fields and click **Save**.

If you are placing the router in a remote, unattended location, you can check **Remember PIN** option to enable it. This feature allows the router to automatically send the PIN to the SIM each time the SIM asks for it (usually at power up). This enables the SIM to be PIN locked (to prevent unauthorized re-use of the SIM elsewhere), while still allowing the router to connect to the cellular service. When this feature is enabled, the PIN you enter is encrypted and stored locally on the router. The next time the SIM asks the router for the PIN the router decrypts the PIN and automatically sends it to the SIM without user intervention.

 **Note:** Select *Remember PIN* if you do not want to enter the PIN code each time the SIM is inserted

### SIM PUK Lock

If you enter the wrong PIN three times the SIM becomes Personal Unblocking Key (PUK) locked.



**SIM SECURITY**

**SIM SECURITY MANAGEMENT**

Status PUK locked

PUK retries remaining 10

Current PUK

Confirm current PUK


New PIN

Confirm new PIN

Remember PIN

Save

To unlock the SIM, you have to request your service provider for a PUK code. Once you have the PUK code, enter it in the **Current PUK** and **Confirm current PUK** fields, enter a new PIN in the **New PIN** and **Confirm new PIN** fields, and then click **Save**. The below prompt is displayed if the SIM is unlocked. Click **Ok** to proceed.



SIM unlocked successfully.

OK

## Changing SIM PIN

To change the PIN of the SIM:

1. Click **Change PIN**, the PIN settings page displays with **New PIN** and **Confirm new PIN** fields.



The screenshot shows the 'SIM SECURITY MANAGEMENT' page. At the top, it says 'SIM SECURITY' in orange. Below that, 'SIM SECURITY MANAGEMENT' is written in blue. The status is 'SIM OK'. There are 'PIN retries remaining 3'. A 'PIN protection' toggle is set to 'On'. A blue 'Change PIN' button is visible. Below it are four input fields: 'Current PIN', 'Confirm current PIN', 'New PIN', and 'Confirm new PIN', each with an eye icon for visibility. At the bottom, there is a 'Remember PIN' checkbox (unchecked) and a 'Save' button.

*Figure 8-6 PIN settings page when changing PIN*

2. Enter the current PIN in **Current PIN** and **Confirm current PIN** fields.
3. Enter the new PIN in **New PIN** and **Confirm new PIN** fields.
4. Click **Save** to save and apply the settings.

## SIM switching

The NTC-550 Series router is equipped with both a removable and an internal SIM. To configure SIM settings and switch between the two SIMs, the SIM switching page is used. The SIM switching page also provides failover options to switch between the SIM cards.

**SIM SWITCHING**

SIM to use on startup Removable SIM

Active SIM Removable SIM **Switch active SIM**

Switch to internal SIM if removable SIM is removed **On** Off

Enable failover based on network and usage factors **On** Off

Save

*Figure 8-7 SIM management*

To select the SIM which should be used on startup, set the **SIM to use on startup** field to either **Internal SIM** or **Removable SIM**.

**Active SIM** displays the SIM that is currently in use. Click **Switch active SIM** to use the other SIM.

To automatically switch to the internal SIM if the removable SIM card is removed, set the **Switch to internal SIM if removable SIM is removed** toggle to **On**.

To configure **Failover** options, set the **Enable failover based on network and usage factors** to **On**, then set the relevant toggles for each condition that you would like to meet.

Click **Save** to save and apply the settings.

## Network bands

The Network bands page allows you to select individual bands from the following band groupings:

- LTE
- 5G NR NSA
- 5G NR SA

To access the Network bands page, navigate to **Networking > Cellular settings > Network bands**. Set each band group to **ON** to enable it.

**NETWORK BANDS**

**4G LTE BANDS**  On  Off

<input checked="" type="checkbox"/> B1	<input checked="" type="checkbox"/> B3	<input checked="" type="checkbox"/> B5	<input checked="" type="checkbox"/> B7	<input checked="" type="checkbox"/> B8
<input checked="" type="checkbox"/> B20	<input checked="" type="checkbox"/> B28	<input checked="" type="checkbox"/> B32	<input checked="" type="checkbox"/> B38	<input checked="" type="checkbox"/> B40
<input checked="" type="checkbox"/> B41	<input checked="" type="checkbox"/> B42	<input checked="" type="checkbox"/> B43		

**5G NR NSA BANDS**  On  Off

<input checked="" type="checkbox"/> n1	<input checked="" type="checkbox"/> n3	<input checked="" type="checkbox"/> n5	<input checked="" type="checkbox"/> n7	<input checked="" type="checkbox"/> n8
<input checked="" type="checkbox"/> n20	<input checked="" type="checkbox"/> n28	<input checked="" type="checkbox"/> n38	<input checked="" type="checkbox"/> n40	<input checked="" type="checkbox"/> n41
<input checked="" type="checkbox"/> n75	<input checked="" type="checkbox"/> n76	<input checked="" type="checkbox"/> n77	<input checked="" type="checkbox"/> n78	

**5G NR SA BANDS**  On  Off

<input checked="" type="checkbox"/> n1	<input checked="" type="checkbox"/> n3	<input checked="" type="checkbox"/> n5	<input checked="" type="checkbox"/> n7	<input checked="" type="checkbox"/> n8
<input checked="" type="checkbox"/> n20	<input checked="" type="checkbox"/> n28	<input checked="" type="checkbox"/> n38	<input checked="" type="checkbox"/> n40	<input checked="" type="checkbox"/> n41
<input checked="" type="checkbox"/> n75	<input checked="" type="checkbox"/> n76	<input checked="" type="checkbox"/> n77	<input checked="" type="checkbox"/> n78	


*Figure 8-8 NTC-550 Series network band selection*

To setup a device for different LTE, 5G non-standalone (5G NR NSA) and 5G Standalone (5G NR SA) modes, refer to [Appendix A – Configuring Radio Access Technologies](#)

Once you select the bands, click **Save** to save and apply the settings.

## Operator selection


The Operator selection page allows you to set how the NTC-550 Series router selects the operator, whether automatically or manually. If you set it to manual, you can override and lock it to a particular carrier or access technology. The operator setting page also contains roaming controls. To access the Operator selection page, navigate to **Networking > Cellular settings > Operator selection**.



The screenshot shows the 'OPERATOR SELECTION' page. Under the 'OPERATOR SELECTION MODE' section, the 'Select operator mode' dropdown is set to 'automatic'. Below it, the 'Current operator registration' is 'Amarisoft / LTE'. There is a 'Scan' button. Under the 'ROAMING CONTROL' section, the 'Enable' toggle is set to 'On'. A 'Save' button is at the bottom.

Figure 8-9 Operator Selection page

## Operator selection mode



The screenshot shows the 'OPERATOR SELECTION' page. Under the 'OPERATOR SELECTION MODE' section, the 'Select operator mode' dropdown is set to 'manual'. Below it, the 'Current operator registration' is 'Amarisoft / LTE'. There is a 'Scan' button.

Figure 8-10 Operator selection mode

To scan for available networks, set the **Select operator mode** to **manual** and click **Scan** button. This operation can take a few minutes and requires that the packet data session be disconnected prior to scanning. A list of the detected service carriers in your area is displayed.

OPERATOR LIST					
	Operator name	MCC	MNC	Operator status	Network type
<input checked="" type="radio"/>	Amarisoft	001	01	current	4G LTE
<input type="radio"/>	airtel	404	49	forbidden	5G NR
<input type="radio"/>	Vi India	404	07	forbidden	4G LTE
<input type="radio"/>	JIO	405	854	forbidden	4G LTE

Figure 8-11 Operator list

Select the required service from the list and click **Save**.

When **Select operator mode** is set to **Automatic**, the router selects the most appropriate operator based on the inserted SIM card. This is the default option and is sufficient for most users.

### Roaming control

Roaming control allows roaming to be enabled or disabled on the NTC-550 Series router. Enable roaming by setting the **Enable** toggle to **On**, then click **Save**.

### ROAMING CONTROL

Enable  On  Off

Figure 8-12 Roaming control toggle

### Cell lock list

The Cell lock function allows you to specify a list of cells that the NTC-550 Series router will not deviate from. The cells are separated on the basis of LTE and NR5G networks. To access the Cell lock list page, navigate to **Networking > Cellular settings > Cell lock list**.

### CELL LOCK LIST

#### LTE CELL LOCK LIST

PCI	EARFCN

#### 5G NR CELL LOCK LIST

gNB PCI	SSB ARFCN	SCS	NR SA band

#### UNLOCK TIMER SETTING

Interval  0=disable, (60-65535) secs

Figure 8-13 Cell lock list

To add a cell to the LTE cell lock list:

1. Click **Add**, next to LTE Cell Lock List.

*Figure 8-14 LTE Cell lock settings*

2. Enter the **PCI** and **EARFCN** values of the cell that you want to lock.
3. Click **Save** button.

To add a cell to NR cell lock list:

1. Click **Add**, next to 5G NR Cell Lock List.
2. Enter the **gNB PCI**, **SSB ARFCN** values, select **SCS** value, and enter **NR SA band** value for the NR5G cell that you want to lock to.

*Figure 8-15 5G NR Cell lock settings*

3. Click **Save** button.

### Unlock Timer Setting

In the **Interval** field, enter duration in seconds for which a locked cell remains restricted before it is automatically unlocked.

### WAN profiles

The WAN profiles page allows you to configure and enable or disable connection profiles.

Each profile refers to a set of configuration items which are used by the router to activate a Packet Data Protocol (PDP) context. Under normal scenarios, you may have a single profile enabled. Multiple profiles can be used for simple fast switching of PDP settings such as APN or advanced networking configuration where multiple simultaneous PDP contexts may be required.

To access the WAN profiles page, navigate to **Networking > Cellular Settings > WAN profiles**.


## WAN PROFILES

Profile no.	Profile name	Status	APN	External SIM APN	e-SIM APN	IP passthrough	Map to LAN/VLAN	Default route
1		<input type="checkbox"/> On <input checked="" type="checkbox"/> Off	blank	blank	blank	<input type="checkbox"/> On <input checked="" type="checkbox"/> Off	bridge0 <input type="button" value="v"/>	<input checked="" type="radio"/>
2		<input type="checkbox"/> On <input checked="" type="checkbox"/> Off	ims	blank	blank	<input type="checkbox"/> On <input checked="" type="checkbox"/> Off	None <input type="button" value="v"/>	<input type="radio"/>
3		<input type="checkbox"/> On <input checked="" type="checkbox"/> Off	sos	blank	blank	<input type="checkbox"/> On <input checked="" type="checkbox"/> Off	None <input type="button" value="v"/>	<input type="radio"/>
4		<input type="checkbox"/> On <input checked="" type="checkbox"/> Off	blank	blank	blank	<input type="checkbox"/> On <input checked="" type="checkbox"/> Off	None <input type="button" value="v"/>	<input type="radio"/>
5		<input type="checkbox"/> On <input checked="" type="checkbox"/> Off	blank	blank	blank	<input type="checkbox"/> On <input checked="" type="checkbox"/> Off	None <input type="button" value="v"/>	<input type="radio"/>
6		<input type="checkbox"/> On <input checked="" type="checkbox"/> Off	blank	blank	blank	<input type="checkbox"/> On <input checked="" type="checkbox"/> Off	None <input type="button" value="v"/>	<input type="radio"/>

Figure 8-16 WAN profiles

Table 8-1 WAN profile parameters

Item	Description
Profile no.	Number of the profile.
Profile name	Name of the profile.
Status	Toggles the corresponding profile on or off. Only one profile may be turned on at any time.
APN	Displays one of the following values depending on the conditions: <ul style="list-style-type: none"> <li>• <b>APN configured for the active SIM</b> – When APN is configured for the active SIM</li> </ul>

Item	Description
	<ul style="list-style-type: none"> <li>• <b>APN picked by the module from the carrier configuration of the active SIM</b> – When APN is not configured for the active SIM and it is not registered with the network or it is registered with the network but the network does not assign an APN</li> <li>• <b>APN assigned by the network to the active SIM</b> – When APN is not configured for the active SIM and the SIM is registered with the network</li> </ul> <p> <b>Note:</b> <i>The APN assigned by the network and the APN picked by the module from the carrier configuration can be the same.</i></p>
External SIM APN	APN configured for the External SIM
e-SIM APN	APN configured for the e-SIM
IP passthrough	<p>Allows a downstream device, such as a router, to manage the connection. The downstream device connects to the Internet and receives a WAN IP address so that all Internet traffic is passed to the downstream device.</p> <p>Internet traffic is still terminated at the gateway (NTC-550 Series router) and passed through to a downstream device, so the carrier is still able to connect to the gateway.</p>
Map to LAN/VLAN	The LAN or VLAN that the profile is assigned to.
Default Route	Sets the profile as the default route for traffic.


### Connecting to the mobile broadband network

The NTC-550 Series router supports the configuration of up to six WAN profiles. These profiles allow you to configure the settings that the router will use to connect to the 5G/4G network and switch easily between different connection settings.

For advanced networking purposes, you may activate a maximum of two profiles simultaneously (dependent on network support). When activating two connection profiles, you should avoid selecting two profiles with the same APN as this can cause only one profile to connect. Similarly, activating two profiles which are both configured to automatically determine an APN can cause a conflict and result in neither profile establishing a connection. It is recommended that the two active connection profiles have differing, manually configured APNs to avoid connection issues and ensure smooth operation.

## Manually configuring a connection profile

To manually configure a connection profile:

1. Click  icon corresponding the profile that you wish to configure.
2. The Wireless WAN Profile Settings page is displayed.

### WIRELESS WAN PROFILE SETTINGS

#### PROFILE SETTINGS

Active SIM 1


Auto Enable  On  Off

Enable  On  Off

Name

APN

Username

Password  

Authentication type  ▼

PDP type  ▼

MTU size  576-1500 (blank: network MTU)

IP passthrough  On  Off

Allow admin access  On  Off

#### PROFILE ROUTING

You may route only particular traffic via this connection profile by specifying the network address and mask below of the destination network. Blank values will route all traffic via this profile. Please leave these settings blank if you are unsure.



Network address  ·  ·  ·

Network mask  ·  ·  ·

*Figure 8-17 Wireless WAN profile settings*

*Table 8-2 WWAN profiles – WWAN profile settings details*

Item	Description
Active SIM	Displays the SIM currently is use. <ul style="list-style-type: none"> <li>• 1 – External SIM (Removable SIM)</li> <li>• 2 – Internal SIM (e-SIM)</li> </ul>
Auto Enable	Set to <b>ON</b> to enable. It is enabled by default.

Item	Description
	<p>When you boot the router for the first time or perform a factory reset, <b>Auto Enable</b> allows the router to automatically enable the default profile for the active SIM and connect to the network via that profile.</p> <p>When <b>Auto Enable</b> is enabled for any one profile for a SIM, it is automatically enabled for all the profiles for that SIM.</p>
Enable	Set to <b>On</b> to enable the profile.
Name	The name of the profile for easy identification on the Wireless WAN profile page. This name is only used to identify the profile on the NTC-550 Series router
APN	Enter the APN (Access Point Name) for the corresponding profile.
Username	The username for the APN (if required).
Password	The password for the APN (if required).
Authentication type	The authentication type required by your provider. This can be set to <b>None</b> , <b>PAP</b> or <b>CHAP</b>
PDP Type	<p>Select the PDP type (IP protocol) to use for the connection.</p> <ul style="list-style-type: none"> <li>• <b>IPv4</b> – Sets a single stack IPv4 connection through which the NTC-550 Series router receives only IPV4 network and DNS addresses.</li> <li>• <b>IPv6</b> – Sets a single stack IPv6 connection through which the NTC-550 Series router receives only IPV6 network and DNS addresses.</li> </ul> <p> <b>Note:</b> Before selecting this PDP type, check with your carrier to confirm that single stack IPV6 connectivity is supported.</p> <ul style="list-style-type: none"> <li>• <b>IPv4v6</b> – Sets a dual stack connection allowing simultaneous IPV4 and IPV6 network connectivity. The NTC-550 Series router receives both IPv4 and IPV6 network and DNS addresses. This is the default <b>PDP type</b></li> </ul>
MTU size	<p>Enter the Maximum Transmission Unit size.</p> <p>This may be from 1 to 1500 bytes.</p>
IP passthrough	<p>Allows a downstream device, such as a router, to manage the connection. The downstream device connects to the Internet and receives a WAN IP address so that all Internet traffic is passed to the downstream device.</p> <p>Internet traffic is still terminated at the gateway (NTC-550 Series) and passed through to a downstream device, so the carrier is still able to connect to the gateway.</p>
Allow Admin Access	<p>Set to <b>On</b>, if you want to allow remote SSH, TR-069, and WebGUI access to the device via this Wireless WAN profile.</p> <p> <b>Note:</b> SSH/HTTP/HTTPS can be individually restricted in the <b>Access Control</b> menu. Note also that this will automatically be enabled if the profile is selected in the <b>TR-069 settings</b> menu.</p>

Item	Description
<b>Profile Routing</b> (See the Profile Routing section below)	
Network address	Enter network address of the remote network.
Network mask	Enter the network mask of the remote network.

### Profile routing

For advanced networking, such as use of dual simultaneous PDP contexts, you can configure a particular profile to route only certain traffic via that profile using the network address and network mask of the destination network. In the Profile Routing section, enter the **Network address** and **Network mask** of the destination network. If you do not want to use this feature, or are unsure, please leave these fields blank. This will route all traffic via this profile.

### 5G network slicing

The 5G Network Slicing page allows to perform network slice configuration. To access the 5G network slicing page, navigate to **Networking > Cellular settings > 5G network slicing**.




Figure 8-18 5G Network slicing page

You can perform automatic or manual network slice configuration.

#### Automatic Network Slice Configuration

To perform automatic network slice configuration:

1. Set **Slice configuration** to **Automatic**.
2. Set **Multi-slice support** to **On** or **Off**.
3. Click **Apply**

In the case **Multi-slice support** is set to **Off**, the below success message displays.

Success!  
Your configuration changes were successfully saved and applied

In the case **Multi-slice support** is set to **On**, the below success message and settings display.

Success!

Your configuration changes were successfully saved and applied

---

### 5G NETWORK SLICING

Slice configuration Automatic ▼

Muti-slice support On Off

#### ROUTE SELECTION POLICY

Number of policies with traffic descriptor 0

Select policy to display  ▼

#### TRAFFIC DESCRIPTOR INFORMATION

#### PDU SESSION PARAMETER

Apply

### Manual Network Slice configuration

To perform manual network slice configuration:

1. Set **Slice configuration** to **Manual** in the 5G Network Slicing page.

### 5G NETWORK SLICING

Slice configuration Manual ▼

#### URSP CONFIGURATION

+ Add

Rule DNN	Rule priority	No. of route selection descriptors

Clear
Apply

*Figure 8-19 Manual Network Slicing*

2. Click **Add** for URSP Configuration, then click **Add** for Route Selection Descriptor. The below settings display.

### 5G NETWORK SLICING

#### TRAFFIC DESCRIPTOR

Rule DNN

Rule priority  (1-255)

#### ROUTE SELECTION DESCRIPTOR

S-NSSAI SST  0-255, text or 2 hex chars(1:EMBB, 2:URLLC, 3:MIOT, 4:V2X)

S-NSSAI SD  optional (append 6 hex characters to SST, eg.00 00 00)

SSC mode  ▼

PDU session type  ▼

RSD priority  (0-255)

*Figure 8-20 Manual Network Slicing Configuration*

*Table 8-3 Manual Network Slicing Configuration details*

Item	Description
<b>Traffic Descriptor</b>	
Rule DNN	Enter the Data Network Name. It identifies the external data network (e.g., "internet" or an enterprise APN) that a PDU session should connect to.
Rule priority	Enter a number from 1 to 255. It Determines the order in which URSP rules are evaluated (lower number = higher priority)
<b>Route Selection Descriptor</b>	
S-NSSAI SST	Enter the required value. Single-Network Slice Selection Assistance Information SST (Slice/Service Type) indicates the category or type of service the slice is intended to provide.
S-NSSAI SD	Enter the required value. Single-Network Slice Selection Assistance Information SD (Slice Differentiator) complements the mandatory SST (Slice/Service Type) to further differentiate between multiple network slices that share the same SST value.
SSC mode	Select a mode. Options are: <ul style="list-style-type: none"> <li>• <b>URSP_SSC_MODE_1</b>: The network preserves the UE's connectivity and retains the same IP address throughout the session.</li> <li>• <b>URSP_SSC_MODE_2</b>: The network may release the PDU session and re-establish a new session, possibly assigning a new IP address.</li> </ul>

Item	Description
	<ul style="list-style-type: none"> <li>• <b>URSP_SSC_MODE_3</b>: The network allows the PDU Session Anchor (PSA) to be relocated while the session remains active, which can result in the IP address being changed.</li> </ul>
PDU session type	Select an option. It specifies the kind of data connectivity established between a user device (UE) and the data network (DN) for a given PDU (Packet Data Unit) session. Options are: <ul style="list-style-type: none"> <li>• <b>PDU_IPV4</b></li> <li>• <b>PDU_IPV6</b></li> <li>• <b>PDU_IPV4V6</b></li> </ul>
RSD priority	Enter a number from 0 to 255. It refers to the order in which Route Selection Descriptors (RSDs) are evaluated within a UE Route Selection Policy (URSP) rule.

3. Click **Save** to save and apply the settings. The above configuration is added to Route Selection Descriptor.

Success!

Your configuration changes were successfully saved and applied

---

### 5G NETWORK SLICING

#### TRAFFIC DESCRIPTOR

Rule DNN

Rule priority  (1-255)

#### ROUTE SELECTION DESCRIPTOR + Add

S-NSSAI	SSC mode	PDU session type	RSD priority	
EMBBFFFFFF	URSP_SSC_MODE_1	PDU_IPV4	1	<input style="width: 20px; height: 20px; border: 1px solid #ccc;" type="text" value="✎"/> <input style="width: 20px; height: 20px; border: 1px solid #ccc;" type="text" value="✕"/>

Save
Cancel

*Figure 8-21 Route Selection Descriptor*

4. Click  icon to edit the Route Selection Descriptor, click  icon to delete it.
5. Click **Save** to save the configuration. The configuration displays in the URSP Configuration.

5G NETWORK SLICING

Slice configuration Manual

URSP CONFIGURATION + Add

Rule DNN	Rule priority	No. of route selection descriptors
MyDNN	1	1

Clear Apply

Figure 8-22 URSP Configuration

6. Click icon to edit that URSP configuration, click to delete it.

### Service assurance

Service assurance allows you to run a number of tests to confirm connectivity on different WWAN profiles. To access the Service assurance page, navigate to **Networking > Cellular settings > Service assurance**.

SERVICE ASSURANCE

Here you can perform a network connectivity status check. Select the WWAN profile below to check.

WWAN profile(s) 1

Enter the addresses and parameters in the fields below to perform the test. Fields left empty will result in the respective tests being skipped.

Domain name for DNS test

Destination for ping test

URL for web test

Request method in web test GET

Start

RESULT

Status

Progress stage

Error

Figure 8-23 Service assurance page

To run a service assurance test:

1. In the **WWAN profiles** field select the WWAN profile you wish to test.
2. In the **Domain name for DNS test** field enter a Domain name to check the DNS connectivity.
3. In the **Destination for ping test** field enter an IPv4 IP address to test the ping.
4. In the **URL for web test** field enter a full URL to test a web page download.
5. In the **Request method in web test** dropdown, select either **GET** or **PUT** as the request method.
6. Press the **Start** button to run the test.

In the Results section, the **Status** for a successful test will show **Passed**, a failed test will show **Failed** and which test failed.

## LAN Settings

### LAN

The **LAN Configuration** page allows you to configure the LAN settings of the NTC-550 Series router. To access the LAN configuration page, go to **Networking > LAN settings > LAN**.

The default IP of the LAN port is 192.168.1.1 with subnet mask 255.255.255.0. To change the IP address, Subnet mask or Hostname enter the appropriate value into the respective field and select the **Save** button.

**Note:** If you change the IP address, remember to refresh the Ethernet interface of your device, or set an appropriate IP address range, then enter the new IP address into your browser address bar to access the NTC-550 Series router.



The screenshot shows the LAN Configuration page with the following fields and controls:

- IP address:** Four input boxes containing the values 192, 168, 1, and 1.
- Subnet mask:** Four input boxes containing the values 255, 255, 255, and 0.
- Hostname:** A text input box containing the value "my.router".
- DNS masquerading:** A toggle switch currently set to "Off".
- Save:** A button at the bottom of the form.

Figure 8-24 LAN configuration

### DNS masquerading

DNS masquerading allows the device to proxy DNS requests from LAN clients to dynamically assigned DNS servers. When enabled, clients on the local LAN network can use the router as a DNS server without needing to know the dynamically assigned cellular network DNS servers.

The DNS masquerading toggle key is **OFF** by default.

With DNS masquerading OFF, the DHCP server hands out the upstream cellular DNS server IP addresses to downstream clients directly, so that downstream clients can send DNS requests directly to the upstream DNS servers without being proxied by the NTC-550 Series router.

With DNS masquerading ON, the DHCP server embedded in the NTC-550 Series router hands out its own IP address (e.g., 192.168.1.1) as the DNS server address to LAN clients. The downstream clients then send DNS requests to the NTC-550 Series router, which proxies them to the upstream DNS servers.

You may also override the DNS Masquerading option by specifying custom DNS Server IP addresses in the DNS server configuration, detailed in [DHCP](#) section. In this case the DHCP server assigns downstream devices the manually configured addresses and the DNS Masquerading option is ignored.

## DHCP

The DHCP configuration page is used to configure the DHCP settings of the NTC-550 Series router. You can manually set the IP address range, the lease time of the assigned address, the default domain name suffix, primary and secondary DNS server, the primary and secondary WINS server, as well as the advanced DHCP settings such as NTP, TFTP and Option 150/Option 160 (VoIP options). To access the DHCP page, navigate to **Networking > Cellular settings > DHCP**.

**DHCP**

**DHCP CONFIGURATION**

DHCP  On  Off

DHCP start range  ·  ·  ·

DHCP end range  ·  ·  ·

DHCP lease time (seconds)  (120~86400)

Default domain name suffix

DNS server 1 IP address  ·  ·  ·

DNS server 2 IP address  ·  ·  ·

WINS server 1 IP address  ·  ·  ·

WINS server 2 IP address  ·  ·  ·

NTP server (option 42)  ·  ·  ·

TFTP server (option 66)

DHCP option 150  ·  ·  ·

DHCP option 160

**DYNAMIC DHCP CLIENT LIST**

Computer name	MAC address	IP address	Expiry time

**ADDRESS RESERVATION LIST**

Computer name	MAC address	IP address	Enable


Figure 8-25 DHCP configuration

Table 8-4 DHCP configuration details

Item	Description
DHCP start range	Sets the first IP address of the DHCP range
DHCP end range	Sets the last IP address of the DHCP range
DHCP lease time (seconds)	The duration in seconds that DHCP allocated IP addresses are valid.
Default domain name suffix	Specifies the default domain name suffix for the DHCP clients. A domain name suffix enables users to access a local server, for example, server1, without typing the full domain name server1.domain.com
DNS server 1 IP address	Specifies the primary DNS (Domain Name System) server's IP address.
DNS server 2 IP address	Specifies the secondary DNS (Domain Name System) server's IP address.
WINS server 1 IP address	Specifies the primary WINS (Windows Internet Name Service) server's IP address
WINS server 2 IP address	Specifies the secondary WINS (Windows Internet Name Service) server's IP address
NTP server (Option 42)	Specifies the IP address of the NTP (Network Time Protocol) server
TFTP Server (Option 66)	Specifies the TFTP (Trivial File Transfer Protocol) server
DHCP option 150	This is used to configure Cisco IP phones. When a Cisco IP phone starts, if it is not pre-configured with the IP address and TFTP address, it sends a request to the DHCP server to obtain this information. Specify the string which will be sent as a reply to the option 150 request.
DHCP option 160	This is used to configure Polycom IP phones. When a Polycom IP phone starts, if it is not pre-configured with the IP address and TFTP address, it sends a request to the DHCP server to obtain this information. Specify the string which will be sent as a reply to the option 160 request.

Click **Save** to save and apply the settings.

### Dynamic DHCP client list

The Dynamic DHCP Client List displays a list of the DHCP clients that have been allocated IP addresses. If you want to reserve the current IP address for a particular device, click clone  icon corresponding to the device details. The device details are added to the Address Reservation List.


DYNAMIC DHCP CLIENT LIST			
Computer name	MAC address	IP address	Expiry time
		192.168.1.191	Wed Apr 1 21:11:02 AEDT 2026 

Figure 8-26 Dynamic DHCP client list

## Address Reservation List

The Address Reservation List displays the list of DHCP clients whose IP address has been reserved and add devices to the list by reserving their IP address.

*Figure 8-27 Address reservation list*

Computer name	MAC address	IP address	Enable
		192.168.1.100	1

To add a device to the address reservation list:

1. Select the **+Add** button. The Static DHCP page appears.

**DHCP**

**STATIC DHCP**

Computer name

MAC address



IP address  ·  ·  ·

Enable  On  Off

*Figure 8-28 Adding device to Address reservation list*

2. In the **Computer name** field enter a name for the device.
3. In the **MAC address** field, enter the device's MAC address.
4. In the **IP address** field, enter the IP address that you wish to reserve for the device.
5. Set the **Enable** toggle to **On** to enable the setting.
6. Select the **Save** button to save the settings.

The device is added to the Address Reservation List.

Click **Edit**  icon to edit the details of that device and  icon to delete that device from the Address Reservation List.

## VLAN

A Virtual Local Area Network (VLAN) is a subnetwork used to group devices located on separate physical networks. This is useful since it allows you to partition your network without the need for additional cabling or wireless access. To access the VLAN page, navigate to **Networking > Cellular settings > VLAN**.

In VLAN Configuration section, set **Enable** to **On** to enable VLAN.

**VLAN**

Configuring VLAN rules may cause your device to reboot.

Device will reboot when going from zero to one or more enabled VLANs, and the reverse. The reboot will take a few minutes, during which you won't be able to access your device.

**VLAN CONFIGURATION**

Enable  On  Off

Save

**VLAN RULES** [+ Add](#)

Name	Interface	Address	Subnet mask	DHCP range	DHCP	Allow admin access	Enabled

*Figure 8-29 VLAN*

### VLAN Settings

To create a VLAN:

1. Click **+Add** button on the VLAN Configuration page. The VLAN Settings display.

## VLAN

Configuring VLAN rules may cause your device to reboot.

Device will reboot when going from zero to one or more enabled VLANs, and the reverse. The reboot will take a few minutes, during which you won't be able to access your device.

### VLAN SETTINGS

Rule name

Interface eth0 ▼

VLAN ID  0~4094 (excl. 253, 254, 255)

IP address ...

Subnet mask ...

DHCP On Off

DHCP start range ...

DHCP end range ...

DHCP lease time (seconds)  (120~86400)

Allow admin access On Off

Enable On Off


Save
Cancel

**Figure 8-30 VLAN Settings**

2. In the **Rule name** field, enter a name for the VLAN rule. This is a name that allows you to easily identify the VLAN.
3. Set **Interface** to the physical Ethernet interface to which the VLAN configuration will be applied. Options are **eth0** and **eth1**.
4. In the **VLAN ID** field, enter a number between 0 and 4094 which will be used by the network to identify the VLAN uniquely.
5. In the **IP address** field, enter the IP address for this device on the VLAN.
6. In the **Subnet mask** field, enter the Subnet mask for the VLAN.
7. To use DHCP, set the **DHCP** to **On** position. Enter values for **DHCP start range** and **DHCP end range** fields. Addresses within this range will be automatically assigned to devices connecting to this VLAN.
8. In the **DHCP lease time (seconds)** field, enter the number of seconds for which the DHCP lease is valid. This value must be 120 or higher.
9. Set **Allow admin access** to **On** to allow remote SSH, TR-069, and WebGUI access to the device via this VLAN.
10. Set the **Enable** toggle to the **On** position to enable the configured VLAN
11. Click **Save** to save and apply the settings.

## Wi-Fi Settings

Wi-Fi settings allow you to configure Wi-Fi functionality of the NTC-550 Series router. To access Wi-Fi settings page, navigate to **Networking > Wi-Fi settings**.




*Figure 8-31 Wi-Fi configuration*

Click each section tab to display the fields in that section.

### Wi-Fi mode

Wi-Fi mode allows you to configure the Wi-Fi mode in which NTC-550 Series router should operate.



*Figure 8-32 Wi-Fi mode*

Select the required mode for the **Wi-Fi mode** field. The following Wi-Fi modes are available:

- **1 x 5GHz AP, 1 x 2.4GHz AP, 1 x Wi-Fi Client** - In this mode, the NTC-550 Series router will broadcast one 5GHz Wi-Fi network, one 2.4GHz network and will be able to connect to another Wi-Fi network to act as a WAN connection for the gateway.
- **2 x 5GHz AP, 1 x 2.4GHz AP** - In this mode, the NTC-550 Series router will broadcast two 5GHz Wi-Fi networks and one 2.4GHz Wi-Fi network.

Click **Save** to save and apply the setting.

## Access Point configuration

Both the 2.4 GHz and 5GHz access points provide the same configuration settings for their relevant band.

**2.4GHZ ACCESS POINT**

**WIRELESS SETUP (2.4GHZ)**

AP radio  On  Off

Country AU

Network mode 802.11b/g/n/ax mixed mode

Channel width selection 20MHz

Frequency (channel) AUTO Current channel: 11

**SSID AND SECURITY SETTINGS (2.4GHZ)**

SSID Lantronix-9224

Activate this SSID  On  Off

Broadcast SSID  On  Off

Wireless client isolation  On  Off

Network authentication WPA2-PSK

WPA pre-shared key .....

WPA group rekey interval 600 seconds

WPA encryption AES

Save

Figure 8-33 2.4GHz access point

### Wireless Setup

To configure the Wireless Setup of the access point:

1. Set the **AP radio** toggle to **On** to enable the access point.
2. The **Country** field is determined by MNC/MCC. It is read only.
3. Select the **Network mode** to the Wi-Fi version which should be broadcast. The default is 802.11b/g/n/ax mixed mode, which covers most modern devices.
4. Select the required value for **Channel Width** field. Lower channel widths will generally provide better stability in an environment with many other interfering Wi-Fi networks or with high levels of frequency interference.
5. Select the required value for **Frequency (channel)** field. The default is **Auto**, for which the router will analyse the surrounding networks and choose the most appropriate channel.
6. Click **Save** to save and apply the settings.

---

## SSID and security settings

To configure the SSID and security settings of the Wi-Fi access point:

1. Set the **SSID** (Wi-Fi name) of the network as required.
2. Set the **Activate this SSID** toggle to **On** to enable the SSID. If the toggle is set to off, clients will be unable to connect to the access point.
3. Set the **Broadcast SSID** toggle to **On** to broadcast the SSID and allow it to be seen by clients. If the toggle is set to **Off** the SSID will not appear in the list of networks for clients to connect.
4. Set the **Wireless client isolation** toggle to **On** to allow Wi-Fi clients to access the internet only via the Wi-Fi network. They will not be able to access other devices on the network. Set the toggle to **Off** to allow clients to find and connect to network resources connected to the NTC-550 Series router.
5. Select the **Network authentication** type. It determines the required level of security for the Wi-Fi network. Options are **Open**, **WPA2-PSK**, and **WPA3-SAE**. If you select **Open** any Wi-Fi device will be able to access the network, which may compromise the security of the router and any other connected devices.
6. Enter a value for **WPA shared key** field. This key should be used by Wi-Fi clients to connect to the network.
7. Enter a value for **WPA group rekey interval**. It is the number of seconds between WPA key rotations. The default is 600 seconds.
8. Set the **WPA encryption** field to either **AES** or **None**. Selecting none may reduce the security of the network key.
9. Click **Save** to save and apply the changes.

## Wi-Fi client

Wi-Fi client allows you to configure the NTC-550 Series router to connect an existing Wi-Fi network, enabling you to rebroadcast an internet connection via the NTC-550 Series router.

WI-FI CLIENT CONFIGURATION

Client radio  On  Off

Status State: Radio off

Auto roaming  On  Off

Short scan interval  seconds

Signal strength threshold  (dBm)

Long scan interval  seconds

Metric  0-65535

SSID to connect to

AP BSSID

Network authentication  ▼

WPA pre-shared key

WPA encryption  ▼

Figure 8-34 Wi-Fi Client

Table 8-5 Wireless Client Configuration Items

Item	Definition
Client radio	Set to <b>On</b> to enable.
Status	Displays the current channel and connection status of the wireless client.
Auto roaming	Set to <b>On</b> to enable. Auto roaming allows the router to scan for other access points with the same SSID at regular intervals to determine whether the signal

Item	Definition
	strength is below the Signal strength threshold and switch to an access point with a stronger signal if it is below the threshold at the time of the scan.
Short Scan Interval	Enter the time in seconds. The interval at which the router will scan all access points with the same SSID when the signal strength is below the Signal strength threshold.
Signal strength threshold	Enter the value. The signal strength value in dBm that determines whether the router should use the Short scan interval or the Long scan interval
Long scan interval	Enter the time in seconds. The interval at which the router will scan all access points with the same SSID when the signal strength is above the Signal strength threshold.
Metric	Enter the required value. It determines the priority of the interface. Lower value implies higher priority and vice versa.
SSID to connect to	Enter the SSID of the network you wish to connect to. Click <b>Scan</b> to discover nearby networks.
AP BSSID	Enter the BSSID or MAC address of the access point to which you are connecting.
Network authentication	Select type of authentication in use on the network from the available options.
WPA pre-shared key	Enter the pre-shared key required to join the wireless network.
WPA encryption	Select the type of encryption in use on the network.

Click **Save** to save and apply the settings.

*Figure 8-35 Wi-Fi Client status*

Status Channel: 4 State: Connected

## WAN Settings

WAN Settings allow you to configure the WAN port on the NTC-550 Series router.

### Interface assignment

The Interface assignment page allows you to configure the functionality of the WAN port or the virtual USB port. To access the Interface assignment page, navigate to **Networking > WAN settings > Interface assignment**.

### INTERFACE ASSIGNMENT

#### ETHERNET INTERFACE ASSIGNMENT


No.	Description	Name	Link status	MAC	Port	Configuration
1	2.5GE LAN/WAN	eth0	Up	D0:DB:B7:E6:51:DA	platform	WAN <input type="button" value="v"/>
2	USB	ecm0	Down	D0:DB:B7:E6:51:DB	virtual	LAN <input type="button" value="v"/>

*Figure 8-36 WAN Interface assignment*

Use the dropdown in the **Configuration** column to set the function of the port. Set the field to **LAN** for the port to function as a **LAN** port. Set the field to **WAN** for the port to function as a WAN port, which allows you to configure it as an incoming connection. Set the field to **Disable** to disable the port. Click **Save** to save and apply the settings.

## WAN configuration

WAN configuration allows you to configure the WAN connection. To access the WAN configuration page, navigate to **Networking > WAN settings > WAN configuration**.



The screenshot displays the 'WAN CONFIGURATION' page with the following settings:

- WAN connection:** eth0
- Connection type:** Static
- IP address:** 0.0.0.0
- Subnet mask:** 255.255.255.255
- Gateway:** 0.0.0.0
- DNS server 1 IP address:** 0.0.0.0
- DNS server 2 IP address:** 0.0.0.0

A blue 'Save' button is located at the bottom of the configuration form.

Figure 8-37 WAN configuration

To configure the WAN connection:

1. Set the **WAN connection** field as the ethernet interface you want to use for WAN connection.
2. Set the **Connection type** field to match the requirements of the WAN connection, either **DHCP** or **Static**.
3. If using **Static**, enter required values for the following fields:
  - **IP address**
  - **Subnet mask**
  - **Gateway**
  - **DNS server 1 IP address**
  - **DNS server 2 IP address**
4. Click **Save** to save and apply the changes.

## Failover

The failover page allows you to configure the priority of failover for WAN connections on the NTC-550 Series router. When multiple connections are active, one can be prioritised over another. The method by which the connection can be monitored can also be configured.

Figure 8-38 WAN Settings – Failover

### WAN FAILOVER

#### WAN INTERFACES

No.	WAN type	Interface	Monitor type	Host	Priority
1	Ethernet	eth0	Link	N/A	<span style="margin-right: 10px;">^</span> <span style="margin-right: 10px;">v</span> <span style="border: 1px solid #ccc; padding: 2px 5px;">✎</span>
2	Cellular	rmnet_data0	Link	N/A	<span style="margin-right: 10px;">^</span> <span style="margin-right: 10px;">v</span> <span style="border: 1px solid #ccc; padding: 2px 5px;">✎</span>


#### WAN CONFIGURATIONS

WAN interfaces can be activated and configured on the following pages.

- [WAN profiles](#)
- [Ethernet WAN](#)
- [Wi-Fi client configuration](#)

Save

Use the **Priority** arrows to move each connection to the appropriate position on the **Failover** table. The interface at the top will receive priority over the connections which follow it. When a connection becomes disconnected, the router will try to failover to the next connection.

Click  icon to manage the connection monitoring method.

## WAN FAILOVER

### FAILOVER CONFIGURATION

Monitoring method  ▼

Verbose logging  On  Off

First destination address

Second destination address

Periodic Ping timer  (3-65535) secs

Retry timer  (2-65535) secs

### CONSECUTIVE ERROR MONITOR

Consecutive error monitor  On  Off

Failover fail count  (3-65535) times

Failback success count  (3-65535) times

### PERIODIC RATIO MONITOR

Periodic ratio monitor  On  Off

Monitor total count  (3-65535) times

Failover fail count  (3-65535) times

Failback success count  (3-65535) times

*Figure 8-39 WAN Failover configuration*

### Monitoring Methods

The following methods are available:

- **Physical link:** If the monitoring method is set to Physical link, the failover mechanism is controlled by the physical detection of the link. When the physical link to eth.0 is broken (i.e. the cable is disconnected, or some other hardware fault causes the physical connection to fail), the router fails over to the WAN interface with the next highest priority.
- **Ping:** If the monitoring method is set to Ping, controlled ping packets can be used to determine the status of the link. These are small packets of data that the router sends to a remote address and if the connection is up, a reply is received. They are sent indefinitely at regular intervals that you specify. At each interval, a set of 3 pings are sent to the first destination address and 3 pings are sent to the second destination address configured for each WAN interface to test the availability of the interface.

## Methods of evaluating ping responses

The following methods are available:

- **Consecutive Error Monitor** - using this method, the router will determine the availability of an interface based on a set number of consecutive ping instance responses.
- **Periodic Ratio Monitor** - using this method, the router will determine the availability of an interface based on a set ratio of ping instance successes or failures to the number of attempts.

It should be noted that the Periodic ratio monitor evaluates an interface over a Series of ping instances (defined by the Total monitor count) and when the Series has completed, the success and fail counts are reset. For example, with the default Total monitor count value set to 10 and Failover fail count set to 5, the router sends 10 ping instances and if 4 of those instances fail and the first instance of the next Series of 10 fails, the router will not fail over because the 5 failed instances occurred across a different Series.

To simplify configuration, we recommend using only one of the monitor types at any point in time.

*Table 8-6 Ping Monitoring Configuration Items*

Item	Description
<b>Failover Configuration</b>	
Monitoring method	Select <b>Ping</b> .
Verbose logging	When enabled, this logs verbose comments in the system log related to the failover monitoring.
First destination address	Enter the first address that the router should ping in order to confirm the connection is up. This may be an IP address or a domain name.
Second destination address	Enter the second address that the router should ping in order to confirm the connection is up. This may be an IP address or a domain name.
Periodic Ping timer	Enter the time in seconds between ping attempts.
Retry timer	Enter the time in seconds between attempts when a ping failure occurs.
<b>Consecutive Error Monitor</b>	
Consecutive error monitor	Set to <b>On</b> to enable.
Failover fail count	Enter the number of failed pings that must occur before the monitor fails the connection over to the next interface.
Failback success count	Enter the number of successful pings that must occur before the monitor fails the connection back to the higher priority interface.
<b>Periodic Ratio Monitor</b>	
Periodic ratio monitor	Set to <b>On</b> to enable.
Monitor total count	Enter the series of pings to consider when calculating whether to fail over or fail back. When the series is completed, the router repeats the ping test and resets the Failover fail count/Failback success count. For the failover or failback ratio

Item	Description
	to be met, the number of Failover fail counts/Failback success counts must occur within a particular Series.
Failover fail count	Enter the number of failed ping results that must occur within a Series of pings configured in the Monitor total count before the router fails over to the next highest priority interface. For example, at the default setting of 5, the router fails over to the next interface when 5 out of 10 ping attempts in a particular Series have failed. The failures need not be consecutive to meet the failover criteria. If any 5 of the 10 pings in a Series have failed, the router deems the interface connection to be down and fails over.
Failback success count	Enter the number of ping successes that must be registered on a higher priority interface within a Series of pings configured in the Monitor total count before the router fails back to that interface.

Click **Save** to save and apply the settings.

## Routing settings

### Static routes

Static routing is used to facilitate communication between devices on different networks. Static routing involves configuring the routers in your network with all the information necessary to allow the packets to be forwarded to the correct destination. If you change the IP address of one of the devices in the static route, the route will be broken.

To access the Static routes page, navigate to **Networking > Routing settings > Static routes**.

STATIC ROUTES							
STATIC ROUTING LIST							
Route name	Destination	Netmask	Gateway	Interface	Metric		
<a href="#">+ Add</a>							
ACTIVE ROUTING LIST							
Destination	Gateway	Netmask	Flags	Metric	Ref	Use	Interface
192.168.1.0	0.0.0.0	255.255.255.0	U	0	0	0	bridge0

*Figure 8-40 Static routes*

### Adding Static Routes

To add a new static route, click **+Add** button, the Route Configuration page displays.

**STATIC ROUTES**

**ROUTE CONFIGURATION**

Route name

Destination IP address

Netmask

Gateway IP address

Network interface

Metric

*Figure 8-41 Route configuration*

1. In the **Route name** field, type a name for the route so that it can be identified in the static routing list.
2. In the **Destination IP address** field, enter the IP address of the destination of the route.
3. In the **Netmask** field, enter the subnet mask for the route. It defines the range of IP addresses to which the static route applies.
4. In the **Gateway IP address** field, enter the IP address of the gateway that will facilitate the route.
5. From the **Network interface** drop-down list, select the interface for which you would like to create a static route.
6. In the **Metric field** enter the metric for the route. The metric value is used by the router to prioritize routes. The lower the value, the higher the priority. To give the route the highest priority, set it to 0.
7. Click the **Save** to save and apply the settings.

The new static route is added to the Static Routing List.

**STATIC ROUTING LIST**

Route name	Destination	Netmask	Gateway	Interface	Metric
Myroute	192.168.1.10	255.255.255.0	192.168.1.1	auto	10

*Figure 8-42 Static routing list*

Click icon to edit the route and click icon to delete the route.

### Active Routing List

The Active routing list displays the routes added by the router by default, such as the Ethernet subnet route for routing to a device on the Ethernet subnet.

**ACTIVE ROUTING LIST**

Destination	Gateway	Netmask	Flags	Metric	Ref	Use	Interface
192.168.1.0	0.0.0.0	255.255.255.0	U	0	0	0	bridge0

*Figure 8-43 Active routing list*

## Firewall

The Firewall on the NTC-550 Series router implements an Intrusion Prevention System (IPS). The IPS works together with system firewalls, but in a different manner, to prevent unauthorised access to your network and potentially malicious attacks. It provides a few more levels of security protection for your system from external threats.

Firewalls are rules-based and allow or exclude broad ranges of traffic that do not meet the criteria. IPS monitors and analyses individual inbound data packets to identify threats. Be aware that an IPS should not be considered a replacement for a well-defined firewall but should be seen as one more defensive weapon in your network security arsenal: firewalls, anti-virus software, etc.

IPS filters are interposed between the firewall and the other NTC-550 Series router functionality. It uses a variety of sophisticated techniques to monitor traffic flows and analyse inbound packets to determine whether they constitute network threats and, if so, deny them access. The IPS firewall allows different levels of protection to be selectively applied, to thwart a specifically identified threat.

To access the Firewall page, navigate to Networking > Routing settings > Firewall

### IPS Firewall Settings

The screenshot shows the 'FIREWALL' configuration page with the 'IPS FIREWALL SETTINGS' section. The settings are as follows:

Setting	Value	Unit / Range
Enable IPS firewall	On	
Logging	On	
SYN flood defence	On	
SYN flood defence threshold	10	Packets/Second (10-10000)
Ping flood defence	On	
Ping flood defence threshold	10	Packets/Second (10-10000)
UDP flood defence	On	
UDP flood defence threshold	10	Packets/Second (10-10000)
IPV4 Ping Max Size (bytes)	512	Packets Size (0-65535)

A 'Save' button is located at the bottom of the settings area.

Figure 8-44 IPS Firewall Settings

The table below lists the IPS Firewall Settings configuration details.

*Table 8-7 IPS Firewall Settings Configuration details*

Item	Description
Enable IPS Firewall	Enables or disables IPS Firewall
Logging	Enables or disables logging of network activity.
SYN flood defense	Enables or disables SYN flood defense which restricts the number of SYN requests processed by the router during a given time frame. When enabled enter the number of packets/second. Default value is 10, range (10-10000)
Ping flood defense	Enables or disables Ping flood defense. When enabled enter the number of packets/second accepted. Default value is 10, range (10-10000)
UDP flood defense	Enables or disables UDP flood defense. When enabled enter the number of packets/second allowed from a single source. Default value is 10, range (10-10000)
IPV4 Ping Max Size (bytes)	Enables or disables IPV4 Ping Max Size which allows you set maximum size for an IPV4 packet. When enabled enter the maximum packet size. Default value is 512, range (0-65535)

Click **Save** to save and apply the settings.

## DMZ

The Demilitarized Zone (DMZ) allows you to configure all incoming traffic on all protocols to be forwarded to a selected device behind the router. This feature can be used to avoid complex port forwarding rules, but it exposes the device to untrusted networks as there is no filtering of what traffic is allowed and what is denied. The DMZ configuration page is used to specify the IP Address of the device to use as the DMZ host.

To access the DMZ page, navigate to **Networking > Routing settings > DMZ**.

*Figure 8-45 DMZ configuration*

To configure DMZ:

1. Set **Enable** to On.
2. Enter the WWAN profile number with which you want to associate the DMZ configuration.
3. Enter the IP Address of the device to be the DMZ host in the **DMZ IP Address** field.
4. Click **Save** to save and apply the settings.

## Port forwarding

Port forwarding allows you to map inbound requests to a specific port on the WAN IP address to any connected device. The Port forwarding list is used to configure the Network Address Translation (NAT) rules currently in effect on the NTC-550 Series router. To access the Port forwarding page, navigate to **Networking > Routing settings > Port forwarding**.



Name	Profile no.	Protocol	Public port	Local IP address	Local port	Enable

Figure 8-46 Port forwarding list

**Note:** Some carriers block inbound connections or require a public IP address to get inbound requests.

### Adding a port forwarding rule

To create a new port forwarding rule:

1. Click **+Add** button on the Port Forwarding List page. The Port Forwarding Settings page displays.






Figure 8-47 Port Forwarding Settings

2. In the **Rule name** field, enter a name for the rule so that it can be easily identified.
3. In the **Profile no.** field, enter the of the Wireless WAN Profile that you want to use for the rule.
4. Use the **Protocol** drop-down list to select the type of protocol you want to use for the rule. The protocols selections available are **TCP**, **UDP** and **TCP/UDP**.
5. In the **Public port** field, enter port number to use for the communication between the NTC-550 Series and the mobile network, range (1-65535)


6. In the **Local IP Address** field, enter the IP address of LAN equipment to which traffic should be routed or a wildcard IP address (0.0.0.0) that allows all IP addresses to access the traffic.
7. In the **Local port** field, enter the port number to use for traffic to the local device, range (1-65535).
8. Set the **Enable** toggle to **On** position.
9. Click **Save** to save and apply the settings.

The rule is added to the Port forwarding List.

To delete a port forwarding rule, click the  icon in the **Port forwarding list** for the rule you want to delete. To edit an existing rule, click the  icon for that rule.

## Filtering

The Filtering feature allows you to restrict devices that are allowed to connect to the NTC-550 Series router bases on their MAC address. To access the Filtering page, navigate to **Networking > Routing settings > Filtering**.



**FILTERING**

**MAC FILTERING**

Enable  On  Off

**MAC WHITELIST** + Add

Name	MAC address	Enable
------	-------------	--------

**MAC / IP / PORT FILTERING**

Enable  On  Off

Default rule (inbound/forward) Accepted

**MAC / IP / PORT FILTERING RULES IN EFFECT** + Add

Index	Protocol	Action	Comment
-------	----------	--------	---------

*Figure 8-48 Filtering*

To enable MAC filtering, set the **Enable** toggle to **On**, then click **Save**.

## MAC whitelist



To add a device to the MAC whitelist:

1. Click the **+Add** button in MAC Whitelist. The MAC whitelist settings page displays.

Figure 8-49 MAC whitelist settings

2. In the **Name** field, enter a name for the device.
3. In the **MAC address** field, enter the MAC address of the device.
4. Set the Enable toggle to **On**.
5. Click **Save** button.

The device displays in the **MAC Whitelist** section.

To remove a device, click the  icon for that device. To edit the device, including temporarily disabling it, click the  button.

## MAC / IP / Port filtering

The MAC/IP/Port filtering allows you to apply a policy to the traffic that passes through the router, both inbound and outbound, so that network access can be controlled. When the filter is enabled with a default rule of “Accepted”, all connections will be allowed except those listed in the “Current MAC / IP / Port filtering rules in effect” list. Conversely, when the default rule is set to “Dropped”, all connections are denied except for those listed in the filtering rules list.

Figure 8-50 Mac/Ip/Port Filtering



**Important:** When enabling MAC / IP / Port filtering and setting the default rule to “Dropped”, you should ensure that you have first added a filtering rule which allows at least one known MAC/IP to access the router, otherwise you will not be able to access the user interface of the router without resetting the router to factory default settings.

### Creating a MAC / IP / Port filtering rule

To create a filtering rule:



1. Set the **MAC / IP / Port** filtering toggle key to ON position.
2. Use the **Default rule (inbound/forward)** drop-down list to select the default action for the router to take when traffic reaches it. By default, this is configured to Accepted. If you change this to Dropped, you should first configure a filter rule that allows at least one device access to the router, otherwise you will effectively be locked out of the router.
3. Click the **Save** button to confirm the default rule.
4. In the Current MAC / IP / Port Filtering Rules in Effect section, click the **+Add** button. The Filter Settings display.

Figure 8-51 MAC/IP/Port Filter Settings

Table 8-8 MAC/IP/Port Filter Settings Configuration Details

Item	Description
Bound	Select the direction of traffic. The options available are: <ul style="list-style-type: none"> <li>• Inbound</li> <li>• Outbound</li> <li>• Forward</li> </ul>
Protocol	Select the protocol of the traffic. The options available are: <ul style="list-style-type: none"> <li>• All</li> <li>• UDP/TCP</li> <li>• UDP</li> <li>• TCP</li> <li>• ICMP</li> </ul>

Item	Description
MAC Address	Enter MAC Address of the source device.
Source IP address	Enter IP address of the source device.
Action	Select the action to be taken. The options available are: <ul style="list-style-type: none"> <li>• <b>Drop</b></li> <li>• <b>Accept</b></li> </ul>
Comment	Add comments for the rule


5. Click **Save** to save and apply the settings.
6. The new rule is displayed in the filtering rules list. To edit the rule, click the  icon and to delete the rule click the  icon.

## Redundancy (VRRP)

Virtual Router Redundancy Protocol (VRRP) is a non-proprietary redundancy protocol designed to increase the availability of the default gateway servicing hosts on the same subnet. This increased reliability is achieved by advertising a “virtual router” (an abstract representation of master and backup routers acting as a group) as a default gateway to the host(s) instead of one physical router. Two or more physical routers are then configured to stand for the virtual router, with only one doing the actual routing at any given time. If the current physical router that is routing the data on behalf of the virtual router fails, an arrangement is made for another physical router to automatically replace it. The physical router that is currently forwarding data on behalf of the virtual router is called the master router. Routers are given a priority of between 1 and 255 and the router with the highest priority is assigned as the master.

A virtual router must use 00-00-5E-00-01-XX as its (MAC) address. The last byte of the address (XX) is the Virtual Router Identifier (VRID), which is different for each virtual router in the network. This address is used by only one physical router at a time and is the only way that other physical routers can identify the master router within a virtual router.

To access the VRRP page, navigate to **Networking > Routing settings > VRRP**.



**VRRP**

**VRRP CONFIGURATION**

VRRP  On  Off

Virtual ID  (1-255)

Router priority  (1-255)

Virtual IP address  ·  ·  ·

**VRRP WAN WATCHDOG**

VRRP WAN watchdog  On  Off

**Save**

Figure 8-52 VRRP

## Configuring VRRP

To configure VRRP, configure multiple devices as follows and connect them together via an Ethernet network switch to downstream devices.

1. Set the **Redundancy (VRRP)** toggle to **On** to enable VRRP.
2. In the **Virtual ID** field, enter an ID between 1 and 255. This is the VRRP ID which is different for each virtual router on the network.
3. In the **Router priority** field, enter a value for the priority – a higher value is a higher priority.
4. The **Virtual IP address** field is used to specify the VRRP IP address – this is the virtual IP address that both virtual routers share.
5. Click **Save** button to apply the new settings.

**Note:** Configuring VRRP changes the MAC address of the Ethernet port which may interrupt the connection to the router. If you want to resume with the web configuration you must use the new IP address (VRRP IP) or clear the arp cache (old MAC address). On Windows, run the following command in command prompt:



```
arp -d <ip address> (i.e. arp -d 192.168.1.1)
```

## Configuring the VRRP WAN watchdog

The VRRP WAN watchdog is disabled by default. When it is disabled, VRRP WAN watchdog monitors the status of the master and slave by the physical link. When enabled, the VRRP WAN watchdog feature monitors the status of the connection by both the physical link and controlled ping packets.

### VRRP WAN WATCHDOG

VRRP WAN watchdog  On  Off

Verbose logging  On  Off

First destination address

Second destination address

Periodic Ping timer  (3-65535) secs

Retry timer  (2-65535) secs

### CONSECUTIVE ERROR MONITOR

Consecutive error monitor  On  Off

Failover fail count  (3-65535) times

Failback success count  (3-65535) times

### PERIODIC RATIO MONITOR

Periodic ratio monitor  On  Off

Monitor total count  (3-65535) times

Failover fail count  (3-65535) times

Failback success count  (3-65535) times

Figure 8-53 VRRP WAN Watchdog

The following table details each field on the VRRP WAN Watchdog page.

*Table 8-9 VRRP WAN Configuration details*

Parameter	Description
VRRP WAN Watchdog	Set to <b>On</b> to enable the watchdog.
Verbose logging	When enabled verbose comments are logged in the system log related to the failover monitoring.
First destination address	The first address the router that the router should ping to confirm the connection is up. This may be an IP address or a domain name.
Second destination address	The second address the router that the router should ping to confirm the connection is up. This may be an IP address or a domain name.
Periodic Ping timer	The time in seconds between ping attempts.
Retry timer	The time in seconds between attempts when a ping failure occurs.
<b>Consecutive error monitor</b>	
Consecutive Error Monitor	Set to <b>On</b> to enable the consecutive error monitor.  Using this method, the router will determine the availability of an interface based on a set number of consecutive ping instance responses.
Failover fail count	The number of failed pings that must occur before the monitor fails the connection over to the next interface.
Failback success count	The number of successful pings that must occur before the monitor fails the connection back to the higher priority interface.
<b>Periodic ratio monitor</b>	
Periodic ratio monitor	Set to <b>On</b> to enable the Periodic ratio monitor.  Using this method, the router will determine the availability of an interface based on a set ratio of ping instance successes or failures to the number of attempts.
Monitor total count	This field specifies a series of pings to consider when calculating whether to fail over or fail back. When the series is completed, the router repeats the ping test and resets the Failover fail count/Failback success count. Therefore, for the failover or failback ratio to be met, the number of Failover fail counts/Failback success counts must occur within a particular Series.
Failover fail count	This field specifies the number of failed ping results that must occur within a series of pings configured in the Monitor total count before the router fails over to the next highest priority interface. For example, at the default setting of 5, the router fails over to the next interface when 5 out of 10 ping attempts in a particular Series have failed. The failures need not be consecutive to meet the failover criteria. If any 5 of the 10 pings in a Series have failed, the router deems the interface connection to be down and fails over.

Parameter	Description
Failback success count	Like the Failover fail count field, this field specifies the number of ping successes that must be registered on a higher priority interface within a Series of pings configured in the Monitor total count before the router fails back to that interface.


Click **Save** to save and apply the settings.

## RIP

RIP (Routing Information Protocol) is used for advertising routes to other routers. By enabling RIP all the routes in the router's routing table will be advertised to other nearby routers. For example, the route for the router's Ethernet subnet could be advertised to a router on the PPP interface side so that a router on this network will know how to route to a device on the router's Ethernet subnet. Static routes must be added manually according to your requirements. See Adding Static Routes for more information.

To access the RIP page, navigate to **Networking > Routing settings > RIP**.

*Figure 8-54 RIP configuration*

 **Note:** Other routers may ignore RIP.

To enable Routing Information Protocol (RIP)

1. Set the **RIP** toggle to **On** to enable RIP.
2. Using the **Version** drop-down list, select the version of RIP to use.
3. Select the **Interface** that RIP should apply on. Options are **LAN**, **WWAN** or **Both**.
4. If you want to turn on authentication, toggle the **Authentication** toggle key to the **ON** position. Use the Authentication type drop-down list to select the method of authentication then enter password in the Password field.
5. Click **Save** to save and apply the settings.


## VPN settings

### IPSec

IPSec operates on Layer 3 of the OSI model and can protect higher layered protocols. IPSec is used for both Site-to-Site VPN and Remote Access VPN. The NTC-550 Series router supports IPSec end points and can be configured with Site-to-Site VPN tunnels for third party VPN routers.

To access the IPSec page, navigate to **Networking > VPN settings > IPSec**.

*Figure 8-55 VPN – IPSec*



The screenshot shows the IPSec configuration page. At the top, there is a header "IPSEC" in orange. Below it, the title "IPSEC TUNNEL LIST" is displayed in blue. To the right of the title is a blue button with a white plus sign and the text "+ Add". Below the title and button is a table with the following columns: "#", "Name", "Remote LAN address/mask", "Remote gateway", "Local LAN address/mask", and "Enable". The table is currently empty.

#	Name	Remote LAN address/mask	Remote gateway	Local LAN address/mask	Enable
---	------	-------------------------	----------------	------------------------	--------

### Configuring an IPSec VPN

Click the **+Add** button to begin configuring an IPSec VPN connection.

## IPSEC

### IPSEC PROFILE EDIT

IPSec profile  On  Off

Profile name

### PHASE 1 PARAMETERS

Remote IPSec address

Key mode

Pre-shared key

Remote ID  (xy.sample.com or blank)

Local ID  (xy.sample.com or blank)

IKE version

IKE mode

IKE encryption

IKE hash

DH group

IKE re-key time  (0-78400, 0=Unlimited) secs

DPD action

DPD keep alive time  secs

DPD timeout  secs

SA life time  (0-78400, 0=Unlimited) secs

### PHASE 2 PARAMETERS

Remote LAN address  ·  ·  ·

Remote LAN subnet mask  ·  ·  ·

Local LAN address  ·  ·  ·

Local LAN subnet mask  ·  ·  ·

Encapsulation type

IPSec encryption

IPSec hash

**Figure 8-56 IPSec Profile Edit**

The following table describes each of the fields of the IPsec VPN configuration page.

*Table 8-10 IPsec configuration details*

Parameter	Description
IPsec profile	Enables or disables the VPN profile.
Profile name	A name used to identify the VPN connection profile.
<b>Phase 1 parameters</b>	
Remote IPsec address	The IP address or domain name of the IPsec server.
Key mode	Select the type of key mode in use for the VPN connection. You can select from: <ul style="list-style-type: none"> <li>• <b>Pre-Shared Keys</b></li> <li>• <b>RSA keys</b></li> <li>• <b>Certificates</b></li> <li>• <b>SCEP client</b></li> </ul>
Pre-shared key	The pre-shared key is the key that peers use to authenticate each other for Internet Key Exchange. The pre-shared key must meet the requirements for a strong password. See the Configuring a strong password section. This field appears if Pre-shared keys is used as the key mode.
Remote ID	Remote ID of the connection. Refer to the documentation of the remote IPsec server for further details. This field may be left blank.
Local ID	Local ID of the connection. Refer to the documentation of the remote IPsec server for further details. This field may be left blank.
Local RSA key upload	Upload the Local RSA key if RSA Keys is used as the Key mode.
Remote RSA key upload	Upload the Remote RSA key if RSA Keys is used as the Key mode.
Private key passphrase	The Private key passphrase is required if Certificates is used as the Key mode.
Key / Certificate	Select the Key / Certificate type for the IPsec connection if Certificates is used as the Key mode.
IPsec certificate upload	Upload the IPsec certificate if Certificates is used as the Key mode.
SCEP remote id	Enter the SCEP remote ID if SCEP client is used as the Key mode.
IKE version	Set the IKE version for the connection. There are two options available <b>IKE V1</b> and <b>IKE V2</b> .
IKE mode	Set the IKE mode for the connection. There are three options <b>Any</b> , <b>Main</b> and <b>Aggressive</b> .
IKE encryption	Select the cipher type to use for the Internet Key Exchange.
IKE hash	Select the IKE Hash type to use for the VPN connection. The hash is used for authentication of packets for the key exchange.

Parameter	Description
DH group	Select the desired Diffie-Hellman group to use. Higher groups are more secure but also require longer to generate a key.
IKE re-key time	Enter the time in seconds between changes of the encryption key. To disable changing the key, set this to 0.
DPD action	Select the required Dead Peer Detection action. This is the action to take when a dead Internet Key Exchange Peer is detected.
DPD keep alive time	Enter the time in seconds for the interval between Dead Peer Detection keep alive messages.
DPD timeout	Enter the time in seconds of no response from a peer before Dead Peer Detection times out.
SA life time	Enter the time in seconds for the security association lifetime.
<b>Phase 2 parameters</b>	
Remote LAN address	Enter the IP address of the remote network for use on the VPN connection.
Remote LAN subnet mask	Enter the subnet mask in use on the remote network.
Local LAN address	Enter the IP address of the local network for use on the VPN connection.
Local LAN subnet mask	Enter the subnet mask in use on the local network.
Encapsulation type	Select the encapsulation protocol to use with the VPN connection. You can choose <b>ESP</b> , <b>AH</b> or <b>Any</b> .
IPSec encryption	Select the IPSec encryption type to use with the VPN connection.
IPSec hash	Select the IPSec hash type to use for the VPN connection. The hash is used for authentication of packets for the VPN connection.

Click **Save** to save and apply the settings.

## OpenVPN

OpenVPN is an open-source virtual private network (VPN) program for creating point-to-point or server-to-multi-client encrypted tunnels between host computers. It can traverse network address translation (NAT) and firewalls and allows authentication by certificate, pre-shared key or username and password. OpenVPN works well through proxy servers and can run over TCP and UDP transports. Support for OpenVPN is available on most operating systems, including Windows, Linux, macOS, Solaris, OpenBSD, FreeBSD, NetBSD and QNX.

To access the OpenVPN page, navigate to **Networking > VPN settings > OpenVPN**.





Figure 8-57 OpenVPN

### Configuring an OpenVPN Server

To add an OpenVPN server, select the **+Add** button to the right of the OpenVPN Server List heading. Each time the **+Add** button is clicked, the router checks if there are existing server certificates. If no server certificate is found, you are prompted to generate a certificate before configuring the OpenVPN server.



Click **OK** button, the Server Certificate page displays. For more information on generating server certificates, refer to the [Server Certificate](#) section of this guide. When you have created the certificate, return to the OpenVPN server configuration page to continue the setup.


To configure an OpenVPN server:

1. Set the **OpenVPN profile** toggle key to **ON** position.
2. In the **Profile name** field, enter a name for the OpenVPN server profile you are creating.
3. In the **Type** field, select the OpenVPN connection type (**TUN/TAP**). Default is **TUN**.
4. In the **Port type** field, select a packet type to use for your OpenVPN Server and in the **Server port** field, enter a port number. The default OpenVPN port is 1194 and default packet type is UDP.
5. In the **Encryption cipher** field, select the encryption type for the connection. The default is **AES-256** as this is the strongest encryption level.
6. Enter a maximum transmission unit value into the **MTU** field. The default is 1500.
7. In the **VPN network address** and **VPN network subnet mask** fields, enter the IP address and network subnet mask to assign to your VPN. This is ideally an internal IP address which differs from your existing address scheme.

8. The Server certificates section displays the details of the certificate. If you wish to change the certificate, click the **Change** button.
9. HMAC or Hash-based Message Authentication Code is a means for calculating a message authentication code using a cryptographic hash function and a cryptographic key. If you wish to use the HMAC signature as an additional key and level of security, under the SSL/TLS handshake section, set the **Use HMAC Signature** toggle key to **On** position, then click the **Generate** button so that the router can randomly generate the key. The **Server key timestamp** field is updated with the time that the key was generated. Click the **Download** button to download the key file so that it can be uploaded on the client.
10. Select an **Authentication type**. Authentication may be done using a Certificate or Username / Password. See the below sections for information on each of the certificate types.

### Certificate authentication

In the Authentication Type section select **Authentication type** as **Certificate**. Enter the required details to create a client certificate. All fields are required. After filling out the required fields, click **Generate** button.




The screenshot shows a web form titled "AUTHENTICATION TYPE". It features a dropdown menu for "Authentication type" set to "Certificate". Below it is another dropdown for "Certificate" set to "New...". The form contains several text input fields: "Name", "Country", "State", "City", "Organisation", and "Email". At the bottom, there are six buttons: "Generate" (blue), "Revoke" (grey), "Download P12" (grey), "Download TGZ" (grey), "Save" (grey), and "Cancel" (blue).


*Figure 8-58 OpenVPN Certificate Authentication*

Once the certificate is generated, click **Download P12** button or **Download TGZ** button to save the certificate file, depending on which format you would like. If for some reason the integrity of your network has been compromised, return to this screen, use the Certificate drop-down list to select the certificate and then select the Revoke button to make the certificate invalid.

## Username / Password Authentication

In the Username/Password section, enter the username and password you would like to use for authentication on the OpenVPN Server. Click the **Download CA certificate** or **Download CA TGZ** depending on file format to save the ca.crt file. This file will need to be provided to the client.

 **Note:** If you wish to have more than one client connect to this OpenVPN server, you must use Certificate authentication mode as Username/Password only allows for a single client connection.



The screenshot shows a configuration window titled "AUTHENTICATION TYPE". At the top, there is a dropdown menu for "Authentication type" currently set to "Username / Password". Below this are two input fields: "Username" and "Password". The "Password" field has a small eye icon to its right, indicating it can be toggled between visible and hidden. Under the "Password" field are two blue buttons: "Download CA TGZ" and "Download CA certificate". Below these are two rows of four input boxes each, labeled "Remote network address" and "Remote network subnetmask". Under the "Remote network subnetmask" row is a blue button labeled "Set network information". At the bottom of the form are two blue buttons: "Save" and "Cancel".

Figure 8-59 OpenVPN Username / Password Authentication

**Optional:** To inform the OpenVPN server of the network address scheme of the currently selected certificate, enter the network address and network subnet mask in the respective fields and click the **Set Network Information** button. If you do not enter the remote subnet here, any packet requests from the server to the client will not be received by the client network because it is not aware of the remote client's subnet.

When you have finished entering all the required information, click **Save** to save the settings and finish configuring the OpenVPN server.

## Configuring an OpenVPN client

To configure and Open VPN client:

1. In the OpenVPN page click the **+Add** button in the **OpenVPN Client List** section. The OpenVPN Client Edit page displays

*Figure 8-60 OpenVPN client edit*

2. Set the **OpenVPN profile** toggle key to the **On** position.
3. In the **Profile name** field, enter a name for the OpenVPN client profile you are creating.
4. In the **VPN network address** field, enter the WAN IP address / host domain name of the OpenVPN server.
5. Select **Type (TUN/TAP)**. Default is **TUN**.
6. In the **Server port** field enter a port number and for **Encryption cipher** select a packet type to use for the OpenVPN server. The default OpenVPN port is 1194 and default packet type is UDP.
7. Enter a maximum transmission unit value in the **MTU** field.
8. If the **Default gateway** option is applied on the OpenVPN client page, the OpenVPN server will enable connections to be made to other client networks connected to it. If it is not selected, the OpenVPN connection allows for secure communication links between this router and the remote OpenVPN server only.
9. Select the **Authentication type** to use for the OpenVPN client. The available options are **Certificate**, **Username and Password**, or **Combination Certificate and Username / Password**. See the below sections to understand the different authentication types.

## Certificate Authentication

To use Certificate Authentication:

1. Set the **Authentication Type** field to **Certificate**.
2. Scroll down to the **Select certificate to upload** field and click **Choose a file** button.

*Figure 8-61 OpenVPN client Certificate upload*

Select certificate to upload  Not uploaded

3. Locate the certificate on your computer, click **Open**, then click **Install**.
4. Once the certificate is uploaded, click the **Save** button to confirm the connection.

## Username / Password Authentication

To use Username / Password Authentication:

1. Set the **Authentication Type** field to **Username / Password**.

**USERNAME / PASSWORD**

Username

Password

**CA UPLOAD**

Select certificate to upload  Not uploaded

*Figure 8-62 OpenVPN client Username / Password Authentication*

2. In the **Username** field, enter the username of the OpenVPN server.
3. In the **Password** field, enter the password of the OpenVPN server.
4. Click **Choose a file** button to locate the CA certificate file you saved from the OpenVPN Server and then click the **Upload** button.
5. If you have an additional SSL/TLS key created on the server, set the **Use HMAC Signature** toggle key to **ON** position. Click **Choose a file** button then locate the key file on your computer. Click the **Upload** button to upload it to the router.
6. Click **Save** to confirm the connection.

## Certificate and Username / Password authentication

The Certificate and Username / Password Authentication option is a combination of both the Certificate and Username / Password authentication methods. This provides additional levels of security since the client must know the username / password combination and be in possession of the certificate. Set the **Authentication type** to **Certificate and Username / Password Authentication**, then follow the instructions in both the above sections to complete the configuration.

---

### Configuring an OpenVPN P2P Connection

The OpenVPN P2P connection allows you to create a Peer-to-peer VPN connection with another router. One router should be the primary router, and the other router should be a secondary router.

To configure an Open VPN P2P profile, click **+Add** button for the OpenVPN P2P list, the OpenVPN Peer Edit page displays.

#### OpenVPN P2P server configuration

In the OpenVPN Peer Edit page, for **Peer type** field select **server**, the OpenVPN P2P server configuration settings display.

### OPENVPN PEER EDIT

OpenVPN profile  On  Off

Profile name

Peer type

Server IP address  leave empty if peer-to-peer server

Type

Port type

Server port  1-65535

Encryption cipher

MTU  (576-1600)

Enable Host to Host  On  Off

Local IP address

Remote IP address

### SERVER CERTIFICATES

Not before Mar 18 20:23:09 2026 GMT

Not after Mar 15 20:23:09 2036 GMT

Country IN

State Telangana

City Hyderabad

Organisation Lantronix

Email support@lantronix.com

### GENERATE CLIENT CERTIFICATE

Authentication type

Certificate

Name

Country

State

City

Organisation

Email

### REMOTE NETWORK

Remote Network LAN address

Remote Network LAN mask

Figure 8-63 OpenVPN P2P server configuration settings

Table 8-11 OpenVPN P2P server configuration details

Parameter	Description
OpenVPN profile	Set to <b>On</b> to enable.
Profile name	Enter a name for OpenVPN P2P profile.
Peer type	Select <b>server</b> .
Server IP address	Leave the field blank.
Type	Enter the type of virtual network interface to create: <ul style="list-style-type: none"> <li>• <b>TUN</b></li> <li>• <b>TAP</b></li> </ul>
Port type	Select a packet type to use: <ul style="list-style-type: none"> <li>• <b>TCP</b></li> <li>• <b>UDP</b></li> </ul> The default packet type is <b>UDP</b> .
Server port	Enter the port number to use. The default OpenVPN port is <b>1194</b> .
Encryption cipher	Select the Encryption cipher to use: <ul style="list-style-type: none"> <li>• <b>AES-256-GCM</b></li> <li>• <b>AES-128-GCM</b></li> <li>• <b>CHACHA20-POLY1305</b></li> <li>• <b>None</b></li> </ul>
MTU	Enter the Maximum Transmission Unit (MTU) size. It specifies the maximum size (in bytes) of a data packet that can be transmitted through the VPN tunnel without fragmentation.
Enable Host to Host	Set to <b>On</b> to enable and <b>Off</b> to disable. When enabled, it allows direct communication between the local and remote VPN endpoint devices over the tunnel. When disabled, only traffic between the connected networks is permitted.
Local IP address	Enter the Local IP address of the VPN tunnel.
Remote IP address	Enter the Remote IP address of the VPN tunnel.
<b>Server Certificates</b>	
Displays the details of the Server certificate used. Click <b>Change</b> to add a different certificate. You will be redirected to OpenVPN Server Certificate page.	
<b>Generate Client Certificate</b>	
For <b>Authentication type</b> field, select <b>Certificate</b> . For <b>Certificate</b> field, select <b>New</b> and enter the required values for all the fields. Click <b>Generate</b> to generate the certificate. Once the certificate is generated, click <b>Download P12</b> or <b>Download TGZ</b> to save the certificate file in the corresponding format. If for some reason	

Parameter	Description
the integrity of your network has been compromised, return to this screen, use the Certificate drop-down list to select the certificate and then click <b>Revoke</b> to make the certificate invalid.	
<b>Remote Network</b>	
Remote Network LAN address	Enter the network address of the remote LAN network on the VPN client side.
Remote Network LAN mask	Enter the subnet mask of the remote LAN network.

Click **Save** to save and apply the settings.

### OpenVPN P2P client configuration

In the OpenVPN Peer Edit page, for **Peer type** field select **client**, the OpenVPN P2P client configuration settings display.

### OPENVPN PEER EDIT

OpenVPN profile  On  Off

Profile name

Peer type

Server IP address  leave empty if peer-to-peer server

Type

Port type

Server port  1-65535

Encryption cipher

MTU  (576-1600)

Enable Host to Host  On  Off

Local IP address

Remote IP address

#### SELECT CLIENT CERTIFICATE

Certificate

Not before

Not after

#### CERTIFICATE ISSUER INFORMATION

Name

Country

State

City

Organisation

Email

#### CERTIFICATE SUBJECT INFORMATION

Name

Country

State

City

Organisation

Email

Select certificate to upload  Not uploaded

#### REMOTE NETWORK

Remote Network LAN address

Remote Network LAN mask

Figure 8-64 OpenVPN P2P client configuration settings

Table 8-12 OpenVPN P2p client configuration details

Parameter	Description
OpenVPN profile	Set to <b>On</b> to enable.
Profile name	Enter a name for OpenVPN P2P profile.
Peer type	Select <b>client</b> .
Server IP address	Enter the WAN IP address/host domain name of the server.
Type	Enter the type of virtual network interface to create: <ul style="list-style-type: none"> <li>• <b>TUN</b></li> <li>• <b>TAP</b></li> </ul>
Port type	Select a packet type to use: <ul style="list-style-type: none"> <li>• <b>TCP</b></li> <li>• <b>UDP</b></li> </ul> The default packet type is <b>UDP</b> .
Server port	Enter the port number to use. The default OpenVPN port is <b>1194</b> .
Encryption cipher	Select the Encryption cipher to use: <ul style="list-style-type: none"> <li>• <b>AES-256-GCM</b></li> <li>• <b>AES-128-GCM</b></li> <li>• <b>CHACHA20-POLY1305</b></li> <li>• <b>None</b></li> </ul>
MTU	Enter the Maximum Transmission Unit (MTU) size. It specifies the maximum size (in bytes) of a data packet that can be transmitted through the VPN tunnel without fragmentation.
Enable Host to Host	Set to <b>On</b> to enable and <b>Off</b> to disable. When enabled, it allows direct communication between the local and remote VPN endpoint devices over the tunnel. When disabled, only traffic between the connected networks is permitted.
Local IP address	Enter the Local IP address of the VPN tunnel.
Remote IP address	Enter the Remote IP address of the VPN tunnel.
<b>Select Client Certificate</b>	
For the <b>Certificate</b> field, select the client certificate generated during the OpenVPN P2P server configuration. The other fields are populated accordingly.	
<b>Certificate Issuer Information</b>	
Click <b>Choose a file</b> , locate and select the client certificate. Click <b>Install</b> to upload the certificate. The other fields are populated accordingly.	
<b>Certificate Subject Information</b>	

Parameter	Description
Click <b>Choose a file</b> , locate and select the client certificate. Click <b>Install</b> to upload the certificate. The other fields are populated accordingly.	
<b>Remote Network</b>	
Remote Network LAN address	Enter the network address of the remote LAN network on the VPN server side.
Remote Network LAN mask	Enter the subnet mask of the remote LAN network.

Click **Save** to save and apply the settings.

## GRE Tunnelling

The Generic Route Encapsulation (GRE) protocol creates a point-to-point connection similar to a VPN between clients and servers or between clients only. GRE is used to encapsulate the data or payload.

To access GRE Tunnelling page, navigate to **Networking > VPN settings > GRE tunnelling**.

The screenshot shows the 'GRE TUNNELLING' page with a 'GRE CLIENT LIST' section. There is a '+ Add' button in the top right corner. Below the button is a table with the following headers: Name, GRE server address, Local tunnel address, Remote tunnel address, and Status. The table is currently empty.

Figure 8-65 VPN – GRE Tunnelling

To configure GRE tunnelling:

1. In the GRE client list section, click the **+Add** button. The GRE Client Edit screen displays.

The screenshot shows the 'GRE TUNNELLING' page with the 'GRE CLIENT EDIT' section. The 'Enable VPN' toggle is set to 'Off'. The fields are as follows: Profile name (text input), GRE server address (text input), Local tunnel address (four numeric input boxes), Remote tunnel address (four numeric input boxes), Remote network address (four numeric input boxes), Remote network subnetmask (four numeric input boxes), TTL (text input with value 255 and range 0-255), Reconnect delay (text input with value 30 and range 30-65535 seconds), and Reconnect retries (text input with value 0 and range 0-65535, 0=Unlimited). There are 'Save' and 'Cancel' buttons at the bottom.


Figure 8-66 GRE Client Edit

2. Set the **Enable VPN** toggle to **On**.
3. In the **Profile name** field, enter a profile name for the tunnel. This name is used to identify the tunnel on the router.
4. In the **GRE server address** field, enter the IP address or domain name of the GRE server.
5. In the **Local tunnel address** field, enter the IP address you want to assign the tunnel locally.
6. In the **Remote tunnel address** field, enter the IP address you want to assign to the remote tunnel.
7. In the **Remote network address** field, enter the IP address scheme of the remote network.
8. In the **Remote network subnetmask** field, enter the subnet mask of the remote network.
9. The **TTL** (Time To Live) field is an 8-bit field used to remove an undeliverable data packet from a network to avoid unnecessary network traffic across the internet. The default value of 255 is the upper limit on the time that an IP datagram can exist. The value is reduced by at least one for each hop the data packet takes to the next router on route the datagram's destination. If the TTL field reaches zero before the datagram arrives at its destination the data packet is discarded and an error message is sent back to the sender.
10. The **Reconnect delay** is the time in seconds that the router will wait before attempting to connect to the GRE server if the connection is broken. The minimum time to wait is 30 seconds so as to not flood the GRE server with connection requests, while the maximum time to wait is 65335 seconds.
11. The **Reconnect retries** is the number of connection attempts that the router will make if the GRE connection goes down. If set to 0, the router will retry the connection indefinitely, otherwise the maximum number of times to retry cannot be greater than 65335.
12. Click the **Save** button to save the changes. The VPN will attempt to connect after your click Save. Select the Status button at the top left of the interface to return to the status window and monitor the VPN's connection state.

## Server Certificate

The Server Certificate page is used to generate a certificate to use for OpenVPN.

To access the Server certificate page, navigate to **Networking > VPN settings > Server certificate**.




The screenshot shows the 'OPENVPN SERVER CERTIFICATE' configuration page. At the top, there is a header 'OPENVPN' in orange. Below it, the title 'OPENVPN SERVER CERTIFICATE' is displayed in blue. The page contains several fields and buttons:

- Server key size:** A dropdown menu currently set to '2048'.
- Diffie-Hellman parameters:** A blue 'Generate' button.
- Certificate serial number:** A text input field.
- Not before:** A text input field.
- Not after:** A text input field.
- Country:** A text input field.
- State:** A text input field.
- City:** A text input field.
- Organization:** A text input field.
- Email:** A text input field.
- Generate server certificate:** A grey 'Generate' button.

*Figure 8-67 Server certificate*


To proceed with generating the certificate, the Diffie-Hellman parameters must first be generated. Click **Generate** for the **Diffie-Hellman parameters** field. The following prompt displays.



This process will take several minutes to generate the DH parameters. It will delete and invalidate all previously generated server and client keys. Are you sure you want to continue?

OK Cancel

Selecting the **OK** button will delete and invalidate all previous server and client keys, if they exist, and generates new parameters. This process will take up to five minutes to complete. Once the files are generated, the Success prompt is shown.



Success!

Generated dh successfully.

The Server Certificate can now be generated.

## Generating the OpenVPN Server Certificate

To generate an OpenVPN Server Certificate:

1. In the **Country** field, enter the SSL Country code for the country the certificate is issued for.
2. In the **State** field, enter the state the certificate is issued for.
3. In the **City** field, enter the city the certificate is issued for.
4. In the **Organization** field, enter the name of the organization for the certificate.
5. In the **Email** field, enter a contact email for the certificate.
6. For the **Generate Server Certificate** field click **Generate** to generate the certificate. Once the certificate is successfully generated, the Certificate serial number and validity dates are shown in **Certificate serial number, Not before and Not after fields.**

OPENVPN

OPENVPN SERVER CERTIFICATE

Server key size 2048

Diffie-Hellman parameters **Generate**

Certificate serial number 9796D3C91D9592CF4B072E71C0A231C5

Not before Mar 18 20:23:09 2026 GMT

Not after Mar 15 20:23:09 2036 GMT

Country IN

State Telangana

City Hyderabad

Organization Lantronix

Email support@lantronix.com

Generate server certificate **Generate**

*Figure 8-68 Server certificate page after certificate generation*

## 9. Services

The Services page allows you to access and configure the following features:

- Network Time (NTP)
- SMS messaging
- Dynamic DNS
- DNS server
- GPS
- Internet of Things
- Remote management
- Serial data status
- Data Stream Manager
- Event configuration
- Email settings
- Low power mode
- IO configuration
- PercepXion

To access the Services page, click **Services** tab on the top menu bar.

The screenshot displays the LANTRONIX web interface. The top navigation bar includes the LANTRONIX logo and tabs for Status, Networking, **Services**, System, and Help. A user profile icon labeled 'root' is visible on the right. The left sidebar contains a list of service categories: Network time (NTP), SMS messaging, Dynamic DNS, DNS server, GPS, Internet of Things, Remote management, Serial data status, Data Stream Manager, Event configuration, Email settings, Low power mode, IO configuration, and PercepXion. The main content area is titled 'NTP' and is divided into two sections: 'TIMEZONE SETTINGS' and 'NTP SETTINGS'. Under 'TIMEZONE SETTINGS', the current time is 'Thu Apr 2 18:03:19 AEDT 2026' and the timezone is '(GMT+10:00) Australia/Sydney'. A 'Daylight savings time schedule' button is present. Under 'NTP SETTINGS', the NTP service is '0.pool.ntp.org'. There are three toggle switches: 'NTP' (On), 'Synchronisation on WWAN connection' (On), and 'Daily synchronisation' (On). A 'Save' button is located at the bottom of the settings area.

Figure 9-1 Services page

## Network time (NTP)

The Network time (NTP) page allows you to configure the NTC-550 Series router to synchronize its internal clock with a global Internet Time server and specify the time zone for the location of the router. This provides an accurate timekeeping function for features such as System Log entries and Firewall settings where the current system time is displayed and recorded. Any Network Time Protocol (NTP) server available publicly on the internet may be used.

To access the Network time (NTP) page, navigate to **Services > Network time (NTP)**.

Figure 9-2 NTP settings

### Timezone Settings

The **Current time** field shows the time and date configured on the router. If this is not accurate, use the Timezone drop-down list to select the correct time zone for the router.

If the selected zone observes daylight savings time, a **Daylight savings time schedule** button displays below the drop-down list. Click **Daylight savings time schedule**, a window displays the start and end times for daylight savings. Click **OK** and click **Save** to save and apply the settings.

### Configuring NTP settings

To configure NTP settings:

1. Set **NTP** toggle key to **On**.
2. In the **NTP service** field, enter the address of the NTP server you want to use.
3. Set the **Synchronization on WWAN connection** toggle key to **On** or **Off** as required. It enables or disables the router to perform time synchronization, each time a mobile broadband connection is established.
4. Set the **Daily synchronization** toggle key to **On** or **Off** as required. It enables or disables the router to perform time synchronization each day.
5. Click **Save** to save and apply the settings.

## SMS messaging

The NTC-550 Series router offers an advanced SMS feature set, including sending messages, receiving messages, redirecting incoming messages to another destination, and supporting remote commands and diagnostics messages.

Some of the functions supported are:

- Ability to send a text message via a cellular network and store it in permanent storage.
- Ability to receive a text message via a cellular network and store it in permanent storage.
- Ability to forward incoming text messages via a cellular network to another remote destination which may be a TCP/UDP server or other mobile devices.
- Ability to receive run-time variables from the device (e.g. uptime) on request via SMS.
- Ability to change live configuration on the device (e.g. network username) via SMS.
- Ability to execute supported commands (e.g. reboot) via SMS.
- Ability to trigger the NTC-550 Series router to download and install a firmware upgrade.
- Ability to trigger the NTC-550 Series router to download and apply a configuration file.

### Setup

The Setup page allows you to configure SMS and SMS forwarding features the router. SMS messaging is enabled by default. To access the Setup page, navigate to **Services > SMS messaging > Setup**.

**SMS SETUP**

**GENERAL SMS CONFIGURATION**

Messages per page  10-50

Encoding scheme

SMSC address

**SMS FORWARDING CONFIGURATION**

Forwarding  On  Off

Redirect to mobile

TCP server address

TCP port

UDP server address

UDP port

Figure 9-3 Setup

Table 9-1 Setup configuration details

Item	Description
<b>General SMS configuration</b>	
Messages per page	Enter the number of SMS messages to display per page. It Must be a value between 10 and 50.
Encoding scheme	Select the encoding method used for outbound SMS messages. GSM 7-bit mode permits up to 160 characters per message but drops to 50 characters if the message includes special characters. UCS-2 mode allows to send Unicode characters and permits a message to be up to 50 characters in length.
<b>SMS forwarding configuration</b>	
Forwarding	Set to <b>On</b> , to enable forwarding. Incoming text messages can be redirected to another mobile device and/or a TCP/UDP message server.
Redirect to mobile	Enter a mobile number as the destination for forwarded SMS messages. You can forward incoming text messages to a different destination number. This destination number can be another mobile phone or a router phone number.  The text message is stored on the router and forwarded to the mobile number at the same time.
TCP server address	Enter an IP address or domain name as the destination for forwarded SMS messages using TCP. You can also forward incoming text messages to a TCP based destination. The TCP server can be any kind of public or private server if the server accepts incoming text-based messages.  The TCP address can be an IP address or domain name.  The text message is stored on the router and forwarded to the TCP server at the same time.
TCP port	The TCP port on which to connect to the remote destination. The port number range is from 1 to 65535. Please refer to your TCP based SMS server configuration for which port to use.
UDP server address	Enter an IP address or domain name as the destination for forwarded SMS messages using UDP. You can also forward incoming text messages to a UDP based destination. The UDP server can be any kind of public or private server if the server accepts incoming text-based messages.  The UDP address can be an IP address or domain name.  The text message is stored on the router and forwarded to the UDP server at the same time.
UDP port	The UDP port on which to connect to the remote destination. The port number range is from 1 to 65535. Please refer to your UDP based SMS server configuration for which port to use.

## Diagnostics

The Diagnostics page allows to configure the SMS diagnostics and command execution configuration. You can change the configuration, perform functions remotely, and check on the status of the router via SMS commands.

To access the Diagnostics page, navigate to **Services > SMS messaging > Diagnostics**.

**SMS MESSAGING**

### SMS DIAGNOSTICS AND COMMAND EXECUTION CONFIGURATION

Enable remote diagnostics and command execution  On  Off

Only accept authenticated SMS messages  On  Off

Send Set command acknowledgement replies  On  Off

Access advanced RDB variables  On  Off

Allow execution of advanced commands  On  Off

Send acknowledgement replies to

Send command error replies  On  Off

Send error replies to

Send a maximum number of  replies per   (0 / 100 messages sent)

Limit the number of diagnostic text messages that can be sent in a designated time period. Currently, the 'messages sent' count automatically resets at the end of the designated time period. For example, it will reset to zero at 01:00, 02:00, 03:00 etc for 'hour', 00:00 for 'day', 00:00 on Monday for 'week' and the first day of the month for 'month', or at anytime the unit reboots.



### WHITELIST FOR DIAGNOSTIC OR EXECUTION SMS

#	Destination number	Password

Figure 9-4 Diagnostics settings

The table below lists the SMS Diagnostics Configuration details.

*Table 9-2 SMS – Diagnostics configuration details*

Item	Description
<b>SMS Diagnostics and Command Execution Configuration</b>	
Enable remote diagnostics and command execution	<p>Enables or disables the remote diagnostics feature. If this setting is enabled all incoming text messages are parsed and tested for remote diagnostics commands.</p> <p>If remote diagnostics commands are found, the router executes those commands.</p> <p>This feature is enabled by default. All remote diagnostic commands that are received are stored in the Inbox.</p> <p> <b>Note:</b> It is possible to adjust settings and prevent your router from functioning correctly using remote diagnostics. If this occurs, you will need to perform a factory reset to restore normal operation.</p>
Only accept authenticated SMS messages	<p>Enables or disables checking the sender's phone number against the allowed sender whitelist for incoming diagnostics and command execution SMS messages.</p> <p>If authentication is enabled, the router will check if the sender's number exists in the whitelist. If it exists, the router then checks the password (if configured) in the incoming message against the password in the whitelist for the corresponding sending number. If they match, the diagnostic or command is executed.</p> <p>If the number does not exist in the whitelist or the password does not match, the router does not execute the incoming diagnostic or command in the SMS message.</p> <p>This is enabled by default, and it is strongly advised that you leave this feature enabled to maintain security.</p> <p> <b>Important:</b> We highly recommended that you use the whitelist and a password when utilising this feature to prevent unauthorised access. See the White list description for more information.</p>
Send Set command acknowledgement replies	<p>The NTC-550 Series router will automatically reply to certain types of commands received, such as get commands, or execute commands. However, acknowledgement replies from the NTC-550 Series router are optional with set commands and the Wakeup command. This option enables or disables sending an acknowledgment message after execution of a set command or SMS Wakeup command. If disabled, the router does not send any acknowledgement after execution of a set command or SMS Wakeup command. All acknowledgment replies are stored in the Outbox after they</p>

Item	Description
	have been sent. This can be useful to determine if a command was received and executed by the router. This option is disabled by default.
Access advanced RDB variables	This option allows access to the full list of RDB variables via SMS. When it is turned off, you are only allowed access to the basic RDB variables listed later in this guide.
Allow execution of advanced commands	This option allows execution of advanced commands such as those which are common to the Linux command line. For example: “execute ls /usr/bin/sms*” to list the contents of the /etc folder on the router.  When it is turned off you are only allowed to execute the basic commands listed later in this guide.
Send acknowledgement replies to	Select <b>A fixed number</b> or <b>The sender’s number</b> . This option allows you to specify where to send acknowledgment messages after the execution of a set, get, or exec command.  If a fixed number is selected, the acknowledgement message will be sent to the number defined in the Fixed number to send replies to field. If the sender’s number is selected, the acknowledgement message will be sent to the number that the SMS diagnostic or command message originated from. The default setting is to use the sender’s number.
Send command error replies	Allows to enable or disable the option to send replies to error messages.
Send error replies to	Select <b>A fixed number</b> or <b>The senders’s number</b> . This is the destination number to which error messages are sent after the execution of a get, set, or exec command whether a fixed number or the sender’s number. This field is only displayed when it set to Fixed Number.
Send a maximum number of, replies per	Allows you to set a maximum number for acknowledgement and error messages sent when an SMS diagnostic or command is executed. The maximum limit can be set per hour, day, week or month. The router will send a maximum of 100 replies per day by default.

Click **Save** to save and apply the settings.

The whitelist is a list of mobile numbers that you can create which are considered “friendly” to the router. If **Only accept authenticated SMS** messages is enabled in the diagnostics section, the router will compare the mobile number of all incoming diagnostic and command messages against this white list to determine whether the diagnostic or command should be executed. You must configure a password for each number added to the whitelist to give an additional level of security.

The Whitelist For Diagnostic Or Execution SMS displays the list of mobile numbers added to white list and their details.

To configure a WhiteList for Diagnostic or Execution SMS:

1. Click **+Add** button, the **Whitelist Setting** page displays.

The screenshot shows a configuration window titled 'SMS MESSAGING' with a sub-section 'WHITELIST SETTING'. It contains three input fields: 'Destination number', 'Password' (with an information icon and a toggle eye), and 'Confirm password' (with a toggle eye). At the bottom are 'Save' and 'Cancel' buttons.

Figure 9-5 Whitelist setting

2. Enter a number in the **Destination number** field to add it to the White List.
3. In the Password field, enter a password. The password must meet the following requirements:
  - Must contain a minimum of eight characters and no more than 128 characters in length.
  - Must contain at least one upper case character, one lower case character and one number.
  - Must contain least one of the following special characters: !\*()?/
4. In the Confirm password field, re-enter the password.
5. Click **Save** to save and apply the settings.

The new setting displays in the Whitelist for Diagnostic or Execution SMS.

The screenshot shows a table titled 'WHITELIST FOR DIAGNOSTIC OR EXECUTION SMS' with a '+ Add' button. The table has columns for '#', 'Destination number', and 'Password'. There is one row with the number '1' in the first column, and the other two columns are redacted with grey boxes. To the right of the redacted cells are edit and delete icons.

Figure 9-6 Whitelist for Diagnostic or Execution SMS

Table 9-3 Whitelist for Diagnostic or Execution SMS details

Item	Description
#	Serial number
Destination number	Mobile number added to Whitelist
Password	Password associated with mobile number
	Click to edit the details of the Whitelist number
	Click to delete the number from the Whitelist

### Sending an SMS diagnostic command

Follow the steps below to configure the router to optionally accept SMS diagnostic commands only from authenticated senders and learn how to send SMS diagnostic commands to the router.

1. Navigate to the **Services > SMS messaging > Diagnostics** page.

2. Confirm that the **Enable remote diagnostics and command execution** toggle key is set to the **On** position. If it is set to **Off** select the toggle key to switch it to the **On** position.
3. If you wish to have the router, only accept commands from authenticated senders, ensure that **Only accept authenticated SMS messages** is set to the **On** position. In the Whitelist for diagnostic or execution SMS messages section, select the **+Add** button and enter the sender's number in international format into the **Destination number** field that appears. You must enter a password in the **Password** field corresponding to the destination number. Re-enter the password in the **Confirm password** field.
4. If you would prefer to accept SMS diagnostic commands from any sender, set the **Only accept authenticated SMS messages** toggle key to the **Off** position.

**Note:** An alternative method of adding a number to the whitelist is to send an SMS message to the router, navigate to *Services > SMS messaging > Inbox* and then select the button next

 to the message which corresponds to the sender's number.

You will then need to set a Password in the Whitelist for diagnostic execution SMS list.

5. Click the **Save** button.

### Types of SMS diagnostic commands

There are three types of commands that can be sent; execute, get and set. The basic syntax is as follows:

- execute COMMAND
- get VARIABLE
- set VARIABLE=VALUE

If authentication is enabled, each command must be preceded by the password:

- PASSWORD execute COMMAND
- PASSWORD get VARIABLE
- PASSWORD set VARIABLE=VALUE

The following are some examples of SMS diagnostic commands:

```
password6657 execute reboot
get rssi
set apn1=testAPNvalue
```

### SMS acknowledgement replies

The router automatically replies to get commands with a value and execute commands with either a success or error response. Set commands will only be responded to if the Send Set command acknowledgement replies toggle key is set to ON. If the Send command error replies toggle key is set to ON, the router will send a reply if the command is correct but a variable or value is incorrect, for example, due to misspelling.

### SMS command format

Generic Format for reading variables:

```
get VARIABLE
PASSWORD get VARIABLE
```

Generic Format for writing to variables:

```
set VARIABLE=VALUE
PASSWORD set VARIABLE=VALUE
```

Generic Format for executing a command:

```
Execute COMMAND
PASSWORD execute COMMAND
```

## Replies

Upon receipt of a successfully formatted, authenticated (if required) command, the gateway will reply to the SMS in the following format:

*Table 9-4 SMS – SMS diagnostics command syntax*

Type	SMS Contents	Notes
get command	"VARIABLE=VALUE"	
set command	"Successfully set VARIABLE to VALUE"	Only sent if the acknowledgment message function is enabled
execute command	"Successfully executed command COMMAND"	

Where "VARIABLE" is the name of the value to be read

Where "VARIABLE (x)" is the name of another value to be read

Where "VALUE" is the content to be written to the "VARIABLE"

Where "COMMAND" is a supported command to be executed by the device (e.g. reboot)

Where "PASSWORD" is the password (if configured) for the corresponding sender number specified in the WhiteList

Multiple commands can be sent in the same message, if separated by a semicolon.

For Example:

```
get VARIABLE1; get VARIABLE2; get VARIABLE3
PASSWORD get VARIABLE1; get VARIABLE2
set VARIABLE=VALUE1 ; set VARIABLE2=VALUE2
PASSWORD set VARIABLE1=VALUE1; set VARIABLE2=VALUE2; set VARIABLE3=VALUE3
```

If required, values can also be bound by an apostrophe, double apostrophe, or back tick.

For Example:

```
"set VARIABLE='VALUE'"
"set VARIABLE="VALUE""
"set VARIABLE=`VALUE`"
"get VARIABLE"
```

A password (if required) only needs to be specified once per SMS but can be prefixed to each command if desired.

```
"PASSWORD get Variable1"; "get VARIABLE2"
"PASSWORD set VARIABLE1=VALUE1"; "set VARIABLE2=VALUE2"
```

If the command sent includes the "reboot" command and has already passed the whitelist password check, the device keeps this password and executes the remaining command line after the reboot with this same password.

For Example:

```
"PASSWORD execute reboot; getVariable1"; "get VARIABLE2"
```

```
"PASSWORD execute reboot; PASSWORD get Variable1"; "get VARIABLE2"
```



**Important:** Commands, variables and values are case sensitive.

### List of basic commands

A list of basic commands which can be used in conjunction with the execute command are listed below:

“pdpcycle”, “pdpdown” and “pdpup” commands can have a profile number suffix ‘x’ added. Without the suffix specified, the command operates against the default profile configured on the profile list page of the Web-UI.

*Table 9-5 List of basic SMS diagnostic commands*

Item	Command	Description
1	<b>reboot</b>	Immediately performs a soft reboot.
2	<b>pdpcycle</b>	Disconnects (if connected) and reconnects the data connection. If a profile number is selected in the command, try to disconnect/reconnect the specified profile in case the profile is active. If no profile number is selected, try to disconnect/reconnect the current active profile. Reports an error if no profile number is selected and there is no currently activated profile.
3	<b>pdpdown</b>	Disconnects the PDP. If a profile number is selected in the command, the router tries to disconnect the specified profile in case the profile is active. If no profile number is selected, try to disconnect the current active profile. Reports an error if no profile number is selected and there is no currently activated profile.
4	<b>pdpup</b>	Reconnects the PDP. If a profile number is selected in the command, the router tries to connect with the specified profile. If no profile number is selected, the router tries to connect to the last active profile. The gateway will check the currently activated profile and disconnect this profile before executing the command. The router reports an error if no profile number is selected and there is no stored last active profile number.
5	<b>factorydefaults</b>	Performs a factory reset on the router. Be aware that this command also clears the SMS whitelist on the router.
6	<b>download</b>	Performs a download and install of a Firmware Upgrade (.cdi), Config File (.tar.gz) or a help document (.pdf) file.  If the file is a firmware image as in the case of a .cdi file, the router will apply the recovery image first and then the main firmware image. The download location is specified immediately after the command and may be from an HTTP or FTP source URL.  If the file is a .cdi file, the router will apply the file as a configuration file update for the device and reboot afterwards.

Item	Command	Description
		<p>If the file is a .pdf, the router will assume this is a user guide document and save it to the router and make the file available for viewing via the help menu on the Web-UI.</p> <p>Note: If your download URL includes any space characters, please encode these prior to transmission according to RFC1738, for example:</p> <pre>ftp://username:password@serveraddress/directory%20with%20spaces/filename.cdi</pre> <p>Note: Authenticated FTP addresses may be used following the format as defined in RFC1738, for example:</p> <p><a href="ftp://username:password@serveraddress/directory/filename.cdi">ftp://username:password@serveraddress/directory/filename.cdi</a></p>
10	<b>ssh.genkeys</b>	Instructs the router to generate new public SSH keys.
11	<b>ssh.clearkeys</b>	Instructs the router to clear the client public SSH key files.

### List of get/set commands

The following table is a partial list of get and set commands which may be performed via SMS.

*Table 9-6 SMS - List of get/set commands*

Command name	Example	Description
get status	<b>get status</b>	Returns the Module firmware version, LAN IP Address, Network State, Network operator and Signal strength.
get sessionhistory	<b>get sessionhistory</b>	Returns the time and date of recent sessions along with the total amount of data sent and received for each session.
set syslogserver	<b>set syslogserver=123.45.67.89:514</b>	Sets a remote syslog server IP or hostname and port.
get plmnscan	<b>get plmnscan</b>	Instructs the router to perform a network scan and returns the results by SMS.
set forceplmn	<b>set forceplmn=505,3</b>	Sets the operator to a manual selection made by the user where "505" is the Mobile Country Code for Australia. As no network type (e.g.. LTE/5G) is specified, it is selected automatically.
get forceplmn	<b>get forceplmn</b>	Returns the operator and network type selection mode (Automatic/Manual), in addition to the MCC and MNC values
get ledmode	<b>get ledmode</b>	Returns the status of the LED operation mode.

Command name	Example	Description
set ledmode	set ledmode=10	Sets the LED operation mode to be always on or to turn off after the specified number of minutes.
get ssh.proto	get ssh.proto	Returns the SSH protocol in use.
set ssh.proto	set ssh.proto=1,2	Sets the SSH Protocol to protocol 1, 2 or both (1,2).
get ssh.passauth	get ssh.passauth	Returns the status of the SSH Enable password authentication option.
set ssh.passauth	set ssh.passauth=1	Sets the SSH Enable password authentication option on or off.
get ssh.keyauth	get ssh.keyauth	Returns the status of the SSH Enable key authentication option.
set ssh.keyauth	set ssh.keyauth=1	Sets the SSH Enable key authentication option on or off.
get download.timeout	get download.timeout	Returns the time in minutes that the router waits before a download times out.
set download.timeout	set download.timeout=20	Sets the time in minutes that the router waits before a download times out. This is set to 10 minutes by default. Supported range is 10 – 1440 minutes.
get install.timeout	get install.timeout	Returns the time in minutes that the router waits before a file that is being installed times out.
set install.timeout	set install.timeout=5	Sets the time in minutes that the router waits before a file that is being installed times out. This is set to 3 minutes by default. Supported range is 3 – 300 minutes.
get sw.version	get sw.version	Returns the software version of the router.

### List of basic RDB variables

The following table lists valid variables where “x” is a profile number (1-6). If no profile is specified, variables are read from or written to for the current active profile. If a profile is specified, variables are read from or written to for the specified profile number (‘x’).

Table 9-7 SMS - List of basic SMS diagnostics RDB variables

#	RDB variable name	SMS variable name	Read/Write	Description	Example VALUE
0	link.profile.1.enable link.profile.1.apn link.profile.1.user link.profile.1.pass link.profile.1.auth_type link.profile.1.iplocal link.profile.1.status	profile	RW	Profile	Read:  (profile no,apn,user,pass,auth,iplocal,status)  1,apn,username,password, chap,202.44.185.111,up  Write:  (apn, user, pass,auth)  apn,username,password
2	link.profile.1.user	username	RW	Cellular broadband username	Guest, could also return "null"
3	link.profile.1.pass	password	RW	Cellular broadband password	Guest, could also return "null"
4	link.profile.1.auth_type	authtype	RW	Cellular broadband Authentication type	"pap" or"chap"
5	link.profile.1.iplocal	wanip	R	WAN IP address	202.44.185.111
6	wwan.0.radio.information.signal_strength	rsi	R	Cellular signal strength	-65 dBm
7	wwan.0.imei	imei	R	IMEI number	3.57347E+14
8	statistics.usage_current	usage	R	Cellular broadband data usage of current session	"Rx 500 bytes, Tx 1024 bytes, Total 1524 bytes" or "Rx 0 byte, Tx 0 byte, Total 0 byte" when wwan down
9	statistics.usage_current	wanuptime	R	Up time of current cellular broadband session	1 days 02:30:12 or 0 days 00:00:00 when wwan down
10	/proc/uptime	deviceuptime	R	Device up time	1 days 02:30:12
11	wwan.0.system_network_status.current_band	band	R	Current band	NR5G BAND 78

## Network scan and manual network selection by SMS

Performing a network scan:

The `get plmnscan` SMS command enables you to perform a scan of the cellular networks available at the time of the scan.

It returns the following semi-colon separated information for each network in range:

- MCC
- MNC
- Network Type (LTE, 5G)
- Provider's Name
- Operator Status (available, forbidden, current)


The following is an example of a response from the `get plmnscan` SMS command:

```
plmnscan=505,03,7,vodafone AU,1;505,03,1,vodafone AU,1;505,03,9,vodafone AU,4;505,01,7,Telstra
Mobile,1;505,01,1,Telstra Mobile,1;505,02,9,YES OPTUS,1;505,02,1,YES OPTUS,1;505,01,9,Telstra
```

*Table 9-8 Operator status codes returned by get plmnscan SMS command*

Operator status	Description
1	Indicates an available operator which may be selected.
2	Indicates a forbidden operator which may not be selected (applies only to generic SIM cards).
4	Indicates the currently selected operator.

### Note:

- If the connection status is *Up* and connection mode is *Always on*, the `get plmnscan` SMS will cause the connection to disconnect, perform the scan, send the result through SMS and then bring the connection back up again. If the connection status is *Down*, the router will perform the PLMN scan, send the result and keep the connection status down.
-  If the connection status is *Waiting* and connection mode is *Connect on demand*, the `get plmnscan` SMS will change the connection status to *Down*, perform the scan, send the result through SMS and then restore the connection status to the *Waiting* state.
- If the connection status is *Up* and connection mode is *Connect on demand*, the `get plmnscan` SMS will cause the connection to disconnect, perform the scan, send the result through SMS, and then restore the connection status to the *Waiting* state unless there is a traffic which triggers a connection in which case the connection status will be set to *Up*.

## Setting the router to connect to a network

The router can be instructed by SMS to connect to one of the networks returned by the `get plmnscan` command. The `set forceplmn` command forces the router to connect to a specified operator network (if available) while the `get forceplmn` command retrieves the currently configured network on the router.

The command format for the `set forceplmn` command is:

```
set forceplmn=0|MCC,MNC| MCC,MNC,Network Type
```

For example:

```
set forceplmn=0
```

Sets the selection of operator and network type to automatic mode.

```
set forceplmn=505,9
```

Sets the operator to a manual selection made by the user where “505” is the Mobile Country Code for Australia and “1” is the Mobile Network Code for Telstra. As no network type (e.g. LTE/5G) is specified, it is selected automatically.

```
set forceplmn=505,1,9
```

Sets the operator and network type to a manual selection made by the user where “505” is the Mobile Country Code for Australia, “1” is the Mobile Network Code for Telstra and “9” is the LTE network type.

*Table 9-9 SMS - Mobile Network Provider codes (Australia)*

Mobile Network Code	Mobile Network Provider
1	Telstra
2	Optus
3	Vodafone

### Confirming the currently configured operator and network type

You can retrieve the currently configured operator and network type using the **get forceplmn** command.

The **get forceplmn** command returns the operator and network type selection mode (Automatic/Manual), in addition to the MCC and MNC values, for example:

```
Automatic,505,1
```

This response indicates that the operator/network selection mode is Automatic, and the network used is Telstra.

### SMS diagnostics examples

The examples below demonstrate various combinations of supported commands. This is not an exhaustive list and serves as an example of possibilities only.

If the default setting of **Only accept authenticated SMS messages** is enabled then password authentication is required. Add your password followed by a space as a prefix to the command, for example

If authentication required:

```
PASSWORD set username= "<username>"
```

If authentication not required:

```
set username='<username>'
```



**Note:** The authentication setting is located in the user interface at Services > SMS messages > Diagnostics.

Table 9-10 SMS – SMS diagnostics example commands

Description	Input Command (without PASSWORD prefix)
Send SMS to change the data connection username	<code>set username='&lt;username&gt;'</code>
Send SMS to change the data connection password	<code>set password= `&lt;password&gt;`</code>
Send SMS to change the data connection authentication	<code>set authtype= 'pap'</code>
Send SMS to reboot	<code>execute reboot</code>
Send SMS to check the WAN IP address	<code>get wanip</code>
Send SMS to check the mobile signal strength	<code>get rssi</code>
Send SMS to check the IMEI number	<code>get imei</code>
Send SMS to check the current band	<code>get band</code>
Send SMS to Disconnect (if connected) and reconnect the data connection	<code>execute pdpcycle</code>
Send SMS to disconnect the data connection	<code>execute pdpdown</code>
Send SMS to connect the data connection	<code>execute pdpup</code>
Send multiple get command	<code>get wanip; get rssi</code>
Send multiple set command	<code>set ssh.genkeys=1; set username=test; set auth=pap</code>
Send SMS to reset to factory default settings	<code>execute factorydefaults</code>
Send SMS to retrieve status of router	<code>get status</code>
Send SMS to retrieve the history of the session, including start time, end time and total data usage	<code>get sessionhistory</code>
Send SMS to configure the router to send syslog to a remote syslog server	<code>set syslogserver=123.209.56.78</code>
Send SMS to perform firmware upgrade when firmware is located on HTTP server	<code>execute download http://download.com:8080/firmware_image.cdi execute download http://download.com:8080/firmware_image_r.cdi</code>
Send SMS to perform firmware upgrade when firmware is located on FTP server	<code>execute download ftp://username:password@download.com/firmware_image.cdi execute download ftp://username:password@ download.com/firmware_image_r.cdi</code>
Send SMS to download and install IPK package located on HTTP server	<code>execute download http://download.com:8080/package.ipk</code>

Description	Input Command (without PASSWORD prefix)
Send SMS to download and install IPK package located on FTP server	execute download ftp://username:password@download.com:8080/package.ipk
Send SMS to set the LED mode timeout to 10 minutes	set ledmode=10
Send SMS to retrieve the current LED mode	get ledmode
Retrieve current SSH protocol	get ssh.proto
Select SSH protocol	set ssh.proto=1
Retrieve password authentication status	get ssh.passauth
Enable/disable password authentication on host	set ssh.passauth=1 or set ssh.passauth=0
Generate set of public/private keys on the host	execute ssh.genkeys
Clear client public keys stored on host	execute ssh.clearkeys
Send SMS to initiate a Network Quality test	get networkquality

## Inbox

The Inbox displays all received messages that are stored on the router. To access Inbox, navigate to **Services > SMS messaging > Inbox**.








Figure 9-7 Inbox



Table 9-11 Inbox details


Icon	Name	Description
	Forward	Opens a new message window where you can forward the corresponding message to another recipient.

Icon	Name	Description
	Reply	Opens a new message window where you can reply to the sender.
	Add to Whitelist	Add the sender's mobile number to the whitelist on the router.
	Delete	Delete the corresponding message.
	Refresh	Refresh the inbox to see new messages.

### Compose message

The Compose message page can be used to send SMS text messages to a single or multiple recipients. To access the Compose message page, navigate to **Services > SMS messaging > Compose message**.

A new SMS message can be sent to a maximum of 9 recipients at the same time. After sending the message, the result is displayed next to the destination number as "Success" or "Failure". By default, only one destination number field is displayed. Additional destination numbers may be added one at a time after entering a valid number for the current destination number field. To add a destination number, select the  button and to remove the last destination in the list, select the  button.



The screenshot displays the 'SMS MESSAGING' interface. At the top, it says 'SMS MESSAGING' in orange. Below that, 'COMPOSE MESSAGE' is written in blue. There is a 'Destination number' label next to an empty text input field. To the right of the input field are two blue buttons: a '+' button and a '-' button. Below the input field is a large, empty rectangular area labeled 'NEW MESSAGES'. At the bottom of the interface, there are two blue buttons: 'Send' and 'Clear'.

*Figure 9-8 Compose message*

Enter recipient number in the **Destination number** field. It should begin with the "+" symbol followed by the country calling code.

For example:

To send a message to the mobile destination number 0412345678 in Australia (country calling code 61), enter "+61412345678".


After entering the required recipient numbers, type your SMS message in the **New Messages** field. As you type your message, a counter shows how many characters you have entered out of the total number available for

your chosen encoding scheme. When you have finished typing your message and you are ready to send it, click **Send** button.

## Outbox

The Outbox displays all sent messages. To access Outbox, navigate to **Services > SMS messaging > Outbox**.

Figure 9-9 SMS - Outbox



Click **Delete All** to delete all messages and empty the outbox.

## Dynamic DNS

Dynamic DNS (DDNS) allows your NTC-550 Series router to associate an easy-to-remember domain name such as **[yourdomainname].com** with the regularly changing IP address assigned by your carrier. This feature allows you to connect to the NTC-550 Series router and its internal network more easily for maintenance.

To access the Dynamic DNS page, navigate to **Services > Dynamic DNS**.

Figure 9-10 Dynamic DNS

To use DDNS, you will need to sign up for a DDNS provider which is supported by the NTC-550 Series router. The supported providers are:

- www.dhs.org
- www.dydns.org
- www.easydns.com

- www.no-ip.com
- www.zoneedit.com

To configure DDNS on the NTC-550 Series router you will require your unique hostname from the provider, as well as your username and password which you used to sign up with the provider.

To configure DDNS:

1. Set the **Enable** toggle to **On**.
2. In the **Dynamic DNS** field select the provider you have signed up with.
3. In the **Hostname** field, enter the custom hostname which you added to your provider.
4. In the **Username** field, enter the username which you used to sign up to your provider.
5. In the **Password** field, enter the password which you used to sign up to your provider.
6. In the **Verify Password** field, re-enter the password which you used to sign up to your provider.
7. Click **Save** to save and apply the settings.

## DNS server

The DNS server page allows you to configure custom DNS servers for your NTC-550 Series router.

To access the DNS server page, navigate to **Services > DNS server**.

*Figure 9-11 DNS server configuration*

To set the DNS servers:

1. In the **Primary DNS server** field, enter the primary DNS server.
2. In the **Secondary DNS server** field, enter the secondary DNS server.
3. In the **DNS Cache Size** field, enter the size of the cache that should be kept on the router.
4. In the **DNS local TTL** field, enter the time to live (TTL), which is the duration for which a cached request remains in the router.
5. Click the **Save** button to save the configuration.

## GPS

The NTC-550 Series router is equipped with GPS which allows the use of location-based services, to monitor field deployed hardware or find the current location of the NTC-550 Series router. The GPS Status window provides up to date information about the current location and the current GPS signal conditions, Position Dilution of Precision (PDOP), Horizontal Dilution of Precision (HDOP), and Vertical Dilution of Precision (VDOP)) of the router.

### GPS Configuration

The GPS Configuration page allows you to configure the settings related to GPS and displays information about the GPS connection.

### GPS CONFIGURATION

**Enable**  On  Off

### GPS APPLICATIONS

### GPS STATUS

**Positioning data source** Stand-alone GPS

**Date & time** Tue Apr 07 2026 16:53:49 GMT+1000 (Australian Eastern Standard Time)

**Latitude & longitude** 33° 49' 8.4326" S, 151° 0' 27.7268" E  
-33.819009, 151.007702

**Altitude & GEOID height** 53.104187011719 m, 33.139045715332 m

**Horizontal speed** 0 km/h

**Vertical speed** 0 km/h

**PDOP, HDOP & VDOP** 1.2999999523163, 1, 0.80000001192093

**Standalone GPS device status** Normal

**Mobile assisted GPS device status** Invalid status

**Number of satellites** 69

### SATELLITE STATUS

Index	System	GNSS SV ID	Health status	SV status	SNR	Elevation	Azimuth
1	GPS	2	✘	track	26	11	98
2	GPS	5	✔	track	28	10	260
3	GPS	7	✘	track	23	49	95

Figure 9-12 GPS configuration

To enable GPS, set **Enable** toggle to **On** and click **Save** button.

Click **Open Google Maps** to open a Google Maps page with the current GPS location pinned.

The **GPS Status** and **Satellite Status** sections provide an overview of the current GPS details and details of the satellites which are in use.

### Assisted GPS

Assisted GPS enables your router to download GNSS data which supplies orbital data to the GPS receiver, enabling it to lock to the satellites more rapidly. The GNSS data is stored on the router to assist the GPS in locating the router.

To access the Assisted GPS page, navigate to **Services > GPS > Assisted GPS**.

**ASSISTED GPS**

**ASSISTED GPS CONFIGURATION**

Enable  On  Off

Maximum retry count  (1~5)

Retry delay  (5~60) minutes

Auto update period  (0=disable, 1~24) hours

GNSS data last update Wed Apr 08 2026 09:40:28 GMT+1000 (Australian Eastern Standard Time)

GNSS data expires Wed Apr 08 2026 10:40:28 GMT+1000 (Australian Eastern Standard Time)

AGPS last update Wed Apr 08 2026 09:45:24 GMT+1000 (Australian Eastern Standard Time)

*Figure 9-13 Assisted GPS*

To setup automatic updates of GNSS data, set the **Enable** toggle key to the **ON** position and then set the automatic retry options. For each retry, the router checks for an updated GNSS data file and downloads the GNSS data if newer than the currently stored data.

The **GNSS data last update** field represents the time that the GNSS data file was created, the **GNSS data expires** field indicates the time until this data is valid, and the **AGPS last update** field specifies the last time the router attempted to retrieve an update to the GNSS data.

When you have finished configuring the settings, click **Save** to save and apply the settings.

## GPS odometer

The GPS Odometer is used to record the distance that the router has travelled.

To access the GPS odometer page, navigate to **Services > GPS > GPS odometer**.

Figure 9-14 GPS odometer

The table below lists the GPS Odometer details.

Table 9-12 GPS Odometer details

Item	Description
<b>Odometer Configuration</b>	
Enable	Set to <b>On</b> to enable GPS Odometer.
Threshold	Enter the required value. It specifies the minimum distance that the router must travel from its current position before the Odometer reading increases.
Measurement system	Select the unit of measurement for the Odometer reading. The options are <b>metric</b> and <b>imperial</b> .
<b>Odometer Status</b>	
Odometer reading	The distance that the device has traveled since the time listed in the <b>Start time</b> field.
Start time	The time that recording of distance travelled began.

Click **Save** to save and apply the settings.

Click **Reset** to reset the odometer reading to zero and the odometer start time to the current time.

## GPS geofence

The GPS Geofence allows you to designate a circular area and then use the router's GPS position to monitor when the NTC-550 Series router moves out of or into that area. You can configure notifications to be sent when the unit enters or exits the area. Notification types are set on the Event notification configuration page.

To access the GPS Geofence page, navigate to **Services > GPS > GPS geofence**.

The screenshot shows the 'GPS GEOFENCE' configuration interface. At the top, there's a header 'GPS GEOFENCE' in orange. Below it, the main section is 'GEOFENCE CONFIGURATION'. This section includes an 'Enable' toggle switch currently set to 'On', a 'Coordinate units' dropdown menu set to 'Decimal degrees', and a 'Measurement system' dropdown menu set to 'Metric'. A blue 'Save' button is located below these settings. Underneath the configuration section is the 'GEOFENCE LIST' section, which contains a '+ Add' button and a table with the following columns: Name, Latitude (decimal degrees), Longitude (decimal degrees), Radius (km), Status, and Notification.

*Figure 9-15 GPS Geofence*

The table below lists the GPS Geofence Configuration details

*Table 9-13 GPS geofence configuration details*



Item	Description
Enable	Set to <b>On</b> to enable GPS Geofence. When On, your currently defined Geofences display in the Geofence list.
Coordinate units	Select how to display the Coordinate units. The options are <b>Decimal degrees</b> and <b>DMS (Degrees/Minutes/Seconds)</b>
Measurement system	Select the type of Measurement system to display the radius of the geofence. Options are <b>metric</b> (kilometres) and <b>imperial</b> (miles).

Click **Save** to save and apply the settings.

The Geofence List displays the list of the configured geofences and their details.

The table below lists the parameters of the Geofence List.

Table 9-14 Geofence list parameters

Item	Description
Name	Name given to the geofence during configuration.
Latitude (decimal degrees)	Latitude of the center of the geofence.
Longitude (decimal degrees)	Longitude of the center of the geofence.
Radius (km)	Radius of the geofence.
Status	<b>In</b> , if the router is inside the radius. <b>Out</b> , if the router is outside the radius.
Notification	The event that triggers a notification. See Add Geofence in next section for the available notification types.
	Click to edit that Geofence.  The user interface is the same as the add Geofence configuration screen, see next section below.
	Click to delete that geofence.

To add a new geofence click **+Add** button in the Geofence List. The Geofence configuration page displays.

**GPS GEOFENCE**

**GEOFENCE CONFIGURATION**

Name

Latitude  (decimal degrees)

Longitude  (decimal degrees)

Radius  (>= 0 km)

Notification  ▼

Event notifications can be configured on the following page:  
[Event Notification Configuration](#)

Figure 9-16 Geofence configuration

The table below lists the new geofence configuration details.

*Table 9-15 GPS – New Geofence Configuration Items*

Item	Description
Name	Enter a name for the geofence. The geofence is added to the Geofence List with this name.
Latitude	Enter the latitude of the center of the geofence.
Longitude	Enter the longitude of the center of the geofence.
<b>Use current location</b> button	Click to automatically populate <b>Latitude</b> and <b>Longitude</b> values.
Radius	Set the radius of the Geofence.
Notification	<p>Select an event to trigger a notification. The options are:</p> <p><b>None</b> – This effectively turns the Geofence function off, although the router’s location is monitored with respect to the Geofence settings. To properly disable the Geofence function, set the Geofence operation toggle key to the off position.</p> <p><b>Entry</b> – A notification is triggered when the router enters the Geofence radius.</p> <p><b>Exit</b> – A notification is triggered when the router leaves the Geofence radius.</p> <p><b>Entry/Exit</b> – A notification is triggered when the router crosses the Geofence radius line.</p>
Open Google maps button	<p>The <b>Open Google Maps</b> button serves the following purposes:</p> <ul style="list-style-type: none"> <li>• When no latitude and longitude has been entered, click it to display the router’s current location on the map.</li> <li>• When coordinates have been entered, clicking on the Google maps button checks that your coordinates go to where you expect them to be.</li> </ul>

Click **Save** to save the settings and add new geofence or complete editing a geofence.


To configure event notifications, click **Event Notification Configuration** link. It will direct you to Event Configuration section.

## Internet of Things

### MQTT client

MQTT is a standards-based messaging protocol used for machine-to-machine communication. Information is sent to clients in the form of a 'topic'. The NTC-550 Series router can be configured to send device information and neighbouring cells as a topic to common IoT monitoring applications, such as Microsoft Azure IoT Hub and Amazon IoT, using MQTT. The MQTT client page is used to configure the NTC-550 Series router to use the MQTT protocol.

To access the MQTT client page, navigate to **Services > Internet of Things > MQTT client**.



The screenshot shows the MQTT Client Configuration page. At the top, there is a grey header with the text "MQTT CLIENT" in orange. Below this is a white section titled "MQTT CLIENT CONFIGURATION" in blue. Inside this section, there is a toggle switch for "MQTT client enable" which is currently set to "On". Below the toggle is a blue "Save" button. Further down, there is a section titled "CLIENT LIST" in blue, with a blue "+ Add" button to its right. Below the "CLIENT LIST" section is a table with two columns: "Name" and "Client ID". The table is currently empty.

*Figure 9-17 MQTT client configuration*

### Configuring MQTT

#### Prerequisites

To configure MQTT on the NTC-550 Series router, you need to create the device on your external MQTT client provider, and generate certificates and keys as required for secure authentication. Refer to your external MQTT provider's documentation for the required authentication configuration.

To configure MQTT:

1. Set the **MQTT client enable** toggle to **On**.
2. Click **+Add** button to add a new client. The **MQTT Client Setting** page displays.

### MQTT CLIENT

#### MQTT CLIENT SETTING

Name

Host name

Client ID

MQTT port  MQTT: 1883, MQTTS: 8883, default: automatic

Auth username

Auth password

Keepalive  (0-65535) secs

MQTT protocol v3.1.1

CA file Choose a file Not uploaded

Client cert file Choose a file Not uploaded

Client key file Choose a file Not uploaded

#### DEVICE ID DATA

Enable On Off

#### CELL REPORT

Enable On Off

#### GPS LOCATION

Enable On Off

Save
Cancel

*Figure 9-18 MQTT Client configuration*

The table below lists the MQTT Client Setting configuration details.

*Table 9-16 MQTT client configuration details*

Item	Description
Name	Enter the name of the client to identify the client on the NTC-550 Series router
Host name	Enter the Hostname of your client
Client ID	Enter Client Id of the client. The Client Id may match the name of your client provider, for example, the name of your AWS IoT ‘Thing’.

Item	Description
MQTT port	Enter the port MQTT should be initiated over.
Auth username	Enter the username of the connection.
Auth password	Enter the password of the connection.
Keepalive	Enter the number of seconds that the connection should be kept alive.
MQTT protocol	Enter the version of MQTT that should be used.
CA file	Upload the Certificate Authority file.
Client cert file	Upload the client certificate file generated as part of your client's configuration.
Client key file	Upload the client key file generated as part of your client's configuration.

3. Click **Save** to save the settings.
4. Configure MQTT topics. You can configure any one or all the available topics.

### DEVICE ID DATA

Enable  On  Off

Publish topic string

Publish QoS at least once

Minimum publish interval  seconds

### CELL REPORT

Enable  On  Off

Publish topic string

Publish QoS at least once

Minimum publish interval  seconds

### GPS LOCATION

Enable  On  Off

Publish topic string

Publish QoS at least once

Minimum publish interval  seconds



Drift interval  metres

Figure 9-19 MQTT client topics

Table 9-17 MQTT client topics details

Item	Description
<b>Device ID Data</b>	
Enable	Set to <b>On</b> to enable the topic
Publish topic string	Enter a string which will identify the topic on the MQTT client.
Publish QoS	<p>Select the Publish QoS (Quality of Service) for the topic. Three options are available:</p> <ul style="list-style-type: none"> <li>• <b>At most once</b></li> <li>• <b>At least once</b></li> <li>• <b>Exactly once</b></li> </ul> <p>At most once is the lowest level of QoS in MQTT, which offers a best-effort delivery mechanism where the sender does not expect an acknowledgment or guarantee of message delivery. At least once guarantees the message delivery but potentially exists duplicate messages. Exactly ensures that messages are delivered exactly once without duplication</p>
Minimum publish interval	Set the minimum publish level in seconds. This is the amount of time the NTC-550 Series router will wait before attempting to publish a message.
<b>Cell Report</b>	
Enable	Set to <b>On</b> to enable the topic
Publish topic string	Enter a string which will identify the topic on the MQTT client.
Publish QoS	<p>Select the Publish QoS (Quality of Service) for the topic. Three options are available:</p> <ul style="list-style-type: none"> <li>• <b>At most once</b></li> <li>• <b>At least once</b></li> <li>• <b>Exactly once</b></li> </ul> <p>At most once is the lowest level of QoS in MQTT, which offers a best-effort delivery mechanism where the sender does not expect an acknowledgment or guarantee of message delivery. At least once guarantees the message delivery but potentially exists duplicate messages. Exactly ensures that messages are delivered exactly once without duplication</p>
Minimum publish interval	Set the minimum publish level in seconds. This is the amount of time the NTC-550 Series router will wait before attempting to publish a message.
<b>GPS Location</b>	
Enable	Set to <b>On</b> to enable the topic

Item	Description
Publish topic string	Enter a string which will identify the topic on the MQTT client.
Publish QoS	<p>Select the Publish QoS (Quality of Service) for the topic. Three options are available:</p> <ul style="list-style-type: none"> <li>• <b>At most once</b></li> <li>• <b>At least once</b></li> <li>• <b>Exactly once</b></li> </ul> <p>At most once is the lowest level of QoS in MQTT, which offers a best-effort delivery mechanism where the sender does not expect an acknowledgment or guarantee of message delivery. At least once guarantees the message delivery but potentially exists duplicate messages. Exactly ensures that messages are delivered exactly once without duplication</p>
Minimum publish interval	Set the minimum publish level in seconds. This is the amount of time the NTC-550 Series router will wait before attempting to publish a message.
Drift interval	Enter the radius. If the device drifts beyond this radius, the message is sent.

5. Click **Save** to create the client. The client displays in the MQTT client list.
6. Click  icon to edit the client and click  con to delete the client.

### Cumulocity agent

The Cumulocity agent page allows you to configure a cumulocity agent on the NTC-550 Series router which facilitates communication and data exchange between the router and the Cumulocity IoT platform. It enables centralized management and monitoring of devices.

To access the Cumulocity agent page navigate to **Services > Internet of Things > Cumulocity agent**.

**CUMULOCITY AGENT**

### AGENT CONFIGURATION

Agent  On  Off

Version 1.1.2

Device ID

Status stopped

Registered No

Server

GPIO analog measurements  seconds (0=disable)

GPS position update interval  seconds (0=disable)

GPS position event  seconds (0=disable)

System resources measurements  seconds (0=disable)

Connection signal measurements  seconds (0=disable)

ModBus TCP port

ModBus read only

ModBus serial port

Log level

*Figure 9-20 Cumulocity agent configuration*

The table below lists the Cumulocity agent configuration details.

*Table 9-18 Cumulocity agent configuration details*

Item	Description
Agent	Set toggle to <b>On</b> to enable the agent.
Version	Version of the Cumulocity platform.
Device ID	Router's serial number. A unique identifier for the router in Cumulocity.
Status	Status of the agent.

Item	Description
Registered	Displays if the device is registered with the Cumulocity platform.
Clear credentials button	Click to clear credentials related to an existing cumulocity configuration.
Server	Enter the URL of the Cumulocity platform.
GPIO analog measurements	Enter the time interval at which the General Purpose Input/Output GPIO measurements are communicated.
GPS position update interval	Enter the time interval at which the GPS position is communicated.
GPS position event	Enter the time interval to generate a GPS position event. A GPS position event is generated by the device to report its current geographic location, using the c8y_Position fragment.
System resources measurements	Enter the time interval at which system resource measurements such as CPU usage, memory consumption, disk, and network I/O are communicated.
Connection signal measurements	Enter the interval at which the cellular signal measurements are communicated.
ModBus TCP port	Enter the server port for ModBus TCP connection. Default port is 502.
ModBus read only	Enter 0 to disable, 1 to enable.
ModBus serial port	Enter the device serial port for ModBus connection. Default port is /dev/ttyHS1
Log level	Enter the log level to be communicated. The available log levels are: <ul style="list-style-type: none"> <li>• <b>1 – dmesg</b></li> <li>• <b>2 – ipsec</b></li> <li>• <b>3 – logread</b></li> <li>• <b>4 – ntcagent</b></li> </ul>

## Remote management

### OMA-LWM2M

The OMA Lightweight M2M (OMA-LWM2M) protocol was designed by the Open Mobile Alliance to provide remote device management specifically for M2M devices. It is less taxing on the system and network than OMA-DM and TRS-069. OMA-LWM2M runs over UDP and supports asynchronous notifications when a resource changes.

It provides:

- Firmware upgrades
- Device monitoring and configuration
- Server provisioning

To access the OMA-LWM2M page, navigate to **Services > Remote management > OMQ-LWM2M**.

## LWM2M CONFIGURATION

### LWM2M CLIENT CONFIGURATION

LwM2M endpoint

Enable LwM2M  On  Off

Management wwan profile no.  ▼

Management port

### OVERRIDE SERVER SETTINGS

Override enable  On  Off

Override once  On  Off

Server URI

Registration lifetime  (60~86400) seconds

Bootstrap server  On  Off

Queue mode  On  Off

Security mode  ▼

Client identity

PSK coding  ▼

Client Pre-Shared Key

*Figure 9-21 LWM2M configuration*

The table below lists the LWM2M Configuration details.

*Table 9-19 LWM2M Configuration items*

Item	Description
<b>LWM2M Client Configuration</b>	
LwM2M Endpoint Name	This is the unique ID the device will use to identify itself with LwM2M servers.
Enable LwM2M	Set to <b>On</b> to enable LwM2M. The configuration settings display.
Management wwan profile no.	Select the wwan profile to use with LwM2M client. Any profile, except default route, will require VLAN mapping. Refer to VLAN settings section for VLAN setup.

Item	Description
<b>LWM2M Client Configuration</b>	
Management port	Enter the port used for client management. UDP port 5683 is the default port for unencrypted communication. UDP port 5684 is the default port for secure communication.
<b>Override Server Settings</b>	
Override Enable	Set to <b>On</b> to enable Override settings. The configuration settings display.  The LwM2M client maintains the list of servers that it will connect to as part of its internal state. Enabling this setting will allow a user to specify new server details that will override whatever current settings the client has.
Override Once	Enable this option to apply the new server details only once, when the client is restarted (normal flow for configuring/reconfiguring the client) and disable this option to apply the new server details every time the client restarts (used for debugging/troubleshooting.)
Server URI	Enter the URI of the LwM2M server to connect to. It must be a fully specified CoAP or CoAPS URI, including port number, e.g. coap://server.com:5683 or coaps://server.com:5864.
Registration Lifetime	Specify the interval (in seconds) at which the LwM2M client will send registration updates (i.e. heartbeat messages) to the server.
Bootstrap server	Set to <b>On</b> , if the new server is an LwM2M bootstrap server
Queue mode	When set to <b>On</b> , the UDP binding mode is reported to the server as queued (UQ binding mode). When set to <b>Off</b> , it is reported as not queued (U binding mode)
Security mode	Select the security mode to be used to connect to the server. The options are <b>No Security</b> and <b>Pre-shared Key</b> . If Pre-shared key is selected the below fields display.
Client Identity	Enter the identity key associated with your pre-shared key.
PSK coding	Select the type of coding for the key. The options are <b>hex</b> and <b>text</b> .
Client Pre-Shared Key	Enter the key. The key can be a hexadecimal string or a plain text string depending on the <b>PSK coding</b> type selected.

### Supported LWM2M objects

The table below lists the supported object IDs on the NTC-550 Series router. For further information on the objects, refer to the [Open Mobile Alliance LWM2M registry](#).

*Table 9-20 LWM2M supported objects*

Object	Object ID	Note
LWM2M Server	1	

Object	Object ID	Note
LWM2M Access Control	2	
Device	3	
Connectivity Monitoring	4	
Firmware Update	5	
Location	6	
APN Connection Profile	11	
System Log	10259	Custom object
Runtime Database Access	10260	Custom object
Phone Module Info	33040	Custom object

### Timeouts

Most mobile networks use stateful firewalls or NAT where the timeout for UDP is approximately 1-2 minutes. If this applies to you, we suggest either configuring the LwM2M client with a registration lifetime that falls within this period (e.g. 60 seconds) or using the queued ("UQ") UDP binding mode.

## SNMP

The Simple Network Management Protocol (SNMP) allows a network administrator to monitor a network by retrieving settings on remote network devices. To do this, the administrator runs an SNMP management station program such as MIB browser on a local host to obtain information from the SNMP agent, in this case the NTC-550 Series router (if SNMP is enabled). An SNMP 'community' performs the function of authenticating SNMP traffic. A 'community name' acts as a password that is typically shared among SNMP agents and managers.

To access the SNMP page, navigate to **Services > Remote Management > SNMP**.

The screenshot shows the SNMP configuration interface. At the top, the title 'SNMP' is displayed in orange. Below it, the section 'SNMP CONFIGURATION' is shown. The 'SNMP' toggle is set to 'On'. The 'SNMP Port' is set to 161, with a range of 1-65535. The 'Version' dropdown is set to v1v2c. The 'Read-only community name' is set to public, and the 'Read-write community name' is set to private. A blue 'Download MIB' button is located below these fields. The 'SNMP TRAPS' section follows, with its toggle also set to 'On'. It includes fields for 'Trap destination', 'Heartbeat interval' (43200 seconds), 'Trap persistence time' (500 seconds), and 'Trap retransmission time' (21600 seconds). At the bottom of this section are 'Send heartbeat' and 'Save' buttons.

Figure 9-22 SNMP Configuration

### Configuring SNMP

1. Set the **SNMP** toggle to **On** to enable SNMP.
2. In the **SNMP Port** field, enter the SNMP port to be used.
3. Use the **Version** dropdown to set the SNMP version to be used. Available options are **v1v2c** and **v3**.
4. In the **Read-only community name**, enter the read community name of the network.
5. In the **Read-write community name**, enter the write community name of the network.
6. Select the **Save** button below the **SNMP Traps** section to apply the configuration.

---

## Configuring SNMP traps

The NTC-550 Series router can be configured to send SNMP traps to a central SNMP Network Management System (NMS) when certain events occur. To configure the SNMP traps:

1. Set the **SNMP Traps** toggle to **On**.
2. In the **Trap Destination** field, enter the address of the SNMP NMS.
3. In the **Heartbeat interval** field, enter the interval in seconds which the NTC-550 Series router should send a heartbeat.
4. In the **Trap persistence time** field, enter the interval in seconds that the NTC-550 Series router should attempt to send a specific trap after the initial occurrence that triggered the trap.
5. In the **Trap retransmission time** field, enter the interval in seconds that the NTC-550 Series router should wait before retransmitting the trap.
6. Use the **Send heartbeat** button to send a test heartbeat.
7. Click **Save** to save and apply the settings.

## TR-069

The Technical Report 069 (TR-069) protocol is a technical specification also known as CPE WAN Management Protocol (CWMP). It is a framework for remote management and auto-configuration of end-user devices such as customer-premises equipment (CPE) and Auto Configuration Servers (ACS). It is particularly efficient in applying configuration updates across networks to multiple CPEs.

TR-069 uses a bi-directional SOAP/HTTP-based protocol based on the application layer protocol and provides several benefits for the maintenance of a field of CPEs:

- Simplifies the initial configuration of a device during installation
- Enables easy restoration of service after a factory reset or replacement of a faulty device
- Firmware and software version management
- Diagnostics and monitoring

**Note:** *You must have your own compatible ACS infrastructure to use TR-069. To access and configure the TR-069 settings, you must be logged into the router with the root account.*



*When a factory reset of the router is performed via TR-069, the TR-069 settings are preserved.*

The NTC-550 Series router sends “inform” messages periodically to alert the ACS server that it is ready. These inform messages can also be configured to accept a connection request from the ACS server. When a connection is established, any tasks queued on the ACS server are executed. These tasks may be value retrieval or changes and firmware upgrades.

To access the TR-069 configuration page, navigate to **Services > Remote management > TR-069**.

**TR-069**

### TR-069 CONFIGURATION

Enable TR-069  On  Off

ACS URL

ACS username

ACS password

Verify ACS password

Connection request username

Connection request password

Verify connection request password

Connection request port  1-65535

Management wwan profile no.

Enable periodic ACS informs  On  Off

Inform period  (30-2592000) secs

Randomise initial inform  On  Off

Initial inform window  (0-3600) secs

### LAST INFORM STATUS

Start at

End at

### TR-069 DEVICEINFO

Manufacturer

Manufacturer OUI

Model name

Description

Product class

Serial number

Figure 9-23 TR069 configuration

---

To configure TR-069:

1. Set **Enable TR-069** toggle key **ON** position.
2. In the **ACS URL** field, enter the Auto Configuration Server's full domain name or IP address.
3. In the **ACS username** field, specify the username used by the server to authenticate the CPE when it sends an "inform" message.
4. In the **ACS password** and **Verify ACS password** fields, enter the password used by the server to authenticate the CPE when it sends an "inform" message.
5. In the **Connection request username** field, enter the username that the CPE uses to authenticate the Auto Configuration Server during a connection request to the CPE.
6. In the **Connection request password** and **Verify connection request password** fields, enter the password that the CPE uses to authenticate the Auto Configuration Server during a connection request to the CPE.
7. In the **Connection request port** field, enter the port that the request should connect to.
8. In the **Management wwan profile no.** field, enter the WAN profile that should handle the request.
9. Select **Enable periodic ACS informs** toggle key to **On** to turn on the periodic ACS inform messages. The inform message acts as a beacon to inform the ACS of the existence of the router.
10. In the **Inform Period** field, enter the number of seconds between the inform messages.
11. Set the **Randomise Initial inform** to **ON** to enable it. This allows the CPE to wait for a random delay within a configured time window before sending the first Inform. It is helpful where many CPE devices contact the AC at the exact same time after reboot or power-up.
12. In the **Initial inform window** field, enter the number of seconds for initial inform window.
13. Select the **Save** button to save the settings.

### TR-369

TR-369 (User Services Platform – USP ) is a device management protocol that allows you to remotely monitor, configure, and control connected devices such as routers, gateways, and IOT devices. It uses a USP controller-USP agent architecture, where a USP controller (central management system) communicates with a USP agent running on the device.

TR-369 supports secure, real-time, and bidirectional communication over multiple transport protocols such as MQTT, WebSockets, etc. NTC-550 Series router uses MQTT protocol for remote management with TR-369 (USP).

To access the TR-369 page, navigate to **Services > Remote management > TR-369**.


**TR-369**

### TR-369 CONFIGURATION

Enable TR-369  On  Off

MQTT broker

MQTT username

MQTT password  

KeepAlive Time  (1-65535) secs

Connect Retry Time  seconds

Connect Retry Interval Multiplier  (1000-65535)

Connect Retry Max Interval  seconds

Controller Endpoint ID

Periodic Event Notification Interval  seconds

Controller topic

Agent EndPoint ID

Agent topic

Port  1-65535

MQTT version 5

### LAST INFORM STATUS

Start at

End at

### TR-369 DEVICEINFO

Manufacturer Lantronix, Inc.

Manufacturer OUI

Model name NTC-552-01

Description

Product class

Serial number


Figure 9-24 TR-369 configuration settings

Table 9-21 TR-369 configuration details

Item	Description
<b>TR-369 Configuration</b>	
Enable TR-369	Set to <b>On</b> to enable TR-369.
MQTT broker	Enter the hostname or IP address of the MQTT broker to which USP agent connects. This broker acts as the message exchange point between the USP controller and the USP agent.
MQTT username	Enter the username used by the USP agent to authenticate with MQTT broker.
MQTT password	Enter the password for the MQTT username for secure authentication with the MQTT broker.
KeepAlive Time	Enter the time interval in seconds between keepalive messages sent by the USP agent to the MQTT broker to ensure the connection remains active.
Connect Retry Time	Enter the initial delay in seconds before the USP agent attempts to reconnect to the MQTT broker after a connection failure.
Connect Retry Interval Multiplier	Enter the factor by which the retry interval increases after each failed connection attempt.
Connect Retry Max Interval	Enter the maximum time interval in seconds between reconnection attempts.
Controller Endpoint ID	Enter a unique ID for the USP controller. It is used by agent to route messages to the correct controller.
Periodic Event Notification Interval	Enter the time interval in seconds at which the USP agent sends periodic event notifications to the controller.
Controller topic	Enter the MQTT topic on which the USP controller listens for messages from the agent. The agent publishes messages to this topic.
Agent EndPoint ID	Enter a unique identifier for the USP agent. It is used by the controller to identify the agent.
Agent topic	Enter the MQTT topic on which the USP agent listens for messages from the controller. The controller publishes messages to this topic.
Port	Enter the port used to connect to the MQTT broker.
MQTT version	Specifies the version of the MQTT protocol used. The version must be supported by the MQTT broker and the USP agent.

## Serial data status

It shows the details of configured and running data streams.



*Figure 9-25 Serial Data Status*

## Data stream manager

The data stream manager allows you to create mappings between two endpoints on the router. These endpoints may be physical or virtual, for example, a serial port connected to the router’s USB port could be configured as an endpoint or you could configure a TCP Server as an endpoint. You can then configure a virtual data tunnel or “stream” between the endpoints.

The data stream manager provides a wide range of possibilities including the forwarding and translation of data between any of the endpoints. For example, you could send the GPS data from the built-in module to a TCP server running on the router. In each case, the logical flow of the stream is from Endpoint A to Endpoint B.

Customers interested in developing their own applications to create custom endpoints and streams can contact Lantronix about our Software Development Kit.

## Endpoints

To create a data stream, you must first define endpoints. The NTC-550 Series router allows you to define the following types of endpoints:

- Serial port (generic)
- TCP server

- TCP client
- UDP server
- UDP client
- GPS data (for devices with GPS receiver)
- User defined executable
- RS232 port
- RS485 port
- RS422 port
- Modem emulator
- PPP server
- IP modem
- TCP connect-on-demand
- DNP3 master

To access the Endpoints page, navigate to **Services > Data Stream Manager > Endpoints**.

The screenshot shows a web interface for adding endpoints. At the top, there is a section titled "ADD ENDPOINTS" with a dropdown menu for "Endpoint type" currently set to "None". Below this is a section titled "ENDPOINTS LIST" which contains a table with three columns: "Name", "Type", and "Summary". The table is currently empty.

*Figure 9-26 Add Endpoints*

To add an endpoint, select the required **Endpoint type**, the configuration settings for the endpoint display. Once you set the values for all the configuration fields for an endpoint and click Save, the endpoint displays in the Endpoints List.

### Serial Port (generic) Endpoint

When a USB to Serial cable is used, this creates a generic serial port as an endpoint defaulting to the commonly used settings as shown below.

The screenshot shows a configuration dialog titled "ADD SERIAL(GENERIC) ENDPOINT". It contains several configuration fields: "Endpoint name" (text input), "Host port" (dropdown menu set to "Built in serial port"), "Baud rate" (dropdown menu set to "115200"), "Data bits" (dropdown menu set to "8bit"), "Stop bits" (dropdown menu set to "1"), and "Parity bits" (dropdown menu set to "None"). At the bottom of the dialog are two buttons: "Save" and "Cancel".

*Figure 9-27 Serial Port endpoint Configuration*

## TCP Server Endpoint

This creates a TCP server endpoint with the settings below.

**ADD TCP SERVER ENDPOINT**

Endpoint name

Port number  1-65535

Keep alive  On  Off

Keep Count  1-50

Keep idle  1-10000

Keep interval  1-1000

Max children  1-20

*Figure 9-28 TCP Server Endpoint Configuration*

## TCP Client Endpoint

This creates a TCP client endpoint with the following options available. The **Time out** period specifies the number of seconds to wait between attempts to re-establish a connection in the event that it is lost. The client will attempt re-connection indefinitely every Retry timeout interval.

**ADD TCP CLIENT ENDPOINT**

Endpoint name

IP address  .  .  .

Port number  1-65535

Keep alive  On  Off

Keep Count  1-50

Keep idle  1-10000

Keep interval  1-1000

Time out  1-1000

*Figure 9-29 TCP Client Endpoint Configuration*

## UDP Server Endpoint

This creates a UDP server endpoint with the following options available.

**ADD UDP SERVER ENDPOINT**

Endpoint name

Port number  1-65535

Max children  1-20

*Figure 9-30 UDP Server Endpoint Configuration*

### UDP Client Endpoint

This creates a UDP client endpoint with the following options available. The **Time out** period specifies the number of seconds to wait between attempts to re-establish a connection in the event that it is lost. The client will attempt re-connection indefinitely every Retry timeout interval.

**ADD UDP CLIENT ENDPOINT**

Endpoint name

IP address

Port number  1-65535

Time out  1-1000

*Figure 9-31 UDP Client Endpoint Configuration*

### GPS Data Endpoint

This creates a GPS data endpoint.

**ADD GPS DATA**

Endpoint name


*Figure 9-32 GPS Data Endpoint Configuration*

### User Defined Executable Endpoint

Allows you to specify an executable and parameters to be used as an endpoint. For example, the following executable reads the phone module temperature every second.

```
while true; do rdb_get wwan.0.radio.temperature; sleep 1; done
```

The temperature can then be sent to another endpoint.



USER DEFINED EXECUTABLE ENDPOINT

Endpoint name


Command

*Figure 9-33 User Defined Executable Endpoint Configuration*

### RS232/RS485/RS422 Port Endpoints

These endpoint types all use the built-in serial port.

When one of these endpoints is used to create a stream, the hardware switches to accommodate the chosen serial communication interface.



ADD SERIAL(GENERIC) ENDPOINT

Endpoint name

Host port

Baud rate

Data bits

Stop bits

Parity bits

*Figure 9-34 RS232/RS485/RS422 Port Endpoints Configuration*

### Modem Emulator Endpoint

Modem emulator allows you to connect legacy equipment such as an RTU or PLC to the serial port of the router in place of a traditional dial-up modem. The NTC-550 Series router emulates the dial-up modem's behaviour and passes the serial data over the IP network.

### MODEM EMULATOR ENDPOINT (MODEM\_EMULATOR)

Endpoint name

Host port

Baud rate

Data bits

Stop bits

Parity bits

Hardware flow control

Software flow control

DSR action

DCD action

DTR action

RI action

Enable auto answer  On  Off

Circuit auto answer rings

### ADVANCED STATUS

Echo enable  On  Off

Quiet mode  On  Off

Send OK on carriage return  On  Off

Suppress line feeds  On  Off

Send OK on unknown command  On  Off

Verbose mode  On  Off

*Figure 9-35 Modem Emulator Endpoint Configuration*

*Table 9-22 Modem Emulator Endpoint Configuration details*

Item	Description
<b>Modem Emulator endpoint</b>	
Endpoint name	Enter a name for the endpoint.

Item	Description
Host port	Select the serial port to use. If no USB-to-Ethernet adapter is connected, the only available selection is the Built-in serial port.
Baud rate	<p>Select baud rate. The serial (V.24) port baud rate. By default the serial line format is 8 data bits, No parity, 1 Stop bit.</p> <p>Refer to the AT (V.250) AT Command Manual if you need to change the serial line format.</p>
Data bits	Select data bits. The default serial line data bits setting used is 8. Options include 5 – 8 bits.
Stop bits	Select stop bits. The default stop bit setting is set to 1. However, the stop bit setting can be set to 2 bits if required.
Parity bits	Select parity bits. Parity is the means to detect transmission errors. An extra data bit is transmitted with each data character and is arranged in a fashion such that the number of 1 bits in each character, including the parity bit, is always odd or always even. If a byte is received with the wrong number of 1s, then this shows the data must be corrupt. Options include none, odd or even. The default setting is none for no parity checks.
Hardware flow control	<p>Select hardware flow control</p> <ul style="list-style-type: none"> <li>• <b>None</b> – Serial port flow control is disabled</li> <li>• <b>RTS/CTS</b> - Serial port uses RTS/CTS flow control</li> </ul>
Software flow control	<p>Select software flow control</p> <ul style="list-style-type: none"> <li>• <b>None</b> – Software flow control is disabled</li> <li>• <b>Xon/Xoff</b> – Xon resumes transmission and Xoff pauses transmission</li> </ul>
DSR action	<p>Select the Data Set Ready action. This is an output from the modem and this configuration determines the pin's behaviour.</p> <ul style="list-style-type: none"> <li>• <b>Always</b> – DSR is always on.</li> <li>• <b>Registered</b> – When connected to a remote CSD endpoint, sets pin to “on” when modem is in data mode.</li> <li>• <b>Session established</b> – When connected to PPP endpoint, sets pin on when PDP is connected, when connected to IP modem endpoint, sets pin to on when modem is in online state (e.g. data connection is established).</li> <li>• <b>Never</b> – DSR is always off.</li> <li>• <b>Mimic DTR</b> – mimics the DTR pin.</li> </ul>
DCD action	<p>Select DCD action. Determines how the router controls the state of the serial port Data Carrier Detect (DCD) line.</p> <ul style="list-style-type: none"> <li>• <b>Always On</b> – DCD is always on.</li> <li>• <b>Connect</b> – DCD is on when a connection is established in response to an ATD command or DTR dial.</li> <li>• <b>Session established</b> – Pin is on when PPP session is in progress or modem is in an online state (e.g. data connection is established).</li> <li>• <b>Always Off</b> – DCD is always off.</li> </ul>

Item	Description
DTR action	Select DTR action. Determines how the router responds to change of state of the serial port DTR line <ul style="list-style-type: none"> <li>• <b>Ignore</b> – Take no action</li> <li>• <b>Enter Command State</b> – when connected to PPP endpoint, this is equivalent to disconnect. When connected to IP modem endpoint, this enters online command state (e.g. process AT commands without dropping the connection).</li> <li>• <b>Disconnect</b> – terminates connection.</li> </ul>
RI action	Select RI action. Determines how the router controls the state of the serial port RI (Ring Indicator) line. <ul style="list-style-type: none"> <li>• <b>Always On:</b> RI is always on.</li> <li>• <b>Incoming Ring:</b> RI is on when an incoming connection request is received.</li> <li>• <b>Always Off:</b> RI is always off</li> </ul>
Enable auto answer	When enabled, the router accepts incoming connections.
Circuit auto answer rings	Select a value. Sets the number of incoming rings after which the router will answer incoming circuit switched data calls. The default value is Off. The other available options are from 1 to 12.
<b>Advanced Status</b>	
Echo enable	Enables echo on the serial side. All commands are echoes. This can be turned on/off via ATE1 and ATE0 commands. Recommended setting for this option is <b>On</b> .
Quiet mode	When <b>On</b> , there is no output from the modem on the serial side, i.e. you do not see OK, Connect etc. Recommended setting for this option is <b>Off</b> .
Send OK on carriage return	If enabled, will print OK every time CR is received on the serial side. Recommended setting for this option is <b>On</b> .
Suppress line feeds	If enabled, line termination is using CR (13). If disabled, line termination is CR LF (13 10).  Recommended setting for this option is <b>Off</b> .
Send OK on unknown command	Will send OK when an unknown/invalid AT command is received. Recommended setting for this option is <b>On</b> .
Verbose mode	The modem returns messages to the computer to indicate the return status of commands and interrupts such as incoming call and call progress.  Recommended setting for this option is <b>On</b> .

Click **Save** to save and apply the settings.

## PPP Server Endpoint

This creates a point-to-point server endpoint.

### PPP SERVER ENDPOINT (PPP)

Endpoint name

PPP server IP address  ·  ·  ·

PPP client IP address  ·  ·  ·

MTU  128-16384

MRU  128-16384

Raw PPP mode  On  Off

Disable CCP  On  Off

*Figure 9-36 PPP Server Endpoint Configuration*

*Table 9-23 PPP Server Endpoint Configuration details*

Item	Description
Endpoint name	Enter a name for the endpoint.
PPP server IP address	Enter IP address of the PPP server. This defaults to the router's current IP address.
PPP client IP address	Enter IP address of the PPP client. This defaults to the next IP address in the DHCP range after the router's address.
MTU	Enter maximum transmission unit size of packets sent by the PPP server.
MRU	Enter the maximum receive unit size of packets received by the PPP server.
Raw PPP mode	This option is provided for compatibility with legacy devices that assume there is a line available and do not require dial commands to be issued first. Raw PPP mode is turned <b>Off</b> by default.
Disable CCP	This option is provided for use with devices that do not support the compression control protocol. The router uses the compression control protocol and the toggle key is in the <b>Off</b> position by default.

Click **Save** to save and apply the settings.

## IP Modem Endpoint

This endpoint can be used to connect to the modem emulator endpoint to achieve similar functionality to PAD Daemon. It allows a data stream from the serial port to a TCP/UDP server/client and provides modem control lines and AT interpreter on the serial side.

*Figure 9-37 IP Modem Endpoint Configuration*

**ADD IP MODEM ENDPOINT**

Endpoint name

Outgoing connections enabled  On  Off

Incoming connections enabled  On  Off

Mode  ▼

Exclusive mode  On  Off First TCP connection has priority

No send delay  On  Off Selecting ON will disable Nagle algorithm

Keepalive  On  Off

Keepalive count  1-50

Keepalive idle  1-10000 seconds

Keepalive interval  1-1000 seconds

*Figure 9-38 IP Modem Endpoint Configuration*

*Table 9-24 IP Modem Endpoint Configuration details*

Item	Description
Endpoint name	Enter a name for the endpoint.
Outgoing connections enabled	Enables or disables the ability of the router to initiate outbound network connections i.e. act as a networking client. It will attempt to connect to the remote server when relevant activity is detected on the serial side e.g. ATD dial command.
Incoming connections enabled	Enables or disables the ability of the router to accept incoming network connections i.e. act as a networking server. When an incoming connection from a remote client is detected, the router simulates a dial-in call on the serial line.
Mode	Sets the IP modem to either TCP or UDP mode.

Item	Description
Exclusive mode	When this is <b>Off</b> , any new client connection disconnects the previous client connection and uses a new client instead.
No send delay	Disables Nagle algorithm. Disabling this is sometimes important so that serial data is sent as soon as possible instead of waiting for a more optimal block of data for Ethernet. Enabling this effectively reduces latency but increases the amount of network traffic.
Keepalive	Keepalive sends a message to check that the link is still active or to keep it active. When enabled the fields below display.
Keepalive count	Enter the number of keepalive messages to send.
Keepalive idle	Enter the duration between two keepalive transmissions when in idle condition.
Keepalive interval	Enter the duration between two successive keepalive retransmissions.

### TCP Connect-on-demand Endpoint

The TCP connect-on-demand endpoint allows data to be buffered and then sent to a TCP server when the buffer has been filled. It is primarily useful in situations where you do not want 'keep alive' packets to keep the socket open and create an overhead when the TCP data connection is not in use.

### ADD TCP CONNECT-ON-DEMAND ENDPOINT

Endpoint name

Primary server IP address  ·  ·  ·

Port number  1-65535

Backup server IP address  ·  ·  ·  Leave blank if backup server not required

Port number  1-65535

Inactivity timeout  0-10000 seconds, 0 Disconnect immediately

Minimum transmit buffer size  576-1500

Start ID  Send this ID to server when connected

End ID  Send this ID to server before disconnecting

Keep alive  On  Off

Keep Count  1-50

Keep idle  1-10000

Keep interval  1-1000

*Figure 9-39 TCP Connect-on-demand Endpoint Configuration*

*Table 9-25 TCP Connect-on-demand Endpoint Configuration details*

Item	Description
Endpoint name	Enter a name for the endpoint.
Primary server IP address	Enter IP address of the TCP server to which the router should attempt the initial connection.
Port number	Enter the port number that the TCP server operates on.
Backup server IP address	Enter IP address. If connection to the primary server fails, the router will attempt to connect to this address.
Port number	Enter the port number that the backup TCP server operates on.
Inactivity timeout	Enter the period, in seconds, that the socket is considered idle/inactive if no packets are sent. The timer begins at the end of the last sent packet. The valid range is 0-10000 seconds. If this field is set to 0, the client disconnects immediately after sending a packet.

Item	Description
Minimum transmit buffer size	Enter the number of bytes that must be reached before the client decides to transmit.
Start ID	This is a string which, if configured, is sent before any serial data is sent, every time the client connects <START ID><SERIAL DATA>
End ID	This is a string which, if configured, is sent after all serial data, just before the client disconnects <START ID><SERIAL DATA><END ID>
Keepalive	Keepalive sends a message to check that the link is still active or to keep it active. When enabled the fields below display.
Keepalive count	Enter the number of keepalive messages to send.
Keepalive idle	Enter the duration between two keepalive transmissions when in idle condition.
Keepalive interval	Enter the duration between two successive keepalive retransmissions.

### DNP3 Master Endpoint

DNP3 is an industrial communication protocol used for data acquisition and control between master systems and remote (slave) devices. The router allows you to create a DNP3 Master endpoint to initiate and manage communication with remote (slave) DNP3 devices.

### ADD DNP3 MASTER ENDPOINT

Endpoint name

Connection type TCP client ▼

Outstation IP address  .  .  .

Outstation port  1-65535

Local address  (0~65535)

Remote address  (0~65535)

Response timeout  (0~65535)Seconds

Unsolicited responses On Off

Specifying data type requests On Off

Request start index  (0~65535)

Request end index  (0~65535)

Request data type Binary ▼

Request period  (0~65535)Seconds

Save
Cancel

*Figure 9-40 DNP3 Master Endpoint Configuration for TCP client connection*

*Table 9-26 DNP3 Master Endpoint Configuration details for TCP client connection*

Item	Description
Endpoint name	Enter a name for the endpoint.
Connection type	Select <b>TCP client</b> .
Outstation IP address	Enter the IP address of the DNP3 Outstation (slave device) to establish a TCP connection.
Outstation port	Enter the port number on the DNP3 Outstation on which the TCP connection is to be established.
Local address	The DNP3 address of the master. A unique identifying number for the master within the DP3 network.

Item	Description
Remote address	The DNP3 address of the outstation. It must match the address configured on the outstation device.
Response timeout	Enter the time in seconds the master waits for a response after sending a request.
Unsolicited responses	Set to <b>On</b> to enable. When enabled, the outstation can send data without being polled. When disabled, the master only receives data when it explicitly polls the outstation.
Specifying data type requests	Set to <b>On</b> to enable. The related fields display.
Request start index	The index of the starting point of the data range requested. For example, enter 0 to begin from the first data point.
Request end index	The index of the end point of the data range.
Request data type	Select the data type requested: <ul style="list-style-type: none"> <li>• <b>Binary</b></li> <li>• <b>Double Binary</b></li> <li>• <b>Counter</b></li> <li>• <b>Frozen Counter</b></li> <li>• <b>Analog</b></li> <li>• <b>Octet String</b></li> <li>• <b>Analog Output Status</b></li> <li>• <b>Binary Output Status</b></li> </ul>
Request period	Enter the time in seconds. It defines how often the master sends the configured request.

Click **Save** to save and apply the settings.

### ADD DNP3 MASTER ENDPOINT

Endpoint name

Connection type Serial

Device name

Baud rate

Data bits

Stop bits

Parity bits

Flow control

Open delay  (0~65535)Millisec

Local address  (0~65535)

Remote address  (0~65535)

Response timeout  (0~65535)Seconds

Unsolicited responses

Specifying data type requests

Request start index  (0~65535)

Request end index  (0~65535)

Request data type Binary

Request period  (0~65535)Seconds

*Figure 9-41 DNP3 Master Endpoint Configuration for Serial connection*

When the connection type is set to Serial, the **Device name** and serial configuration fields display. The **Device name** specifies the serial interface used by the master.

Select required values for serial configuration fields, **Baud rate**, **Data bits**, **Stop bits**, **Parity bits**, and **Flow control**.

For **Open delay** field enter the time in milliseconds the system waits before starting communication after opening the serial port.

For other configuration settings see [Table 9-25](#).

The configured endpoints display in the Endpoints List.

Figure 9-42 Endpoints List

### ADD ENDPOINTS

Endpoint type None ▼

### ENDPOINTS LIST

Name	Type	Summary		
Serial	Serial	Dev name:/dev/ttyHS1 Baud rate:115200 Parity:none Data bits:8 Stop bits:1		
TCPServer	TCP server	Port number:80 Keep alive:1 Keep count:10 Keep idle:5000 Keep interval:500 Max children:10		

Click icon edit that endpoint and click icon to delete that endpoint.

### Data stream

When you have created the required endpoints, you can then proceed to set up a data stream. A data stream sends data from one endpoint to another, performing any transformation of the data as required. When a stream is added, an underlying process on the router checks the validity of the stream, checking for conflicts and illogical configurations.

**Important:**



- *When any changes to the Data stream manager configuration are detected, all data streams are stopped and restarted as per the new configuration.*
- *Multiple Modbus clients cannot connect simultaneously to Modbus serial slaves connected to the router.*

To access the Data stream page, navigate to **Services > Data Stream Manager > Data Stream**

Figure 9-43 Data Stream List

### DATA STREAM LIST

+ Add

Name	Endpoint A	Mode	Endpoint B	Mode	Enabled	Status

Every Data stream requires two endpoints, Endpoint A and Endpoint B. In all cases, the flow of data is from Endpoint A to Endpoint B.

To create a new Data stream:

1. Click **+Add** in the Data Stream List, the Edit Data Stream page displays.

*Figure 9-44 Edit Data Stream*

2. Set **Activate** toggle to **On** to activate the Data stream.
3. In the **Data stream name** field, enter a name for the Data stream.
4. For **Endpoint A name** field, select one of the endpoints you created previously. This endpoint should be the starting point of the stream.
5. For **Endpoint A mode** field, select the mode of operation of the endpoint. The mode can be thought of as a transformation of the data as it leaves this endpoint. For example, if Endpoint A type is Serial port (generic), the Mode can be set to various Modbus server and client types. This means that upon arrival at Endpoint A, the data will be transformed into the chosen Modbus format, ready to be sent to Endpoint B.
6. For **Endpoint B name** field, select one of the endpoints you created previously. This endpoint should be the destination of the stream.
7. For **Endpoint B mode** field, select the mode of operation of the endpoint. The mode can be thought of as a transformation of the data as it arrives at this endpoint.
8. Click **Save**, the new Data stream displays in the Data Stream List.

Name	Endpoint A	Mode	Endpoint B	Mode	Enabled	Status		
DataStream1	Serial	Raw	TCPServer	Raw	Stopped	Stopped		

*Figure 9-45 Data Stream List with Data Stream*

Click icon to edit that Data stream and click icon to delete that Data stream.

## Event Configuration

### Notification configuration

The NTC-550 Series router can be configured to send notifications when certain events occur on the router. These notifications can be used for proactive monitoring of events such as unit reboots and Ethernet link changes.

### EVENT NOTIFICATION CONFIGURATION

Enable  On  Off

Maximum event buffer size  (100-10000)

Maximum retry count  (1-20)

Event notification log file

Unit ID E651D9

### EVENT NOTIFICATION TYPES AND DESTINATIONS MAPPING

Event ID	Event notification type	Destination profile
1	Unit powered up	Default <input type="button" value="v"/>
2	Unit rebooted	Default <input type="button" value="v"/>
3	Link status change	Default <input type="button" value="v"/>
4	WWAN IP address change	Default <input type="button" value="v"/>
5	WWAN Registration change	Default <input type="button" value="v"/>
6	WWAN Cell ID change	Default <input type="button" value="v"/>
7	WWAN technology change	Default <input type="button" value="v"/>
8	Number of connected Ethernet interfaces change	Default <input type="button" value="v"/>
10	Login status	Default <input type="button" value="v"/>
15	Digital input change	Default <input type="button" value="v"/>
16	Analog input threshold	Default <input type="button" value="v"/>
17	Digital output change	Default <input type="button" value="v"/>
20	FOTA/DOTA status	Default <input type="button" value="v"/>
23	USB connection change	Default <input type="button" value="v"/>
24	GPS GEOFENCE status change	Default <input type="button" value="v"/>
25	Low voltage threshold triggered	Default <input type="button" value="v"/>

Figure 9-46 Event Notification Configuration


To configure Event Notifications:

1. Enable event notifications by setting the **Enable** toggle to **On**.
2. In the **Maximum buffer event size** field, specify the buffer size for event notifications which failed to be delivered or are yet to be sent.
3. In the **Maximum retry count** field, enter the number of times the NTC-550 Series router should attempt to deliver the notification in the event of a delivery failure.
4. If required, adjust the output location of the **Event notification log file**.
5. For each of the **Event Notification Types** select the **Destination Profile**, which specifies where the notification should be sent once they are triggered. For details on how to configure the Destination Profiles, view the [Destination Configuration](#) section.
6. Click **Save** to save and apply the settings.

### Destination configuration

The **Destination Configuration** page allows for the configuration of the Event Destination List, which specifies where notifications should be sent when they are triggered.

Figure 9-47 Log – Event destination list



Multiple destinations can be configured and assigned to different event types, depending on what notifications need to be sent.

To configure or edit an event destination:


1. Click **+Add** to add a destination or  icon to edit an existing destination. The Event Destination Profile Settings page opens.

Figure 9-48 Event Destination Profile settings

2. In the **Destination** name **field** enter a name to identify the destination profile. This name will appear on the Event Notification Configuration page, in the Destination Profile column.
 

**Note:** The Email address, SMS number, TCP address, UDP address and Custom command fields listed below are all optional. Complete the fields which should be included when a notification is sent. The TCP port and UDP port fields are required if using a TCP address or UDP address.
3. In the **Email address** field, enter an email address to receive the notification.
4. In the **SMS number** field, enter a phone number to receive the notification as an SMS.
5. In the **TCP address** and **TCP port** fields, enter a TCP address and TCP port to receive the notification over TCP.
6. In the **UDP address** and **UDP port** fields, enter a UDP address and UDP port to receive the notification over UDP.
7. In the **Custom command** field, enter a custom command to execute when the notification is triggered. The command should be a bash compatible command.
8. Select the **Save** button to save the destination profile.
9. Apply the destination profile by returning to the **Event Configuration > Event Notification Configuration** page.
10. Use the **Destination profile** dropdown for an event to select the required notification Destination for that event.

EVENT NOTIFICATION TYPES AND DESTINATIONS MAPPING		
Event ID	Event notification type	Destination profile
1	Unit powered up	<div style="border: 1px solid #ccc; padding: 2px;">           Default <span style="float: right;">▼</span> </div> <div style="border: 1px solid #ccc; padding: 2px; margin-top: 2px;">           Default         </div> <div style="border: 1px solid #ccc; padding: 2px; margin-top: 2px; background-color: #0070c0; color: white;">           Destination1         </div>

*Figure 9-49 Services – Event Configuration – Destination profile mapping*

11. Click **Save** button at the bottom of the **Event Notification Configuration** page.

### Event notification log

The **Event Notification Log** displays a log of Events which have been triggered. Click **Update** button to refresh the content in the Log Content window. Click **Download** button to download a log file for review in an external application. Click **Clear** button to clear the log.




Figure 9-50 Event notification log

### Email settings

Email settings allows you to configure the SMTP server to be used to deliver Event Notifications (configured in the Event notification configuration section).

To access the Email settings page, navigate to **Services > Email settings**.




Figure 9-51 Email Client Setting

The table below lists the Email Server Settings Configuration Details

Table 9-27 Email Server Settings Configuration details






Item	Description
From	Enter Email address that should represent sender of the email notification.
CC	Enter Email address or addresses that the notification should be sent to.
Email server address (SMTP)	Enter Domain name of the SMTP server that the email should be sent through.
Email server port	Enter the port that the SMTP server is expecting email on. The port varies depending on the encryption type used, refer to your email provider's SMTP instructions on which port is correct. The available encryption types are <b>STARTTLS (Port 587)</b> , <b>SSL/TLS (Port 465)</b> , or <b>Default (Port 25)</b> .
Encryption	Select the encryption type from the drop-down. Available types are <b>STARTTLS</b> , <b>SSL/TLS</b> , <b>None</b> .
Enable authentication	Set to <b>On</b> if the SMTP server is expecting authentication.
Username	Enter Username to authenticate with the SMTP server.
Password	Enter Password to authenticate with the SMTP server.
Confirm password	Re-enter the password to authenticate with the SMTP server.
Email test recipient	Enter recipient email address here after completing the previous details to test the SMTP configuration.
<b>Send test email</b> button	Click to send the test email to the address configured in the <b>Email test recipient</b> field.

Click **Save** to save and apply the settings.

## Low power mode

The Low power mode page provides an overview of the power profiles and allows you configure them. Up to five power profiles can be configured and all of them can be active simultaneously.

To access the Low power mode page, navigate to **Services > Low power mode**.

LOW POWER MODE				
POWER PROFILE LIST				
Name	Status	Sleep mode	Wake mode	
Profile1	On <input type="checkbox"/> Off <input checked="" type="checkbox"/>	Scheduled	Ignition	
Profile2	On <input type="checkbox"/> Off <input checked="" type="checkbox"/>	Scheduled	Ignition	
Profile3	On <input type="checkbox"/> Off <input checked="" type="checkbox"/>	Scheduled	Ignition	
Profile4	On <input type="checkbox"/> Off <input checked="" type="checkbox"/>	Scheduled	Ignition	
Profile5	On <input type="checkbox"/> Off <input checked="" type="checkbox"/>	Scheduled	Ignition	
<input type="button" value="Save"/>				

*Figure 9-52 Low power mode profiles*

The **Status** column indicates whether the profile is active, while the **Sleep mode** and **Wake mode** columns display the method set for router sleep and wake functions.



**Important:** When configuring multiple power profiles, be careful so that they do not overlap or conflict with one another, for example, configuring a schedule which wakes up the unit when another profile has it scheduled to be in low power mode.


Click  icon to edit that profile.

Figure 9-53 Low Power Mode Configuration

The table below lists the Low Power Mode configuration details.

Table 9-28 Low Power Mode Configuration Items

Item	Description
<b>Power Profile Settings</b>	
Profile	Set to <b>On</b> to activate the profile
Profile name	Enter a name for the profile.
<b>Sleep Settings</b>	
Sleep mode	Select Sleep mode from the following options: <ul style="list-style-type: none"> <li>• <b>Sleep triggered by Ignition pin</b></li> <li>• <b>Sleep after timer</b></li> <li>• <b>Sleep at scheduled time</b></li> </ul> The Sleep mode selects the condition for the router to enter sleep mode.
Remain awake after ignition off	Enter the duration for which the router should remain awake after ignition is off, when Sleep mode is selected as <b>Sleep triggered by Ignition pin</b> .
Sleep after timer	Enter the duration after which the router should go to sleep mode, when Sleep mode is selected as <b>Sleep after timer</b> .
Schedule sleep time	Enter the time when the router should go to sleep mode, when Sleep mode is selected as <b>Sleep at schedule time</b> .
Wake mode	Select Wake mode from the following options: <ul style="list-style-type: none"> <li>• <b>Wake up triggered by Ignition pin</b></li> <li>• <b>Wake up triggered by bt button</b></li> <li>• <b>Wake at scheduled time</b></li> </ul> The Wake mode selects the condition for the router to wake up.

Item	Description
Schedule wake up at	Enter the time when the router should wake up, when the Wake mode is selected as <b>Wake at scheduled time</b> .

Click **Save** to save the settings, the configured profile displays in the Power Profile List.

### IO configuration

The NTC-550 Series router is equipped with a 6-way terminal block connector providing three identical multipurpose inputs and outputs as well as a dedicated ignition input. These inputs and outputs may be independently configured for various functions, including:

- NAMUR (EN 60947-5-6 / IEC 60947-5-6) compatible proximity sensor input
- Proximity sensor input for use with contact closure (open/closed) type of sensors (PIR sensors, door/window sensors for security applications) with the input tamper detection possible (four states detected: open, closed, short and break) using external resistors
- Analogue 0V to 30V input
- Digital input (the I/O voltage measured by the iMX283 LRADC and the software making decision about the input state) with the threshold levels configurable in software
- Open collector output.

To access the IO configuration page, navigate to **Services > IO configuration**.

**IO CONFIGURATION**

IO functionality  On  Off

Pull up voltage 3V

IO manager debug level  error notice info debug

**PIN CONFIGURATION**

Pin	Mode	Pull up	Threshold	Value
1	Digital Input	<input type="checkbox"/> On <input checked="" type="checkbox"/> Off	1.6	Low
2	Digital Input	<input checked="" type="checkbox"/> On <input type="checkbox"/> Off	1.6	High
3	Digital Input	<input type="checkbox"/> On <input checked="" type="checkbox"/> Off	1.6	Low

**Save**

Figure 9-54 IO Configuration

Use the pull up voltage options to select the desired output voltage of the I/O pins. The pull up voltage you select will be the same for each pin when pull up is enabled for that pin. Each pin is capable of outputting either 3 V or 8.2 V.

The table below lists the IO configuration details.

*Table 9-29 IO Configuration Items*

Item	Description
<b>IO Configuration</b>	
IO Functionality	Enables the configuration of the input and output pins on the four-way terminal block connector.
Pull up voltage	Specifies the output voltage of the I/O pins.
IO Manager Debug level	Use the slide bar to adjust the level of detail you would like to see in the log for IO messages. A higher debug level displays more detailed messages in the log file.
<b>Pin Configuration</b>	
Pin	The I/O pin number corresponding to the pin on the 6-way terminal block connector that you wish to configure.
Mode	<p>The mode of operation for the corresponding pin.</p> <p>Available options are:</p> <ul style="list-style-type: none"> <li>• <b>Digital Input</b> – The corresponding pin accepts digital input. Pull up may be on or off and both 3 V and 8.2 V are available as pull up voltages. The value column displays whether the signal received on the pin is High or Low. The default value is High. When the I/O pin is shorted to ground the value changes to Low.</li> <li>• <b>Digital Output</b> – The corresponding pin outputs a digital signal. Pull up may be on or off and both 3 V and 8.2 V are available as pull up voltages. The value column contains a toggle key allowing you to set whether the output signal is High or Low. When set to Low, the output of the I/O pin is 0 V. When set to High, the output of the I/O pin is 5 V.</li> <li>• <b>Analogue input</b> – The corresponding pin accepts an analogue signal. Pull up may be on or off and both 3 V and 8.2 V are available as pull up voltages. The value column displays the current voltage detected on the pin.</li> <li>• <b>Namur input</b> – NAMUR is a sensor standard using low-level current signals. It can supply two different signal levels depending on the state of the switch and is commonly used in hazardous or explosive locations where compact sensors are required. When a pin is set to NAMUR mode, Pull up is turned on and the global Pull up voltage is set to 8.2 V. These settings may not be changed for as long as a pin is set to NAMUR mode as they are required settings according to the NAMUR IEC 60947-5-6 standard.</li> </ul>

Item	Description
	<p>The value column displays whether the signal received on the pin is High or Low.</p> <ul style="list-style-type: none"> <li>• <b>Contact closure input</b> –A common type of digital input where a sensor or switch opens or closes a set of contacts as a result of a process change. An electrical signal is then used to determine whether the circuit is open or closed. When a pin is set to Contact closure input, Pull up is enabled for that pin and may not be turned off as long as the pin remains configured as a Contact closure input. Global pull up voltage may be either 3 V or 8.2 V.</li> </ul>
Pull up	<p>Use the pull up toggle keys to turn the pull up <b>On</b> or <b>Off</b> for the corresponding pin.</p> <p>When turned <b>On</b>, the pull up voltage output is the value specified in the “Pull up voltage” option in the IO configuration section of this dialog box.</p>
Threshold	Displays the current voltage threshold configured for the I/O pin.
Value	<p>The value column displays whether the voltage detected on the line is low or high or allows you to set the output value to high or low.</p> <p>This can be useful for applications where monitoring of the transition between low and high is used to trigger an action.</p>

Click **Save** to save and apply the settings.



**Important:** Please refer to the SDK Developer Guide for hardware information about the Input/Output pins, wiring examples and configuration of the pins via the command line interface. There are also wiring examples in Appendix J of this User Guide.

## PercepXion

The NTC-550 series router comes integrated with PercepXion cloud platform to allow for remote management of devices.

### Configuration

The configuration page allows you to configure the PercepXion client settings. To access the configuration page, navigate to **Services > PercepXion > Configuration**.

The screenshot displays the 'PERCEPXION CLIENT CONFIGURATION' interface. At the top, the word 'PERCEPXION' is written in orange. Below it, the title 'PERCEPXION CLIENT CONFIGURATION' is in blue. The settings are as follows:

- Enable:** A toggle switch set to 'On'.
- Device ID:** An empty text input field.
- Device Key:** An empty text input field.
- Serial Number:** An empty text input field.
- Device Name:** An empty text input field.
- Device Description:** A text input field containing 'Lantronix NTC-552'.
- Status Update Interval (in minutes):** A text input field containing '5'.
- Send Dynamic Updates:** An unchecked checkbox.
- Content Check Interval (in hours):** A text input field containing '48'.
- Apply Firmware Updates:** A checked checkbox.
- Apply Configuration Updates:** A dropdown menu set to 'Always'.
- Reboot After Update:** A checked checkbox.
- Allow Remote Connections:** A checked checkbox.
- Remote Access Local Port:** A text input field containing '999', with a range indicator '1-65535' to its right.
- Audit Log:** An unchecked checkbox.
- Active Connection:** A dropdown menu set to 'Connection 1'.

At the bottom center of the form is a 'Save' button.

Figure 9-55 PercepXion client configuration settings

Table 9-30 PercepXion configuration details

Item	Description
Enable	Set to <b>ON</b> to enable PercepXion client.
Device ID	Displays the Device ID. Read only.
Device Key	Displays <Configured>. Read only.
Serial Number	Displays the device Serial Number. Read only.
Device Name	Displays the PercepXion Device name. You can modify this value as required.
Device Description	Displays the PercepXion Device description. You can modify this value as required.
Status Update Interval (in minutes)	Enter the time interval in minutes at which the gateway updates the device status to PercepXion
Send Dynamic Updates	Click the checkbox to enable. If enabled, the device will send updates for RSSI and temperature. The fields will be dynamically updated on PercepXion.
Content Check Interval (in hours)	Enter the time interval in hours at which the device checks PercepXion for updates to configuration or firmware.
Apply Firmware Updates	Click the checkbox to allow firmware updates to be applied via PercepXion.
Apply Configuration Updates	Select when to apply configuration updates. Options are: <ul style="list-style-type: none"> <li>• <b>Always:</b> Always apply configuration updates.</li> <li>• <b>Never:</b> Never apply configuration updates.</li> </ul>
Reboot After Update	Click the checkbox to automatically reboot the device after configuration update.
Allow Remote Connections	Click the checkbox to allow remote connections.
Remote Access Local Port	Enter the local port for remote access connection.
Audit Log	Click the checkbox to enable. If enabled, the device will send audit events such as user login, firmware update, configuration update, and CLI access to PercepXion server.
Active Connection	Select the connection instance to use when connecting to PercepXion. Options are: <ul style="list-style-type: none"> <li>• <b>Connection 1</b></li> <li>• <b>Connection 2</b></li> </ul> You can configure two connection instances.

Click **Save** to save and apply the settings.

## Connection 1

The Connection 1 page allows you configure the settings for PercepXion connection instance **Connection 1**. To access Connection 1 configuration page, navigate to **Services > PercepXion > Connection 1**.

*Figure 9-56 Connection 1 configuration settings*

*Table 9-31 Connection1/Connection2 configuration details*

Item	Description
Connect To	Select the type of PercepXion connection. Options are: <ul style="list-style-type: none"> <li>• <b>Cloud</b></li> <li>• <b>Premise</b></li> </ul>
Host	Enter the host name or IP address of the PercepXion server, used to register the device.
Port	Enter the PercepXion port. Default port is 443.
Secure Port	Click the checkbox to enable the PercepXion client secure port 443.
Validate Certificates	Click the checkbox to enable the validation of the PercepXion server certificates. To validate certificates, both MQTT Security and Secure Port must be enabled.
Local Port	Enter local port for the PercepXion client. When configured, a total of 32 consecutive ports will be reserved.

MQTT State	Click the checkbox to enable MQTT.
MQTT Port	Enter the port number of the PercepXion MQTT server. When configured, a total of 32 consecutive ports will be reserved.
MQTT Security	Click the checkbox to enable SSL for MQTT.
MQTT Local Port	Enter the local port for PercepXion MQTT client. When configured, a total of 32 consecutive ports will be reserved.

Click **Save** to save and apply the settings.

## Connection 2

The Connection 2 page allows you configure the settings for PercepXion connection instance **Connection 2**. To access Connection 2 configuration page, navigate to **Services > PercepXion > Connection 2**.

See [Table 9-30](#) for configuration details.

## 10. System

The

### Log

The Log section allows you to download the System logs, Diagnostic logs and IPSec logs on the router.

#### System log

The System Log enables you to troubleshoot any issues you may be experiencing with your NTC-550 Series router. To access the System Log page, navigate to **System > Log > System log**

The Log Filter Level allows you to select the type of logs you want to download

*Table 10-1 Log – System Log Filter Level*

Item	Description
Debug	Shows extended system log messages with full debugging level details.
Info	Shows informational messages only.
Notice	Shows normal system logging information.
Warning	Shows warning messages only.
Error	Shows error condition messages only.

Once you have selected the Log Filter Level, click **Download** to download the log file.

The downloaded log file is in Linux text format with carriage return (CR) only at the end of a line, therefore it is recommended to use a text file viewer which displays this format correctly (e.g. Notepad++).

#### System log settings

To access the System log settings, navigate to **System > Log > System log settings**.

Log data is stored in RAM and therefore when the unit loses power or is rebooted the RAM will lose any log information stored in the RAM. To ensure that log information is accessible between reboots of the router there are two options:

- Enable the Log to non-volatile memory option.
- Use a Remote syslog server.

Figure 10-1 Log – System log settings

### Log capture level

The log capture level defines the amount of detail that the system log stores. This setting also affects the Display level setting on the System log page, for example, if this is set to a low level, such as “Error”, the System log will not be able to display higher log levels.

Table 10-2 Log - System Log Settings – Log Capture Level

Item	Definition
Debug	Shows extended system log messages with full debugging level details.
Info	Shows informational messages only.
Notice	Shows normal system logging information.
Warning	Shows warning messages only.
Error	Shows error condition messages only.

### Volatile Log

The size of the volatile log buffer can be configured to store larger logs if required. The default is 256KB.

### Non-volatile Log

When the router is configured to log to non-volatile memory, the log data is stored in flash memory, making it accessible after a reboot of the router.

### Remote syslog server

The router can be configured to output log data to a remote syslog server. This is an application running on a remote computer which accepts and displays the log data. Most syslog servers can also save the log data to a file on the computer on which it is running allowing you to ensure that no log data is lost between reboots.

To configure the NTC-550 Series router to output log data to a remote syslog server enter IP address or hostname of the syslog server in the **IP / Hostname [:PORT] field** in Remote Syslog Server section. You can also specify the port number after the IP or hostname by entering a semi-colon and then the port number e.g. 192.168.1.102:514. If you do not specify a port number, the router will use the default UDP port 514.

Click **Save** to save and apply all the above settings.

*Figure 10-2 Log – System log settings – Remote syslog server*

REMOTE SYSLOG SERVER

IP / Hostname [:PORT]

**Save**

### Diagnostic log

The router may be configured to enable the collection of diagnostic logs for the purpose of troubleshooting problems. These log files are intended for use by Lantronix technicians. By default, this feature is disabled and should only be enabled if you are trying to find out the cause of a problem and are instructed to enable this by Lantronix technical support staff.

DIAGNOSTIC LOG

LOG CONFIGURATION

Diagnostic log collection  On  Off

Log capture interval  ▾

Maximum diagnostic log size  100-10000 (KB)

Maximum kernel panic data size  1-1000 (KB)

**Save**

LOG CAPTURE INFORMATION

Number of captured diagnostic logs 0

Captured kernel panic data 0 (KB)

*Figure 10-3 Log – Diagnostic log configuration and download*

*Table 10-3 Diagnostic log descriptions*

Item	Description
Diagnostic log configuration	

Item	Description
Diagnostic log collection	Turn on this toggle key to enable diagnostic log collection.
Log capture interval	Select the interval at which the router should collect diagnostic log data.
Maximum diagnostic log size (KB)	Enter the maximum size of the log file in kilobytes.
Maximum kernel panic data size (KB)	Enter the maximum size of the kernel panic data file in kilobytes.
<b>Save</b> button	Click to save Log Configuration.
<b>Log capture information</b>	
Number of captured diagnostic logs	Displays the number of captured periodic logs.
Captured kernel panic data (KB)	Displays the total size of captured kernel panic data in kilobytes.
<b>Download</b> button	Click to download all captured logs.
<b>Clear</b> button	Click clear all captured periodic logs.

## IPSec log

The IPSec Log allows you to identify and troubleshoot issues with the IPSec VPN connection. To access the IPSec Log page, navigate to **System > Log > IPSec log**.

### IPSEC LOG

**common level**  the common level for all types

Please set the level for each type

**app**  applications other than daemons

**dmn**  Main daemon setup/cleanup/signal handling

**mgr**  IKE\_SA manager, handling synchronization for IKE\_SA access

**ike**  IKE\_SA/ISAKMP SA

**chd**  CHILD\_SA/IPsec SA

**job**  Jobs queuing/processing and thread pool management

**cfg**  Configuration management and plugins

**knl**  IPsec/Networking kernel interface

**net**  IKE network communication

**asn**  Low-level encoding/decoding (ASN.1, X.509 etc.)

**enc**  Packet encoding/decoding encryption/decryption operations

**lib**  libstrongswan library messages

**esp**  libipsec library messages

**tls**  libtls library messages

**tnc**  Trusted Network Connect

**imc**  Integrity Measurement Collector

**imv**  Integrity Measurement Verifier

**pts**  Platform Trust Service

### LOG CONTENT

There is no log content, please check the IPSec VPN configuration or connection status.

**Figure 10-4 IPSec Log**

To use the IPsec log, set the **common level** for each type of log that should be captured. The following log levels are available:

*Table 10-4 common level log options*

ITEM	DEFINITION
Off	No logs collected.
0 (auditing)	Auditing is the lowest log level, providing minimal information. This level is typically used for logging only critical security events or administrative actions that have a significant impact on the VPN.
1 (control low)	Control Flow logging provides information about the establishment and termination of IPsec VPN connections and security associations (SAs). Control Flow includes details about the negotiation of encryption and authentication parameters, as well as key exchange protocols like IKE (Internet Key Exchange).
2 (debug control flow)	Debug Control Flow logging provides more detailed information than the standard Control Flow level. Debug Control Flow includes additional debugging information related to the establishment and management of IPsec SAs.
3 (raw data dumps)	Raw Data Dumps logging is a very verbose level that includes detailed packet-level information. Raw Data Dumps logs raw data, such as the contents of IPsec packets and payloads.
4 (private data dumps)	Private Data Dumps logging is the highest log level and provides the most detailed information. Private Data Dumps logs sensitive and private data, such as encryption keys and other security-related information. This level should only be used in a secure environment for advanced debugging or security analysis.

Once the log level has been set, click **Save** button to apply the log configuration.

You can also set the level for individual log types as required. This will override the common level for that log type.

As logs are collected, they are visible in the Log Content section at the bottom of the page. Click **Update** button to refresh the Log Content window.

Click **Download** button to download and view the logs in an external tool

## Watchdog

### Periodic ping

The Periodic ping page allows you to configure the behaviour of the Periodic Ping monitor function.

When configured, the Ping watchdog feature transmits controlled ping packets to 1 or 2 user specific IP addresses. Should the watchdog not receive responses to the pings, it will reboot the device in a last resort attempt to restore connectivity.

Caution should be exercised when using this feature in situations where the device is intentionally offline for a particular reason (e.g. user configured PDP session disconnect, or the Connect on demand feature enabled). The

ping watchdog feature expects to be able to always access the internet and will always eventually reboot the router if access isn't restored by the time the various timers and retries expire.

The ping watchdog being a last resort standalone backup mechanism, it will continue to do its job and reboot the device even when the Connect on demand session is idle, or the PDP context is disabled by the user. It is recommended to disable this feature if Connect on demand is configured, or if the PDP context will be intentionally disconnected on the occasion.

The feature operates as follows:

1. After every "Periodic Ping timer" configured interval, the router sends 3 consecutive pings to the "First destination address".
2. If all 3 pings fail the router sends 3 consecutive pings to the "Second address".
3. The router then sends 3 consecutive pings to the "Destination address" and 3 consecutive pings to the "Second address" every "Retry timer" configured interval.
4. If all retry pings in step 3 above fail the number of times configured in "Fail count", the router reboots.
5. If any ping succeeds, the router returns to step 1 and does not reboot.

**WATCHDOG**

**PERIODIC PING**

Enable  On  Off

First destination address

Second destination address

Periodic Ping timer  (300-65535) secs

Retry timer  (0=disable, 60-65535) secs

Fail count  (1-65535) times

**PERIODIC REBOOT**

Enable  On  Off

Force reboot every  (5-65535) mins

Random delay before reboot

Figure 10-5 Watchdog page

To configure the ping watchdog:

1. Enable the ping watchdog by setting the **Enable** toggle to **On**.
2. In the **First destination address** field, enter a website address or IP address to which the router will send the first round of ping requests.
3. In the **Second destination address** field, enter a website address or IP address to which the router will send the second round of ping requests.

4. In the **Periodic Ping timer** field, enter a number between 300 and 65535 for the number of seconds the router should wait between ping attempts. Setting this to 0 disables the ping watchdog function.
5. In the **Retry timer** field, enter a number between 60 and 65535 for the number of seconds the router should wait between retry ping attempts, i.e. pings to the second destination address.
6. In the **Fail count** field, enter an integer between 1 and 65535 for the number of times an accelerated ping should fail before the router reboots. Setting this to 0 disables the ping watchdog function.
7. Click **Save** to save and apply the settings.

### Periodic reboot

The router can be configured to automatically reboot after a period of time specified in minutes. While this is not necessary, it does ensure that in the case of remote installations, the router will reboot if some anomaly occurs.

To configure Periodic reboot:

1. Set the **Enable** toggle to **On**.
2. In the **Force reboot every** field, enter the time in minutes between forced reboots. The default value is 0 which disables the Periodic reboot function. The minimum period between reboots is 5 minutes while the maximum value is 65535 minutes.
3. If you have configured a forced reboot time, select a time for **Random delay before reboot** from the drop-down list. Randomly delaying the reboot time is useful for preventing a large number of devices from rebooting simultaneously and flooding the network with connection attempts. When configured, the router waits for the configured Force reboot every time and then randomly selects a time that is less than or equal to the **Random delay before reboot** time setting. After that time has elapsed, the router reboots.



**Important:** *The Random delay before reboot time is not persistent across reboots; each time the router is due to reboot, it randomly selects a time less than or equal to the time set for Random delay for reboot.*

4. Click **Save** to save and apply the settings.

## System configuration

### LDAP Settings

The LDAP Settings allows you to configure a Lightweight Directory Access Protocol (LDAP) on the NTC-550 Series router. The LDAP allows the router to use a centralized directory service for user authentication and authorization.

Figure 10-6 LDAP Settings

Table 10-5 LDAP Configuration

Item	Description
Enable LDAP	Set to <b>On</b> to enable LDAP
Use LDAP Secure	Set to <b>On</b> to enable use of LDAP over SSL/TLS, a secure version of LDAP.
Registered	Displays whether the LDAP server is registered on the router.
<b>Clear Credentials</b> button	Click to clear credentials related to an existing LDAP configuration.
LDAP Basedn	Enter the LDAP Base Distinguished Name. It specifies the starting point within the LDAP directory tree from which searches will be performed.

Item	Description
LDAP Binddn	Enter the LDAP Bind Distinguished Name of the LDAP entry used to authenticate (bind) to the LDAP server.
LDAP Server List	Enter the IP address or Hostname of the LDAP server and port number. (IP address/Hostname:Port)
LDAP Admin Binddn	Enter the LDAP Admin Bind Distinguished Name, which refers to a special Bind DN with administrative privileges in the LDAP directory.
LDAP Admin Bind Password	Enter the password for the LDAP Admin Bind DN used.
<b>Save</b> button	Click to save and apply the settings.

### Restore factory defaults

Restoring factory defaults will reset the NTC-550 Series router to its factory default configuration. You may encounter a situation where you need to restore the factory defaults on your NTC-550 Series router.

To access the Restore factory defaults page, navigate to **Services > System configuration > Restore factory defaults**.

*Figure 10-7 Restore factory defaults*

The **Reset to factory default settings** is generally used for refurbishment or to remove an erroneous configuration. This will remove all settings including the carrier settings that are required for the device to operate on the network. All configurations and settings are completely removed.




**Important:** The full factory reset will require the NTC-550 Series to be completely reconfigured.

To perform a factory reset:

1. Click the **Clear HTTPS certificate** checkbox if you want to clear the HTTPS certificate.
2. Select **Reset to factory default settings**.

3. Click **Reset**. You will be prompted to confirm. Click **OK** to proceed with the reset.



4. Wait for the router to reset and reboot, then access the device through the web interface at **https://192.168.1.1**

### Web server setting

Allows you to configure and generate a Web Server certificate and also upload an existing Web Server certificate.

To access the Web server setting page, navigate to **System > System configuration > Web server setting**.

#### WEB SERVER CERTIFICATE

**Certificate serial number** 11432044149183B88B2BFFEE1F18EF68C9EC7BB4

**Not before** Nov 20 02:14:29 2024 GMT

**Not after** Feb 23 02:14:29 2027 GMT

**Server key size**

**Country**

**State**

**City**

**Organization**

**Generate server certificate**

#### UPLOAD WEB SERVER CERTIFICATE

Alternatively, please provide a web server certificate in a .zip file that contains the certificate and key file.

*Figure 10-8 Web server setting*

To generate a Web Server certificate, select required **Server Key size** and enter required values for all the fields in the Web Server Certificate section. Then click **Generate**.

To upload a Web Server certificate, click **Choose a file**, locate and select the certificate.

## Administration settings

The Administration settings page allows you to update administration credentials and Web UI login limits.

To access the Administration settings page, navigate to **System > System configuration > Administration settings**.

### ADMINISTRATION SETTINGS

#### WEB UI CREDENTIALS

Username

Current password

New password

Confirm new password

#### WEB UI LOGIN LIMIT

Incorrect login attempt limit  (3-5)

Login lock duration  (1-10 minutes)

IP login attempt limit  (5-8)

LAN IP address lock duration  (5-10 minutes)

WAN IP address lock duration  (10-20 minutes)

Session timeout  (5-60 minutes)

#### SSH CREDENTIALS

Username

Current password

New password

Confirm new password

Figure 10-9 Administration settings

## Web UI credentials

Use this section to update the password for the different users that have access to the NTC-550 Series router via the web interface.

*Table 10-6 Web UI credentials configuration details*

Item	Description
Username	Select the user whose password needs to be updated.
Current password	Enter the current password for that user.
New password	Enter the new password.
Confirm new password	Re-enter the above password.
<b>Save</b> button	Click to save and apply the settings.

## Web UI login limits

The Web UI login limits section allows you to configure the timeout and lock setting for access to the web interface. It is designed to improve security by reducing the risk of brute force attacks on the web interface.

*Table 10-7 WebUI login limits configuration details*

Item	Description
Incorrect login attempt limit	Enter the number of times an incorrect password can be entered into the web interface before it locks access and does not allow any further attempts.
Login lock duration	Enter the amount of time the login lock lasts.
IP login attempt limit	Enter the number of logins that can be attempted from one IP before any further attempts are locked out.
LAN IP address lock duration	Enter the amount of time an IP attempting to log in from the LAN is forbidden from trying to login.
WAN IP address lock duration	Enter the amount of time an IP attempting to log in from the WAN is forbidden from trying to login.
Session timeout	The amount of time in minutes that a logged in session lasts on the web interface without any activity. The web interface will log out the current user after the configured time.
<b>Save</b> button	Click to save and apply the settings

## SSH credentials

Use this section to update the password for SSH access to the NTC-550 Series router. The default SSH username is root.

## Settings backup/restore

The Settings Backup and Restore page allows you to backup or restore the router's configuration. To view this page, you must be logged in to the web user interface as root or admin. The backup / restore functions can be used to easily configure many NTC-550 Series routers by configuring one router with your desired settings, backing them up to a file and then uploading that file to multiple NTC-550 Series routers.

To access the Settings Backup and Restore page, navigate to **System > System configuration > Settings backup/restore**.

Figure 10-10 Settings backup and restore

### Creating a settings backup

To create a settings backup, in the Save a Copy of Current Settings section, click the **Save** button. The configuration will download. If you wish to protect the configuration with a password, enter a password in the **Password** and **Confirm password** fields, then click **Save**.

### Restoring a settings backup

To restore a settings backup:


1. In the Restore Saved Settings section, click **Choose a file** for the **Select file to upload** field.
2. Locate and upload the saved configuration.
3. If the file was saved with a password, enter the password, then click **Restore**. You will be prompted to confirm, select **Ok** to proceed. The device will reboot with the saved settings.

Figure 10-11 Systems configuration – Restoring a settings backup confirmation

## Site and location settings

The Site and location settings allows you to add a name that displays in the System information section of the Status page. This can be useful for identifying the particular device you are using when you have a fleet of them in various locations.

To access the Site and location settings page, navigate to **System > System configuration > Site and location settings**.




*Figure 10-12 Site and location settings*

Enter the values for **Site name** and **Location** fields. Click **Save** to save and apply the settings

## Runtime configuration

Runtime Configuration allows you to load a configuration file containing carrier-specific settings such as default settings, MBN changes which is not possible via the web user interface. It is used for late binding of carrier configurations at the time of installation.

To access the Runtime configuration page, navigate to **System > System configuration > Runtime configuration**.



*Figure 10-13 Runtime configuration*

To apply runtime configuration:

1. Click the **Choose a file** button, locate the configuration file and select it.
2. **Uploaded** displays next to the button.
3. Click the **Apply** button to install the configuration file.
4. The device automatically reboots after successful upload of the configuration file.

## SSH key management

Secure Shell (SSH) is UNIX-based command interface and network protocol used to gain secure access to a remote machine, execute commands on the remote machine, and transfer files between machines.

SSH uses RSA public key cryptography for both connection and authentication. Two common ways of using SSH are:

- Use automatically generated public-private key pairs to encrypt the network connection and then use password authentication to log on.
- Use a manually generated public-private key pair to perform the authentication and allow users or programs to log in without using a password.

To access the SSH key management page, navigate to **System > System configuration > SSH Key Management**.

**SSH SERVER CONFIGURATION**

**SSH SERVER SETTINGS**

SSH Protocol: Protocol 2

Password Authentication enable: On

Key Authentication enable: On

Save

**HOST KEY MANAGEMENT**

Key type	Date
ssh_host_rsa_key	2026-03-19 02:35:40
ssh_host_ecdsa_key	2026-03-19 02:35:40
ssh_host_ed25519_key	2026-03-19 02:35:40

Generate keys | Get keys | Get public keys | Upload keys

**CLIENT KEY MANAGEMENT**

Username	Hostname	Key type	Delete
Clear   Upload			

Figure 10-14 SSH server configuration

## SSH Server Configuration

To configure the SSH server settings:

1. Select the **SSH Protocol** to use. Protocol 2 is more recent and is considered more secure.
2. Select the type of authentication you want to use by setting **Password Authentication enable** and **Key Authentication enable** toggle keys to **On** or **Off**. Note that you may have both authentication methods on, but you cannot turn them both off.


3. Click the **Save** to save and apply the settings.

### Host key management

The Host key management section allows you to manage the SSH keys on the NTC-550 Series router.

Click the **Generate Keys** button to generate new keys. Use caution when selecting the **Generate Keys** button, as this invalidates any previously generated keys.

Click the **Get Keys** button to download the generated private and public keys. You will be asked to enter a password for the keys file.



Enter the password for the keys file

Password

Confirm password


OK Cancel

In the **Password** field enter a password and in the **confirm password** field, re-enter the password. Click the **OK** button to download the keys file.

Click the **Get Public Keys** button to download just the public keys.

Click the **Upload keys** button to upload a keys file. You will be prompted to enter the password created in the **Get Keys** step to upload the file. The keys will replace the previously generated keys.


### Client key management

The Client key management section allows you to upload client keys to the NTC-550 Series router and enables key based SSH access to the NTC-550 Series router. Click the **Upload** button to upload the public key of your SSH client. The key displays in **Client key management** window. Click  in the **Delete** column to remove that key. Click **Clear** to clear all the uploaded keys.

### LED operation mode

The LED operation mode page allows you to control the operation of the LED indicator lights on the NTC-550 Series router. There are two modes available, **Always on** and **Turn off after timeout**. Setting the mode to **Always on** sets the indicator LEDs to be lit when the device is on. Setting the mode to **Turn off after timeout** sets the indicator LEDs to turn off after the timer has expired.

To access LED operation mode page, navigate to **System > System configuration > LED operation mode**.



LED OPERATION MODE

LED OPERATION MODE SETTING

Mode

Save

Figure 10-15 LED operation mode

### Setting the LED operation mode

To set the LED operation mode:



1. Select the **Mode** to use. Options are **Always on** and **Turn off after timeout**.
2. If using the **Turn off after timeout** mode, set the LED power off timer to the number of **minutes** that the indicator LEDs should be lit after the device has started.
3. Click **Save** to save and apply the settings.

## A/B system

The A/B system page allows you to switch between an active and previous firmware. Switching between firmware allows you to restore a previous firmware for troubleshooting in the event of an issue with the current firmware. Restoring a previous firmware should only be used for troubleshooting.


To access the A/B system page, navigate to **System > System configuration > A/B system**.

Figure 10-16 A/B System configuration

A/B SYSTEM CONFIGURATION			
CURRENT STATUS			
Bank	Firmware version	Module firmware version	Status
A	1.2.61.0		Standby
B	2.3.1.0R3		Active

[Switch active bank](#)

To switch the active bank, click the **Switch active bank** button. You will be prompted with the following message:



To proceed click the **OK** button. Once the reboot is complete, the previous firmware will be restored. To switch active banks again, return to this screen and select the **Switch active bank** button.

## Firmware upgrade

The Firmware upgrade page allows you to upload firmware files to the NTC-550 Series router and perform a Firmware Upgrade. The firmware upgrade will be applied to the Standby bank, to ensure the current firmware can be restored in the event of an issue. Once the Firmware is successfully upgraded and the device reboots, the Standby bank becomes Active bank.

To access the Firmware Upgrade page, navigate to **System > Firmware Upgrade**.

The screenshot shows the 'FIRMWARE UPGRADE' page. At the top, there is a table with the following data:

Bank	Firmware version	Module firmware version	Status
A	1.2.61.0	<input type="text"/>	Standby
B	2.3.1.0R3	<input type="text"/>	Active

Below the table is the 'UPGRADE FIRMWARE' section. It includes a 'Select firmware to upload' label, a 'Choose a file' button, and 'Not uploaded' text. There is also a 'Reset to default config' toggle with 'On' and 'Off' options. A note states: 'The system must be rebooted to complete the firmware upgrade. Please choose when you would like the reboot to occur.' Below this is a 'Reboot' dropdown menu set to 'Immediately' and an 'Upgrade' button.

Figure 10-17 Firmware Upgrade

## Updating the router firmware

To update the NTC-550 Series router's firmware:

1. In the Upgrade Firmware section, click **Choose a file** button. Locate the firmware image file on your computer and select **Open**.
2. If required set the **Reset to default config** toggle to **On** to reset the NTC-550 Series router to the default configuration.
3. Select an option for Reboot field. The options are **Immediately** and **Scheduled**. If you select **Scheduled** option, the **Date** and Time **settings** display.

Reboot: Scheduled

Date: Mar 2026

Su	Mo	Tu	We	Th	Fr	Sa
1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31				

Time: 06:44 AM

*Figure 10-18 Scheduled Firmware Upgrade*

4. Set the required **Date** and **Time**.
5. Click **Upgrade** button to upgrade the firmware.

## SD Card


The SD card page displays available space and contents of micro-SD card, when installed.


To access the SD card page, navigate to **System > SD card**.

You can click **Upload** to add a file to the SD Card.

## Access control

The Access control page allows you to configure remote and local access protocols to access the router.

 **Note:** All remote access to the router is disabled by default.



**ACCESS CONTROL**

**REMOTE ACCESS CONTROL**

HTTPS enable  On  Off [Update server certificate if necessary](#)

HTTPS port  1-65535

HTTPS source IP allow list

Comma-separated list of unicast IP addresses and/or network IP addresses (with /mask where mask is a plain number). If it is blank, all IP addresses are permitted.

SSH enable  On  Off

SSH port  1-65535

Ping enable  On  Off

**LOCAL ACCESS CONTROL**

HTTPS enable  On  Off

SSH enable  On  Off

Figure 10-19 Access control page

Table 10-8 Access control configuration details


Item	Description
<b>Remote Access Control</b>	
HTTPS enable	Enable or disable remote HTTPS access to the router.
HTTPS port	When HTTPS is enabled you can set the HTTPS remote access port. Enter a port number between 1 and 65534 to use when accessing the router remotely over a secure HTTPS connection.
HTTPS source IP allow list	When HTTPS is enabled you can enter a 'whitelist' of IP addresses that will be permitted to access the router.  Enter a list of comma-separated unicast IP addresses. You may also enter IP addresses in CIDR notation, however, no spaces are permitted.  If this field is left blank, all IP addresses will be permitted to access the router.
SSH enable	Enable or disable Secure Shell access to the router.

Item	Description
SSH port	When SSH is enabled you can set the SSH access port.  Enter the port number for remote SSH access. The port number must be between 1 and 65534.
Ping enable	Enable or disable remote ping responses on the WWAN connection.
<b>Local Access Control</b>	
HTTPS enable	Enable or disable local secure HTTP access (https). It is enabled by default.
SSH enable	Enable or disable local Secure Shell on the router. It is enabled by default.
<b>Save</b> button	Click to save and apply the settings.

## Reboot

The Reboot page provides you the option to perform a soft reboot of the device. This can be useful if you have made configuration changes you want to implement.


To access the Reboot page, navigate to **System > Reboot**.



*Figure 10-20 Reboot*

To reboot the NTC-550 Series:

1. Click **Reboot**. The below prompt is displayed.



2. If you wish to proceed, click **OK** button.

## Field test

The Field test page displays the following information which may be useful when troubleshooting signal strength issues.

- LTE PCELL Information
- LTE SCELL Information
- 5G NR Serving Cell Information
- 5G NR Extended Information

To access the Field test page, navigate to **System > Field test**.

FIELD TEST											
LTE PCELL INFORMATION											
PCI	EARFCN	Band	Bandwidth	UL power	DL/UL modulation	Rank	CQI				
1	2525	5	10MHz		/						
LTE SCELL INFORMATION											
CC ID	PCI	EARFCN	Band	Bandwidth	UL configured	State					
5G NR SERVING CELL INFORMATION											
CC ID	Cell ID	DL ARFCN	UL ARFCN	SSB-ARFCN	Band	Band type	DL BW	UL BW	DL max MIMO	UL max MIMO	RSRP (dBm)
5G NR EXTENDED INFORMATION											
CQI	DL modulation			UL modulation			RX SINR (dB)				

Figure 10-21 Field Test

Table 10-9 LTE PCELL Information

LTE PCELL INFORMATION	
Item	Description
PCI	Physical Cell ID of the LTE Cell.
EARFCN	E-UTRA Absolute Radio Frequency Channel Number. Uniquely identifies the LTE Band and carrier frequency.
Band	The current LTE band.
Bandwidth	The current LTE bandwidth.
UL power	The transmit power used by the device for uplink communication to the serving cell.

LTE PCELL INFORMATION	
Item	Description
DL/UL modulation	The modulation scheme used for downlink (DL) and uplink (UL) transmissions.
Rank	The number of transmission layers used in MIMO communication between the device and the serving cell.
CQI	The quality of the radio channel as reported by the device.

*Table 10-10 LTE SCELL Information*

LTE SCELL INFORMATION	
Item	Description
CC ID	Component Carrier ID.
PCI	Physical Cell ID of the LTE Cell.
EARFCN	E-UTRA Absolute Radio Frequency Channel Number. Uniquely identifies the LTE Band and carrier frequency.
Band	The current LTE band.
Bandwidth	The current LTE bandwidth.
UL Configured	Indicates if the uplink is configured.
State	The current state of the LTE SCELL.

*Table 10-11 5G NR Serving cell information*

5G NR Serving Cell Information	
Item	Description
CC ID	Component Carrier ID.
Cell ID	The physical cell identifier.
DL ARFCN	Downlink Absolute Radio Frequency Channel Number.
UL ARFCN	Uplink Absolute Radio Frequency Channel Number.
SSB-ARFCN	Absolute Radio Frequency Channel Number corresponding to the Synchronization Signal Block (SSB) of the serving cell.
Band	The NR5G band.
Band Type	The type of the NR5G band, e.g. Sub6 or mmWave.
DL BW	Downlink bandwidth.
UL BW	Uplink bandwidth.

5G NR Serving Cell Information	
Item	Description
DL max MIMO	Downlink maximum Multiple Input Multiple Output.
UL max MIMO	Uplink maximum Multiple Input Multiple Output.
RSRP (dBm)	The average power level of reference signals received from the serving cell.

*Table 10-12 5G NR Extended Information*

5G NR Extended Information	
Item	Description
CQI	Indicates the quality of the downlink radio channel as reported by the device.
DL modulation	Specifies the modulation scheme used for downlink transmissions from the serving cell to the device.
UL modulation	Specifies the modulation scheme used for uplink transmissions from the device to the serving cell.
RX SINR (dB)	Received Signal to Interference plus Noise Ratio. The ratio of the received signal power to the combined interference and noise.

## Encrypted debuginfo

The Encrypted debuginfo page contains 5G NR cell information which may be useful when troubleshooting signal strength issues.

To access the Encrypted debuginfo page, navigate to **System > Encrypted debuginfo**.

Click **Generate** to force the NTC-550 Series router to create a debug file. A success message will display when the debug file generation is complete. Click **Download** to download the generated file.




*Figure 10-22 Encrypted debuginfo*

## USB-OTG

The USB-OTG page allows you to enable or disable the USB port. The port is enabled by default.

To access the USB-OTG page navigate to **System > USB-OTG**.



The screenshot shows the 'USB-OTG CONFIGURATION' interface. It includes the following elements:

- Enable port:** A toggle switch currently set to 'On'.
- Current status:** Displays 'device mode'.
- Automatic mode:** A toggle switch currently set to 'On'.
- Manual selection:** A dropdown menu currently set to 'Host'.
- Save:** A blue button at the bottom to apply the changes.

*Figure 10-23 USB-OTG Configuration*

When the port is enabled, the USB-OTG page displays the current status of the USB port, i.e. whether it is in **Device mode** or **Host mode**.

**Automatic mode** is set to **On** by default, allowing the router to intelligently choose the correct mode. If you wish to manually override this selection, turn **Automatic mode** to **Off** and set **Manual selection** to **Host** or **Device** mode.

## Storage

The Storage page provides the list of storage devices and configuration options with relation to USB and SD storage devices.

To access the Storage page, navigate to **System > Storage**.

*Figure 10-24 Storage Settings Configuration*

The Storage Device List displays any connected storage devices and summarises the type, file system, size, used space, and available space on each device. Additionally, an eject button is provided to unmount the storage device so you can safely remove it.

Storage devices connected to the router can be shared using the Samba protocol. The table below lists the Network Samba Storage Settings Configuration details

*Table 10-13 Network Samba Storage Settings Configuration Items*

Item	Description
Storage access	Set to <b>On</b> to enable Samba sharing function
Verbose logging	Set to <b>On</b> to provide additional logging data in the system log. This should generally only be used when debugging to avoid generating excessively long logs.
<b>Authenticated Access</b>	
Username	The username to be used for authenticated access to the storage device. This is configured as <b>smbuser</b> and cannot be changed.

Item	Description
Password	Enter the password to be used for authenticated access to the storage device.
Verify password	Re-enter the password to be used for authenticated access to the storage device.
Read-only	Set to <b>On</b> to provide read-only access to the files on the connected storage device(s). When read-only access for authenticated accounts is turned on, the guest access read-only option is hidden and guests are provided read-only access also.
<b>Guest access</b>	
Guest access	Set to <b>On</b> to enable guest access to the storage device.
Read-only	Set to <b>On</b> , to provide read-only access to the files on the connected storage device(s) for guest users. If the authenticated account has Read-only enabled then this option is not available and read-only access is automatically granted to guest users.

Click **Save** to save and apply the settings.

## Voltage Monitor

The Voltage Monitor page displays the Current Input Voltage and allows you to set a threshold voltage for event notification.

To access the Voltage Monitor page navigate to **System > Voltage Monitor**.

*Figure 10-25 Voltage Monitor Configuration*

**VOLTAGE MONITOR**

**VOLTAGE MONITOR CONFIGURATION**

Current input voltage 11.649813

Event notification threshold  8v to 38v

**EVENT NOTIFICATION CONFIGURATIONS**

Event notifications can be configured on the following page:  
[Event Notification Configuration](#)

Save


In the **Event notification threshold** field, enter the value for threshold voltage. If the voltage drops below this value, notification is generated.

Click **Save** to save the settings

Click the **Event Notification Configuration** link to go to Event Notification Configuration page.

## 11. Help

The Help page provides links to access the NTC-550 Series User Guide and Lantronix Support Portal. To access the Help page, click the **Help** tab on the top menu bar.




**LANTRONIX** | Status | Networking | Services | System | **Help** | root

### HELP

**Product User Guide and Additional Resources**

Find out more at <https://www.lantronix.com/products/ntc-550-series>

For further support, please visit <https://tickets.lantronix.com/>



**Trademark Notice**

On December 26, 2024, Lantronix, Inc. acquired the Industrial Internet of Things (IIoT) product portfolio from NetComm Wireless Pvt Ltd and is authorized to use the NetComm trademark in association with this product. This product may reference NetComm.

*Figure 11-1 Help page*

## Appendix A. Configuring Radio Access Technologies

This device supports the following modes of operations in various combinations

- **LTE** (3GPP Core Network Option 1)
- **5G Non Standalone** (3GPP Core Network Option 3x)
- **5G Standalone** (3GPP Core Network Option 2)

Please refer to the following table to understand which modes of operation are possible and how to configure them.

*Table A-1 RAT/Band Selection table*

Mode	Allowed RAT			Supported	How to Configure	
	LTE	5G NSA	5G SA		RAT Selection Menu	Band Selection Menu
LTE Only	Yes	No	No	Yes	Select LTE only	Select LTE Frequency Bands
LTE + 5G NSA	Yes	Yes	No	Yes	Select LTE + 5G NR	Select LTE + NSA Frequency Bands
5G NSA Only	No	Yes	No	No	–	–
LTE + 5G NSA + 5G SA	Yes	Yes	Yes	Yes	Select LTE + 5G NR	Select LTE + NSA + SA Frequency Bands
LTE + 5G SA	Yes	No	Yes	No	–	–
5G NSA + 5G SA	No	Yes	Yes	No	–	–
5G SA Only	No	No	Yes	Yes	Select 5G NR	Select SA Frequency Bands

Use this table in conjunction with the settings described in sections **6.2.1.3 RAT selection** and **6.2.1.2 Band selection** of this guide.

 **Note:** 5G Standalone Mode is not supported when utilising mmWave frequency bands.


## Appendix B. Inputs / Outputs

The NTC-550 Series router is equipped with a 6-way terminal block connector providing 3 identical multipurpose inputs and outputs as well as a dedicated ignition input. These inputs and outputs may be independently configured for various functions, including:

- NAMUR (EN 60947-5-6 / IEC 60947-5-6) compatible sensor input
- Proximity sensor input for use with contact closure (open/closed) type of sensors (PIR sensors, door/window sensors for security applications) with the input tamper detection possible (four states detected: open, closed, short and break) by the use of external resistors
- Analogue 2.7V to 30V input
- Digital input (the I/O voltage measured by the Analogue input and the software making a decision about the input state) with the threshold levels configurable in software
- Open collector output.

### Hardware Interface

The interface of the 3 multipurpose inputs/outputs are based on the circuit diagram below



The Input/Output label is the physical connection to the outside world. There are protection devices and resistor dividers to condition the signal prior to it going into the processor. The three labels to the right are the interface to the processor. Output Enable activates the Transistor which provides an open collector (ground) output and can sink 200mA at 230C. It is protected by a resettable fuse and transient protection diode. If used with the pull up resistor, which can be activated by the Pull up Voltage Enable pin, then you can have a High or Low output rather than open drain. The resistor can be pulled up to 3V3 for Cmos compatible output or 8.2V by software. The Analogue Input pin can read values from 0V to 30V. It is divided by a resistor network to read appropriate levels in the processor. Depending on the sensor type used, the pull up resistor can be switched on or off. If using the NAMUR sensor configuration, the pull up will be activated to 8V2 by default.


## Wiring examples

The following examples are shown as a guide as to what can be achieved by the I/O features. It is up to the system integrator to have enough knowledge about the interface to be able to achieve the required results.

**Important:** Lantronix does not offer any further advice on the external wiring requirements or wiring to particular sensors and will not be responsible for any damage to the unit or any other device used in conjunction with it. Using outputs to control high voltage equipment can be dangerous. The integrator must be a qualified electrician if dealing with mains voltages controlled by this unit.


## Open Collector Output driving a relay

Any output can be configured to control a relay. This is an example where the transistor will supply the ground terminal of the solenoid. External voltage is supplied to the other side of the solenoid.




## Logic level output

An output can be used with the pull up resistor to provide a logic level output which would be suitable to control an external digital device.



## LED output


An LED can be controlled by simply providing an open collector ground to an externally powered LED Resistor value and Voltage will need to suit the LED type used. Alternatively, an LED can be powered using 8V2 via 1K resistor. The suitability of the LED will need to be investigated.





### Digital inputs

There are several ways to connect a digital input. A digital input can be anything from a simple switch to a digital waveform or pulses. The unit will read the voltage in as an analogue input and the software will decode it in a certain way depending on your configuration.

Below is a contact closure type input, which is detecting an Earth. Pull up is activated for this to work.




The following input detects an input going high. The turn on/off threshold can be set in the software.




## NAMUR sensor

A NAMUR sensor is a range of sensors which conform to the EN 60947-5-6 / IEC 60947-5-6 standards. They basically have two states which are reflected by the amount of current running through a sense resistor.




## Analogue Sensor with Voltage output

There are various analogue sensors that connect directly to the unit which can provide a voltage output. These would require an external power source which may or may not be the same as the unit itself. The voltage range they provide can be between 2.7V and 30V. Some common sensor output ranges include 0V to 10V. These would work on the unit, The pull up resistor is not activated in this case.




## Analogue Sensor with 4 to 20mA output

Another common type of sensor type is the 4-20mA current loop sensor. It provides a known current through a fixed resistor, usually 750 ohms thus producing a voltage of 3v to 15V at the input. The sensor would require an external power source which may or may not be the same as the unit itself. It will also require an external resistor. The internal pull up resistor is not activated.



## Analogue Sensor with Thermistor


Some sensors work by changing resistance due to a change, such as temperature, light etc. These may be wired up to an external or internal power source and the resistance can be read into the analogue signal. This will require some software calibration like scaling or offset to map the voltage received to the sensor resistor value. An example below shows the internal pull-up voltage and 1K resistor activated. The voltage received depends on the combination of resistors and the value of the resistance of the sensor itself.




**Note:** Need to choose NTC with maximum temperature to have impedance > 500 Ohms

## System Example – Solar powered router with battery backup

The previous examples of wiring can be used to come up with a system. The following test case is an example of how the I/O's can be used to enhance a simple router setup.



## Power detection (ignition) input



The Power detection or Ignition input will detect the presence of three states from the connector side (outside world). It will detect three states, those being High, Low and Unconnected (floating).

The detection uses both analogue and digital inputs to the microprocessor.

- This is the “LOW” state:  
If input voltage at POWER port is less than 0.5V the transistor Q1 is shut, POWER FAIL is asserted high advising micro that no Backup Power is present on POWER port.
- This is the “Floating” state:  
If voltage at POWER port is 0.5-3V POWER FAIL signal de-asserts but POWER MON signal can be measured by ADC of micro and advise the system that there is little or no connection to the unit.
- This is the “HIGH” state:  
If voltage at POWER port is higher than 3.3V (which normally is an indication of presence of decent power source), the POWER FAIL is still de-asserted, the POWER MON will measure from 3.3V up to whatever voltage is detected. The maximum detection voltage is 30V and clamps to anything above 36V.

The states can be adjusted in software to fine tune the transition points between the states.

## Appendix C. Compliance Information

(According to ISO/IEC Guide and EN 45014)

### Manufacturer's Name & Address:

Lantronix, Inc. 48 Discovery, Suite 250, Irvine, CA 92618 USA

### Product Family:



NTC-550 Series

Conforms to the following standards or other normative documents:

Country	Models	Specification
Australia – RCM	NTC-552	Supplier's Declaration of Conformity
USA – FCC	NTC-551	FCC ID: R68NTC551
Canada – IC	NTC-551	IC: 3867A-NTC551
EU	NTC-552	See EU Declaration of Conformity (see <a href="#">Figure C-1</a> )
UK	NTC-552	See UK Declaration of Conformity (see <a href="#">Figure C-2</a> )
Safety	NTC-552	EN IEC 62368-1 AS/NZS 62368-1


## EU Declaration of Conformity

Figure C-1 EU Declaration of Conformity


  

  
**EU DECLARATION OF CONFORMITY**

**Manufacturer's Name:** LANTRONIX, INC.  
**Manufacturer's Address:** 48 Discovery, Suite 250 Irvine, CA 92618 USA  
**Model Name:** NTC-552  
**Rated:** 12Vdc, 3A  
**Intended use:** Commercial installations, indoor use

**Manufacturer's Quality System:**



ISO 9001:2015 Certificate No. 74 300 4282 TUV Rheinland

**Applicable EU Directives:**

**Low Voltage Directive (2014/35/EU)**

- EN IEC 62368-1:2020/A11:2020

**EMC Directive (2014/30/EU)**

- EN 301 489-1 V2.2.3 (2019-11) Class B
- EN 301 489-17 V3.2.4 (2020-09)
- EN 301 489-19 V2.2.1 (2022-09)
- EN 301 489-52 V1.2.1 (2021-11)
- EN 55032:2015/A11:2020, Class B
- EN 55035:2017+A11:2020
- EN 61000-3-2:2014 Class A
- EN 61000-3-3:2013

**RF Radio Directive (2014 / 53 / EU)**

- EN 301 908-1 V15.2.1(2023-01)
- EN 301 908-2 V13.1.1 (2020-06)
- EN 301 908-13 V13.2.1 (2022-02)
- Draft EN 301-908-25 V15.1.1\_15.0.9 (2021-06)
- EN 300 328 V2.2.2 (2019-07)
- EN 301 893 V2.1.1 (2017-05)
- EN 303 413 V1.2.1 (2021-04)


**Health Directive (2014 / 53 / EU)**

- EN IEC 62311:2020

**RoHS 2011/65/EU(RoHS 2.0) & and its subsequent amendments Directive (EU) 2015/863**

- EN 62321-2:2021

**Statement of Conformity:** The product specified above complies with applicable EU directive referenced, including the application of sound engineering practice.

Signature:  \_\_\_\_\_ Date: 26 Jun 2025  
 Name: Steve Burrington Title: Vice President RnD

CERT-00512 rev A

## EU Statements

Table C-1 EU Statements

Code	Language	Statement
bg	Bulgarian	<p>Lantronix, Inc., декларира, че този NTC-550 Series отговаря на основните изисквания и други приложими разпоредби на Директива 2014/53/EU.</p> <p>Пълният текст на декларацията на ЕС за съответствие е достъпен на следния интернет адрес: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>Известие на ЕС за ограничения при употреба: Това устройство е ограничено само за вътрешна употреба. Може да не се работи наоткрито.</p>
cs	Česky [Czech]	<p>Lantronix, Inc. tímto prohlašuje, že tento NTC-550 Series je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 2014/53/EU.</p> <p>Úplné znění ES prohlášení o shodě je k dispozici na této internetové adrese: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>Oznámení EU o omezení používání: Toto zařízení je omezeno pouze na použití uvnitř. Nesmí být provozován venku.</p>
da	Dansk [Danish]	<p>Undertegnede Lantronix, Inc. erklærer herved, at følgende udstyr NTC-550 Series overholder de væsentlige krav og øvrige relevante krav i direktiv 2014/53/EU.</p> <p>Den fulde tekst til EU-overensstemmelseserklæringen er tilgængelig på følgende internetadresse: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>EU-meddelelse om begrænsninger i brug: Denne enhed er kun begrænset til indendørs brug. Det betjenes måske ikke udendørs.</p>
de	Deutsch [German]	<p>Hiermit erklärt Lantronix, Inc., dass sich das Gerät NTC-550 Series in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 2014/53/EU befindet.</p> <p>Der vollständige Text der EU-Konformitätserklärung ist unter folgender Internetadresse abrufbar: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>EU-Hinweis zu Nutzungsbeschränkungen: Dieses Gerät darf nur in Innenräumen verwendet werden. Es darf nicht im Freien betrieben werden.</p>
et	Eesti [Estonian]	<p>Käesolevaga kinnitab Lantronix, Inc. seadme NTC-550 Series vastavust direktiivi 2014/53/EU põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.</p> <p>EL-i vastavusdeklaratsiooni täielik tekst on saadaval järgmisel Interneti-aadressil: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>EL-i teade kasutuspiirangute kohta: seda seadet saab kasutada ainult siseruumides. Seda ei tohi õues kasutada.</p>

Code	Language	Statement
en	English	<p>Hereby, Lantronix, Inc., declares that this NTC-550 Series is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.</p> <p>The full text of the EU declaration of conformity is available at the following internet address: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>EU Notice of Restrictions on Use: This device is limited to indoor use only. It may not be operated outdoors.</p>
es	Español [Spanish]	<p>Por medio de la presente Lantronix, Inc. declara que el NTC-550 Series module cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 2014/53/EU.</p> <p>El texto completo de la declaración de conformidad de la UE está disponible en la siguiente dirección de Internet: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>Aviso de restricciones de uso de la UE: este dispositivo está limitado solo para uso en interiores. No puede ser operado al aire libre.</p>
el	Ελληνική [Greek]	<p>ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Lantronix, Inc. ΔΗΛΩΝΕΙ ΟΤΙ ΝΤC-550 Series ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 2014/53/EU.</p> <p>Το πλήρες κείμενο της δήλωσης συμμόρφωσης της ΕΕ διατίθεται στην ακόλουθη διεύθυνση διαδικτύου: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>Ειδοποίηση της ΕΕ για περιορισμούς χρήσης: Η συσκευή αυτή περιορίζεται μόνο σε εσωτερικούς χώρους χρήσης. Μπορεί να μην λειτουργεί σε εξωτερικούς χώρους.</p>
fr	Français [French]	<p>Par la présente Lantronix, Inc. déclare que l'appareil NTC-550 Series est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 2014/53/EU.</p> <p>Le texte complet de la déclaration de conformité UE est disponible à l'adresse Internet suivante: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>Avis de restrictions d'utilisation de l'UE: Cet appareil est limité à une utilisation en intérieur uniquement. Il ne doit pas être utilisé à l'extérieur</p>
is	Icelandic	<p>Hér með lýsir Lantronix, Inc. því yfir að NTC-550 Series sé í samræmi við grunnkröfur og önnur viðeigandi ákvæði tilskipunar 2014/53 / ESB.</p> <p>Í heildartexta ESB-samræmisýfirlýsingarinnar er að finna á eftirfarandi internetfangi: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>Tilkynning ESB um takmarkanir á notkun: Þetta tæki er eingöngutakmarkað við notkun innanhúss. Það má ekki nota það úti.</p>
it	Italiano [Italian]	<p>Con la presente Lantronix, Inc. dichiara che questo NTC-550 Series è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 2014/53/EU.</p>



Code	Language	Statement
		<p>Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>Avviso di restrizioni d'uso dell'UE: questo dispositivo è limitato esclusivamente all'uso in interni. Potrebbe non essere utilizzato all'aperto.</p>
lv	Latviski [Latvian]	<p>Ar šo Lantronix, Inc. deklarē, ka NTC-550 Series atbilst Direktīvas 2014/ 53/EU būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.</p> <p>Pilns ES atbilstības deklarācijas teksts ir pieejams šādā tīmekļa vietnē: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>ES paziņojums par lietošanas ierobežojumiem: šo ierīci var izmantot tikai iekštelpās. To nedrīkst darbināt ārpus telpām.</p>
lt	Lietuvių [Lithuanian]	<p>Šiuo Lantronix, Inc. deklaruojama, kad šis NTC-550 Series atitinka esminius reikalavimus ir kitas 2014/53/EU Direktyvos nuostatas.</p> <p>Visą ES atitikties deklaracijos tekstą galite rasti šiuo interneto adresu: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>ES pranešimas apie naudojimo apribojimus: Šis prietaisas skirtas naudoti tik patalpose. Jo negalima naudoti lauke.</p>
nl	Nederlands [Dutch]	<p>Hierbij verklaart Lantronix, Inc. dat het toestel NTC-550 Series overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 2014/53/EU.</p> <p>De volledige tekst van de EU-conformiteitsverklaring is beschikbaar op het volgende internetadres: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>EU kennisgeving van gebruiksbepalingen: dit apparaat is beperkt tot gebruik binnenshuis. Het mag niet buitenshuis worden gebruikt.</p>
mt	Malti [Maltese]	<p>Hawnhekk, Lantronix, Inc., jiddikjara li dan NTC-550 Series jikkonforma malħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 2014/53/EU.</p> <p>It-test sħiħ tad-dikjarazzjoni ta 'konformità tal-UE huwa disponibbli flindirizz tal-internet li ġej: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>Avviż tal-UE dwar Restrizzjonijiet fuq l-Użu: Dan l-apparat huwa limitat għal użu ġewwa biss. Ma jistax jiħaddem barra.</p>
hu	Magyar [Hungarian]	<p>Alulírott, Lantronix, Inc. nyilatkozom, hogy a NTC-550 Series megfelel a vonatkozó alapvető követelményeknek és az 2014/53/EU irányelv egyéb előírásainak.</p> <p>Az EU-megfelelőségi nyilatkozat teljes szövege a következő internetes címen érhető el: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>EU értesítés a korlátozásokról: Ez az eszköz csak beltéri használatra korlátozódik. Lehet, hogy szabadban nem üzemeltethető.</p>
no	Norwegian	<p>Lantronix, Inc. erklærer herved at denne NTC-550 Series er i samsvar med de grunnleggende kravene og andre relevante bestemmelser i direktiv 2014/53 / EU.</p>

Code	Language	Statement
		<p>Den fullstendige teksten til EU-samsvarserklæringen er tilgjengelig på følgende internettadresse: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>EUs merknad om bruksbegrensninger: Denne enheten er bare begrenset til innendørs bruk. Det kan hende at den ikke brukes utendørs.</p>
pl	Polski [Polish]	<p>Niniejszym Lantronix, Inc. oświadcza, że NTC-550 Series jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 2014/53/EU.</p> <p>Pełny tekst deklaracji zgodności EU jest dostępny pod następującym adresem internetowym: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>Zawiadomienie UE o ograniczeniach użytkowania: To urządzenie jest przeznaczone wyłącznie do użytku w pomieszczeniach. Nie można go obsługiwać na zewnątrz.</p>
pt	Português [Portuguese]	<p>Lantronix, Inc. declara que este NTC-550 Series está conforme com os requisitos essenciais e outras disposições da Directiva 2014/53/EU.</p> <p>O texto completo da declaração UE de conformidade está disponível no seguinte endereço na Internet: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>Aviso da UE de restrições de uso: Este dispositivo está limitado apenas ao uso interno. Não pode ser operado ao ar livre.</p>
ro	Romanian	<p>Prin prezenta, Lantronix, Inc., declară că acest NTC-550 Series respect cerințele esențiale și alte dispoziții relevante din Directiva 2014/53 / UE.</p> <p>Textul complet al declarației de conformitate a UE este disponibil la următoarea adresă de internet: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>Notificarea UE privind restricțiile de utilizare: Acest dispozitiv este limitat numai la uz interior. Este posibil să nu funcționeze în aer liber.</p>
sr	Serbian	<p>Овиме, Лантроник, Инц., изјављује да је овај NTC-550 Series у складу са суштинским захтевима и осталим релевантним одредбама Директиве 2014/53 / ЕУ.</p> <p>Комплетан текст ЕУ изјаве о усаглашености доступан је на следећој Интернет адреси: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>Обавештење ЕУ о ограничењима употребе: Овај уређај је ограничен само на унутрашњу употребу. Можда се не користи на отвореном.</p>
sl	Slovensko [Slovenian]	<p>Lantronix, Inc. izjavlja, da je ta NTC-550 Series v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 2014/53/EU.</p> <p>Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>Obvestilo EU o omejitvah uporabe: Ta naprava je omejena samo na notranjo uporabo. Morda ga ne uporabljate na prostem.</p>
sk	Slovensky [Slovak]	<p>Lantronix, Inc. týmto vyhlasuje, že NTC-550 Series enterprise Wi-Fi IoT module spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 2014/53/EU.</p>

Code	Language	Statement
		<p>Úplné znenie EÚ vyhlásenia o zhode je k dispozícii na tejto internetovej adrese: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>Oznámenie EÚ o obmedzeniach pri používaní: Toto zariadenie je obmedzené iba na použitie v interiéri. Nesmie sa používať vonku.</p>
fi	Suomi [Finnish]	<p>Lantronix, Inc. vakuuttaa täten että NTC-550 Series tyyppinen laite on direktiivin 2014/53/EU oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.</p> <p>EU-vaatimustenmukaisuusvakuutuksen koko teksti on saatavana seuraavassa Internet-osoitteessa: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>EU: n ilmoitus käyttörajoituksista: Tämä laite on rajoitettu vain sisäkäyttöön. Sitä ei saa käyttää ulkona.</p>
sv	Svenska [Swedish]	<p>Härmed intygar Lantronix, Inc. att denna NTC-550 Series står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 2014/53/EU.</p> <p>Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande internetadress: <a href="https://www.lantronix.com/products/ntc-550-series/">https://www.lantronix.com/products/ntc-550-series/</a></p> <p>EU-meddelande om begränsningar för användning: Den här enheten är endast begränsad till inomhusbruk. Det får inte användas utomhus.</p>


## UK Declaration of Conformity

Figure C-2 UK Declaration of Conformity


  

  
**UK DECLARATION OF CONFORMITY**

**Manufacturer's Name:** LANTRONIX, INC.  
**Manufacturer's Address:** 48 Discovery, Suite 250 Irvine, CA 92618 USA  
**Model Name:** NTC-552  
**Rated:** 12Vdc, 3A  
**Intended use:** Commercial installations, indoor use

**Manufacturer's Quality System:**



ISO 9001:2015 Certificate No. 74 300 4282 TUV Rheinland

**Applicable EU Directives:**

**Electrical Equipment Regulations 2016**

- EN IEC 62368-1:2020/A11:2020
- EN IEC 62311:2020

**Electromagnetic Compatibility Regulations 2016**

- EN 301 489-1 V2.2.3 (2019-11) Class B
- EN 301 489-17 V3.2.4 (2020-09)
- EN 301 489-19 V2.2.1 (2022-09)
- EN 301 489-52 V1.2.1 (2021-11)
- EN 55032:2015/A11:2020, Class B
- EN 55035:2017+A11:2020
- EN 61000-3-2:2014 Class A
- EN 61000-3-3:2013


**Radio Equipment Regulations 2017**

- EN 301 908-1 V15.2.1(2023-01)
- EN 301 908-2 V13.1.1 (2020-06)
- EN 301 908-13 V13.2.1 (2022-02)
- Draft EN 301-908-25 V15.1.1\_15.0.9 (2021-06)
- EN 300 328 V2.2.2 (2019-07)
- EN 301 893 V2.1.1 (2017-05)
- EN 303 413 V1.2.1 (2021-04)

**RoHS**  
**UK SI 2012 No. 3032 for Restriction of Hazardous Substance (RoHS2) with exemption 7(c)-I and 6(c).**  
**2011/65/EU(RoHS 2.0) & and its subsequent amendments Directive (EU) 2015/863**

- BS EN 62321-2:2021

**Statement of Conformity:** The product specified above complies with applicable EU directive referenced, including the application of sound engineering practice.

Signature:  \_\_\_\_\_ Date: 26 Jun 2025  
 Name: Steve Burrington Title: Vice President RnD

CERT-00513 rev A