

| | | | |
|---|---|--|---------------------------------|
|  | <h1>Release Notes</h1> | | Lantronix AVL Products |
| | | | Release date: November 27, 2019 |
| | Firmware version: avl_3.3.0_rc15 | | Document revision: 3.3.0.0 |

Lantronix AVL FIRMWARE RELEASE

VERSION: [avl_3.3.0_rc15](#)
 BIOS version: [3.0.2](#)
 Official release date: [10/02/2019](#)
 Affecting deliveries from: [08/21/2019](#)
 List of firmware files: [avl_3.3.0_rc15_20190919.frp](#)
[avl_3.3.0_rc15-Ze4114daf.zip](#)
[avl_3.3.0_rc15_20190919.txt](#)

Hardware compatibility: This firmware applies to the following LANTRONIX products with Cortex processor:

| Devices | Hardware Revisions | Supported firmware versions | Notes |
|------------------|-------------------------|--------------------------------|--|
| FOX3-2G Series | 13,15,17,19,20,21 | avl_3.x.x (only) | 1) Use the PFAL command \$PFAL,MSG.Version.HardwareRev to get shown the hardware revision of your AVL device. The device responses with (second line shows the hardware version): \$<MSG.Version.HardwareRev> \$11-NUCHB \$SUCCESS |
| FOX3-3G Series | 06,11,13,15,17,19,20,21 | avl_3.x.x (only) | |
| FOX3-3G-BID* | | | |
| FOX3-4G Series | All | avl_3.x.x (only) | 2) The hardware revision is also printed on the product label, located on the back panel of the device. In the Serial Number (S/N) field there are 3 digits in parenthesis, for example, 60148(9XX)50600014, and the number “XX” is the hardware revision of the device. If the number is “11”, it means that the hardware revision is 11. |
| BOLERO40 Series* | All | avl_3.x.x (only) | |

* On request


NOTE: This firmware version is **ONLY** for the LANTRONIX products explicitly mentioned above! Do not try to update other LANTRONIX products with this firmware, otherwise you will not be able to operate your device anymore.

DOCUMENTATION:

| Filename | Description |
|---|---|
| AVL_PFAL_Commands_Set.pdf | Lists and describes all PFAL commands supported by this firmware release. |

SUMMARY OF CHANGES:

| Version | Description | Created by | Date (M/D/Y) |
|---------|-----------------------------------|------------|--------------|
| 3.3.0.0 | Firmware release "avl_3.3.0_rc15" | Lantronix | 10/02/2019 |
| 3.2.0.3 | Firmware release "avl_3.2.0_rc39" | FALCOM | 07/04/2019 |
| 3.1.0.2 | Firmware release "avl_3.1.0_rc33" | FALCOM | 11/09/2018 |
| 3.1.0.1 | Firmware release "avl_3.1.0_rc20" | FALCOM | 05/15/2018 |

| | | | |
|---|---|--|---------------------------------|
|  | <h1>Release Notes</h1> | | Lantronix AVL Products |
| | | | Release date: November 27, 2019 |
| | Firmware version: avl_3.3.0_rc15 | | Document revision: 3.3.0.0 |

1) Preface

This release note describes the new functionalities of the firmware release "**avl_3.3.0_rc15**" and is intended for use as a reference when updating an AVL device to version "**avl_3.3.0_rc15**".

2) Important Notes

The firmware file with extension "***.frp**" is for the update through the **Workbench** and for the update remotely OTA (RUpdate). The firmware file with extension "***.txt**" is for the update through **terminal emulators** (e.g.: Hyperterminal, PComm Pro). The firmware file with extension "***.zip**" is for the WebUpdate. To update the firmware with the extension "***.frp**", please use the **Workbench** version **2.6.2_RC7** or higher. To update the firmware with the extension "***.txt**" you can use any **terminal emulator** (example: Hyper terminal, Pcomm Pro). To initiate a WebUpdate use the command **\$PFAL,SYS.WebUpdate.Start,"url",80** on the device.

DON'T switch off the AVL device while it reboots after the firmware update. The duration of the reboot after the firmware update may take approx. 45 seconds.

Before upgrading the firmware on the device, it is strongly recommended to upload and backup all history data on your server (if needed) and finally delete this data on the device.

NOTE: If FOX3-3G-BLE devices with older firmware versions (e.g. 3.0.0_xx) are upgraded to this new firmware version (3.3.0_xx), please contact LANTRONIX to receive the BLE activation codes and continue to use this feature without additional costs.

NOTE 1: The latest FW 3.3.0_rc15 is for FOX3-2G/3G/4G as well as BOLERO40 series.

NOTE 2: This firmware version (3.3.0_rc15) currently does not support Sleep=Ring and DOZE on BOLERO40 series.

NOTE 3: Doze mode and Sleep=Ring on BOLERO40 series are in preparation for the next AVL firmware release. In future Sleep=RING works only in SIMSLOT2 (the upper SLOT) on BOLERO40 series.

3) Firmware Installation Notes

The installation package consists of firmware in three different formats *.txt, *.frp and *.zip. You can choose whether you want to update the firmware via following interfaces:

| Interfaces | File | Description | References |
|-----------------------|-------|---|------------|
| RS-232 PORT | *.frp | This is primarily intended for updating one device first, to ensure the process completes properly before rolling the update to a group of other devices. Use " Workbench " and update the "*.frp"-file via the serial port. | |
| WEB-SERVER | *.zip | This is a perfect solution when multiple deployed AVL devices need updating. The firmware file is located in your web-server and you send to the AVL device the URL of a web server you have set up for downloading over-the-air the firmware file. | |
| Remote with Workbench | *.frp | This solution lets you update the firmware remotely on several AVL devices. More details can be found in the online help in the Workbench software. | |
| TCP-SERVER | *.frp | This solution lets you update the firmware remotely on several AVL devices. | |

| | | | |
|---|---|--|---------------------------------|
|  | <h1>Release Notes</h1> | | Lantronix AVL Products |
| | | | Release date: November 27, 2019 |
| | Firmware version: avl_3.3.0_rc15 | | Document revision: 3.3.0.0 |


4) Prerequisites concerning the PC

A 32/64-bit-WINDOWS operating system (Windows XP, Vista, 7) or Linux is running on your PC and about 50 MByte free space on your hard disk is required. The RS-232 interface must be configured with the following parameters:

- Baud rate: 115200
- Data Bits: 8
- Parity: None
- Stopbits: 1
- Flow Control: None

5) Firmware Update Process

1. Download "**avl_3.3.0_rc15.zip**" and extract the file you downloaded into a temporary folder on your PC.
2. Run the "**workbench**" software.




(a) Begin the firmware update process (refer to the fig. above).

1. Connect the AVL device to your PC either directly using the programming cable or the corresponding evaluation board.
2. Do **NOT** update the firmware version 3.x.x on FOX3-2G/3G/4G devices with an older processor. The firmware version 3.x.x is **ONLY** for FOX3-2G/3G/4G and BOLERO40 devices with the **CORTEX (CT)** processor. Please verify the hardware revision from the table "**Hardware compatibility**" above and make sure you are upgrading a FOX3-2G/3G/4G device with CORTEX processor. LANTRONIX takes no liability and no responsibility for any cases, firmware versions have been flashed wrongly nor will LANTRONIX cover any costs associated with this happening.
3. Click **Port** (1) icon, select the COM port settings from the **PortView1** (2) and click the **Play** button next to the text "COM.." to open the selected COM port.

| | | | |
|---|---|--|---------------------------------|
|  | <h1>Release Notes</h1> | | Lantronix AVL Products |
| | | | Release date: November 27, 2019 |
| | Firmware version: avl_3.3.0_rc15 | | Document revision: 3.3.0.0 |

4. Click **Terminal** (3) icon, select the **TerminalView** 1 (4) and go to the **ConnectionView** (5) and connect it to the **Serial Port COM1**.
5. Click **Firmware** (6) icon, select "SERIAL" from the **Transmission Options** (7), go to **ConnectionView** (8) and connect it to the **Serial Port COM1**.
6. Click **Browse** (9) button and select the firmware file as "*.frp" from the temporary folder where the firmware was expanded.
7. Click **Play** (10) button to start the firmware update. This button appears only if the firmware file has already been selected.
8. Wait until the update process completes. While the update is running, do not send any command to the device and do not manually reboot it until the device restarts itself.
9. After the update process successfully completes, a success message will appear. Click "OK" button to restart the AVL device.
10. After device restarts and configuring the unit, you can execute the command **\$PFAL,Cnf.Backup** to save the user configuration as factory settings. If the AVL device was already configured, you can execute the same command after the firmware update to save the user configuration as factory settings.
11. LANTRONIX recommends that you update one device first, to ensure the process completes properly before rolling the update to a group of other devices.
12. Click **Help** (11) button for more details about the workbench software.

| | | | |
|---|---|--|---------------------------------|
|  | <h1>Release Notes</h1> | | Lantronix AVL Products |
| | | | Release date: November 27, 2019 |
| | Firmware version: avl_3.3.0_rc15 | | Document revision: 3.3.0.0 |

6) New and Modified Functions

NEW FEATURES:


This is a list of new features in the current firmware release.

- ✓ Added new PFAL commands/configuration/event/states/dynamic variables.

| PFAL Commands | |
|--|---|
| MSG.Event[,<interface>],<"text"> | Generates interface event with text, if the interface parameter is omitted sending event to the current one. Optional <port>: Serial0 Serial port 0 Serial1 Serial port 1 USB USB port User User interface TCP TCP interface <"text">: Any text can be specified |
| Sys.Can.DTCO.FMS.Enable | Enable tachograph communication on the 1 st CAN port (main port) |
| Sys.Can.DTCO.FMS.Disable | Disable tachograph communication on the 1 st CAN port (main port) |
| Sys.Can.DTCO.SendAPDU,<TA>,"bytes" | It transmit n bytes b0...bn to target with address <TA> b0 ... bn are coded as space separated hex values 0x<nn> e.g.: \$pfal,Sys.Can.DTCO.SendAPDU,0xee,"0x10 0x7e" |
| Sys.Can.Timeout,<timeout_s> | CAN timeout in s for the 1 st CAN port |
| Alarm.Call,<index> | Executes actions on the specified alarm index in range 0 -99 or if you are using the premium feature ALARM it ranges from 0-249. |
| GPS.Nav.HoldPosition=<mode> | Holds the current GPS position at this location to avoid GPS position jumps around from your real parking location. <mode> settings: 0 Deactivates holding of GPS position. 1 Activates holding of GPS position |
| Msg.Send.RawFlashBuffer,<protocols>,<"text"> | Stores the specified protocols and/or user text in raw format to the nonvolatile TcpFlashBuffer inside the device <protocols> settings: Specifies the protocols to be sent to the buffer <"text"> Up to 1450 chars. |
| Msg.Send.RawTCPBuffer,<protocols>,<"text"> | Stores the specified protocols and/or user text in the raw format to the temporary TcpBuffer inside the device. <protocols> settings: Specifies the protocols to be sent to the buffer <"text"> Up to 1450 chars. |
| Msg.Send.RawTCP,<protocols>,<"text"> | Sends the specified protocols and/or user text in the raw format to the connected server <protocols> settings: Specifies the protocols to be sent to the buffer <"text"> Up to 1450 chars. |

| | |
|---|--|
| Msg.ClearBuffer,<interface> | Clears the input/output buffer of the specified port. <port> settings: Serial0 Serial port 0 Serial1 Serial port 1 USB USB port TCP TCP port |
| SYS.Device.HealthState | Shows battery and lifetime statistics |
| SYS.can.UpdateIoBox,"<filename>" | Updates IOBOX-CAN from file system |
| Configuration parameters | |
| DEVICE.CAN.DTCOFMS.STARTUP=<mode>,<port> | Enables or disables reading of tachograph data via FMS interface on the specified CAN port <mode> off Disable reading of tachograph data. on Enables reading of tachograph data. <port> 0 Enables reading of DTCO on 1st CAN. 1 Enables reading of DTCO on IOBOX-CAN |
| DEVICE.CAN.FMS.STARTUP=<format>,<port> | Defines the frame format to enable reading of FMS messages on the specified CAN port. <format> Std Enables the 11-bit identifier (CAN2.0A). Ext Enables the 29-bit identifier (CAN2.0B) <port> 0 Enables reading of DTCO on 1st CAN. 1 Enables reading of DTCO on IOBOX-CAN |
| DEVICE.CAN.STARTUP<port>=<on_off>,<baud>,<mode> | <can_port> 0 Enables reading on 1st CAN interface (main port). 1 Enables reading on 2nd CANB interface (IOBOX-CAN) <on_off> off Disable CAN functionality on the specified port. on Enables CAN functionality on the specified port. <baud> 10K -CAN interface operates at 10 Kbits/s. 20K -CAN interface operates at 20 Kbits/s. 33K3 -CAN interface operates at 33.3 Kbits/s. 50K -CAN interface operates at 50 Kbits/s. 83K3 -CAN interface operates at 83.3 Kbits/s. 95K2 -CAN interface operates at 95.2 Kbits/s . 100k -CAN interface operates at 100 Kbits/s . 125K -CAN interface operates at 125 Kbits/s. 250K -CAN interface operates at 250 Kbits/s. 500K -CAN interface operates at 500 Kbits/s. 666K6 -CAN interface operates at 666.6 Kbits/s 800K -CAN interface operates at 800 Kbits/s. 1M -CAN interface operates at 1024 Kbits/s. <mode> RO Read Only mode (Silent mode). RW Read Write mode (Running mode) Some CAN interfaces require the ACK. Thus, RW is needed. LB Loop back mode, for self-test function SLB Loop back combined with silent mode, for self-test function |
| DEVICE.DTCO.D8=B0,<format> | Enables IN4 (PIN 8) on the IOBOX-CAN for reading tachograph data via D8 interface. |

| | |
|--------------------------------------|--|
| | <format> settings VDO VDO data format. SRE Stoneridge data format. |
| DEVICE.DTCO.D8=off | Disables the IN4 (PIN 8) on the IOBOX-CAN for reading tachograph data via D8 interface |
| DEVICE.CAN.ERR.EVENTS=<mode> | Activates error CAN events. Default: off |
| Events/States | |
| Can.error=<cond>[,<cond>] | This event occurs when the received error from CAN bus matches the user specified condition(s) <cond> settings: STUFF - More than 5 equal bits in a sequence have occurred FORM - A fixed format part of a received frame has the wrong format ACK - Sent message was not acknowledged by another node BIT1 - Bit 1 error (monitored bus value was dominant) BIT0 - Bit 0 error (monitored bus value was recessive) CRC - The CRC check sum was incorrect in the message received WARNING_RX - TX error counter (TEC) reached warning level (>96) WARNING_TX - RX error counter (REC) reached warning level (>96) PASSIVE - CAN "error passive" occurred BUS_OFF - CAN "bus off" error occurred OVERRUN_RX - Overrun in RX queue or hardware occurred OVERRUN_TX - Overrun in TX queue occurred ARBITRATION_LOST - Arbitration lost PHY_FAULT - General failure of physical layer detected (if supported by hardware) PHY_H - Fault on CAN-H detected (Low Speed CAN) PHY_L - Fault on CAN-L detected (Low Speed CAN) |
| Can.eStat=<mode> | This event is occurred when the 1 st CAN bus (on the main port) goes idle or active accordingly. <mode> settings: idle - CAN bus is in idle mode (CAN stops sending data for the user specified time out). active - CAN bus is in active mode(CAN starts sending data for the user specified time out) Example: \$pfal,config.set,AL10=Sys.Can.estat=idle:Msg.Send.Serial0,0,"CAN idle" \$pfal,config.set,AL11=Sys.Can.estat=active:Msg.Send.Serial0,0,"CAN active" \$pfal,sys.can.Timeout,10 |
| SYS.iobox.eReset[=<cond>[...<cond>]] | This event is occurred when the IOBOX-CAN/MINI/WLAN makes software reset. Optional <cond> settings: "PINRST" 0x04 PIN reset |

| | | | |
|---|---|--|---------------------------------|
|  | <h1>Release Notes</h1> | | Lantronix AVL Products |
| | | | Release date: November 27, 2019 |
| | Firmware version: avl_3.3.0_rc15 | | Document revision: 3.3.0.0 |

| | |
|---------------------------------------|---|
| | "PORRST" 0x08 POR/PDR reset "SFTRST" 0x10 Software reset "IWDGRST" 0x20 Independent watchdog reset "WWDGRST" 0x40 Window watchdog reset "LPWRRST" 0x80 Low-power reset |
| SYS.Device.eStart=Reset,Watchdoglobox | This event is occurred when IOBOX-CAN/MINI/WLAN watchdog causes a device reset. |
| SYS.ioBox.eLost | This event is occurred when IOBOX-MINI/CAN/WLAN is disconnected. |
| SYS.1Wire.sAvailable=whitelist | Compares the id of 1-Wire devices with the values of whitelist and sets this state to true as long as the comparison matches. |
| SYS.eCan.DTCO.Confirm | True if the incoming APDU message has data. |
| SYS.eCan.DTCO.Incoming | This event is generated whenever an APDU message has been sent completely to the tachograph. This is just a confirmation event. |
| SYS.sCan.DTCO.Confirm | This event is generated whenever a new incoming APDU message is received \$PFAL,CNF.Set,AL1=Sys.eCan.DTCO.Incoming:Msg.Send.Serial0,0,"dtco: &(Can.Dtco.Incoming)" |
| Dynamic entries | |
| &(RAT) | It is used to report the GSM radio access technology. 0: GSM (2G) 1: GSM COMPACT 2: UTRAN 3: GSM with EDGE availability 4: UTRAN with HSDPA availability 5: UTRAN with HSUPA availability 6: UTRAN with HSDPA and HSUPA availability 7: LTE |
| &(UnixTime2) | It is used to report the number of seconds since 1.1.1970 UTC (UNIX epoch time) |
| &(UserEventText) | It is used to report the user text causes the event |
| &(Can.Dtco.Incoming) | Used to report the incoming data from the tachograph in the format "<SA> <TA> <xx>...<xx>" <SA> hexadecimal source address <TA> hexadecimal target address <xx> hexadecimal data bytes |


NEW FEATURES FOR FOX3-3G-BLE:

This section presents what is new in the firmware release regarding the FOX3-3G-BLE.

- ✓ Added new PFAL commands/configuration/event/states/dynamic variables for BLE tags/sensors:

| PFAL Commands | |
|----------------------------|--|
| SYS.BLE.ListDev[=<filter>] | List of active beacons with corresponding content. Optional <filter> settings: Name Show the list with names. MAC Show the list with MACs. |

| | | |
|----------------------------|--|---|
| | UUID RSSI | Show the list with UUIDs. Show the list with RSSIs. |
| SYS.BLE.ListAdd[=<filter>] | List of added beacons with corresponding content Optional <filter> settings: Name MAC UUID RSSI | Show the list with names. Show the list with MACs. Show the list with UUIDs. Show the list with RSSIs. |
| SYS.BLE.ListRel[=<filter>] | List of released beacons with corresponding content. Optional <filter> settings: Name MAC UUID | Show the list with names. Show the list with MACs. Show the list with UUIDs. |
| Dynamic entries | | |
| &(BLE.ListDev[:<filter>]) | It is used to report the list of active beacons Optional <filter> settings: Name MAC UUID RSSI | Show the list with names. Show the list with MACs. Show the list with UUIDs. Show the list with RSSIs. |
| &(BLE.ListAdd[:<filter>]) | It is used to report the list of added beacons Optional <filter> settings: Name MAC UUID RSSI | Show the list with names. Show the list with MACs. Show the list with UUIDs. Show the list with RSSIs. |
| &(BLE.ListRel[:<filter>]) | It is used to report the list of released beacons Optional <filter> settings: Name MAC UUID | Show the list with names. Show the list with MACs. Show the list with UUIDs. |
| &(BLE.Name[:index]) | It is used to report the Name of active beacon. Optional <index> settings: 0...n | The indexed tag during scanning. |
| &(BLE.MAC[:index]) | It is used to report the MAC of active beacon Optional <index> settings: 0...n | The indexed tag during scanning. |
| &(BLE.UUID[:index]) | It is used to report the UUID of active beacon Optional <index> settings: 0...n | The indexed tag during scanning. |
| &(BLE.Major[:index]) | It is used to report the Major of active beacon Optional <index> settings: 0...n | The indexed tag during scanning. |
| &(BLE.Minor[:index]) | It is used to report the Minor of active beacon Optional <index> settings: 0...n | The indexed tag during scanning. |
| &(BLE.relName[:index]) | It is used to report the name of released beacon Optional <index> settings: 0...n | The indexed tag during scanning. |
| &(BLE.relMAC[:index]) | It is used to report the MAC of released beacon Optional <index> settings: 0...n | The indexed tag during scanning. |

| | | | |
|---|---|--|---------------------------------|
|  | <h1>Release Notes</h1> | | Lantronix AVL Products |
| | | | Release date: November 27, 2019 |
| | Firmware version: avl_3.3.0_rc15 | | Document revision: 3.3.0.0 |

| | |
|-------------------------|--|
| &(BLE.relUUID[:index]) | It is used to report the UUID of released beacon Optional <index> settings: 0...n The indexed tag during scanning. |
| &(BLE.relMajor[:index]) | It is used to report the Major of released beacon Optional <index> settings: 0...n The indexed tag during scanning. |
| &(BLE.relMinor[:index]) | It is used to report the Minor of released beacon Optional <index> settings: 0...n The indexed tag during scanning. |

NEW FEATURES FOR FOX3-3G-BID:

This section presents what is new in the firmware release regarding the product FOX3-3G-BID.

- ✓ None

NEW FEATURES FOR IOBOX-MINI:

This section presents what is new in the firmware release regarding the IOBOX-MINI.


- ✓ None

NEW FEATURES FOR NFC Reader:

This section presents what is new in the firmware release regarding the Near Field Communication (NFC) reader.

- ✓ Added new PFAL commands/configuration/event/states/dynamic variables

| PFAL Commands | |
|---------------------------------------|--|
| SYS.NFC.play,"<tone><tone>....<tone>" | <p>This command is used to turn on and play specific tones on the buzzer on the NFC reader.</p> <p>Following settings are available:</p> <p><tone>: <note> <pause>[<shift>][<oktave>][/[<duration>.[<art>]</p> <p><note> - <pause> - _ <shift> - # - <oktave> - 0 1 2 3 4 5 6 7 8 <duration> - 1 2 4 8 16 <art> - l s ss # - increase - - decrease (b) . - dotted duration l - legato: tone duration until the next tone without pause s - staccato: shortened tone duration ss - staccatissimo: strongly shortened tone duration</p> <p>Valid tones C0 to C8 Standard octave = 3 Standard duration 1/4 non legato</p> <p>Example: \$PFAL,SYS.NFC.play,"cdefgahc4" \$PFAL,SYS.NFC.play,"c4 d4 e4 f4 g4 a4 h4 c5" \$PFAL,SYS.NFC.play,"c4,d4,e4,f4,g4,a4,h4,c5" \$PFAL,SYS.NFC.play,"c4/8 d4/8 e4/8 f4/8 g4/8 a4/8 h4/8 c5/8"</p> |

| | | | |
|---|---|--|---------------------------------|
|  | <h1>Release Notes</h1> | | Lantronix AVL Products |
| | | | Release date: November 27, 2019 |
| | Firmware version: avl_3.3.0_rc15 | | Document revision: 3.3.0.0 |

| | |
|--|---|
| | <pre>\$PFAL,SYS.NFC.play,"c4/8ss d4/8ss e4/8ss f4/8ss g4/8ss a4/8ss h4/8ss c5/8ss" \$PFAL,SYS.NFC.play,"c5d5e5f5g5a5h5c6" \$PFAL,SYS.NFC.play,"a4/8l f#5/l a4/8l d5/l a4/8l f#5/l a4/8l d5/l" \$PFAL,SYS.NFC.play,"a4/16l d5/4.l a4/16l d5/16l a4/16l d5/16l a4/16l d5/4.l"</pre> |
|--|---|

NEW FEATURES FOR BOLERO40 Series:

This section presents what is new in the firmware release regarding the BOLERO40.

- ✓ None

NEW FEATURES FOR IOBOX-CAN:

This section presents what is new in the firmware release regarding the IOBOX-CAN.

- ✓ Added new events for IOBOX-CAN

| PFAL Commands | |
|------------------------------|---|
| Sys.CanB.DTCO.FMS.Enable | Enable tachograph communication on the 2nd CAN port (IOBOX-CAN) |
| Sys.CanB.DTCO.FMS.Disable | Disable tachograph communication on the 2nd CAN port (IOBOX-CAN) |
| Sys.CanB.Timeout,<timeout_s> | CAN timeout in s for the 2nd CAN port (IOBOX-CAN) |
| EVENTS | |
| CanB.eStat=<mode> | <p>This event is occurred when the 2nd CAN bus (on the IOBOX-CAN) goes idle or active accordingly. <mode> settings:</p> <p>idle - CAN bus is in idle mode (CAN stops sending data for the user specified time out).</p> <p>active - CAN bus is in active mode(CAN starts sending data for the user specified time out)</p> <p>Example:</p> <pre>\$pfal,config.set,AL10=Sys.CanB.estat=idle:Msg.Send.Serial0,0,"CAN idle" \$pfal,config.set,AL11=Sys.CanB.estat=active:Msg.Send.Serial0,0,"CAN active" \$pfal,Sys.CanB.Timeout,10</pre> |

NEW FEATURES FOR IOBOX-WLAN:

This section presents what is new in the firmware release regarding the IOBOX-WLAN.

- ✓ Added new PFAL commands/configuration/event/states/dynamic variables.


| PFAL Commands | |
|--------------------------|---|
| WLAN.Connect,<id> | Connects to the wireless access point specified in the profile id. Up to 5 profiles can be defined. <id> = Ranges from 0 to 4 |
| Configuration parameters | |
| WLAN.NET<id>.SSID=<ssid> | <p>Defines the SSID of the network (max. 32 characters) to connect to the WLAN access point.</p> <p><id> Ranges from 0 to 4</p> <p><ssid> SSID of the access points with a max. of 32 characters.</p> |

| | |
|--|---|
| WLAN.NET<id>.TYPE=dhcp | Defines the type DHCP of connection to the WLAN access point. <id> = Ranges from 0 to 4 |
| WLAN.NET<id>.TYPE=static,<own_ip>,<netmask>,<gatewayIP>,<dnslIP> | Defines the settings for connecting to the wireless access point with a static IP address. <div> <div><id></div> <div>Ranges from 0 to 4</div> </div> <div> <div><own_ip></div> <div>Specifies the static IP address set on that wireless access point</div> </div> <div> <div><netmask></div> <div>Specifies the network mask of that wireless access point</div> </div> <div> <div><gatewayIP></div> <div>Specifies the gateway IP of that wireless access point</div> </div> <div> <div><dnslIP></div> <div>Specifies the network IP address of that DNS wireless access point</div> </div> |
| WLAN.NET<id>.PSK=<psk> | Specifies the (PSK) Pre-Shared-Key (max. 63 characters) of that wireless access point <div> <div><id></div> <div>Ranges from 0 to 4</div> </div> <div> <div><psk></div> <div>Sets the pre-shared key (PSK) of the WLAN network</div> </div> |
| WLAN.NET<id>.IP=<ip> | Specifies the IP address of the remote server to connect to after establishing a WLAN connection. <div> <div><id></div> <div>Ranges from 0 to 4</div> </div> <div> <div><ip></div> <div>IP address in dotted-four-byte ("xxx.xxx.xxx.xxx") format</div> </div> |
| WLAN.NET<id>.PORT=<port> | Specifies the Port number of the remote server to connect to after establishing a WLAN connection. <div> <div><id></div> <div>Ranges from 0 to 4</div> </div> <div> <div><port></div> <div>Specifies the port number that is used to send the data</div> </div> |
| WLAN.NET<id>.SECURITY=<type> | Specifies the security type of connection for that wireless access point. <div> <div><id></div> <div>Ranges from 0 to 4</div> </div> <div> <div><type> settings</div> <div> <div>WEP</div> <div>Wired Equivalent Privacy.</div> </div> <div> <div>WPA</div> <div>Wireless Protected Access.</div> </div> <div> <div>WPA2</div> <div>Second version of the WPA standard.</div> </div> <div> <div>WPA2_MIX</div> <div>WPA2 mixed mode.</div> </div> <div> <div>NONE</div> <div>No security.</div> </div> </div> |
| WLAN.MODE=<mode> | Defines the connection mode to the WLAN network. <div> <div><mode></div> <div>Ranges from 0 to 4</div> </div> <div> <div><mode> settings:</div> <div> <div>off</div> <div>Automatic connection mode is turned off.</div> </div> <div> <div>Scan</div> <div>Automatic connection mode after the scan.</div> </div> <div> <div>Connect<id></div> <div>Automatic connection mode with profile <id>.</div> </div> </div> |
| WLAN.RSSIMIN | Defines the minimum RSSI (Received Signal Strength Indication) level to be able to reliably connect to that wireless access points |
| Events/States | |
| SYS.WLAN.TCP.ePingSent | This event is occurred when a ping is sent to connected TCP server over the wireless access point. |

NEW PREMIUM-FEATURES

This is a list of new PREMIUM-FEATURES in this firmware release.

- ✓ LUA
- ✓ CAN_CPC

| | | | |
|---|---|--|---------------------------------|
|  | <h1>Release Notes</h1> | | Lantronix AVL Products |
| | | | Release date: November 27, 2019 |
| | Firmware version: avl_3.3.0_rc15 | | Document revision: 3.3.0.0 |

NEW FEATURES FOR LUA:

This is a list of new PREMIUM-FEATURES in this firmware release.

- ✓ PFAL & LUA commands/Constants/event/states. An application note on how to get started with Lua is in preparation.

| PFAL commands | |
|--|---|
| SYS.Lua.Start | Starts the Lua script loaded to the device. To automate starting the LUA script, an alarm configuration line is needed: \$PFAL,CNF.Set,AL1=Sys.Device.eStart:SYS.Lua.start |
| SYS.Lua.Stop | Stops a running the Lua script loaded to the device |
| SYS.Lua.Dump | Reads the source code of that Lua script available on the device |
| SYS.Lua.Lock,<"password"> | Locks the Lua script with a password from reading |
| SYS.Lua.Unlock,<"password"> | Unlocks the Lua script |
| SYS.Lua.Dump[,<"password">] | Reads the source code of that Lua script available on the device that is locked with a password |
| SYS.Lua.Clear | Clears the Lua script available on the device |
| SYS.LUA.Info | Shows the header of installed script |
| SYS.LUA.Event,<id>,<"text"> | Generates custom events for LUA |
| LUA Commands | |
| os.sleep(millies) | Suspends the execution of the current thread until the time-out interval in milliseconds elapses. |
| os.trace("format", args) | LUA debug output ("DBG.EN=1" must enabled). |
| PFAL command request | |
| bState, sResult := avl.pfal("command") | Reads the state and the result of the execution of the PFAL command that has been defined in the "command" field |
| PFAL alarm request | |
| ev := avl.event(timeout) | <p>When an event happens in the device, the FOX3 creates an event type, puts details into it and passes it to the Lua. The "ev" reads that event type. To read the type and data of that event use the one of the event listed under "Event Requests".</p> <p>For example:</p> <pre> ev = avl.event(1000) if ev ~= nil then if ev.type == ALARM_SYS_BLE_TAGDATA then ble_data = ev.u_string os.trace("DATA = [%s]", ble_data); end; end; </pre> |
| ev := avl.setevent(id[, "text"]) | Send event back to LUA, this is identical to the command "SYS.LUA.Event,<id>,<"text">" when executed. |
| avl.useevent(type[, OnOff]) | Mask/Unmask LUA event types (i.e ALARM_SYS_BLE_TAGDATA,ALARM_SYS_CANMSG) |

LUA Event Requests

| | |
|--|--|
| <pre> ev := [ev.type ev.time ev.idx ev.u_value ev.u_string ev.u_starttype ev.u_startreason ev.u_recvdata ev.u_recvlen ev.u_ipaddress ev.u_opid ev.u_opname ev.u_callid ev.u_smsnum ev.u_smstext ev.u_msgid ev.u_msgtype ev.u_msglen ev.u_msgdata] </pre> | <p>The “ev” reads the type and data of event</p> <p>// values of “ev.u_XXX” fields depending on the event type</p> <p>// integer event type</p> <p>// integer timestamp</p> <p>// integer subindex</p> <p>// integer value type</p> <p>// string value type</p> <p>// integer starttype</p> <p>// integer startreason</p> <p>// string recvdata buffer</p> <p>// integer recvlen length</p> <p>// string ipaddress</p> <p>// integer operator id</p> <p>// string operator name</p> <p>// string caller name</p> <p>// string SMS number</p> <p>// string SMS text</p> <p>// CAN msg id</p> <p>// CAN msg type</p> <p>// CAN msg length</p> <p>// CAN msg data</p> |
|--|--|

LUA EVENTS / Notification

| | |
|------------------------------|--|
| ALARM_SYS_DEVICE_WAKEUP | This event is created after the device is woken up from a sleep mode |
| ALARM_SYS_DEVICE_START | This event is created after the device has been successfully started up |
| ALARM_SYS_DEVICE_SHUTDOWN | This event is created before the device is being shut down (turned off or go sleeping) |
| ALARM_SYS_DEVICE_OVERVOLTAGE | This event is created when the device detects overvoltage on the input power supply |
| ALARM_SYS_TIMER | This event is created whenever a Timer runs out. |
| ALARM_SYS_TRIGGER | This event is created whenever a Trigger changes its state |
| ALARM_SYS_COUNTER | This event is created whenever a Counter changes its state |
| ALARM_SYS_nvCOUNTER | This event is created whenever a nvCounter changes its state |
| ALARM_SYS_ERROR | This event is created whenever a system error is detected |
| ALARM_SYS_USEREVENT0 | This event is created whenever a user event 0 to 9 is detected accordingly |
| ALARM_SYS_USEREVENT1 | |
| ALARM_SYS_USEREVENT2 | |
| ALARM_SYS_USEREVENT3 | |
| ALARM_SYS_USEREVENT4 | |
| ALARM_SYS_USEREVENT5 | |
| ALARM_SYS_USEREVENT6 | |
| ALARM_SYS_USEREVENT7 | |
| ALARM_SYS_USEREVENT8 | |
| ALARM_SYS_USEREVENT9 | |
| ALARM_SYS_SERIALDATA0 | This event is created whenever the device detects incoming |

| | |
|----------------------------|---|
| ALARM_SYS_SERIALDATA1 | data on the serial port 0, 1 accordingly |
| ALARM_SYS_USBDATA | This event is created whenever the device detects incoming data on the USB port |
| ALARM_SYS_BLE_TAGDATA | This event is created whenever the device detects Manufacture Specific Data advertised from the scanned Bluetooth Low Energy beacons |
| ALARM_SYS_CAN | This event is called whenever the device detects incoming data from the CAN interface |
| ALARM_SYS_TIMESYNC | This event is created whenever the device detects time synchronization |
| ALARM_SYS_OBDII_DTC | This event is created whenever the device detects incoming data from the OBDII DTC interface |
| ALARM_SYS_OBDII | This event is created whenever the device detects incoming data from the OBDII |
| ALARM_SYS_FMS_VAR | This event is created whenever the device detects incoming data from the FMS VAR |
| ALARM_SYS_J1939_VAR | This event is created whenever the device detects incoming data from the J1939 VAR |
| ALARM_SYS_FMS | This event is created whenever the device detects incoming data from the FMS interface |
| ALARM_SYS_J1939 | This event is created whenever the device detects incoming data from the J1939 interface |
| ALARM_SYS_1WIRE_REGISTER | This event is created whenever a 1-Wire device is connected and registered to the 1-Wire interface of the FOX3-2G/3G/4G |
| ALARM_SYS_1WIRE_RELEASE | This event is created whenever a 1-Wire device is released from the 1-Wire interface of the FOX3-2G/3G/4G |
| ALARM_SYS_BAT_LOWBAT | This event is created whenever the internal battery gets low |
| ALARM_SYS_BAT_CHARGE | This event is created whenever the internal battery starts charging process. |
| ALARM_SYS_POWER_DETECTED | This event is created whenever a connection to an external power supply is detected |
| ALARM_SYS_POWER_DROPPED | This event is created whenever the external power supply is dropped |
| ALARM_SYS_NFC_DETECTED | This event is created whenever the external NFC reader detects/reads a NFC tag |
| ALARM_SYS_NFC_RELEASED | This event is created whenever a connected NFC reader loses the attached NFC TAG |
| ALARM_SYS_BLE_REGISTER | This event is created whenever the device detects a BLE tag during scanning |
| ALARM_SYS_BLE_RELEASE | This event is created whenever the device loses a detected BLE tag after scanning ends |
| ALARM_SYS_BLE_CONNECTED | This event is created once a connection is established between the FOX3-3G-BLE as a peripherals and one central device (such as a mobile phone) |
| ALARM_SYS_BLE_DISCONNECTED | This event is called once the FOX3-3G-BLE is disconnected from the central device (such as a mobile phone) |
| ALARM_SYS_BLE_SCANEND | This event is created once the FOX3-3G-BLE has ended a scan |

| | |
|---------------------------------|---|
| | session for BLE sensors |
| ALARM_SYS_WLAN_CONNECTING | This event is created when the IOBOX-WLAN is trying to connect to one of 5 wireless access points |
| ALARM_SYS_WLAN_CONNECTED | This event is created once the IOBOX-WLAN is connected to one of 5 wireless access points |
| ALARM_SYS_WLAN_DISCONNECTED | This event is created once the IOBOX-WLAN is disconnected from one of 5 wireless access points |
| ALARM_SYS_WLAN_RECEIVED | This event is created whenever the IOBOX-WLAN receives data from one of 5 wireless access points |
| ALARM_SYS_WLAN_TCP_CONNECTED | This event is created once a connection is established between the device and remote server over one of 5 wireless access points |
| ALARM_SYS_WLAN_TCP_DISCONNECTED | This event is created once the device is disconnected from the remote server over one of 5 wireless access points |
| IO | |
| ALARM_IO_IN | This event is created whenever a device input/output signal changes its state |
| ALARM_IO_MOTION_MOVING | This event is created once the device detects moving (IO.Motion.eMoving) based on pre-defined threshold. |
| ALARM_IO_MOTION_STANDING | This event is created once the device detects standing (IO.Motion.eStanding) based on pre-defined threshold. |
| ALARM_IO_MOTION_FORCE | This event is created once the pre-configured force acceleration (IO.Motion.eForce) is exceeded. |
| ALARM_IO_MOTION_3DFORCE | This event is created once the device exceeds the configured force acceleration in one direction (IO.Motion.e3DForce) |
| ALARM_IO_MOTION_CRASH | Not supported (Event from external motion sensor) |
| ALARM_IO_MOTION_INTERNAL | Not supported (Event from external motion sensor) |
| ALARM_IO_MOTION_EXTERNAL | Not supported (Event from external motion sensor) |
| ALARM_IO_BEARING | This event is created once the device detects moving (IO.Motion.eBearing) based on pre-defined threshold. |
| GPS | |
| ALARM_GPS_NAV_FIX | This event is called once the device gets a valid GNSS fix |
| ALARM_GPS_NAV_HEADING | This event is created once the device detects changes in heading for more than the specified heading tolerance (GPS.Nav.eChangeHeading). |
| ALARM_GPS_NAV_HEADING2 | This event is created once the device detects changes in heading2 for more than the specified heading2 tolerance (GPS.Nav.eChangeHeading2). |
| ALARM_GPS_GEOFENCE | This event is created once the device detects in/out of one of pre-configured geofences. |
| ALARM_GPS_AREA | This event is created once the device detects in/out of one of pre-configured areas. |
| ALARM_GPS_MULTI_GEOFENCE | This event is created once the device detects in/out of one of pre-configured multi-geofences |
| ALARM_GPS_WAYPOINT_GEOFENCE | This event is created once the device leaves the corridor of preconfigured waypoints. |

| | |
|--------------------------------------|---|
| ALARM_GPS_JAMMING | This event is created once the GPS jamming is detected |
| ALARM_GPS_ANT_PLUGGED | This event is created once an external GPS antenna is plugged/connected |
| ALARM_GPS_ANT_UNPLUGGED | This event is created once an external GPS antenna is unplugged/disconnected |
| GSM | |
| ALARM_GSM_OPFOUND | This event is created once a GSM network operator is found |
| ALARM_GSM_OPLOST | This event is created when the GSM network operator is lost |
| ALARM_GSM_CELLCHANGE | This event is created whenever a GSM cell is changed |
| ALARM_GSM_CBM | This event is created whenever new cell broadcast message is received |
| ALARM_GSM_SIMLOST | This event is created whenever a simcard is not longer present |
| ALARM_GSM_MCCCHANGE | This event is created whenever a mobile country code is changed |
| ALARM_GSM_JAMMING | This event is created whenever GSM jamming is detected |
| ALARM_GSM_VOICECALL_INCOMING_RING | This event is created when an incoming voice call is received |
| ALARM_GSM_VOICECALL_RING_STOPPED | This event is created when the device stops ringing |
| ALARM_GSM_VOICECALL_OUTGOING_DIAL | This event is created when an outgoing voice call is dialled |
| ALARM_GSM_VOICECALL_CALL_ESTABLISHED | This event is created when an outgoing voice call is established |
| ALARM_GSM_VOICECALL_CALL_FINISHED | This event is created when an outgoing voice call is finished |
| ALARM_GSM_SMS_INCOMING | This event is created when an SMS is received |
| ALARM_GSM_SMS_SENT | This event is created when an SMS is sent |
| ALARM_GSM_GPRS_CONNECTING | This event is created when device starts connecting to GPRS services |
| ALARM_GSM_GPRS_CONNECTED | This event is created when the device is attached to GPRS services |
| ALARM_GSM_GPRS_DISCONNECTING | This event is created when the device stars disconnecting from GPRS services |
| ALARM_GSM_GPRS_DISCONNECTED | This event is created when the device is successfully detached from GPRS services |
| TCP | |
| ALARM_TCP_CLIENT_CONNECTING | This event is created when device starts connecting to a TCP server |
| ALARM_TCP_CLIENT_CONNECTED | This event is created when device is connected to the TCP server |
| ALARM_TCP_CLIENT_PACKETSENT | This event is created when a TCP packet is sent |
| ALARM_TCP_CLIENT_PINGSENT | This event is created when a TCP ping is sent |
| ALARM_TCP_CLIENT_RECEIVED | This event is created when data is received from the TCP server |
| ALARM_TCP_CLIENT_DISCONNECTING | This event is created when device starts disconnecting from the TCP server |

| | |
|------------------------------------|--|
| ALARM_TCP_CLIENT_DISCONNECTED | This event is created when device is disconnected from the TCP server |
| ALARM_TCP_CLIENT_BUFFER_EMPTY | This event is created once the TCP buffer is emptied |
| ALARM_TCP_CLIENT_FLASHBUFFER_EMPTY | This event is created once the flash buffer is emptied |
| ALARM_TCP_SMTP_SENT | This event is created once an email is sent |
| ALARM_TCP_SMTP_FAILED | This event is created when sending email failed |
| ALARM_TCP_UDP_RECEIVED | This event is created when receiving data via UDP |
| FILE | |
| ALARM_FILE_AVAILABLE | This event is created when file is available |
| ECODRIVE | |
| ALARM_ECODRIVE_START | These events are created when the ecodrive is started/stopped/on harsh-turn/-brake/-accelerate |
| ALARM_ECODRIVE_STOP | |
| ALARM_ECODRIVE_TURN | |
| ALARM_ECODRIVE_BRAKE | |
| ALARM_ECODRIVE_ACCELERATE | |
| BLUEID | |
| ALARM_BLUEID_CMD | These events are created when BLUEID gets command, data or tickets |
| ALARM_BLUEID_DATA | |
| ALARM_BLUEID_TICKETS | |
| TYPE | |
| ALARM_TYPE_INTERNAL | User specific event types for LUA (i.e timer or user events) |
| LUA | |
| ALARM_SYS_LUA_START | These events are created when Lua is started or stopped |
| ALARM_SYS_LUA_STOP | |
| DTCO | |
| ALARM_SYS_DTCO_CONFIRM | Confirmation that the message has been sent completely |
| ALARM_SYS_DTCO_INCOMING | Indication that the requested message has got incoming data |
| CAN | |
| ALARM_SYS_CANMSG | This event is created when contents of this CAN message is changed |
| TCP Socket | |
| NET_TCP | Socket is used for a TCP connection |
| NET_UDP | Socket is used for a UDP connection |
| ALARM_TCP_SOCKET_IFUP | Socket interface is up |
| ALARM_TCP_SOCKET_IFDOWN | Socket interface is down |
| ALARM_TCP_SOCKET_CONNECTED | Socket interface is connected |
| ALARM_TCP_SOCKET_DISCONNECTED | Socket interface is disconnected |
| ALARM_TCP_SOCKET_RECV | Socket interface has received data |

| | |
|--|---|
| ALARM_TCP_SOCKET_SENT | Socket interface has sent data |
| IOBOX | |
| ALARM_SYS_IOBOX_LOST | This event is created when a connection to the IOBOX-MIN/CAN or WLAN is lost |
| PFAL state request | |
| state := avl.state(type[,index]) | <p>When a state changes in the device, the FOX3 creates a state type, puts details into it and passes it to the Lua. The “state” reads that state type. To read the type and data of that state use the one of the state types listed under “State Requests”. For example:</p> <pre>st = avl.event(1000) if st ~= nil then if st.type == STATE_SYS_BLE_CONNECTED then ble_data = st.u_string os.trace("DATA = [%s]", ble_data); end; end;</pre> |
| State Requests | |
| <pre>state := [state.type state.idx state.u_bool state.u_value state.u_string state.u_starttype state.u_startreason state.u_opid state.u_opname]</pre> | <p>Reads the type and the data assigned to that state</p> <p>// values of “state.u_XXX” fields depends on the state type</p> <p>// integer state type</p> <p>// integer subindex</p> <p>// boolean value type</p> <p>// integer value type</p> <p>// string value type</p> <p>// integer starttype</p> <p>// integer startreason</p> <p>// integer operator id</p> <p>// string operator name</p> |
| STATES / Notifications | |
| STATE_SYS_DEVICE_START | Value of the PFAL SYS.Device.sStart state |
| STATE_SYS_TIMER | Value of the PFAL SYS.Timer.s<id> state |
| STATE_SYS_TRIGGER | Value of the PFAL SYS.Trigger.s <id> state |
| STATE_SYS_COUNTER | Value of the PFAL SYS.Counter.s <id> state |
| STATE_SYS_nvCOUNTER | Value of the PFAL SYS.NVCounter.s <id> state |
| STATE_SYS_CAN | Value of the PFAL SYS.sCan state |
| STATE_SYS_BAT_VOLTAGE | Value of the PFAL SYS.Bat.sVoltage state |
| STATE_SYS_BAT_CHARGE | Value of the PFAL SYS.Bat.sCharge state |
| STATE_SYS_BAT_MODE | Value of the PFAL SYS.Bat.sMode state |
| STATE_SYS_POWER_VOLTAGE | Value of the PFAL SYS.Power.sVoltage state |
| STATE_SYS_1WIRE_REGISTER | Value of the PFAL SYS.Power.sRegister state |
| STATE_SYS_NFC_DETECTED | Value of the PFAL SYS.NFC.sDetected state |
| STATE_SYS_BLE_CONNECTED | Value of the PFAL SYS.BLE.sConnected state |
| STATE_SYS_WLAN_CONNECTED | Value of the PFAL SYS.WLAN.sConnected state |
| STATE_SYS_WLAN_DISCONNECTED | Value of the PFAL SYS.WLAN.sDisconnected state |

| | |
|-------------------------------------|--|
| STATE_SYS_WLAN_TCP_CONNECTED | Value of the PFAL SYS.WLAN.sTCPConnected state |
| STATE_SYS_WLAN_TCP_DISCONNECTED | Value of the PFAL SYS.WLAN.sTCPDisconnected state |
| IO | |
| STATE_IO_IN | Value of the PFAL IO.IN.s<id> state |
| STATE_IO_ANA | Value of the PFAL IO.ANA.s<id> state |
| STATE_IO_PULSECNT | Value of the PFAL IO.PulseCount.s<id> state |
| STATE_IO_MOTION_MOVING | Value of the PFAL IO.Motion.sMoving state |
| STATE_IO_MOTION_STANDING | Value of the PFAL IO.Motion.sStanding state |
| GPS | |
| STATE_GPS_NAV_FIX | Value of the PFAL GPS.Nav.sFix state |
| STATE_GPS_NAV_SPEED | Value of the PFAL GPS.Nav.sSpeed state |
| STATE_GPS_NAV_POSITION | Value of the PFAL GPS.Nav.sPosition state |
| STATE_GPS_NAV_DIST | Value of the PFAL GPS.Nav.sDist state |
| STATE_GPS_NAV_DELTASPEED | Value of the PFAL GPS.Nav.sDeltaSpeed state |
| STATE_GPS_HISTORY_DIST | Value of the PFAL GPS.History.sDist state |
| STATE_GPS_AREA | Value of the PFAL GPS.Area.s<id> state |
| STATE_GPS_GEOFENCE | Value of the PFAL GPS.Geofence.s<id> state |
| STATE_GPS_MULTI_GEOFENCE | Value of the PFAL GPS.MultiGeofence.s<id> state |
| STATE_GPS_WAYPOINT_GEOFENCE | Value of the PFAL GPS.WPGF.s<id> state |
| GSM | |
| STATE_GSM_OPVALID | Value of the PFAL GSM.sOpValid state |
| STATE_GSM_HOME | Value of the PFAL GSM.sNoRoaming state |
| STATE_GSM_ROAMING | Value of the PFAL GSM.sRoaming state |
| STATE_GSM_VOICECALL_READY_FOR_CALL | Value of the PFAL GSM.Voicecall.sReady state |
| STATE_GSM_VOICECALL_INCOMING_RING | Value of the PFAL GSM.Voicecall.sIncoming state |
| STATE_GSM_VOICECALL_NUMBER_OF_RINGS | Value of the PFAL GSM.Voicecall.sRingCounter state |
| STATE_GSM_VOICECALL_OUTGOING_DIAL | Value of the PFAL GSM.Voicecall.sOutgoing state |
| STATE_GSM_VOICECALL_INSIDE | Value of the PFAL GSM.Voicecall.sInside state |
| STATE_GSM_GPRS_CONNECTING | Value of the PFAL GSM.GPRS.sConnecting state |
| STATE_GSM_GPRS_CONNECTED | Value of the PFAL GSM.GPRS.sConnected state |
| STATE_GSM_GPRS_DISCONNECTING | Value of the PFAL GSM.GPRS.sDisconnecting state |
| STATE_GSM_GPRS_DISCONNECTED | Value of the PFAL GSM.GPRS.sDisconnected state |
| TCP | |
| STATE_TCP_CLIENT_IDLE | Value of the PFAL TCP.Client.sIdle state |
| STATE_TCP_CLIENT_CONNECTING | Value of the PFAL TCP.Client.sConnecting state |
| STATE_TCP_CLIENT_CONNECTED | Value of the PFAL TCP.Client.sConnected state |
| STATE_TCP_CLIENT_DISCONNECTING | Value of the PFAL TCP.Client.sdisconnecting state |
| STATE_TCP_CLIENT_DISCONNECTED | Value of the PFAL TCP.Client.sDisconnected state |

| | |
|--|--|
| ECODRIVE | |
| STATE_ECODRIVE_START | Value ecodrive state is started |
| STATE_ECODRIVE_STOP | Value ecodrive state is stopped |
| STATE_ECODRIVE_SPEED1 | Value ecodrive has speed limit1 |
| STATE_ECODRIVE_SPEED2 | Value ecodrive has speed limit2 |
| STATE_ECODRIVE_SPEED3 | Value ecodrive has speed limit3 |
| GSM | |
| GSM_DISABLED | Value GSM state is disable |
| GSM_SLEEP | Value GSM state is sleep |
| GSM_IDLE | Value GSM state is idle |
| GSM_INIT_BASE | Value GSM state is initializing base commands |
| GSM_INIT_MAIN | Value GSM state is initializing main commands |
| GSM_INIT_NET | Value GSM state is initializing gprs commands |
| GSM_VERSION | Value GSM state is checking cellular version |
| GSM_IMSI_CHECK | Value GSM state is checking IMSI number |
| GSM_SMS_CHECK | Value GSM state is checking SMS activity |
| READY_FOR_CALL | Value GSM is ready for call |
| INCOMING_VOICE_CALL | Value GSM has incoming voice call |
| INCOMING_DATA_CALL | Value GSM has incoming data call |
| INCOMING_FAX_CALL | Value GSM has incoming fax call |
| OUTGOING_VOICE_CALL | Value GSM has outgoing voice call |
| INSIDE_VOICE_CALL | Value GSM is inside voice call |
| TIMER | |
| TIMER_ERASED | Timer is cleared |
| TIMER_INACTIVE | Timer is inactive |
| TIMER_PAUSED | Timer is paused |
| TIMER_RUNNING | Timer is running |
| String formatting with dynamic entries | |
| sResult := avl.format("format", args) | Reads the formatted "args" that has been defined in the "args" field |
| PFAL variables | |
| sResult := avl.version() | Reads the firmware version |
| sResult := avl.device() | Reads the device name |
| iResult := avl.timer(index) | Reads the timer index |
| iResult := avl.trigger(index) | Reads the trigger index |
| iResult := avl.counter(index) | Reads the counter index |
| iResult := avl.nvcounter(index) | Reads the nvcounter index |
| PFAL file transfer | |

| | |
|--|---|
| len := avl.file_upload(buffer) | Reads the length of the file |
| GPS state and data | |
| sValue := avl.gps_version() | Reads the GPS firmware version |
| tResult := avl.gps_data() | Reads the current GPS data |
| tResult := avl.gps_sats() | Reads the GPS satellites in use |
| GPS data | |
| record := [lat lon alt speed course ecef_x ecef_y ecef_z dop time fix] | Reads the GPS values listed within the [] square brackets. // Latitude (degree) // Longitude (degree) // Altitude (meter) // speed (m/s) // course (degree) // ECEF-X (meter) // ECEF-Y (meter) // ECEF-Z (meter) // pdop value // time (seconds) // fix (boolean) |
| GPS satellites record | |
| record := [gps_num gps_sat1 .. gps_sat12 gls_num gls_sat1 .. gls_sat12] | Reads the GPS values listed within the [] square brackets. // Number of GPS satellites // Dump of satellite data // "SatID,Elevation,Azimuth,AvgCNo,Used" // Number of GLS satellites // Dump of satellite data // "SatID,Elevation,Azimuth,AvgCNo,Used" |
| GSM state and data | |
| sValue := avl.gsm_version() | Reads the GSM firmware version |
| tResult := avl.gsm_data() | Reads the current GSM data |
| sValue := avl.gsm_imei() | Reads the IMEI of the device |
| sValue := avl.gsm_imsi() | Reads the IMSI of the SIM card |
| sValue := avl.gsm_iccid() | Reads the ICCID of the SIM card |
| GSM data | |
| record := [state csq creg cpas lac cellid opid opname callstate callnumber] | Reads the GSM values listed within the [] square brackets. // GSM state // CSQ value // CREG value // CPAS value // local area code // cell id // operator id // operator name (string) // call state // caller number (string) |

| | |
|--|---|
|] | |
| Motion data | |
| tResult := avl.motion_data() | Reads the motion data |
| Motion data | |
| <pre>record := [val_x val_y val_z min_x min_y min_z max_x max_y max_z nsum_x nsum_y nsum_z]</pre> | Reads the motion values listed within the [] square brackets. // Current X acceleration // Current Y acceleration // Current Z acceleration // Min. X acceleration in <g_coe> interval // Min. Y acceleration // Min. Z acceleration // Max. X acceleration in <g_coe> interval // Max. Y acceleration // Max. Z acceleration // Normal X gravitation in <g_coe> interval // Normal Y gravitation // Normal Z gravitation |
| Timer variable | |
| timer := avl.tick(interval, event_type); | |
| timer:start([time]) | Restarts a timer or start a timer with a new interval |
| timer:stop() | Stops the timer |
| timer:single() | Restarts a single timer |
| timer:cyclic() | Restarts a cyclic timer |
| iResult := timer:id() | Reads the timer event type |
| iResult := timer:interval() | Reads the timer interval time |
| iResult := timer:elapsed() | Reads the timer elapsed time |
| Socket interface | |
| <pre>socket := net.create_socket([type, param]) socket:connect(<"IP" "URL">, port) socket:close([flush]) socket:flush() socket:hold() socket:unhold() tVal := socket:unsent() tVal := socket:tll([ttl]) tVal := socket:bufsize([bytes]) tBytes := socket:send(data) data, tBytes := socket:recv() tIP, tPort := socket:getaddr() tIP, tPort := socket:getpeer() tIP := net.dns_resolve("URL") socket:on(<"connection" "disconnection" "sent" "receive">, function())</pre> | TCP socket implementation for LUA // Create a socket // Connect the socket to peer // Close the socket // Flush the socket // Hold the socket // Unhold the socket // Unsent socket data // Set/Read TTL value // Set/Read buffer size // Send data to socket // Read data from socket // Socket address // Peer address // Resolve URL // Socket callbacks |
| LUA I2C access | |

| | |
|--|---|
| count := avl.i2c_read(addr, register, data) | Read data from I2C devices connected to FOX3-2G/3G/4G |
| count := avl.i2c_write(addr, register, data) | Write data to I2C devices connected to FOX3-2G/3G/4G |
| avl.i2c_reset() | Reset the I2C bus |
| LUA DTCO-commands | |
| tBytes = dtco.iso_send(TA, strData) | Sends requests to the specified address: tBytes - count of transmitted bytes TA - target address strData - string variable |
| tData, tBytes, SA := dtco.iso_rcv() | Reads the data the tachograph has transmitted on request: tData - received data tBytes - count received bytes SA - source address |
| LUA file access | |
| file := io.open(filename [, mode]) io.lines (filename) io.read(...) io.write(...) io.type (file) io.flush(file) io.close(file) file:read(...) file:write(...) file:lines() file:flush() file:close() file:seek ([whence] [, offset]) os.remove(name) os.rename(oldname, newname) os.mkdir(name) | Working with files // Open a file // Read one line from file // Read data from file // Write data to file // Type of file // Flush written data // Close file // File operations // Remove a file on disk // Rename a file on disk // Make a directory |
| LUA library | |
| os.clock(), os.date(), os.time(), os.difftime(), os.exit(), os.execute(), os.getenv(), os.setenv(), os.sleep(), os.setlocale() | Documentation for LUA under < https://www.lua.org/manual/5.2 > or < https://www.lua.org/pil/contents.html > |
| coroutine.create(), coroutine.resume(), coroutine.running(), coroutine.status(), coroutine.wrap(), coroutine.yield() | |
| string.byte(), string.char(), string.dump(), string.find(), string.format(), string.gmatch(), string.gsub(), string.len(), string.lower(), string.match(), string.rep(), string.reverse(), string.sub(), string.upper(), string.replace() | |
| table.concat(), table.insert(), table.pack(), table.unpack(), table.remove(), table.sort() | |
| math.abs(), math.acos(), math.asin(), | |

math.atan2(), math.atan(), math.ceil(),
math.cosh(), math.cos(), math.deg(),
math.exp(), math.floor(), math.fmod(),
math.frexp(), math.ldexp(), math.log(),
math.max(), math.min(), math.modf(),
math.pow(), math.rad(), math.random(),
math.randomseed(), math.sinh(), math.sin(),
math.sqrt(), math.tanh(), math.tan()

bit32.arshift(), bit32.band(), bit32.bnot(),
bit32.bor(), bit32.bxor(), bit32.btest(),
bit32.extract(), bit32.lrotate(), bit32.lshift(),
bit32.replace(), bit32.rrotate(), bit32.rshift()

NEW FEATURES FOR CAN_CPC:

This section presents what is new in the firmware release regarding the Premium-Feature CAN_CPC.


- ✓ Added PFAL commands/configuration/event/states/dynamic variables.

| Events | Description |
|--|--|
| SYS.eJ1939.TIRE_FAULT<comp><value> | This event is generated whenever the contents of the J1939.TIRE_FAULT variable changes. <i>Example: SYS.eJ1939.TIRE_FAULT=0 or SYS.eJ1939.TIRE_FAULT>0</i> |
| SYS.eJ1939.TIRE_STAT<comp><value> | This event is generated whenever the contents of the SYS.eJ1939.TIRE_STAT changes. <i>Example: SYS.eJ1939.TIRE_STAT=0 or SYS.eJ1939.TIRE_STAT>0</i> |
| SYS.eJ1939.TIRE_CPC_STAT_HEALTH<comp><value> | This event is generated whenever the contents of the SYS.eJ1939.TIRE_CPC_STAT_HEALTH variable changes. <i>Example: SYS.eJ1939.TIRE_HEALTH>=0</i> |
| SYS.eJ1939.TIRE_CPC_STAT_WEX<comp><value> | This event is generated whenever the contents of the SYS.eJ1939.TIRE_CPC_STAT_WEX variable changes. <i>Example: SYS.eJ1939.TIRE_CPC_STAT_WEX>=0</i> |
| SYS.eJ1939.TIRE_CPC_STAT_LEARN<comp><value> | This event is generated whenever the contents of the SYS.eJ1939.TIRE_CPC_STAT_LEARN variable changes. <i>Example: SYS.eJ1939.TIRE_CPC_STAT_LEARN>=0</i> |
| SYS.eJ1939.TIRE_CPC_TTM_STATE<comp><value> | This event is generated whenever the contents of the SYS.eJ1939.TIRE_CPC_TTM_STATE variable changes. <i>Example: SYS.eJ1939.TIRE_CPC_TTM_STATE>=0</i> |
| SYS.eJ1939.TIRE_CPC_TTM_ALARM<comp><value> | This event is generated whenever the contents of the SYS.eJ1939.TIRE_CPC_TTM_ALARM variable changes. <i>Example: SYS.eJ1939.TIRE_CPC_TTM_ALARM>=0</i> |
| SYS.eJ1939.TIRE_CPC_TTM_BAT<comp><value> | This event is generated whenever the contents of the SYS.eJ1939.TIRE_CPC_TTM_BAT variable changes. <i>Example: SYS.eJ1939.TIRE_CPC_TTM_BAT>=0</i> |
| SYS.eJ1939.TIRE_CPC_TTM_DEFECT<comp><value> | This event is generated whenever the contents of the SYS.eJ1939.TIRE_CPC_TTM_DEFECT variable changes. <i>Example: SYS.eJ1939.TIRE_CPC_TTM_DEFECT>=0</i> |
| SYS.eJ1939.TIRE_CPC_TTM_LOSE<comp><value> | This event is generated whenever the contents of the SYS.eJ1939.TIRE_CPC_TTM_LOSE variable changes. <i>Example: SYS.eJ1939.TIRE_CPC_TTM_LOSE>=0</i> |

| | | |
|--|---------|--|
| | <comp> | <comp> Compares the contents of this variable with the used specified one and return a Boolean (True/False) representing the result of the comparison. It can be set to =, !=, <, >, <= or >=. |
| | <value> | <value> Specifies the value to be compared. |
| Dynamic Variables | | |
| Tire Condition | | |
| J1939.TIRE_TEMP ≡ PGN 0xFE433 | | It reports, into the comma separated value format, the temperature of each wheel as follows. e.g. 00:21,01:22,10:20,11:20,12:20,13:21,20:21,21:22 00 = wheel position, 21 = temperature in °C. |
| J1939.TIRE2_NOMPRESS ≡ PGN 0xFE433 | | It reports, into the comma separated value format, the nominative pressure in kPa of each tire as follows. e.g.: 00:790,01:795,10:790,11:795,12:790,13:795,13:790,13:795 00 = wheel position, 790 = nominative tire pressure in kPa. |
| J1939.TIRE2_PRESSURE ≡ PGN 0xFE433 | | It reports, into the comma separated value format, the pressure of each tire as follows. e.g.: 00:4,01:4,10:249,11:4,12:4,13:4,20:249,21:4 10:790 - 00 = wheel position, 249 = tire pressure in kPa. |
| J1939.TIRE_PRESSURE ≡ PGN 0xFE433 | | It reports, into the comma separated value format, the pressure of each tire as follows. e.g.: 00:4,01:4,10:248,11:4,12:4,13:4,20:248,21:4 10 = wheel position, 248 = tire pressure in kPa. |
| J1939.TIRE_FAULT ≡ PGN 0xFE433 | | It reports, into the comma separated value format, the fault state of each tire as follows. e.g.: 00:0,01:0,10:0,11:1, 12:0,13:0,20:0,121:0 11 = wheel position, 0 = no fault; 1 = fault. |
| J1939.TIRE_PTD ≡ PGN 0xFE433 | | It reports, into the comma separated value format, the pressure threshold detection of each tire as follows. e.g.: 00:4,01:2,10:2,11:2,12:4,13:2,20:2,21:2 00 = wheel position; 1 = Over pressure, 2 = No warning pressure, 3 = Under pressure, 4 = Extreme under pressure. |
| J1939.TIRE_PLOSS ≡ PGN 0xFE433 | | It reports, into the comma separated value format, the pressure loss of each tire as follows. e.g.: 00:0,01:0,10:0,11:0,12:0,13:0,20:0,21:0 00 = wheel position; 1 = tire pressure loss in Pa/s (0.1 Pa/s per bit). |
| J1939.TIRE_SEN ≡ PNG 0xFE433 | | It reports, into the comma separated value format, if the sensors are enabled as follows. e.g.: 00:1,01:1,10:1,11:1,12:1,13:1,20:1,21:1 00:1 - 00 = wheel position; 0 = Sensor disabled, 1 = Sensor enabled. |
| J1939.TIRE_STAT ≡ PGN 0xFE433 | | It reports, into the comma separated value format, the status of each tire as follows. e.g.: 00:0,01:0,10:0,11:0,00:0,01:0,10:0,11:0 00 = wheel position; 0 = tire OK, 1 = tire leak. |
| J1939.TIRE_ETP ≡ PGN 0xFE433 | | It reports, into the comma separated value format, the while position and if the extended tire pressure is supported as follows. e.g.: 00:1,01:1,10:1,11:1,20:1,21:1,30:1,31:1 00 = wheel position; 0 = Not using Extended Tire Pressure, 1 = Using Extended Tire Pressure, 10: Error, 11: Not available/Not supported |
| CPC System Configuration | | |
| J1939.TIRE_CPC_CNF_NAXLE ≡ PGN 0xFF0033 | | It reports the number of axles for the tractor or trailer as follows. e.g.: 00:4 00 = tractor, 01 = trailer; 4 = Number of axles. |
| J1939.TIRE_CPC_CNF_NCTTM ≡ PGN 0xFF0033 | | It reports the number of TTMs for the tractor and trailer as follows. e.g.: 00:8 00 = tractor, 01 = trailer; 08 = Number of TTMs. |

| CPC System Status | |
|---|--|
| J1939.TIRE_CPC_STAT_HEALTH ≡ PGN 0xFF0133 | It reports the status of CPC system for the tractor and trailer as follows. e.g.: 00:1 00 = tractor, 01 = trailer; 0 = OK; "No TTM mounted" NOT detected, 0 = "No TTM mounted" detected. |
| J1939.TIRE_CPC_NOTTM ≡ PGN 0xFF0133 | It reports if no TTMs mounted for the tractor and trailer as follows. e.g.: 00:0 00 = tractor, 01 = trailer; 0 = OK "No TTM mounted" NOT detected, 0 = "No TTM mounted" detected. |
| J1939.TIRE_CPC_STAT_WEX ≡ PGN 0xFF0133 | It reports, into the comma separated value format, the single wheel exchange as follows. e.g.: 00:n/a 00 = tractor, 01 = trailer; 0 = "Single wheel exchanged" not detected, 0 = "Single wheel exchanged" detected. |
| J1939.TIRE_CPC_STAT_LEARN ≡ PGN 0xFF0133 | It reports, into the comma separated value format, the automatic trailer learning as follows. e.g.: 00:0 00 = tractor; 0: Automatic trailer learning ongoing; 1: Automatic trailer learning finished, known trailer found, 2: Automatic trailer learning finished, new trailer found, 3: Automatic trailer learning finished, no trailer found, 4: Feature not active. |
| CPC TTM Data | |
| J1939.TIRE_CPC_TTM_PRESSURE ≡ PGN 0xFF0233 | It reports, into the comma separated value format, the TTM pressure 4.706 kPa/bit as follows. e.g.: 00:aa,01:0,02:0,03:0,04:0,05:0,06:0,07:0,08:0,09:0 00...1F = index range in hex used to identify a sensor id; 0 = Sensor defective or data not available; 01...FF = (aa -1) * 4.706 kPa/bit = 800 kPa, FF=Overflow. |
| J1939.TIRE_CPC_TTM_TEMP ≡ PGN 0xFF0233 | It reports, into the comma separated value format, the TTM temperature 1 °C/bit -50 K offset as follows. e.g.: 00:22,01:22,02:22,03:22,04:22,05:22,06:22,07:22,08:22,09:22 00...1F = index range in hex used to identify a sensor id; 0 = Sensor defective or data not available; 01...FF = (4F -50K) = 45 °C, FF=Overflow. |
| J1939.TIRE_CPC_TTM_STATE ≡ PGN 0xFF0233 | It reports, into the comma separated value format, the TTM state as follows. e.g.: 00:8,01:8,02:8,03:8,04:8,05:8,06:8,07:8,08:8,09:8 00...1F = index range in hex used to identify a sensor id; 00-FE = Don't care, FF = No TTM data since Power On |
| J1939.TIRE_CPC_TTM_ALARM ≡ PGN 0xFF0233 | It reports, into the comma separated value format, the alarm and warning as follows. e.g.: 00:2,01:2,02:2,03:2,04:2,05:2,06:2,07:2,08:2,09:2 00...1F = index range in hex used to identify a sensor id; 0: OK, 1: Under-inflation warning, 2: Under-inflation alarm, 3: Tire leak alarm, 4: TTM mute, 5: Temperature warning, 8: TTM over temperature warning |
| J1939.TIRE_CPC_TTM_BAT ≡ PGN 0xFF0233 | It reports the battery flag as follows. e.g.: n/a n/a = Battery flag. |
| J1939.TIRE_CPC_TTM_DEFECT ≡ PGN 0xFF0233 | It reports the TTM defective as follows. e.g.: n/a 00 = wheel position; n/a = TTM defective. |
| J1939.TIRE_CPC_TTM_LOSE ≡ PGN 0xFF0233 | It reports, into the comma separated value format, the loose TTM detection as follows. e.g.: 00:0,01:0,02:0,03:0,04:0,05:0,06:0,07:0,08:0,09:0 00...1F = index range in hex used to identify a sensor id; 0: OK, 1: TTM |

| | |
|--|---|
| | loose, 2: TTM turned |
| CPC Graphical Position Configuration | |
| J1939.TIRE_CPC_POS:H<n> ≡ PGN 0xFF0433 | It reports, into the comma separated value format, the value according to the matrix (graphical position and tire location) and the index used as a reference/conjunction for matching the tire location, graphical position and ID of the sensors in hexadecimal as follows. e.g.: 00:03,01:0b,02:43,03:4b,04:53,05:5b 00...1F = index range in hex used to identify a sensor id; 0b = Hexadecimal value to identify the graphical position of the sensors. Refer to the pic. 3 and Table 5 below. |
| J1939.TIRE_CPC_POS ≡ PGN 0xFF0433 | It reports, into the comma separated value format, the value according to the matrix (graphical position and tire location) and the index used as a reference/conjunction for matching the tire location, graphical position and ID of the sensors in decimal as follows. e.g.: 00:3,01:11,02:67,03:75,04:83,05:91 00...1F = index range in hex used to identify a sensor id; 0b = Decimal value to identify the graphical position of the sensors. Refer to the pic. 3 and Table 5 below. |
| J1939.TIRE_CPC_LOC:H<n> ≡ PGN 0xFF0433 | It reports, into the comma separated value format, the value according to the matrix (graphical position and tire location) and the index used as a reference/conjunction for matching the tire location, graphical position and ID of the sensors in hexadecimal as follows. e.g.: 00:00,01:01,02:10,03:11,04:20,05:21 00...1F = index range in hex used to identify a sensor id; 11 = Hexadecimal value to identify the tire location. Refer to the pic. 3 and Table 5 below. |
| J1939.TIRE_CPC_LOC ≡ PGN 0xFF0433 | It reports, into the comma separated value format, the value according to the matrix (graphical position and tire location) and the index used as a reference/conjunction for matching the tire location, graphical position and ID of the sensors in decimal as follows. e.g.: 00:0,01:1,02:16,03:17,04:32,05:33 00...1F = index range in hex used to identify a sensor id; 17 = decimal value to identify the graphical position of the sensors. Refer to the pic. 3 and Table 5 below. |
| J1939.TIRE_CPC_TTM_ID ≡ PGN 0xFF0433 | It reports, into the comma separated value format, the while position and the TTM ID of the sensor in decimal as follows. e.g.: 00:1835297152,01:1835297152,02:1821695488,03:1818171136,04:1825507328,05:1825000448,06:1821695360,07:1821695232 00...1F = index range in hex used to identify a sensor id; 1835297152=TTM ID in decimal value. Refer to the pic. 3 and Table 5 below. |
| J1939.TIRE_CPC_TTM_ID:H<n> ≡ PGN 0xFF0433 | It reports, into the comma separated value format, the while position and the TTM ID of the sensor in <n> decimal digits as follows. e.g.: J1939.TIRE_CPC_TTM_ID:H8 00:6d646950,01:6d646948,02:6c94de3c,03:6c5f16e6,04:6ccf0811,05:6cc74bf2,06:6c94dd4e,07:6c94dd08 00...1F = index range in hex used to identify a sensor id; 6d646950=TTM ID in hexadecimal value. Refer to the pic. 3 and Table 5 below. |
| J1939.TIRE_CPC_X ≡ PGN 0xFF0433 | It reports, into the carriage-return and line-feed, the collection of all CPC messages as follows. e.g.: J1939.TIRE_CPC_CNF_NAXLE:00:4 J1939.TIRE_CPC_CNF_NCTTM:00:8 J1939.TIRE_CPC_STAT_HEALTH:00:1 J1939.TIRE_CPC_STAT_WEX:n/a J1939.TIRE_CPC_STAT_LEARN:00:0 J1939.TIRE_CPC_TTM_PRESSURE:00:aa,01:0,02:0,03:0,04:0,05:0,06:0, |

| | | | |
|---|---|--|---------------------------------|
|  | <h1>Release Notes</h1> | | Lantronix AVL Products |
| | | | Release date: November 27, 2019 |
| | Firmware version: avl_3.3.0_rc15 | | Document revision: 3.3.0.0 |

| | |
|--|---|
| | 07:0,08:0,09:0 J1939.TIRE_CPC_TTM_TEMP:00:22,01:22,02:22,03:22,04:22,05:22,06:22,07:22,08:22,09:22 J1939.TIRE_CPC_TTM_STATE:00:8,01:8,02:8,03:8,04:8,05:8,06:8,07:8,08:8,09:8 J1939.TIRE_CPC_TTM_ALARM:00:2,01:2,02:2,03:2,04:2,05:2,06:2,07:2,08:2,09:2 J1939.TIRE_CPC_TTM_BAT:n/a J1939.TIRE_CPC_TTM_DEFECT:n/a J1939.TIRE_CPC_TTM_LOSE:00:0,01:0,02:0,03:0,04:0,05:0,06:0,07:0,08:0,09:0 J1939.TIRE_CPC_POS:00:3,04:11,08:19,0c:27,10:67,14:75,18:83,1c:91 J1939.TIRE_CPC_LOC:00:0,04:1,08:16,0c:17,10:32,14:33,18:48,1c:49 J1939.TIRE_CPC_TTM_ID:00:1835297152,01:1835297152,02:1821695488,03:1818171136,04:1825507328,05:1825000448,06:1821695360,07:1821695232 |
|--|---|

TTM=Truck tire module "Sensor inside the tire"

REMOVED/NOT SUPPORTED:

This section presents what has been removed/not supported in this firmware release.


- ✓ SYS.BLE.eRegister=whitelist

CHANGES:

This section presents what has been changed in this firmware release.

- ✓ Changed PFAL commands/configuration/event/states/dynamic variables

| PFAL Commands | |
|--|---|
| Sys.Can.OBDII.Enable[,<format>] | Enables the OBD-II [and the format] for reading its messages on 1 st CAN interface (on main port) Optional <format> settings: Std Enables the 11-bit identifier (CAN2.0A) Ext Enables the 29-bit identifier (CAN2.0B) |
| Sys.CanB.OBDII.Enable[,<format>] | Enables the OBD-II [and the format] for reading its messages on 2 nd CAN interface (IOBOX-CAN) Optional <format> settings: Std Enables the 11-bit identifier (CAN2.0A) Ext Enables the 29-bit identifier (CAN2.0B) |
| MSG.Mode.<interface>=<output>,D=<msg_output_channel> | Changed the transparent data mode between channels: Supported <msg_output_channel> settings: 1 1 st Serial port. 2 2 nd Serial port. 4 USB port 10 TCP port. |
| Configuration parameters | |
| DEVICE.CAN.OBD.STARTUP=<format>,<port> | Enables the OBD-II [and the format] for reading its messages on the user specified CAN port <format> settings: |

| | | | |
|---|---|--|---------------------------------|
|  | <h1>Release Notes</h1> | | Lantronix AVL Products |
| | | | Release date: November 27, 2019 |
| | Firmware version: avl_3.3.0_rc15 | | Document revision: 3.3.0.0 |

| | |
|--|--|
| | Std Enables the 11-bit identifier (CAN2.0A) Ext Enables the 29-bit identifier (CAN2.0B) <port> 0 Enables reading on 1st CAN interface (on main port). 1 Enables reading on 2nd CANB interface (on IOBOX-CAN) |
|--|--|

IMPROVEMENTS:

This section presents what has been improved in this firmware release.

- ✓ AES key handling (Support AES128/192/256 keys).
- ✓ Added LUA support for flash filesystem.
- ✓ Read/Write data from I2C devices.
- ✓ BIOS 3.0.2: Optimized for BOLERO40 series.
- ✓ Improvements of the LUA net socket class.
- ✓ Double buffer handling in OBD2 and ISO-TP.
- ✓ Increase the "CAN message filter" on the main interface and IOBOX-CAN.

BUGS FIXED:

This is a list of internal problems that were fixed in the current firmware release.


- ✓ The setting \$PFAL,CNF.Set,DEVICE.PFAL.SEND.FORMAT=<...>.
- ✓ The event GSM.Voicecall.eIncoming" will be generated when a voice call comes in.
- ✓ Fixed flag Enable/Disable in the Dead-Reckoning function for FOX3-3G-DR.
- ✓ Fixed wrong hysteresis "Sys.Device.sleep=AiWu=<min>,<max>".
- ✓ Changed default for TCP.CLIENT.LOGIN=<parameter>.

KNOWN ISSUES:

This is a list of known issues in the current firmware release.

| Mantis ID | Priority | Status | Bug Summary |
|-----------|----------|--------|--|
| - | - | - | RFID-A-B-EXT & AVL device. When the AVL device goes into the doze low power mode, a Tag should be double passed within the reader magnetic field to detect the ID of that Tag on the AVL serial port. The first swipe is to wake up the AVL device from the doze mode and the second swipe is to detect the Tag and generate the corresponding event. |
| - | - | - | |

References

| | | | |
|---|---|--|---------------------------------|
|  | <h1>Release Notes</h1> | | Lantronix AVL Products |
| | | | Release date: November 27, 2019 |
| | Firmware version: avl_3.3.0_rc15 | | Document revision: 3.3.0.0 |

This is a list of references used for updating this firmware release into one of the LANTRONIX AVL devices. The current version of the documents/software can be directly downloaded from the LANTRONIX website:

Workbench Tool

<https://www.lantronix.com/products/workbench/#tab-docs-downloads>

WebUpdate

https://cdn.lantronix.com/wp-content/uploads/pdf/AppNote_WebUpdate_Howto.pdf

Remote Update with Workbench

https://cdn.lantronix.com/wp-content/uploads/pdf/AppNotes_Remote_Update_With_Workbench.pdf