User Guide

M/E-TX-FX-01 Mini Media Converter

- 100Base-TX RJ-45 to 100Base-FX
 - Low cost 100M standalone media converter
 - With Auto-Negotiation, Auto-cross, etc.



Contents

Introduction	1
Product Details	2
Model Numbers	2
nstallation	3
Observe ESD Precautions	3
Copper and fiber ports	3
Connect the fiber cable	3
Connect the twisted-pair copper cable	4
Power warnings	
Power up the media converter	
Power adapter	5
Operation	
Status LEDs	5
Features	6
Cable Specifications	7
Technical Specifications	8
Troubleshooting	9
Contact Us1	
Compliance Information1	1
Declaration of Conformity1	1
CE Mark1	
Record of Revisions1	2

Introduction

Transition Networks' M/E-TX-FX-01 is a mini form factor, 100Base-TX RJ-45 to 100Base-FX converter. The M/E-TX-FX-01 is a plug and play operation fast Ethernet layer 1 standalone media converter that supports these features:

- Auto-Negotiation
- Auto-cross
- Far End Fault
- · Automatic link restoration

Product Details

Power Input: 12 VDC coax barrel input (7.5~13.9 VDC)

Data speed: 100 Mbps Copper port: RJ-45

Fiber Port connector: ST, SC or SFP

Jumbo Frames (Ethernet port): Supported up to 9016bytes DIP Switches / jumpers: None; fixed configurations

Model Numbers

Model	Description	Fiber connector
M/E-TX-FX-01(ST)	100Base-TX to 100Base-FX Mini	MM ST 2KM
M/E-TX-FX-01(SC)	100Base-TX to 100Base-FX Mini	MM SC 2KM
M/E-TX-FX-01(SM)	100Base-TX to 100Base-FX Mini	SM SC, 20KM
M/E-TX-FX-01(SFP)	100Base-TX to 100Base-X Mini	SFP slot (empty)
M/E-TX-FX-01(100)	100BASE-TX (RJ-45) [100 m/328 ft.] to 100BASE-FX 1310nm TX/1550nm RX	SM SC 20 KM (12.4 mi.)
M/E-TX-FX-01(101)	100BASE-TX (RJ-45) [100 m/328 ft.] to 100BASE-FX 1550nm TX/1310nm RX	SM SC 20 KM (12.4 mi.)

^{*} Typical maximum cable distance; actual distance depends on the physical characteristics of the network. Longer transmission distances, bi-directional transmissions, and CWDM technology are all supported via specific SFP modules



Models M/E-TX-FX-01 and M/E-TX-FX-01(SFP)

Installation


Observe ESD Precautions

Always observe the following ESD (Electrostatic Discharge) precautions when installing or handing the M/E-TX-FX-01 media converter:

- Do not remove the converter from its protective packaging until you are ready to install it.
- Wear an ESD wrist grounding strap before handling any module or component. If you do not have a wrist strap, maintain grounded contact with the system unit throughout any procedure requiring ESD protection.

Copper and fiber ports


The figure below shows the front panel of the M/E-TX-FX-01 media converters.



Connect the fiber cable

Full duplex (always ON) is on the fiber side only; therefore, the 512-Bit Rule does not apply. The cable lengths are constrained by the cable requirement.

- 1. Locate or build IEEE 803.2 compliant 100 Base-X fiber cable with male, two-stranded TX to RX connectors installed at both ends.
- 2. Connect the fiber cable to the M/E-TX-FX-01 media converters as follows:
 - Connect the male TX cable connector to the female TX port.
 - Connect the male RX cable connector to the female RX port.
- 3. Connect the fiber cable to the other device (another media converter, hub, etc.) as follows:
 - Connect the male TX cable connector to the female RX port.
 - Connect the male RX cable connector to the female TX port.




Connect the twisted-pair copper cable

The AutoCross feature allows either MDI (straight-through) or MDI-X (crossover) cable connections to be configured automatically, according to network conditions.

• If full-duplex mode is used, the 512-Bit Rule does not apply. The cable lengths are constrained by the cable requirements.

Perform these steps:

- Locate or build IEEE 803.2[™] compliant 100Base-TX cable, with RJ-45 connectors installed at both ends.
- 2. Connect the RJ-45 connector at one end of the cable to the RJ-45 port on the M/E-TX-FX-01 media converter.
- 3. Connect the RJ-45 connector at the other end of the cable to the RJ-45 port on the other device (switch, workstation, etc.).




Power warnings

<u>WARNING</u>: If the media converter is an IEEE802.3-2005 Powered Device (PD) capable of receiving power via the Media Dependent Interface (MDI) leads, the power source, connector, and cables attached to the barrel power connector must meet the isolation requirement specified in IEEE 802.3-2005.

Power up the media converter

The figure below shows the power connector.



M/E-TX-FX-01 and M/E-TX-FX-01(SFP) Back Panel Power

Power adapter

AC power

- 1. Connect the barrel connector of the power adapter to the media converter's power port (located on the back panel of the media converter).
- 2. Connect the power adapter plug to AC power.
- 3. Verify that the media converter is powered up by observing the illuminated LED power indicator light on the front panel.

DC power

Consult the user's guide for the Transition Networks SPS-1872-SA DC external power supply for powering the media converter.

Operation

Status LEDs

Use the LEDs to monitor the status of the media converter.

FX-Link/Act LED

Green ON = Link (fiber)


Flashing = Activity

TX-Link/Act LED

Green ON = Link

Flashing = Activity

Power LED ON = Connected to power



Features

Auto-Negotiation

The Auto-Negotiation feature is ON permanently for the M/E-TX-FX-01 media converters. Auto-Negotiation allows the media converter to configure itself automatically to achieve the best possible mode of operation over a link. It broadcasts speed (100 Mbps) and duplex capabilities (full) to the other device and negotiates the best mode of operation. Auto-Negotiation allows quick and easy installation because the optimal link is established automatically.

In a scenario where an auto-negotiation device is linked to a non-negotiating device, the negotiating device via parallel detection recognizes the speed of the second device then establishes the best operating speed (100 Mbps).

AutoCross™

The AutoCross feature allows using either straight-through (MDI) or crossover (MDI-X) copper cables when connecting to 100Base-TX devices. AutoCross determines the characteristics of the connection and automatically configures the device to link up, regardless of the copper cable configuration (MDI or MDI-X).

Automatic link restoration

The media converter will automatically re-establish the link when connected to a switch if the link is lost, even with Auto-Negotiation enabled.

Far-End Fault (always ON)

When a fault occurs on an incoming fiber link (1), the media converter transmits a Far-End Fault signal on the outgoing fiber link (2).

Cable Specifications

Cable physical characteristics must meet or exceed IEEE 802.3[™] specifications.

Fiber optic

Bit Error Rate: <10-9
Single mode fiber (recommended): 9 μm
Multimode fiber (recommended): 62.5/125 μm

Multimode fiber (optional): 100/140, 85/140, 50/125 μm

M/E-TX-FX-01

M/E-TX-FX-01 (SC) 1300 nm multimode

Fiber Optic Transmitter Power: min: -19.0 dBm max: -14.0 dBm Fiber Optic Receiver Sensitivity: min: -30.0 dBm max: -14.0 dBm

Link Budget: 11.0 dB

M/E-TX-FX-01 (SM) 1310 nm single mode

Fiber-optic Transmitter Power: min: -15.0 dBm max: -8.0 dBm Fiber-optic Receiver Sensitivity: min: -31.0 dBm max: -8.0 dBm

Link Budget: 16.0 dB

M/E-TX-FX-01 (100) (SM) 1310TX/1550RX nm, single-strand fiber M/E-TX-FX-01 (101) (SM) 1550TX/1310RX nm, single-strand fiber

Fiber-optic Transmitter Power: min: -13.0 dBm max: -6.0 dBm Fiber-optic Receiver Sensitivity: min: -32.0 dBm max: -3.0 dBm

Link Budget: 19.0 dB

The fiber optic transmitters on this device meet Class I Laser safety requirements per IEC825/CDRH standards and comply with 21 CFR1040.10 and 21CFR1040.11.

Copper cable


Category 5: (Minimum requirement for 100 Mb/s operation)

Gauge 24 to 22 AWG

Attenuation 22.0 dB /100m @ 100 MHz

Maximum Cable Distance 100 meters

- Straight-through or crossover twisted-pair cable may be used.
- Shielded (STP) or unshielded (UTP) twisted-pair cable may be used.
- Pins 1&2 and 3&6 are the two active pairs in an Ethernet network.
- Use only dedicated wire pairs for the active pins:
 (e.g., blue/white & white/blue, orange/white & white/orange, etc.)
- Do not use flat or silver satin wire.



Technical Specifications

For use with Transition Networks Model M/E-TX-FX-01 converters.

Standards: IEEE 802.3™, IEEE 802.3u

Regulatory Compliance for Emission FCC Class A; EN55022 Class A

Regulatory Compliance for Immunity EN55024, Safety Compliance Unit: CE Mark

Data rate: 100 Mb/s

Dimensions: 1.8"W x 3.35"D x 0.85"H (45.7 x 85.1 x 21.6 mm)

Weight: 2 lbs. (0.90 kg) approximately

Power consumption: 2.6 watts

MTBF*: 41,680 hours ((MIL-HDBK-217F)

114,580 hours (Bellcore7 V5.0)

Power sources: Barrel connector – Wall Mount AC power adapter 12VDC 400mA

(the external power supply provided with this product is UL listed and

C-UL listed Canada by the manufacturer).

Environment: Tmra**: 0°C to 50°C (32°F to 122°F)

Storage Temp: -15°C to 65°C (-5°F to 149°F) Humidity: 5% to 95%, non-condensing

Warranty: Lifetime

<u>WARNING</u>: If the media converter is an IEEE802.3-2005 Powered Device (PD) capable of receiving power via the Media Dependent Interface (MDI) leads, the power source, connector, and cable attached to the barrel power connector must meet the isolation requirement specified in IEEE802.3-2005. Failure to observe this warning could result in an electrical shock.

<u>CAUTION</u>: Copper based media ports, e.g., Twisted Pair (TP) Ethernet, USB, RS232, RS422, RS485, DS1, DS3, Video Coax, etc., are intended to be connected to intrabuilding (inside plant) link segments that are not subject to lightening transients or power faults. Copper-based media ports, e.g., Twisted Pair (TP) Ethernet, USB, RS232, RS422, RS485, DS1, DS3, Video Coax, etc., are NOT to be connected to interbuilding (outside plant) link segments that are subject to lightening transients or power faults. Failure to observe this caution could result in damage to equipment.

Copper-based media ports, e.g., Twisted Pair (TP) Ethernet, USB, RS232, RS422, RS485, DS1, DS3, Video Coax, etc., are intended to be connected to intra-building (inside plant) link segments that are not subject to lightening transients or power faults. Copper based media ports, e.g., Twisted Pair (TP) Ethernet, USB, RS232, RS422, RS485, DS1, DS3, Video Coax, etc., are NOT to be connected to interbuilding (outside plant) link segments that are subject to lightening transients or power faults.

<u>WARNING</u>: Visible and invisible laser radiation when open. Do not stare into the beam or view directly with optical instruments. Failure to observe this warning could result in an eye injury or blindness.

<u>WARNING</u>: Use of controls, adjustments, or the performance of procedures other than those specified herein could result in hazardous radiation exposure. The information in this user's guide is subject to change. For the most current information, view the online user guide at <u>www.transition.com</u> and the click on *Product/Product Finder*.

^{*} MTBF (*Mean Time Between Failure*) is estimated using the predictability method. The computation is based on the MIL-HDBK-217 F and Bellcore standards.

^{**}Manufacturer's rated ambient temperature.

Troubleshooting

If the media converter fails, isolate and correct the failure by determining the answers to the following questions, and then taking the indicated action:

1. Is the power LED lit and did the TX and FX LEDs turn ON and then turn OFF?

NO

- Is the device powered by an adapter?
- Is the power adapter the proper type of voltage and cycle frequency for the AC outlet?
- Is the power adapter properly installed in the media converter and in the AC outlet?
- Contact Technical Support: US/Canada: 1-800-260-1312, International: 00-1-952-941-7600.

YES

Proceed to step 2.

Note: the M/E-TX-FX-01 (no link pass-through option), the TX LED will turn ON when the twisted pair copper cable is installed; the FX LED will turn ON when the fiber cable is installed.

2. Are the "TX and FX-Link/ACT" LEDs lit on the RJ-45 port?

NO

Check the copper cables for proper connection.

Check the fiber cables for proper connection.

Contact Technical Support: US/Canada: 1-800-260-1312, International: 00-1-952-941-7600.

YES

Contact Technical Support: US/Canada: 1-800-260-1312, International: 00-1-952-941-7600.

Contact Us

Technical support

Technical support is available 24-hours a day

US and Canada: 1-800-260-1312 International: 00-1-952-941-7600

Transition now

Chat live via the Web with Transition Networks Technical Support. Log onto www.transition.com and click the **Transition Now** link.

Web-based seminars

fax:

Transition Networks provides seminars via live web-based training. Log onto www.transition.com and click the **Learning Center** link.

E-Mail

Ask a question anytime by sending an e-mail to our technical support staff. techsupport@transition.com


Address

Transition Networks
10900 Red Circle Drive
Minnetonka, MN 55343, U.S.A.
telephone: 952-941-7600
toll free: 800-526-9267

952-941-2322

Compliance Information

Declaration of Conformity



CE Mark

FCC regulations

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at the user's own expense.

Canadian regulations

This digital apparatus does not exceed the Class A limits for radio noise for digital apparatus set out on the radio interference regulations of the Canadian Department of Communications. Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la Class A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

European regulations

Warning

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Achtung!

Dieses ist ein Gerät der Funkstörgrenzwertklasse A. In Wohnbereichen können bei Betrieb dieses Gerätes Rundfunkstörungen auftreten. In diesem Fäll is der Benutzer für Gegenmaßnahmen verantwortlich.

Attention!

Ceci est un produit de Classe A. Dans un environment domestique, ce produit risque de créer des interférences radioélectriques, il appartiendra alors à l'utilsateur de prende les measures spécifiques appropriées.



In accordance with European Union Directive 2002/96/EC of the European Parliament and of the Council of 27 January 2003, Transition Networks will accept post usage returns of this product for proper disposal. The contact information for this activity can be found in the 'Contact Us' portion of this document.



CAUTION: RJ connectors are NOT INTENDED FOR CONNECTION TO THE PUBLIC TELEPHONE NETWORK. Failure to observe this caution could result in damage to the public telephone network.

Der Anschluss dieses Gerätes an ein öffentlickes Telekommunikationsnetz in den EGMitgliedstaaten verstösst gegen die jeweligen einzelstaatlichen Gesetze zur Anwendung der Richtlinie 91/263/EWG zur Angleichung der Rechtsvorschriften der Mitgliedstaaten über Telekommunikationsendeinrichtungen einschliesslich der gegenseitigen Anerkennung ihrer Konformität.

Record of Revisions

Rev	Date	Notes
Α	04/11/13	Initial release.
В	07/30/13	Add M/E-TX-FX-01(100) and M/E-TX-FX-01(101).

Trademark Notice

All trademarks and registered trademarks are the property of their respective owners.

Copyright restrictions

© 2012, 2013 Transition Networks, Inc.

All rights reserved. No part of this work may be reproduced or used in any form or by any means - graphic, electronic or mechanical - without written permission from Transition Networks.